

**OWNER'S MANUAL
SUPPLEMENT
4600 SCB SPORTYACHT**



MAXUM




Port Engine Serial Number: _____

Stbd. Engine Serial Number: _____

Hull Identification Number: _____

The Hull Identification Number (HIN) is located on the starboard side of the transom.. Be sure to record the HIN in the space provided above and refer to the HIN for any correspondence or orders.



© 2000 Maxum Marine Technical Publications. All rights reserved.

No part of this publication may be reproduced, stored in any retrieval system, or transmitted in any form by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written permission of Maxum. Printed in the U.S.A.

General Notes

The material in this document is for information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, Maxum assumes no liability resulting from errors or omissions in this document, or from the use of information contained herein.

Due to our commitment to product improvement, Maxum reserves the right to make changes in the product design, specifications and equipment at any time without notice or obligation. Illustrations and/or photos may show optional equipment. All Maxum products meet or exceed USCG (United States Coast Guard) and/or NMMA (National Marine Manufacturer's Association) construction standards. Manufactured with 1,1,1 Trichloroethane, a substance which harms public health and environment during the manufacturing process by destroying ozone in the upper atmosphere.

Proprietary Rights

This document discloses subject matter in which Maxum has proprietary rights. The information and design disclosed herein were originated by and are the property of Maxum. Neither receipt nor possession thereof confers or transfers any right to reproduce, copy, alter or disclose the document or any part thereof, any information contained therein, or to construct boats or any item from it, except by written permission from or written agreement with Maxum. This document is to be returned upon request to Maxum.



Congratulations and welcome aboard your new Maxum Sport Yacht!

Thank you for choosing our product. Maxum is committed to the goal of building the highest quality products in the marine industry and to providing the finest after-the-sale support in the world.

Maxum has instituted an ongoing **Total Customer Satisfaction Program**.

The guiding principles of this program are:

- Design, build and support the finest marine products in the world, in every market we serve.
- Be personally and individually responsible for the customer's total satisfaction.
- Remember that every customer has a choice, and we want them to choose Maxum!

Welcome to the Maxum family. We are looking forward to serving your boating needs, now and in the future!

CONTENTS

Chapter 1: Welcome Aboard!

- 1 Dealer Service
- 1 Boating Experience
- 1 Engines/Accessories Guidelines
- 1 Qualified Maintenance
- 2 Structural Limitations
- 2 Safety Standards
- 2 Hazard Boxes & Symbols
- 3 Special Care For Moored Boats

Chapter 2: Components/Systems

- 4 Dimensions and Tank Capacities
- 4 Layout View
- 4 Yacht Lifting
- 5 Hull Exterior Hardware & Drains
- 6 Command Bridge Layout
- 7 Deck Hardware
 - 7 Anchor Windlass
 - 7 Davit (Option)
 - 8 Deck Fill Fittings & Pump-out Locations
 - 8 Windshield Wipers (Option)
- 8 Electrical System
- 9 DC Electrical System
 - 9 Fuses and Circuit Breakers
 - 9 Batteries
 - 9 Battery Maintenance
 - 9 Battery Condition
 - 9 Battery Switches
 - 10 Battery Charger
- 10 AC Electrical System
 - 11 Shore Power
 - 12 Generator Power (Option)
 - 14 Inverter Power (Option)
- 14 Audio & Visual Equipment
- 14 Navigation & Communication Equipment
 - 14 VHF Radio (Option)
 - 14 Compass
 - 14 Depth Finder (Option)
 - 15 Autopilot (Option)

- 15 Lighting
 - 15 Navigation and Interior Lights
 - 15 Spotlight
- 15 Appliances
 - 16 TV/Telephone Dockside Inlet (Option)
- 16 Vacuum System (Option)
- 16 Propulsion
 - 16 Engines
 - 16 Exhaust System
 - 17 Engine Cooling System
 - 17 Engine Room Ventilation System
 - 17 Shaft Log Packless Sealing System
 - 18 Shaft-Transmission Alignment
 - 18 Rudder Stuffing Gland
- 19 Controls
 - 19 Steering System
 - 19 Shifter/Throttle Reservoir Routing
 - 20 Trim Tabs
- 20 Bilge Pumps
 - 21 Autofloat Switches
- 22 Fuel System
 - 22 Fuel Quality
 - 22 Fuel Fills
 - 22 Anti-siphon Valves
 - 23 Fuel Management Board
 - 24 Fuel Transfer Pump (Diesel Only)
 - 24 Fuel Filters & Water Separators
- 24 Freshwater System
 - 25 Water Heater
 - 25 Fresh Water System Winterization
 - 26 Transom Shower
 - 26 Fresh Water Washdown Faucet
 - 26 Gray Water Drain System
- 26 Raw Water System
 - 26 Seacocks
 - 26 Raw Water Strainers
 - 27 Raw Water Washdown
- 28 Standard Marine Head System
 - 28 Macerator Delete Head System (Option)
 - 29 Vacuflush Head System (Option)
 - 29 Air Conditioning & Heating (Option)

Chapter 3: Electrical Routings

- 31 AC Wiring
- 31 Shore Power/Generator Harnesses
- 32 Positive Battery Cable Routing
- 33 DC Engine Harness
- 33 Battery Ground Cable Routing
- 34 Negative Battery Cable Routing
- 34 Battery Isolator System Wiring

Chapter 4: Wiring Schematics

- 35 AC Electrical System
- 36 DC Electrical System
- 37 Gas Engine Electrical System
- 38 Diesel Engine Electrical System

Appendix A: Express Limited Warranty

Chapter 1: Welcome Aboard!

This owner's manual supplement provides specific information about your boat that is not covered in the owner's manual. Please study the owner's manual and this supplement carefully, paying particular attention to the **Express Limited Warranty** in **Appendix A** of this supplement. Keep the owner's manual and supplement on your boat in a secure, yet readily available place.

Dealer Service

Make sure you receive a full explanation of all systems from the selling dealer before taking delivery of your boat. Your selling dealer is your key to service. If you experience any problems with your new boat, immediately contact the selling dealer. If for any reason your selling dealer is unable to help, you can call us direct on our customer service hotline: 360-403-0274 or send us a FAX: 360-403-4235.

Boating Experience

If this is your first boat or if you are changing to a type of boat you are not familiar with, for your own comfort and safety, please ensure that you obtain handling and operating experience before assuming command of the boat.

We strongly recommend that you take one of the boating safety classes offered by the U.S. Power Squadrons or the U.S. Coast Guard Auxiliary. For more course information, including dates and locations of upcoming classes, contact the organizations directly:

- U.S. Power Squadrons: 1-888-FOR-USPS (1-888-367-8777) or on the Internet at: <http://www.usps.org>
- U.S. Coast Guard Auxiliary: 1-800-368-5647 or on the Internet at: <http://www.cgaux.org>

Outside the United States, your selling dealer, national sailing federation or local yacht club can advise you of local sea schools or competent instructors.



WARNING!

CONTROL HAZARD! A qualified operator must be in control of the yacht at all times. DO NOT operate your yacht while under the influence of alcohol or drugs.

Engines/Accessories Guidelines

Your boat's engines and accessories were selected to provide optimum performance and service. Installing different engines or other accessories may cause unwanted handling characteristics. Should you choose to install different engines or to add accessories that will affect the boat's running trim, have an experienced marine technician perform a safety inspection and handling test before operating your boat again.

Please be advised that certain modifications to your boat can result in cancellation of your warranty protection. Always check with your dealer before making any modifications to your boat.

The engines and accessories installed on your boat come with their own operation and maintenance manuals. We strongly urge you to read and understand these manuals before operating the engines and accessories.

Qualified Maintenance

Failure to maintain your boat's systems as designed could violate the laws in your jurisdiction and could expose you and other people to the danger of bodily injury or accidental death. We recommend that you follow the instructions provided in the owner's manual this owner's manual supplement, the engine owner's manual and all accessory instruction sheets/manuals included in your boat's owner's packet.



WARNING!

To maintain the integrity and safety of your yacht, only qualified personnel should perform maintenance on, or in any way modify: The steering system, propulsion system, engine control system, fuel system, environmental control system, electrical system or navigational system.

Structural Limitations

The command bridge, transom platform and bow platform are designed to be lightweight for proper boat balance. The load limit for these platforms is 30 pounds per square foot, evenly distributed.

Safety Standards

Your boat's mechanical and electrical systems were designed to meet safety standards in effect at the time it was built. Some of these standards were mandated by law, all of them were designed to insure your safety, and the safety of other people, vessels and property.

In addition to this owner's manual supplement, please read the owner's manual and all accessory instruction sheets for important safety standards and hazard information.

! DANGER!	
	PERSONAL SAFETY HAZARD! Do not allow anyone to ride on parts of the yacht not designated for such use. Sitting on seat backs, lounging on the forward deck, bow riding, gunwale riding or occupying the transom platform while underway is especially hazardous and will cause personal injury or death.

Hazard Boxes & Symbols

The hazard boxes and symbols shown below are used throughout this supplement to call attention to potentially dangerous situations which could lead to either personal injury or product damage. **We urge you to read these warnings carefully and follow all safety recommendations.**

! DANGER!	
This box alerts you to immediate hazards which WILL cause severe personal injury or death if the warning is ignored.	

! WARNING!	
This box alerts you to hazards or unsafe practices which COULD result in severe personal injury or death if the warning is ignored.	

! CAUTION!	
This box alerts you to hazards or unsafe practices which COULD result in minor personal injury or cause product or property damage if the warning is ignored.	

NOTICE	
This box calls attention to installation, operation or maintenance information, which is important to proper operation but is not hazard related.	

 EXPLOSION HAZARD!	 OPEN FLAME HAZARD!	 HOT HAZARD!	 ELECTRICAL HAZARD!	 PERSONAL INJURY & FALLING HAZARD!	 ROTATING PROPELLER HAZARD!
---	--	---	--	---	--

Special Care For Moored Boats

If moored in saltwater or fresh water, your boat will collect marine growth on its hull bottom. This will detract from the boat's beauty, greatly affect its performance and may damage the gelcoat. There are two methods of slowing marine growth:

- Periodically haul the boat out of the water and scrub the hull bottom with a bristle brush and a solution of soap and water.
- The hull below the waterline was painted with anti-fouling paint by the factory. Occasionally you will need to re-paint it with a good grade of anti-fouling paint.

NOTICE


- **To help seal the hull bottom and reduce the possibility of gelcoat blistering on moored boats, we recommend the application of an epoxy barrier coating, such as INTERLUX, *Interprotect 2000E/2001E*. The barrier coating should be covered with several coats of anti-fouling paint.**
- **Many states regulate the chemical content of bottom paints in order to meet environmental standards. Check with your local dealer about recommended bottom paints, and about the laws in effect in your area.**

Chapter 2: Components/Systems

Dimensions and Tank Capacities


Overall Length	Bridge Clearance	Beam	Draft	Fuel Capacity (gal)	Freshwater Capacity (gal)	Waste holding Tank Capacity (gal)
45' 11"	18' 0"	14' 4"	4' 0"	418	100	75

Layout View



Yacht Lifting

- When lifting your yacht, always follow the owner's manual recommendations as well as the lift equipment's requirements and safety guidelines.
- If water is present in the bilge, pump the water out of the bilge areas before lifting your yacht. Excessive amounts of bilge water add weight and can shift and change the balance of the load.
- Always position the lifting slings at the port and starboard sling label positions (see drawing on right).




CAUTION!


PRODUCT OR PROPERTY DAMAGE HAZARD!

- When lifting any boat **ALWAYS** use a spreader bar. The spreader bar must be equal to the width of the boat at the lifting point.
- Lift slings may slip on the hull. Avoid serious injury or death by securing the slings together before lifting.


Hull Exterior Hardware & Drains



Command Bridge Layout



COMMAND BRIDGE HELM & DASH LAYOUT




Deck Hardware

Anchor Windlass

Your yacht features an anchor windlass. Be sure to read the windlass manual supplied in your yacht's owner's packet for detailed operating instructions and observe the following:

- To haul the anchor, use engine power (not the windlass) to move the boat to, and directly above, the anchor. Activate the windlass to disengage the anchor from the bottom by pulling it straight up.
- Verify that the windlass breaker is activated before using the anchor windlass.



CAUTION!

DO NOT pull the boat to the anchor using the windlass or continue to operate the windlass if it has stalled or is overloaded.

Davit (Option)

Your yacht may be equipped with an optional electric davit. Before using the davit, be sure to read the davit's manual which explains operation, and important safety hazards.

Observe the following:

- The davit control plugs into the back side of the davit, just above the davit base (see figure 1 at right).
- Inspect the davit's cable often for wear and replace if frayed. The cable should be kept tight and even on the spool when under tension during winch operation. (figure 2).
- Secure the davit to the davit eye (located on the transom platform) when the davit is not in use (figure 3).
- Secure the davit to the davit eye (located on the transom platform) when the davit is not in use (figure 3).

FIGURE 1




FIGURE 2






FIGURE 3




WARNING!



FALLING & PERSONAL INJURY HAZARD!

- **DO NOT** allow passengers inside a suspended boat since falling may cause injury or death.
- **NEVER** exceed the davit's maximum load limit.
- Since water is heavy, lifting a dinghy to drain its bilge may exceed the davit's maximum load limit.
- Use extreme caution when using the davit in rough weather or rough sea conditions as the load may start swinging.
- Only operate the davit when it is securely locked in the upright position.

Deck Fill Fittings & Pump-out Locations



Windshield Wipers (Option)

- Windshield wiper/washer control switches are located at the optional lower helm.
- Periodically, due to wear and environmental exposure, the wiper blades will need to be replaced using 28" blade refills.
- The windshield wiper fluid level should be checked occasionally and refilled as necessary. The windshield wiper fluid bottle can be accessed through the lower helm's inboard access panel.

Electrical System

We strongly recommend that you read and understand this section and the electrical section of the owner's manual. Electrical routing drawings are provided in Chapter 3 of this supplement; wiring schematics in Chapter 4.

DANGER!

EXTREME FIRE, SHOCK & EXPLOSION HAZARD!

- To minimize the risks of fire and explosion, NEVER install knife switches or other arcing devices in the fuel compartments.
- NEVER substitute automotive parts for marine parts. Electrical, ignition and fuel system parts were designed and manufactured to comply with rules and regulations that minimize risks of fire and explosion.
- DO NOT modify the electrical systems or relevant drawings.
- Only qualified personnel should install batteries and/or perform electrical system maintenance.
- Insure that all battery switches are turned OFF before performing any work in the engine spaces.

WARNING!

FIRE, OPEN FLAME & EXPLOSION HAZARD!

- Fuel fumes are heavier than air and will collect in the bilge areas where they can be accidentally ignited. Visually and by smell (sniff test), check the engine and fuel compartments for fumes or accumulation of fuel. ALWAYS operate the bilge blowers for at least four minutes prior to engine starting, electrical system maintenance or activation of electrical devices.
- Minimize the danger of fire and explosion by not exposing batteries to open flame or sparks. It is also important that no one smoke anywhere near the batteries.

! CAUTION!

SHOCK & ELECTRICAL SYSTEM DAMAGE HAZARD! NEVER disconnect the battery cables while the engine is running since it can cause damage to your boat's electrical system components.

NOTICE

Electrical connections are prone to corrosion. To reduce corrosion caused electrical problems, keep all electrical connections clean and apply a spray-on protectant that is designed to protect connections from corrosion.

DC Electrical System

Your yacht is equipped with a 12 volt DC (direct current) system. Your yacht's DC main distribution panel is located inside the AC/DC cabinet, next to the aft berth steps in the aft salon on the starboard side.

Fuses and Circuit Breakers

- The fuses and circuit breakers for engines, accessory power and windlass power are located on the DC main distribution panel.
- An accessory fuse block for electronics, such as the VHF radio, is located under the upper helm dash. Some equipment, such as depth finders, may have secondary fuse protection at the unit.

Batteries

The batteries installed on your yacht supply electricity for lights, accessories as well as engine, optional generator and optional inverter starting.

Battery Maintenance

- Periodically remove the battery caps and check the electrolyte level; if the zinc plates are exposed, add distilled water until they are covered.
- Corroded battery terminals can be cleaned with baking soda and water. After cleaning the terminals, coat them with a light film of battery terminal lubricant and tighten all battery connections.

Battery Condition



- The port and starboard engine battery conditions can be read on the helm's instrument panel voltmeters.
- The condition of the accessory battery can be read on the starboard engine voltmeter when the accessory battery switch is activated.

Battery Switches

- There are two battery switches installed inside the starboard transom storage tub.
- The battery switch labeled "PORT ENGINE" activates the port engine battery while the starboard engine/house battery switch, labeled "STBD ENGINE/HOUSE" activates the starboard engine and the house batteries.
- Battery switches should be switched to the OFF position whenever the yacht is left unoccupied for long periods of time.

Starting Positions

The port engine battery switch must be turned ON to start the port engine and optional generator. The starboard engine/house battery switch must be ON to start the starboard engine. After starting your boat's engines, the battery switches must be kept ON until the engines and/or optional generator is turned OFF.



Parallel Battery Switch

- An emergency crossover (parallel) switch at the helm enables you to start an engine using both engine batteries if the designated engine battery is low.
- To use the parallel mode, make sure both battery switches are turned ON. Hold down the parallel switch while cranking the engine. Once the engine has started, release the switch.



CAUTION!

SYSTEM DAMAGE HAZARD!

- **NEVER** disconnect battery cables or turn off battery switches while the engines or optional generator is running as this can cause damage to your boat's electrical components.
- The parallel switch should only be used in an emergency.

Battery Charger

Your yacht is equipped with a battery charger. We recommend that you thoroughly read and understand the battery charger manual before using the charger.

- The battery charger will charge the yacht's batteries whenever the boat is plugged into 120 volt shore power or while the generator is operating.
- The battery charger can be accessed through the aft bulkhead access panel in the aft berth.
- The battery charger's circuit breaker is located on the AC panel and must be turned on for charging to occur.



CAUTION!

The battery charging systems (alternators and battery charger) are designed to charge conventional lead-acid batteries. Before installing gel-cell (or other new technology) batteries, consult with the battery manufacturer about charging systems requirements.

AC Electrical System

Your yacht uses 120v/60Hz or optional 240v/60Hz AC (alternating current) systems. The AC system can be energized by shore power, generator power or optional inverter power. This system is designed so that ship's power and shore power sources cannot supply power simultaneously.

The AC panel is located on the port side of the salon, outboard of the aft berth steps. The AC panel's master circuit breakers provide power source selections to the accessory breakers that are directly below the designated master breaker.


MAIN DISTRIBUTION (AC/DC) PANEL

DINETTE CUSHION
OR OPTIONAL
HELM SEAT
CUSHION

AC PANEL

DC PANEL

AFT



NOTICE

Accessories that are powered by the optional inverter have white-colored AC panel breakers.




CAUTION!

- The simultaneous operation of several AC accessories can result in an overloaded circuit. It may be necessary to turn off one accessory while operating another.
- **WATER HEATER DAMAGE HAZARDS!** DO NOT energize the AC water heater electrical circuit until the heater is *completely* filled with water. Even momentary operation in a dry tank will damage the heating elements. Warranty replacements *will not* be made on elements or tank damaged in this manner. The tank is full if water flows from the tap when the hot water is turned on in the galley.

Shore Power

Your yacht features two standard-equipped 120v/30 amp shore power receptacles (located inside the starboard transom stowage tub). The shore power inlets are labeled line 1 and line 2, which corresponds to the line 1 and line 2 master breakers on the AC panel. This system is designed so that each line operates independent of each other.

If your yacht is equipped with an optional air conditioning system, a single 50 amp inlet (240 volt) may be installed in place of the two standard 30 amp inlets. Electricity from the single 50 amp inlet is evenly distributed to both line 1 and line 2 master breakers (120 volt) on the AC panel. This system is also designed so that each line operates independent of each other.



⚠ DANGER!



FIRE, EXPLOSION & SHOCK HAZARD!

- DO NOT alter shore power connectors and use only compatible connectors.
- Before connecting or disconnecting the shore power cord to your yacht, verify all breakers and switches on the AC master panel are turned OFF.
- To prevent shock or injury from an accidental dropping of the “hot” cord into the water, ALWAYS attach the shore power cord to the boat inlet first; then to the dockside connection. When disconnecting from shore power, disconnect the shore power cord from the dockside connection first.
- NEVER leave a shore power cord connected to the dockside connection only.
- Only use shore power cords approved for marine use. NEVER use ordinary indoor or outdoor extension cords that are not rated for marine use.

⚠ CAUTION!



FIRE, SHOCK & ELECTRICAL SYSTEM DAMAGE HAZARD!

- NEVER connect dockside power to your boat outside North America unless you have purchased the international electrical conversion option.
- The simultaneous use of several AC components can result in an overloaded circuit. It may be necessary to turn off one or more accessories in order to use another accessory.
- Use double insulated or three-wire protected electrical appliances whenever possible.
- Periodically check the shore power cord(s) for deterioration or damage. Damaged or faulty cords should NEVER be used since the danger of fire and electrical shock exists.
- DO NOT pinch shore power cords in doors or hatches, or coil the shore power cord too tightly since these situations can generate enough heat to result in a fire.
- If a shore power cord should accidentally become immersed in water, THOROUGHLY dry the blades and contact slots before re-using.

NOTICE

Some dockside installations may be rated less than 30 amps, therefore, you may need to purchase lower amp adapters. Whenever a lower amp adapter is used, however, there will be a corresponding drop in supplied power from the dockside system.

Connecting to Shore Power

1. Monitor the AC panel's polarity indicator lights (next to the line 1 and line 2 master breakers) as follows:
 - A GREEN light illuminating after the power cord is plugged into the yacht's external power receptacle indicates acceptable electrical power in which you may energize the main breaker switches.
 - A RED light, however, indicates reversed polarity, which could cause electrical system damage and possibly electrical shock injuries. In this case, DO NOT energize the main breaker switches (see warning below).
2. Activate the AC system by turning the main ship/shore breaker to the "DOCKSIDE" position.
3. Turn ON the master breakers and individual component breakers as required.

 **WARNING!**

 **SHOCK & ELECTRICAL SYSTEM DAMAGE HAZARD!**

- Monitor the polarity indicator lights EVERY TIME you connect to shore power.
- When connecting to shore power and you encounter a reversed polarity light (RED colored), DO NOT energize the main breaker switches. Instead, IMMEDIATELY disconnect the shore power cord (ALWAYS from the dockside receptacle first) and notify marina management.

NOTICE

The voltage on each line can be read by setting the voltmeter selector switch.

Generator Power (Option)

Your yacht may come equipped with an optional gas or diesel generator. Prior to initially operating your generator, read the generator manual for information on pre-start checks, break-in procedures and detailed operating instructions and observe the following:

- Operate the bilge blowers for a minimum of four minutes before starting the generator. Leave the blowers on while the generator is operating unless the yacht is running at cruising speed.
- Make sure the generator's seawater pickup system's seacock is in the *open* position before starting your generator and keep the seacock open throughout generator operation.
- The generator's starter switch and breakers are located on the AC electrical panel.
- **Diesel generator:** Activate the generator's preheat switch (located on the AC panel) for approximately one minute before attempting to start your diesel generator.
- **Gas generator:** Simultaneously press the oil pressure button (labeled "PREHEAT") and turn the starter switch until the generator starts.
- Fuel to run the generator is supplied from the starboard fuel tank.
- In addition to servicing the filters attached to the generator, the fuel filters/separators (located near the fuel shut-off valve) should be serviced as described in the manufacturer's manual.
- The generator runs off the port engine battery.
- The generator's coolant mixture consists of equal parts of water and antifreeze (Ethylene Glycol). Coolant (anti-freeze) levels should be checked at the generator-mounted expansion tank and at the coolant recovery bottle (located near the generator).
- Check the generator's seawater strainer for leaks and clean out debris according to the *Seawater Strainer* section of this supplement.


 **CAUTION!**

- Always verify the generator's seawater pickup system's seacock is in the OPEN position prior to starting the generator and whenever the generator is operating.
- NEVER operate the generator starter for more than 30 seconds. If the generator does not start, wait at least 30 seconds before another start attempt is made.
- After starting the generator, wait for the generator to stabilize before activating component breakers on the AC panel.

NOTICE

If your yacht features a diesel fuel system and a fuel management board; the generator fuel selector valves must be set so that return fuel is routed back to the SAME tank from which it was drawn. Otherwise, generator fuel drawn from a partially full tank and returned to a full tank may spill overboard through the tank venting system.


Generator Routing



Inverter Power (Option)

Your yacht may feature an optional inverter, which is located under the aft dinette seat. Be sure to refer to the inverter manual for detailed operating procedures. Observe the following:

- The inverter comes with its own battery and battery charger.
- Activate the AC system under inverter power by switching on the inverter master breaker (located in the starboard cockpit stowage locker) and pressing the ON/OFF switch on the inverter control panel (located on the inverter).
- The inverter only provides AC power to the accessories on the AC panel that have white breakers (line 1).



Audio & Visual Equipment

All audio and visual equipment installed on your yacht have separate manuals (included in your yacht's owner's packet) that explain their operating procedures in detail.

NOTICE

AM radio reception may be impaired in areas where reception is limited or anytime the engines are running.

Navigation & Communication Equipment

The owner's packet contains operation manuals for all navigation & communication equipment installed on your yacht. We *strongly* recommend that you thoroughly read and understand these manuals before using these systems. Additionally, read the warnings below carefully and follow all safety recommendations.

VHF Radio (Option)

Your yacht may include an optional VHF (Very High Frequency) radio at the helm. The VHF radio can be used to access weather reports, summon assistance or contact other vessels as permitted by the FCC (Federal Communications Commission). Be sure to contact the FCC for licensing, rules and regulations concerning VHF radio usage.

Compass

NOTICE

Compass accuracy can be affected by many factors. We strongly recommend having a qualified technician calibrate your compass. Make sure the technician gives you a deviation card which shows the corrections to apply in navigational calculations. Keep a copy of the deviation card at each helm.

Depth Finder (Option)



WARNING!

- **DO NOT** use the depth finder as a navigational aid to prevent collision, grounding, boat damage or personal injury.
- **When the boat is moving, submerged objects will not be seen until they are already under the boat. Bottom depths may change too quickly to allow time for the boat operator to react. If you suspect shallow water or submerged objects, operate the boat at very slow speeds.**

Autopilot (Option)



WARNING!

PERSONAL INJURY & PRODUCT HAZARD! Never leave the helm while the autopilot system is on! Someone should always stay at the helm as a lookout in case a dangerous situation suddenly develops.

NOTICE

The autopilot system is only an aid to navigation. It's accuracy can be affected by many factors, including equipment failure or defects, environmental conditions & improper handling or use.

Lighting

Navigation and Interior Lights

We strongly recommend that you understand navigation light section of the owner's manual. The navigation and interior lights installed on your yacht are of top quality, but you should be aware that failure may periodically occur for a variety of reasons:

1. There may be a blown fuse - *replace the fuse.*
2. The bulb may be burned out - *carry spare bulbs for replacement.*
3. A wire may be damaged or may have come loose - *repair as required.*
4. The bulb base may be corroded - *clean the base and coat it with non-conductive electrical lubricant.*



CAUTION!

- Avoid the storage of gear where it would block navigation lights from view.
- Be conservative in the use of battery power. Prolonged operation of cabin interior lights (overnight) will result in a drained battery.

Spotlight

Your yacht is equipped with a spotlight which is located on the command bridge. The spotlight is controlled from a switch at the command bridge helm. Detailed operating instructions can be found in the spotlight's operation manual.

Appliances

All appliances installed on your yacht come with their own manuals that contain detailed operating instructions and important safeguards. Thoroughly read and understand these manuals before operating your yacht's appliances.

- Appliances operate on 120v AC power, which may be supplied from: Shore power, generator power or optional inverter power.
- Make sure the AC breaker is activated for the appliance you wish to turn on.

NOTICE

Always keep an approved ABC-type fire extinguisher in galley area.



WARNING!




HOT & FIRE HAZARD!

STOVE: DO NOT touch stove burners, grates or areas near the stove units as they may be hot even when they are dark in color. Areas near burners and grates may become hot enough to cause burns. During use and afterwards, DO NOT touch or let clothing or other flammable material come in contact with heated units (or areas near the units) until they have had sufficient time to cool.

TV/Telephone Dockside Inlet (Option)

Your yacht may come equipped with an optional cable television/telephone dockside inlet. The inlet is located inside the aft starboard transom stowage tub, near the shore power inlets. The yacht must be hooked up to a dockside source for telephone service or to receive cable television transmission.

DOCKSIDE TV & TELEPHONE INLET



Vacuum System (Option)

- Your yacht may feature an optional built-in vacuum system. The vacuum unit is located in the floor-level cabinet, across from the dinette table.
- Refer to the vacuum manual included in your yacht's owner's packet for complete operating instructions.
- Before attempting to operate the vacuum, make sure the breaker switch on the AC master panel is turned ON.


Propulsion

Engines

The owner's packet contains detailed engine operation and maintenance manuals. Be sure to read and understand these manuals before operating or performing maintenance to the engines.

Exhaust System


The exhaust system is designed to keep water out of the engines in most sea conditions, however, **DO NOT** anchor the stern to sea or shut engines off if the seas are too high. Always use good seamanship and consider the sea conditions before anchoring or shutting off the engines.



NOTICE

Check all exhaust system hose clamps after the first 20 hours and continue to check all of the clamps periodically after that

Exhaust System Routings




Engine Cooling System

The engine cooling system circulates water through a heat exchanger on the engine to reduce engine temperature.

- Engine coolant (antifreeze) levels should be checked at the engine-mounted expansion tanks and at the coolant recovery bottles, located near the engines.

CAUTION!

HOT HAZARD! NEVER check coolant levels when the engine is hot or while the engine is running.




- The engine cooling system's raw water strainers (located in the engine room) should be checked for leaks and cleaned *every time* you use your yacht. For instructions on how to clean the strainers, see the *Raw Water Strainer* section of this supplement.
- Make sure both of the engine's raw water intake valves (seacocks) are OPEN before starting the engines and always keep them open whenever the engines are running.

CAUTION!

SYSTEM DAMAGE HAZARD! The engine cooling system's seacocks must be in the OPEN position before engines are started and while the engines are operating.

Engine Room Ventilation System

- The bilge blowers remove fumes from the engine compartment and draws fresh air into the compartment through the deck vents.
- To ensure fresh air circulation, always operate the bilge blowers for at least four minutes prior to starting the engine (or generator); during starting, and while operating your yacht below cruising speed.



WARNING!

EXPLOSION HAZARD!

- Operation of the blower system is not a guarantee that explosive fumes have been removed. If you smell fuel, DO NOT start the engines. If the engines are already running, IMMEDIATELY shut OFF the engines and all electrical accessories and investigate.
- DO NOT obstruct or modify the ventilation system.

Shaft Log Packless Sealing System

The shaft seal, which is part of the shaft log packless sealing system, is a maintenance-free, watertight seal that doesn't require packing or adjustments.

Shaft-Transmission Alignment


Alignment between the engine transmission output shaft and the propeller shaft is critical. This alignment has been performed at the factory, and was rechecked by the dealer after the yacht had been in the water for 48 hours.

- An alignment inspection should be performed as part of the routine maintenance program by a marine mechanic after the initial 30 hours of operation, then annually or whenever an unusual noise or vibration is noticed.
- The gap between flange faces should be less than 0.003".
- Replacement flange bolts, nuts and washers must be corrosion resistant and grade 8 or better.
- Recheck flange bolt torque after 20 hours of operation. Tighten the flange bolts according to the torque specifications listed in the table below.


FLANGE BOLT SPECIFICATIONS

BOLT SIZE	TORQUE
3/8" - 24	40 +/- 7 lb.
7/16" - 20	65 +/- 10 lb.
1/2" - 20	95 +/- 15 lb.
5/8" - 18	200 +/- 30 lb.
M16 x 1.5	175 +/- 25 lb.

TYPICAL TRANSMISSION-TO-PROP SHAFT COMPONENTS
TRANSMISSION-TO-PROP SHAFT COMPONENTS VARY, DEPENDING UPON ENGINE TYPE AND SIZE



DETAILED VIEW



CAUTION!

- A marine mechanic should perform the engine alignment since it requires moving the engine.
- If a shaft misalignment exists, have a qualified marine mechanic perform an alignment as soon as possible. Continued use may lead to premature engine, transmission, shaft, shaft seal and/or hull damage!

Rudder Stuffing Gland

The rudder stuffing gland is part of the assembly where the rudders emerge from the bottom of the boat. The shaft stuffing gland should not leak any water. If a leak develops, it can usually be stopped by tightening the packing gland nuts *slightly*. If stuffing gland leakage becomes excessive, packing replacement can be performed as follows:

Rudder Stuffing Gland Replacement Procedure:

1. Remove the boat from water.
2. Loosen the packing gland nuts and back the packing gland from the sleeve.
3. Remove the old packing.
4. Wrap new packing around the shaft.
5. Cut the rings with a razor blade at an angle approximately 30 degrees to the long axis of the shaft.
6. Stagger the ends of each ring around the shaft and insure that the ring are at the bottom in the sleeve.
7. Tighten the packing gland nuts until resistance is felt.



CAUTION!


PRODUCT DAMAGE HAZARD! DO NOT over tighten the packing gland nuts.

Controls


Steering System

Your yacht is equipped with a manual hydraulic steering system, therefore the system will not operate as easily as a car's power steering.

- The hydraulic steering system comes with its own manual that explains the steering operation in detail.
- The shifter/throttle controls are located at the helm.
- A rhythmic pulsing when turning the wheel is a characteristic of the pump and is *not* a malfunction. Also, when coming off a hard-over position, a resistance may be felt, followed by a distinct sound. This is a normal situation resulting from the release of the check valve.
- The steering fluid level should be checked according to the instructions and maintenance suggestions outlined in the steering manual.




Shifter/Throttle Reservoir Routing



Trim Tabs

Trim tabs control the longitudinal and lateral trim of your boat at cruising speeds and are controlled by two rocker switches, located at the helm station. Before using the trim tab switches, we strongly urge you to read and understand the trim tab operation manual included in your yacht's owner's packet and observe the following:

- Once the best bow cruising trim is reached, use the port or starboard trim switches, one at a time, to correct unequal lateral loading.
- Trim tab adjustment should be performed by several short touches to the switch rather than one long one. After each short touch allow about five seconds for the hull to react.
- The trim tab hydraulic fluid reservoir is located in the engine compartment. The fluid level should be checked periodically (at least once a year) and refilled as necessary.




WARNING!

LOSS OF CONTROL HAZARD!

- **Improper use of trim tabs may cause loss of control! DO NOT use trim tabs in a following sea as they may cause broaching or other unsafe handling characteristics.**
- **NEVER allow anyone unfamiliar with trim tabs to operate them and DO NOT use trim tabs to compensate for excessive unequal weight distribution.**

Bilge Pumps

- Your yacht is equipped with three automatic impeller-type bilge pumps which are used to pump water out of the bilge.
- Bilge pumps are controlled by automatic bilge pump float switches (autofloat switches) and/or switches at the helm.
- Bilge pumps are wired directly to the battery so they will function even when the yacht is completely shut down and left unattended.



NOTICE


Discharge of oil, oil waste or fuel into navigable waters is prohibited by law. Violators are subject to legal action by the local authorities.

Bilge Pump Testing

Bilge pumps should be tested often to verify that they are working properly. To manually test a bilge pump's operation, activate the dash-mounted switch and verify that water in the bilge is pumped overboard. If bilge water is present and the pump motor is running but *not* pumping, inspect the discharge hose for a kink or collapsed area. If no problems are found, check the bilge pump housing for clogging debris as follows:

Bilge Pump Cleaning:

1. Remove the power cartridge:
 - a. Lift the tab while rotating the fins counterclockwise.
 - b. Lift out the power cartridge.
 - c. Clear the outer housing of debris.
2. Reinstall the power cartridge:
 - a. Make sure the "O" ring is properly seated.
 - b. Coat the "O" ring with a light film of vegetable or mineral oil.
 - c. Align the two cams on either side of the power cartridge with the two slots on the outer housing and press the power cartridge into the housing while twisting clockwise.
 - d. To ensure proper reinstallation of the power cartridge, attempt to twist the fins counterclockwise without lifting the tab: The cartridge should stay in place.


**Autofloat Switches**

Automatic bilge pumps use electromagnetic float (autofloat) switches to automatically activate the pump whenever water accumulates above a preset level in the bilge. One autofloat switch is mounted next to the bilge pump it activates, and is wired directly to the battery so it will normally function even when the yacht is completely shut down and left unattended.

Autofloat switches should be tested often for proper operation as follows:

Float Switch Test:

1. Push the float switch test button *up* to activate the bilge pump.
If the pump does not turn on, check the inline fuse. If the fuse is good but the switch doesn't work, it may indicate a bad switch or possibly a low battery.
2. Push the test button all the way *down* to return the float switch back into the auto mode.

**CAUTION!**

When test is completed on a float switch, you must push the test button all the way down to the auto position to turn the switch back into auto mode!

Fuel System

Carefully read the fuel sections of the owner's manual and the engine operation manual.

! WARNING!



FIRE, EXPLOSION AND OPEN FLAME HAZARD!

- It is very important that the fuel system be inspected thoroughly the first time it is filled and at each subsequent filling.
- The fueling instructions in the engine operation manual **MUST** be followed.

! CAUTION!


- Diesel Only:*** Air in the diesel supply system can stop an engine or severely restrict performance. If you suspect air in the fuel lines, refer to your engine operation manual for detailed instructions on how to bleed the system.
- Avoid the storage or handling of gear near the fuel lines, fittings and tanks.

NOTICE

Discharge of fuel into navigable waters is prohibited by law. Violators are subject to legal action by the local authorities.

Fuel Quality

Make sure your fuel suppliers are reputable and can be relied upon to furnish clean, high quality fuel. Once you have found such suppliers, keep your tank as full as possible with their fuel, allowing for expansion due to temperature variations. Then, if you are forced to add to the tank with a potentially poor quality supply, the portion of poor quality fuel will be minimized.



Fuel Fills

Fuel fill fittings are located on the port and starboard side decks (see right). Fuel receptacle caps are marked either "Diesel" or "GAS". If you experience difficulty filling a fuel tank, check to see that the fuel fill and vent lines are free of obstructions and kinks.


Anti-siphon Valves

- If your yacht is gas powered, it may be equipped with anti-siphon valves. Anti-siphon valves are an integral part of the gas fuel line barb fitting on each fuel tank. These valves are spring loaded and are opened by fuel pump vacuum.
- In the unlikely event of a fuel line rupturing, the anti-siphon valve would prevent fuel from siphoning from the tank.

! WARNING!



FIRE & EXPLOSION HAZARD! If an engine problem is caused by fuel starvation, check the anti-siphon valve. If the valve is stuck or clogged, shut down the engine and replace it. Except in an emergency, **NEVER** operate the engines without the anti-siphon valve.





Fuel Management Board

Your yacht may or may not be equipped with a fuel management board.


- On models equipped with a fuel management board (located under the galley steps and thru the access hatch next to the water heater), fuel can be directed from either tank to the engines and generator using the supply valves.
- On models that are not equipped with a fuel management board, the port fuel tank provides fuel for the port engine while the starboard fuel tank provides fuel for the starboard engine and the generator.

Fuel System Routing - With Fuel Management Board

FUEL MANAGEMENT BOARD LAYOUTS VARY, DEPENDING ON ENGINE TYPE & OPTIONAL EQUIPMENT



Fuel System Routing - Without Fuel Management Board



Fuel Transfer Pump (Diesel Only)


Yachts without a fuel management board are equipped with a fuel transfer pump. The fuel transfer pump is used to transfer fuel from a full tank to a nearly empty tank. The pump is activated by the using the fuel transfer switch, located at the upper helm station.


CAUTION!

ENVIRONMENTAL HAZARD! NEVER transfer fuel into a full (or nearly full) fuel tank. Fuel transferred into a full tank may spill overboard through the tank venting system.

Fuel Filters & Water Separators


Fuel filters and water separators should be inspected periodically for debris and replaced according to the guidelines and instructions detailed in your engine manual, generator manual and in the filter literature.




Freshwater System

Your is equipped with a pressure-demand (potable) freshwater system.


- When *not* connected to a dockside water supply, the water pump's DC breaker must be turned ON to use freshwater.
- The water pump's DC breaker should be turned OFF when any of the following occurs:
 - 3 When the boat is not in use.
 - 3 Whenever the water tank is empty.
 - 3 When connected to a dockside water supply.
- The water tank fill fitting is located on the starboard side deck. The city water inlet is located on the starboard side of the aft cockpit.



- The water tank is equipped with a water level indicator located on the AC panel. The indicator may not be 100% accurate, so it is recommended that the water tank be topped off at every opportunity to avoid the possibility of running short of freshwater.
- A pressure accumulator tank is installed in the freshwater system. The pressure accumulator tank assists the pressure pump by reducing on/off cycling and distributing an even flow of water.




- When your boat is to be left unattended for long periods of time, pump the water tank dry to prevent stored water from becoming stagnant and distasteful. Should it become necessary to disinfect the freshwater system, ask your dealer about treatments available for your yacht's system.
- The water filter, located under the floor cutout in the aft berth, should be inspected and cleaned often.
- The water tank is located in the aft berth, under the inboard mattress.



Water Heater

- Your yacht is equipped with a water heater. The water heater is located in the utility room.
- The water heater is connected to the AC power system, therefore, you must verify that the water heater breaker on the AC panel is turned ON before water will be heated.
- There is a heat exchanger system connected to the port engine. All hoses related to this system should be checked frequently for proper condition, and leakage.
- Be sure to read the manufacturer's instruction manual supplied in your yacht's owner's packet and observe the following warnings:



! WARNING!

! HOT HAZARD! Water heated by the water heater can reach temperatures high enough to scald the skin.

! CAUTION!

WATER HEATER DAMAGE HAZARDS! DO NOT energize the AC water heater electrical circuit until the heater is *completely* filled with water. Even momentary operation in a dry tank will damage the heating elements. Warranty replacements *will not* be made on elements or tank damaged in this manner. The tank is full if water flows from the tap when the hot water is turned on in the galley.


The water heater should be drained and the power turned OFF when the possibility of freezing exists.

Fresh Water System Winterization

To reduce the possibility of system damage due to extreme weather (such as freezing), freshwater systems that have a city water inlet installed should be winterized as follows:

Water Heater Pressure Relief Valve/Overboard Discharge Hose Winterization:

1. Disconnect the pressure relief overboard discharge hose from the water heater.
 - a. If no water is present in the hose, proceed to step two (2).
 - b. If water is present in the hose, the water heater pressure relief valve is not working properly and will need to be replaced. After replacing the pressure relief valve, empty all of the water from the hose before storing your yacht.
2. Reconnect the hose to the water heater.





Transom Shower

Your yacht is equipped with a freshwater transom shower, located inside the port transom stowage tub.


Fresh Water Washdown Faucet

The freshwater cockpit washdown faucet is located on the port side of the aft cockpit.



Gray Water Drain System

- Gray water (water from sinks and showers) above the waterline is gravity drained overboard, while gray water below the waterline is drained into a small holding tank that contains the sump pump and float switch.
- The holding tank is located in the aft section of the utility room. When the holding tank reaches a predetermined level, the tank's float switch automatically activates the sump pump to empty the tank's gray water overboard. After the tanks are drained, the sump pumps are designed to automatically shut off.
- The shower sump pump and holding tank is located under the companion way floor hatch.
- The sump pump should be periodically cleaned of debris and the float switch tested for proper operation according to the instructions outlined in the bilge pump and float switch sections of this supplement.



Raw Water System

Seacocks


Seacocks are valves which are typically used to manage the intake of raw water through the hull below the water line (raw water intake seacocks). Seacocks may also be used to discharge waste or water through the hull below the water line (discharge seacocks).

Seacocks are controlled by a 90° lever and are used on your yacht in the following raw water intake/discharge systems: Engines, generator system, (optional) air conditioning system and standard marine head (toilet) system.



CAUTION!

SYSTEM DAMAGE HAZARD! Verify that the system's seacock is open before the system is started and keep the seacock open until the system is shut off. Close seacocks whenever the systems will not be used for long periods of time



Raw Water Strainers

Raw water strainers are used in water pickup systems to filter incoming raw water. The typical layout is one strainer for each of the following: Engine, generator and optional air conditioning system. Raw water strainers are located near raw water intake valves (seacocks) and should be checked every time you use your yacht for leaks/or debris. If debris is found, clean the strainer as follows:

1. Make sure the component/system that the strainer is connected to is turned OFF.
2. CLOSE the seacock that sends raw water to the strainer you are about to clean. The seacock must remain closed until the strainer is completely reassembled.
3. Take apart the raw water strainer.
4. Remove debris.
5. Flush strainer with water.
6. Reassemble the strainer.
7. OPEN the seacock and check for leaks around the strainer. If no leaks are found, you may activate the component or system.




CAUTION!

- **FLOODING HAZARD!** The seacock that sends raw water to the strainer must be CLOSED before disassembling the strainer to prevent the yacht from taking on water through the raw water strainer assembly. Keep the seacock CLOSED until the raw water strainer is completely reassembled.
- **SYSTEM DAMAGE HAZARD!** After reassembling the raw water strainer, verify that the seacock valve is OPEN before energizing the component/system.


Raw Water Washdown

The raw water washdown faucet is located on the forward deck port-side tub.



Standard Marine Head System

Your yacht comes with a marine head (toilet) and holding tank system. Be sure to read the manufacturer's operation manual included in your yacht's owner's packet. The standard marine head system installed on your yacht uses raw water to flush waste from the toilet directly into the holding tank.



- The raw water intake seacock is located inboard of the holding tank and must be opened prior to using the head system. The seacock should be left closed whenever the yacht is left unattended.
- The holding tank is plumbed to a fitting on the starboard deck for dockside pump-out and to a macerator pump for pumping waste directly into the water through an underwater discharge seacock (where regulations permit). The macerator switches are located at the helm and must be pressed simultaneously for pumping to occur.
- The holding tank is equipped with a level indicator (located on the forward bulkhead in the head). Even so, it is advisable to empty the holding tank at every opportunity.

NOTICE


Check with local authorities for regulations regarding the legal use of marine head systems.

Manual Flush Marine Head Operation:

1. OPEN the head's raw water intake valve (seacock).
 2. Before using the head, pump enough water into the bowl to wet the sides.
 3. After use, pump until the bowl is thoroughly cleaned. Continue pumping a few more times to clean the lines. If excess waste causes the water to rise in the bowl, stop pumping until the water recedes.
- If you are unable to pump water into the bowl, the probable cause is debris in the pump diaphragm. To remedy this, shut OFF the raw water intake valve (seacock) and dismantle the pump. The pump is generally held together with six screws (the design is simple and the problem will be obvious when the pump body is split open).
 - To winterize the head, shut OFF the intake seacock and pump until the bowl is dry. Remove the drain plug in the base and pump again to remove all of the water. DO NOT fill the bowl with antifreeze.


Macerator Delete Head System (Option)

Since this optional system does not contain a macerator, the holding tank is plumbed to a fitting on the deck for dockside pump-out only.



Vacuflush Head System (Option)

- The optional vacuflush head system uses freshwater (not raw water) to flush waste from the toilet to the holding tank.
- If the system is equipped with a macerator pump, waste may be pumped from the holding tank into the water through an underwater discharge seacock (where regulations permit). The macerator switches are located at the helm station and must both be pressed simultaneously for pumping to occur.
- If your yacht does not include a macerator (macerator delete option), waste can only be pumped out of the holding tank to the receptacle on the deck for dockside pump-out only.





Air Conditioning & Heating (Option)

Your yacht may be equipped with an optional air conditioning & heating system. Both heating and cooling are controlled from the same panel. Please refer to the air conditioner/heater manual for detailed operating instructions.

- Before operating the air conditioning and heating system, make sure the breakers on the AC main distribution panel are activated and verify the system's raw water pickup seacock is OPEN. The seacock must remain OPEN anytime the air conditioner/heater is in use.
- The raw water pickup strainer should be checked periodically for debris according to the directions given in the *Raw Water Strainer* section of this supplement.


CAUTION!

SYSTEM DAMAGE HAZARD! The air conditioning system's seacock must be OPENED before turning on an air conditioning unit and must remain open during operation.


Air Conditioning System Duct Routing***Air Conditioning Water Pickup Routing***

Chapter 3: Electrical Routings


AC Wiring




Shore Power/Generator Harnesses




Positive Battery Cable Routing




DC Engine Harness




Battery Ground Cable Routing



Negative Battery Cable Routing




Battery Isolator System Wiring




Chapter 4: Wiring Schematics


AC Electrical System




4600 SCB Owner's Manual Supplement



Gas Engine Electrical System



4600 SCB Owner's Manual Supplement



Appendix A: Express Limited Warranty

MAXUM EXPRESS LIMITED WARRANTY

Limited Warranty for New 2000 or 2001 Model Year Sport Yachts (3500SCR, 3700SCR, 4100SCA, 4100SCB, and 4600SCB)

Maxum warrants to the first retail purchaser ("Owner") of a new 2000 or 2001 Model Year Maxum Sport Yacht (3500SCR, 3700SCR, 4100SCA, 4100SCB, and 4600SCB) purchased from an authorized dealer, operated under normal, noncommercial use, that the selling dealer will (or, in Maxum's discretion, it will):

- (1) repair or replace any parts found to be defective in materials and workmanship occurring within 1 (one) year of the date of delivery;
- (2) repair any defects in materials and workmanship in structural fiberglass parts of the hull (and specifically excluding the deck) occurring within 7 (seven) years of the date of delivery; and
- (3) repair any defects in materials and workmanship that result in osmotic blistering of the exterior gel coat surface of the hull laminate occurring within 5 (five) years of the date of delivery, *except that Maxum shall not be liable or responsible to correct, repair, or replace any damage from osmotic blistering if the original gel surface has been altered in any way, including repair or application of any coating other than marine anti-fouling bottom paint or improper surface preparation for paint, or excessive sanding or sandblasting.* Maxum shall repair osmotic blisters based upon customary and reasonable charges with the method and extent of repair subject to Maxum's prior approval.

Owner's sole and exclusive remedy for defects covered by this limited warranty shall be the repair or replacement, at the option of Maxum, of the defective part or component. **THE REMEDY DESCRIBED IN THIS LIMITED WARRANTY SHALL BE THE SOLE AND EXCLUSIVE REMEDY PROVIDED BY MAXUM.**

Terms and Conditions

This limited warranty is subject to the specific terms and conditions set forth below.

In order to receive this limited warranty coverage, Maxum must receive the limited warranty registration card from the authorized selling dealer within 30 days of delivery of the Sport Yacht. Receipt by Maxum of the limited warranty registration card is a condition to the processing of a warranty claim.

All repairs under the terms of this warranty are subject to pre-approval from Maxum service personnel. Employees of Maxum dealers are not authorized to make warranties or approve warranty repairs other than those set forth herein.

To obtain warranty service, the Sport Yacht, including any allegedly defective part, must be returned to the authorized Maxum dealer from whom the Sport Yacht was purchased within the applicable warranty period. All warranty repairs must be performed at the Maxum dealer's facilities or, at Maxum's discretion, at an authorized Maxum repair facility.

The Owner is responsible for all expenses associated with transporting the Sport Yacht and/or defective part to and from the Maxum dealer, expenses associated with haul outs, yard fees, and any other expenses associated with transferring the yacht to the Maxum dealer or authorized Maxum repair facility for warranty service.

What Is Not Covered

Maxum shall not be responsible for any condition that may be affected by the Owner's failure to use, maintain, or store the Sport Yacht as specified in the Maxum owner's manual, and any other failure to provide reasonable care and maintenance.

Maxum hereby assigns all warranties provided by the manufacturers and distributors of components and parts (including but not limited to engines, transmissions, outdrives, and appliances) for the Sport Yacht to the Owner and Owner's sole remedy for defects in components or parts subject to those warranties shall be the assertion of Owner's rights against those manufacturers or distributors.

Maxum shall have no liability or responsibility for any damage or expense, and no Maxum warranty is provided for, the following:

A Sport Yacht purchased from any party other than an authorized Maxum dealer; a Sport Yacht, including components and systems, that has been altered or modified from factory specifications; equipment and accessories (including engines) not factory installed by Maxum; a Sport Yacht used for commercial purposes; any components or parts (including but not limited to engines, transmissions, outdrives, and appliances) that carry their own warranties; damage or deterioration of cosmetic surface finishes, including cracking, crazing, discoloration, air voids, fading or oxidation of gel coat, wood finishes (varnishes, stains and paints), fabrics, vinyls, plastics, plated or painted metal and stainless steel finishes; anti-fouling bottom paint or zinc anodes; the cost to remove, disassemble or reinstall components not installed by Maxum that require removal to access parts covered by this warranty; a Sport Yacht which has been misused, operated in a negligent manner, used for racing or military purposes; operated without normal maintenance, operated contrary to any instructions furnished by Maxum or its component suppliers, or operated in violation of applicable law or regulations; any representation or implication relating to speed, range, fuel consumption or estimated performance characteristics; window glass and windshield damage or breakage; damage, shrinkage, or deterioration of carpet, upholstery and exterior canvas tops, enclosures, and weather covers (including rainwater leakage); and any damage, cost, or expense caused by an act of nature.

Other Limitations

IN NO EVENT SHALL MAXUM OR THE SELLING DEALER BE RESPONSIBLE FOR INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (including but not limited to loss of time, loss of use, inconvenience, travel expense, transportation costs, towing, damage or loss of use of other property or equipment, loss of profits, and loss of contracts), WHETHER SUCH CLAIM OR ACTION IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, STRICT LIABILITY OR ANY OTHER TORT. Some states do not allow the exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives the Owner specific legal rights, and the Owner may also have other rights which vary from state to state. This document contains the entire warranty given by Maxum and there are no terms, promises, conditions or warranties, express or implied, other than those contained herein. **ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING IMPLIED WARRANTIES OF FITNESS AND MERCHANTABILITY ARE EXPRESSLY EXCLUDED. TO THE EXTENT ALLOWED BY LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY IS LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Maxum specifically does not authorize any person to extend the time or scope of this warranty or to create or assume for Maxum any other obligation or liability with respect to Maxum Sport Yachts.

Transferability

The unexpired portion of this warranty may be transferred to a second owner upon purchase of the Sport Yacht from an authorized Maxum dealer. A non-refundable recording fee of \$250.00 must accompany any transfer request. Maxum reserves the right to reject a warranty transfer request for a Sport Yacht that has been damaged, neglected, or otherwise previously excluded from warranty. Maxum will confirm all warranty transfers in writing to the dealer and the second owner.

For further information regarding this limited warranty, please contact Maxum at:

Maxum Marine
P.O. Box 6050
Arlington, WA 98223-6050
Phone (360) 435-6534

[illegible]

Part Number 1706511

Rev. A