



SERVICE MANUAL

NUMBER 22

MARINE ENGINES IN-LINE DIESEL

D2.8L D-Tronic Serial Number 0K000001 and Above

D4.2L D-Tronic Serial Number 0K000001 and Above

Notice

Throughout this publication, Dangers, Warnings and Cautions (accompanied by the International HAZARD Symbol ) are used to alert the mechanic to special instructions concerning a particular service or operation that may be hazardous if performed incorrectly or carelessly. **OBSERVE THEM CAREFULLY!**

These Safety Alerts alone cannot eliminate the hazards that they signal. Strict compliance to these special instructions when performing the service, plus common sense operation, are major accident prevention measures.

DANGER

Immediate hazards which will result in severe personal injury or death.

WARNING

Hazards or unsafe practices which could result in severe personal injury or death.

CAUTION

Hazards or unsafe practices which could result in minor personal injury or product or property damage.

Notice to Users of This Manual

This service manual has been written and published by the Service Department of Mercury Marine to aid our dealers' mechanics and company service personnel when servicing the products described herein.

It is assumed that these personnel are familiar with marine product servicing procedures. Furthermore, it is assumed that they have been trained in the recommended service procedures of Mercury MerCruiser product, including the use of mechanics' common hand tools and the special Mercury Marine or recommended tools from other suppliers.

We could not possibly know of and advise the marine trade of all conceivable procedures and of the possible hazards and/or results of each method. Therefore, anyone who uses a service procedure and/or tool, which is not recommended by the manufacturer, first must completely satisfy himself that neither his nor the products safety will be endangered.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication. As required, revisions to this manual will be sent to all dealers contracted by us to sell and/or service these products.

We reserve the right to make changes to this manual without prior notification.

Refer to dealer service bulletins, operation maintenance and warranty manuals and installation manuals for other pertinent information concerning the products described in this manual.

It should be kept in mind, while working on the product, that the electrical system is capable of violent and damaging short circuits or severe electrical shocks. When performing any work where electrical terminals could possibly be grounded or touched by the mechanic, the battery cables should be disconnected at the battery.

Any time the intake or exhaust openings are exposed during service they should be covered to protect against accidental entrance of foreign material which could enter the cylinders and cause extensive internal damage when the engine is started.

It is important to note, during any maintenance procedure replacement fasteners must have the same measurements and strength as those removed. Numbers on the heads of the metric bolts and on the surfaces of metric nuts indicate their strength. American bolts use radial lines for this purpose, while most American nuts do not have strength markings. Mismatched or incorrect fasteners can result in damage or malfunction, or possibly personal injury. Therefore, fasteners removed should be saved for reuse in the same locations whenever possible. Where the fasteners are not satisfactory for re-use, care should be taken to select a replacement that matches the original.

Engine Mechanical Components

Many of the engine mechanical components are designed for marine applications. Unlike automotive engines, marine engines are subjected to extended periods of heavy load and wide open throttle operation and, therefore, require heavy-duty components. Special marine engine parts have design and manufacturing specifications that are required to provide long life and dependable performance. Marine engine parts also must be able to resist the corrosive action of salt or brackish water that will rust or corrode standard automotive parts within a short period of time.

Failure to use recommended Mercury / Quicksilver service replacement parts can result in poor engine performance and/or durability, rapid corrosion of parts subjected to salt water and possibly complete failure of the engine.

Replacement Parts

Use of parts other than the recommended service replacement parts, will void the warranty on those parts that are damaged as a result.

WARNING

Electrical and fuel system components on Mercury MerCruiser Engines and Stern Drives are designed and manufactured to comply with U.S. Coast Guard Rules and Regulations to minimize risks of fire or explosion.

Use of replacement electrical or fuel system components, which do not comply to these rules and regulations, could result in a fire or explosion hazard and should be avoided.

When servicing the electrical and fuel systems, it is extremely important that all components are properly installed and tightened. If not, any electrical component opening would permit sparks to ignite fuel vapors from fuel system leaks, if they existed.

Models Covered in This Manual

Sterndrive (MCM)	Serial Number
D2.8L D-Tronic	0K000001 and Above
D4.2L D-Tronic	0K000001 and Above

Inboard (MIE)	Serial Number
D2.8L D-Tronic	0K000001 and Above
D4.2L D-Tronic	0K000001 and Above

Service Manual Outline

Section 1 - Important Information

- A - General Information
- B - Maintenance
- C - Troubleshooting

Section 2 - Removal and Installation

- A - Sterndrive (MCM) Models
- B - Inboard (MIE) Models

Section 3 - Engine Mechanical

- A - D2.8L D-Tronic And D4.2L D-Tronic Engines

Section 4 - Electrical System

- A - Starting System
- B - Charging System
- C - Glow Plug System (If Equipped)
- D - Instrumentation
- E - Wiring Diagrams

Section 5 - Fuel System

- A - Description
- B - Fuel Delivery Pump and Fuel Filter
- C - Injectors
- D - Injection Pump
- E - EDI Diagnosis

Section 6 - Cooling System

- A - Seawater Cooling System
- B - Closed Cooling System

Section 7 - Intake And Exhaust System

- A - Intercooler
- B - Intake / Exhaust Manifold, Elbows and Risers
- C - Turbocharger

Section 8 - Drive System

- A - ZF / Hurth Transmissions
- B - Propeller Shaft Models

Section 9 - Power Steering System

- A - Pump And Related Components

Important Information

1

Removal And Installation

2

Engine Mechanical

3

Electrical System

4

Fuel System

5

Cooling System

6

Intake And Exhaust System

7

Drive System

8

Power Steering System

9

IMPORTANT INFORMATION

Section 1A - General Information

Introduction	1A-3	Engine Break-In	1A-6
How to Use This Manual	1A-3	Initial Break-In Procedure	1A-6
Page Numbering	1A-3	Mercury/Quicksilver Lubricants, Sealants	
Engine Serial Number / Decal Locations	1A-4	And Adhesives	1A-7
Operation / Duty Cycle	1A-5		

IMPORTANT INFORMATION

Section 1B - Maintenance

Torque Specifications	1B-3	Throttle Cable	1B-39
Special Tools	1B-3	Shift Cable	1B-39
Tools	1B-3	Engine Coupler / U-joint Shaft Splines	1B-40
Lubricants / Sealants / Adhesives	1B-3	U-joints	1B-41
Engine Specifications	1B-4	Drive Shaft Extension Models	1B-42
Sterndrive (MCM) Engines	1B-4	Sterndrive Unit and Transom	
Inboard (MIE) Engines	1B-5	Assembly	1B-42
Capacities	1B-6	Continuity Circuit	1B-43
Engines	1B-6	Continuity Circuit (continued)	1B-44
Drives	1B-6	MerCathode	1B-45
Transmissions	1B-6	Engine Mounts	1B-45
Maintenance Schedules	1B-7	Electrical System	1B-45
Maintenance Intervals	1B-7	Power Steering	1B-46
Sterndrive (MCM) Engines	1B-8	Checking Fluid Level	1B-46
Inboard (MIE) Engines	1B-11	Filling and Bleeding	1B-48
Engine External Views	1B-13	Transmission	1B-49
Starboard Side View	1B-13	Checking Fluid Level	1B-49
Front View	1B-14	Power Trim	1B-50
Port Side View	1B-15	Checking Fluid Level	1B-50
Rear View	1B-16	Filling	1B-51
Engine Oil	1B-17	Gear Lube Monitor	1B-52
Oil Level	1B-17	Checking Fluid Level	1B-52
Changing Engine Oil and Oil Filter	1B-19	Filling	1B-52
Fuel	1B-21	Seawater Strainer	1B-53
Precautions	1B-21	Air Filter	1B-54
General Information	1B-22	Removal	1B-54
Diesel Fuel In Cold Weather	1B-22	Inspection	1B-54
Fuel Filter	1B-23	Cleaning	1B-55
Closed Cooling System	1B-28	Installation	1B-55
Coolant Requirement	1B-28	Drive Belts	1B-56
Checking Level	1B-29	General Information	1B-56
Draining	1B-30	Inspection	1B-57
Filling	1B-32	Engine Water Circulating Pump Belt	1B-57
Sacrificial Anodes	1B-33	Alternator Belt	1B-58
Removal	1B-33	Power Steering Pump Belt	1B-60
Inspection	1B-33	Vacuum Pump Belt	1B-62
Disassembly	1B-34	Battery	1B-64
Reassembly	1B-34	Charging System	1B-64
Installation	1B-34	Corrosion and Corrosion Protection	1B-64
Flushing Seawater System	1B-35	Saltwater Operation	1B-64
SternDrive (MCM) Models	1B-35	Freezing Temperature and Cold Weather	
Inboard (MIE) Models	1B-36	Operation	1B-65
Inspect Water Pickups	1B-38	Cold Weather or Extended Storage	1B-66
SternDrive Gear Housing	1B-38	Power Package Layup	1B-66
Inboard Through the Hull Pickup	1B-38	Draining	1B-67
Lubrication	1B-39	Recommissioning	1B-73

IMPORTANT INFORMATION

SECTION 1C - Troubleshooting

Precautions	1C-3	Turbocharger	1C-18
Poor Boat Performance and/or Poor Maneuverability	1C-5	Engine Noise	1C-19
Improper Full Throttle Engine RPM	1C-6	Valve Cover Area	1C-20
RPM Too High	1C-6	Cylinder Area	1C-20
RPM Too Low	1C-6	Camshaft Area	1C-21
Engine Cranks Over But Will Not Start Or Starts Hard	1C-7	Crankshaft Area	1C-22
Electrical	1C-7	Miscellaneous	1C-23
Fuel System	1C-7	Oil Pressure	1C-23
Miscellaneous	1C-9	Low Oil Pressure	1C-25
Engine Will Not Crank Over or Starter Inoperative	1C-9	High Oil Pressure	1C-25
Glow Plugs Inoperative	1C-10	Excessive Oil Consumption	1C-26
Charging System Inoperative	1C-11	Water / Coolant in Engine	1C-27
Noisy Alternator	1C-11	Important Information	1C-27
Engine Operates Poorly at Idle	1C-12	Water / Coolant In Crankcase Oil	1C-27
Engine Operates Poorly At High Rpm ...	1C-13	Water / Coolant On Top Pistons	1C-28
Poor Fuel Economy	1C-14	Engine Overheats	1C-29
Engine Smoking	1C-15	Cooling System	1C-29
Black Smoke	1C-15	Mechanical	1C-30
Blue Smoke	1C-16	Power Steering	1C-31
White Smoke	1C-16	Poor, Erratic or No Assist	1C-31
Exhaust Gas Temperature	1C-17	Noisy Pump	1C-32
High	1C-17	Fluid Leaks	1C-32
Low	1C-17	Insufficient Water Flow From Belt Driven Seawater Pump	1C-33
		ZF / Hurth Hydraulic Transmission	1C-34

REMOVAL AND INSTALLATION

Section 2A - Sterndrive (MCM) Models

Torque Specifications	2A-3	Throttle Cable Installation and Adjustment	2A-21
Special Tools	2A-3	Shift Cable Installation and Adjustment	2A-23
Lubricants / Sealants / Adhesives	2A-4	Troubleshooting Shift Problems	2A-28
Removal	2A-4	Battery Cables	2A-30
Installation	2A-7		
Engine Installation / Alignment	2A-7		
Engine Connections	2A-15		

REMOVAL AND INSTALLATION

Section 2B - Inboard (MIE) Models

Torque Specifications	2B-3	Engine Final Alignment	2B-11
Tools/Lubricants/Adhesives	2B-3	Engine Connections	2B-18
Removal	2B-4	Throttle Cable Installation and Adjustment	2B-21
Engine Removal	2B-4	Shift Cable Installation And Adjustment	2B-21
Installation	2B-7	Battery Cables	2B-21
Engine Installation and Initial Alignment	2B-7		

ENGINE

Section 3A - Engine Mechanical

Identification	3A-3	Installation	3A-34
Torque Specifications	3A-4	Water Manifold	3A-37
Tools	3A-6	Exploded Views	3A-37
Special Tools	3A-6	Removal	3A-38
Special Tools (continued)	3A-7	Cleaning	3A-38
Snap-On Tools	3A-8	Inspection	3A-38
Kent-Moore Tools	3A-8	Installation	3A-39
Lubricants/Sealants/Adhesives	3A-9	Cylinder Heads	3A-40
Engine Specifications	3A-10	Exploded Views	3A-40
Piston Rings	3A-10	Removal	3A-42
Cylinder Liner Diameter	3A-10	Disassembly	3A-44
Cylinder Liner Protrusion	3A-11	Cleaning	3A-44
Head Gaskets	3A-11	Inspection	3A-45
Cylinder Head	3A-11	Repair	3A-50
Oil Pump	3A-12	Expansion Plugs	3A-50
Camshaft	3A-12	Assembly	3A-52
Valve Lifter	3A-12	Installation -	
Rocker Arm	3A-13	Using Early Model Gaskets	3A-55
Valve Adjustment	3A-13	Installation -	
Valve	3A-13	Using Late Model Gaskets	3A-62
Valve Seat	3A-13	Rocker Arm	3A-71
Valve Guide	3A-14	Removal	3A-71
Valve Spring	3A-14	Cleaning	3A-71
Crankshaft	3A-15	Inspection	3A-71
Crankshaft (continued)	3A-16	Assembly	3A-72
Connecting Rods	3A-17	Installation	3A-73
Connecting Rod Crank Pin Bore	3A-17	Timing Gear Cover	3A-77
Connecting Rod Bushings	3A-17	Exploded View	3A-77
Pistons	3A-17	Removal	3A-78
Flywheel	3A-17	Cleaning	3A-78
Precautions	3A-18	Inspection	3A-78
General Information	3A-19	Installation	3A-79
Engine Rotation	3A-19	Oil Pump	3A-81
Engine Firing Order	3A-19	Removal	3A-81
Late Model Cylinder Head Gasket -		Cleaning	3A-81
Torque Sequence and Specifications	3A-20	Inspection	3A-82
Early Model Cylinder Head Gasket -		Reassembly	3A-83
Torque Sequence and Specifications	3A-25	Installation	3A-83
Lubrication System - All Models	3A-28	Oil Pressure Relief Valve	3A-84
Examples of Bearing Failures	3A-29	Removal	3A-84
Compression Testing Procedure	3A-30	Disassembly	3A-85
Engine Cover	3A-31	Cleaning	3A-85
Removal	3A-31	Inspection	3A-86
Cleaning	3A-31	Assembly	3A-86
Inspection	3A-31	Installation	3A-87
Installation	3A-31	Oil Pan and Oil Pick-Up Tube Assembly	3A-88
Valve Covers	3A-32	Removal	3A-88
Removal	3A-32	Cleaning	3A-89
Cleaning	3A-33	Inspection	3A-89
Inspection	3A-33	Installation	3A-89

ENGINE (continued)

Section 3A - Engine Mechanical (continued)

Adapter / Oil Thermostat	3A-91	Cleaning	3A-109
Removal	3A-91	Inspection	3A-109
Disassembly	3A-92	Assembly	3A-113
Cleaning and Inspection	3A-92	Installation	3A-114
Testing	3A-92	Rear Oil Seal	3A-116
Installation	3A-93	Removal	3A-116
Camshaft	3A-95	Installation	3A-117
Exploded View	3A-95	Crankshaft and Main Bearings	3A-118
Testing - Measuring Lobe Lift	3A-96	Removal	3A-118
Removal	3A-96	Cleaning	3A-123
Inspection	3A-98	Inspection	3A-124
Installation	3A-99	Installation	3A-127
Camshaft Bearings	3A-100	Cylinder Liners	3A-136
Inspection	3A-100	Removal	3A-136
Removal	3A-100	Identification	3A-137
Installation	3A-101	Cleaning and Inspection	3A-138
Valve Lifters	3A-102	Installation	3A-139
Removal	3A-102	Flywheel Housing, Coupler / Drive Plate And	
Cleaning	3A-103	Flywheel	3A-144
Inspection	3A-103	Exploded View	3A-144
Installation	3A-104	Flywheel Housing	3A-148
Valve Push Rods	3A-105	Sterndrive (MCM) Coupler / Inboard (MIE)	
Removal	3A-105	Drive Plate	3A-150
Cleaning	3A-105	Flywheel	3A-151
Inspection	3A-105	Engine Mounts	3A-152
Installation	3A-105	Front Mounts	3A-152
Connecting Rod / Piston Assembly	3A-106	MIE (Inboard) Transmission Mounts .	3A-153
Measuring Rod Bearing Clearance ..	3A-106	Engine 20-Hour Break-In Period	3A-154
Removal	3A-107	After Break-in Period	3A-154
Disassembly	3A-108		

ELECTRICAL SYSTEMS

Section 4A - Starting System

Identification	4A-3	Testing Voltage	4A-6
Specifications	4A-3	Removal	4A-7
Torque Specifications	4A-3	Starter Motor	4A-7
Lubricants / Sealants / Adhesives	4A-3	Solenoid Switch	4A-8
Replacement Parts	4A-4	Installation	4A-9
Starting System Components	4A-4	Solenoid Switch	4A-9
Inspection	4A-6	Starter Motor	4A-10
Periodic Inspection	4A-6		

ELECTRICAL SYSTEMS

Section 4B - Charging System

Identification	4B-3	Circuitry Test	4B-10
Replacement Parts Warning	4B-3	Output Circuit	4B-11
Specifications	4B-4	Excitation Circuit	4B-12
Torque Specifications	4B-4	Sensing Circuit	4B-13
Special Tools	4B-5	Current Output Test	4B-14
Lubricants/Sealers/Adhesives	4B-5	Exploded View	4B-16
Wire Color Code Abbreviations	4B-5	Removal	4B-17
Precautions	4B-6	Alternator	4B-17
General	4B-6	Alternator Bracket	4B-17
Electronic Diesel Injection (EDI)		Installation	4B-18
Electrical System Precautions	4B-6	Alternator Bracket	4B-18
Battery Precautions - Multiple EDI		Alternator	4B-18
Engines	4B-7	Battery Isolators	4B-19
Charging System Components	4B-8	Dual Battery Charging Systems	4B-19
Inspection	4B-9	Battery Isolator Diagram	4B-20
Troubleshooting Tests (Alternator on Engine)	4B-10		

ELECTRICAL SYSTEMS

Section 4C - Glow Plug System

Identification	4C-3	Inspection	4C-7
Specifications	4C-3	Installation	4C-8
Torque Specifications	4C-4	Glow Plug Actuator Relay and Auxiliary Relay	4C-9
Lubricants / Sealants / Adhesives	4C-4	Testing	4C-9
Special Tools	4C-4	Removal	4C-10
Description	4C-4	Cleaning	4C-10
Precautions	4C-4	Inspection	4C-10
Glow Plug Testing (Prior to Removal)	4C-5	Installation	4C-10
Removal	4C-6	Glow Plug Circuit Diagram	4C-11
Cleaning	4C-7		

ELECTRICAL SYSTEMS

Section 4D - Instrumentation

Identification	4D-3	Oil Pressure	4D-11
Gauges	4D-3	Water Temperature - Primary Station	4D-13
Panels	4D-3	Primary Station Switches	4D-15
Special Tools	4D-4	Ignition Key Switch	4D-15
Tools	4D-4	Audio Warning Test and Panel Light Switch	4D-17
Lubricants / Sealants / Adhesives	4D-4	Audio Warning System	4D-19
Wire Color Abbreviations	4D-4	Alarm	4D-19
Precautions	4D-5	Oil Pressure Switch	4D-20
General Information	4D-6	Water Temperature Switch / Sender	4D-21
Special Information	4D-6	Transmission Fluid Temperature Switch	4D-24
Tachometer	4D-6	Second Station Extension Harness	4D-26
QSI Series Gauge Lighting Options	4D-7	Remote Control / Neutral Start Safety Circuit	4D-29
Gauges	4D-8	Primary Station	4D-29
Removal	4D-8	Secondary Station	4D-30
Testing	4D-8		
Installation	4D-11		
Senders	4D-11		

ELECTRICAL SYSTEMS

Section 4E - Wiring Diagrams

Wire Color Abbreviations	4E-3	MerCathode System Wiring Diagram .	4E-15
Tools	4E-3	Inboard (MIE) Models	4E-16
Lubricants / Sealants / Adhesives	4E-3	Engine Wiring - Starting and Charging	
General Information	4E-3	System	4E-16
SternDrive (MCM) Models	4E-4	ECM and Fuel System Wiring	4E-20
Engine Wiring - Starting and Charging		Quicksilver Primary Instrumentation	
System	4E-4	Wiring	4E-22
ECM and Fuel System Wiring	4E-8	Models With Early Connectors	4E-26
Quicksilver Instrumentation Wiring ...	4E-10	Models With 21-Pin Deutsch TM	
Power Trim System Wiring Diagram ..	4E-14	Connector	4E-28

FUEL SYSTEM

Section 5A - Description

Introduction	5A-3	Analog Signals	5A-9
Precautions	5A-4	Analog Value Conditioning	5A-11
Testing Procedure	5A-5	Digital Signals	5A-13
General Information	5A-6	Engine Control Module (ECM)	5A-15
Basic Knowledge and Tools Required .	5A-6	Speed Density System	5A-17
Visual/Physical Inspection	5A-6	ECM Input and Sensor Descriptions ..	5A-18
Electrostatic Discharge Damage	5A-6	Fuel Management	5A-26
Diagnostic Information	5A-7	Control	5A-26
Terminology	5A-7	Modes Of Operation	5A-27
Electronic Control Module (ECM)		Diagnosis and Testing	5A-30
and Sensors	5A-9	ECM Reactions During Operation	5A-30
General Description	5A-9	ECM Self-Diagnostics	5A-30
Computers and Voltage Signals	5A-9		

FUEL SYSTEM

Section 5B - Fuel Delivery Pump and Fuel Filter

Identification	5B-3	Testing	5B-8
Specifications	5B-3	Removal	5B-10
Torque	5B-3	Installation	5B-11
Tools	5B-3	Water Separating Fuel Filter	5B-13
Lubricants / Sealants / Adhesives	5B-3	Removal	5B-13
Precautions	5B-4	Installation	5B-13
Exploded View	5B-6	Water Drain Valve Operation	5B-15
Fuel Delivery Pump, Fuel Filter		Purging Air From The Fuel System	5B-16
and Related Components	5B-6		

FUEL SYSTEM

Section 5C - Fuel Injectors

Identification	5C-3	Exploded View	5C-8
Specifications	5C-3	Injector Test (Engine Misfiring)	5C-9
Torque	5C-3	Removal	5C-10
Tools	5C-4	Inspection	5C-12
Bosch	5C-4	Testing	5C-12
Lubricants / Sealants / Adhesives	5C-4	Installation	5C-13
Precautions	5C-5	Purging Air From Fuel Injectors	
Description	5C-6	(Bleeding)	5C-16
Fuel Injector (Cutaway View)	5C-7		

FUEL SYSTEM

Section 5D - Injection Pump

Identification	5D-2	Repair and Service	5D-7
Pump Code and Identification		General Information	5D-7
Number Location	5D-2	Service Information	5D-7
Specifications	5D-2	Precautions	5D-9
Injection Pump	5D-2	Exploded View	5D-10
Timing	5D-3	Fuel Injection Pump Removal	5D-11
Torque Specifications	5D-3	Fuel Injection Pump Installation	5D-16
Special Tools	5D-3	Installation With Engine Assembled ..	5D-16
Tools	5D-4	Installation During Engine	
Special EDI Tools	5D-4	Reassembly	5D-19
Kent-Moore Tools	5D-4	Fuel Injection Pump Timing	5D-23
Lubricants / Sealants / Adhesives	5D-4	Checking	5D-23
Description	5D-5	Setting	5D-23
Fuel Ratings	5D-6	Starting Engine - After Fuel Injection	
Diesel Fuel in Cold Weather	5D-6	Pump Installation and Timing	5D-28

FUEL SYSTEM

Section 5E - EDI Diagnosis

General Information	5E-2	Main Relay	5E-46
Introduction	5E-2	Timing Actuator	
Basic Knowledge and Tools Required .	5E-2	(Timing Solenoid Valve)	5E-48
Visual/Physical Inspection	5E-3	Glow Plug Main Relay	
Electrostatic Discharge Damage	5E-3	(Glow Plug Relay Actuator),	
Special Tools	5E-4	If Equipped	5E-50
Special EDI Tools	5E-4	Glow Plug Auxiliary Relay, If Equipped	5E-52
Kent-Moore Tools	5E-4	Glow Plug Lamp (Glow Plug Display) .	5E-54
Service Precautions	5E-5	Glow Plug Lamp (Glow Plug Display) .	5E-56
Diagnostic Information	5E-7	MIL [Malfunction Indicator Lamp	
Abbreviations	5E-7	(Diagnostic Lamp)]	5E-58
ECM Self-Diagnosis	5E-8	MIL [Malfunction Indicator Lamp	
Malfunction Indicator Lamp	5E-9	(Diagnostic Lamp)]	5E-60
Intermittent Problems and		Fuel Shut Off Valve [EAB	
Malfunction Indicator Lamp	5E-10	(Electrical Shut Off)]	5E-62
Reading Codes	5E-10	EEPROM Fault (EEPROM and	
Clearing Codes	5E-13	Configuration)	5E-64
Diagnosis of Driveability Concerns ...	5E-14	RPM Signal From Injector	
ECM Input and Sensor Diagram	5E-15	(Secondary Engine Speed Sensor) ..	5E-66
ECM Connector Pin Layout	5E-16	Troubleshooting For EDI Systems	5E-68
Connector Chart	5E-17	Trouble Codes	5E-68
MAP (Manifold Air Pressure) Sensor .	5E-20	Display Terminology	5E-69
ECT (Engine Coolant Temperature)		Troubleshooting Charts	5E-74
Sensor	5E-22	Repair Procedures	5E-93
Fuel Temperature Sensor	5E-24	Service Precautions	5E-93
RPM (Engine Speed) Sensor	5E-26	Replacement Parts Warning	5E-94
BARO (Atmospheric Pressure)		Torque Specifications	5E-95
Sensor	5E-28	Lubricants / Sealants / Adhesives	5E-95
IAT (Intake Air Temperature) Sensor .	5E-30	System Components	5E-96
Instrumented Injector		Fuel Injection Pump Repair	5E-98
(Needle Movement Sensor)	5E-32	Wiring Harness Service	5E-99
Fuel Quantity Actuator		Relay, Module and Sensor Servicing	
(Pump Actuator)	5E-34	(On-Board Service)	5E-102
Fuel Quantity Sensor		Precautions	5E-102
(Control Sleeve Position Sensor)	5E-36	Main Relay	5E-102
Timing Fault		ECM (Electronic Control Module) ...	5E-104
(Timing Advance Regulation)	5E-38	ECT (Engine Coolant Temperature)	
TP (Throttle Position)		Sensor	5E-106
Sensor / Low Idle Switch	5E-40	MAP (Manifold Absolute Pressure) /	
Battery Voltage	5E-42	IAT (Intake Air Temperature) Sensor	5E-108
Battery (Switched K15)	5E-43	Throttle Position (TP) Sensor	5E-110
Microcontroller Fault	5E-44	Instrumented Injector	5E-112
ECM Reference Voltage		Engine RPM Speed Sensor	5E-112
(u_ref - 2.5v)	5E-45	Idle Speed Setting Circuit	5E-113

COOLING SYSTEM

Section 6A - Seawater Cooling System

Torque Specifications	6A-3	Inspection	6A-18
Lubricants / Sealants / Adhesives	6A-3	Assembly	6A-19
Tools	6A-3	Installation	6A-25
Seawater (Raw Water) System		Seawater Strainer	6A-27
Specifications	6A-4	Exploded View	6A-27
Seawater Pump Delivery Rates	6A-4	Removal	6A-28
Seawater Pickup Connections	6A-4	Installation	6A-30
Precautions	6A-5	Oil / Power Steering / Transmission	
Seawater Pickup Connection	6A-5	Fluid Coolers	6A-31
Seacock	6A-6	General Information	6A-31
Seawater Strainer	6A-6	Exploded View	6A-32
Exploded View - Seawater Pumps	6A-7	Location of Coolers	6A-33
D2.8L D-Tronic	6A-7	Inspection Before Removal	6A-34
D4.2L D-Tronic	6A-8	Cleaning Without Removal	6A-34
Seawater Flow Diagram	6A-10	Engine Oil Cooler	6A-35
Seawater Pump	6A-12	Power Steering	6A-40
Removal	6A-12	Transmission Fluid Cooler	6A-42
Disassembly	6A-13	Installation	6A-43
Cleaning	6A-17		

COOLING SYSTEM

Section 6B - Closed Cooling System

Specifications	6B-4	Draining Closed Cooling System	6B-17
Capacity	6B-4	Cleaning Closed Cooling System	6B-19
Thermostats	6B-4	Using A Cleaner	6B-19
Pressure Cap	6B-4	Heat Exchanger and Cooler Cleaning	6B-19
Coolant	6B-4	Flushing The Closed Cooling System	6B-20
Torque Specifications	6B-5	Filling The Closed Cooling System	6B-21
Lubricants / Sealants / Adhesives	6B-5	Thermostats	6B-22
Tools	6B-5	Removal	6B-22
Special Tools	6B-5	Testing	6B-23
Tools	6B-5	Installation	6B-25
Diagrams and Exploded Views	6B-6	Heat Exchanger	6B-26
Coolant Flow Diagram	6B-6	Testing	6B-26
Heat Exchanger / Coolant Tank and Related Components	6B-8	Repair	6B-26
Engine Water Circulating Pump	6B-10	Removal	6B-27
Checking Coolant Level	6B-11	Cleaning and Inspection	6B-28
Testing Closed Cooling System	6B-12	Installation	6B-29
Testing Coolant for Alkalinity	6B-12	Water Circulating Pump	6B-31
Pressure Testing System	6B-12	Removal	6B-31
Testing for Cylinder Head		Cleaning and Inspection	6B-31
Gasket Leak	6B-14	Installation	6B-32
Testing Pressure Cap	6B-15	Coolant Manifold	6B-33
Coolant Change Interval	6B-17	Corrosion Protection	6B-33
Coolant Requirement	6B-17	Auxiliary Hot Water Heater Connections	6B-33

INTAKE AND EXHAUST SYSTEM

Section 7A - Intercooler

Torque Specifications	7A-3	Removal	7A-8
Lubricants / Sealants / Adhesives	7A-3	Disassembly	7A-11
Exploded Views	7A-4	Cleaning and Inspection	7A-13
D2.8L Intercooler	7A-4	Assembly	7A-14
D4.2L Intercooler	7A-6	Installation	7A-17
Intercooler	7A-8		

INTAKE AND EXHAUST SYSTEM

Section 7B - Manifolds, Elbows And Risers

Torque	7B-3	Locating And Installing The Inboard (MIE) Exhaust System	7B-9
Lubricants / Sealants / Adhesives	7B-3	Exhaust Pipe - Sterndrive (MCM)	7B-11
Description	7B-3	Removal	7B-11
Exploded Views	7B-4	Cleaning	7B-11
Typical Intake / Exhaust Manifold	7B-4	Installation	7B-12
Sterndrive (MCM) Exhaust Systems	7B-5	Intake / Exhaust Manifold	7B-13
Inboard (MIE) Exhaust Systems	7B-6	Removal	7B-13
Representative View of Complete Inboard Exhaust System	7B-7	Cleaning and Inspection	7B-14
Locating and Installing The Sterndrive (MCM) Exhaust System	7B-8	Installation	7B-15

INTAKE AND EXHAUST SYSTEM

Section 7C - Turbocharger

Identification	7C-3	Testing Turbocharger Boost Pressure	7C-9
Turbocharger Specifications	7C-3	Checking Turbine Bearings (Assembled)	7C-10
Torque Specifications	7C-4	Removal	7C-11
Lubricants / Sealants / Adhesives	7C-4	Disassembly	7C-15
Description	7C-5	Cleaning	7C-17
Turbocharger	7C-5	Inspection	7C-18
Wastegate	7C-5	Assembly	7C-19
Exploded Views	7C-6	Installation	7C-21
Turbocharger And Related Components	7C-6	Boost Pressure Control	7C-28
Boost Pressure Control (Wastegate) Components	7C-8	Exhaust Pipe	7C-28
Turbocharger	7C-9	Valve	7C-31
		Wastegate	7C-33

DRIVES

Section 8A - ZF/Hurth Transmissions

Identification	8A-3	Transmission Fluid Level	8A-8
Specifications	8A-4	Checking	8A-8
Operating Specifications	8A-4	Filling	8A-9
Ratios and Part Numbers	8A-4	Changing	8A-9
Fluid Specifications	8A-4	Transmission Removal	8A-12
Torque	8A-5	Transmission Inspection	8A-13
Tools	8A-5	Transmission Installation	8A-13
Lubricants / Sealants / Adhesives	8A-5	Shift Control And Cables	8A-15
Important Information	8A-6	Transmission Shift Lever And Shift	
Engine	8A-6	Cable Bracket	8A-15
Transmission	8A-6	Shift Cable Installation and	
Propeller	8A-6	Adjustment	8A-16
Transmission / Propeller Rotation	8A-7	Pressure And Temperature Tests	8A-21
		Transmission Repair	8A-21

DRIVES

Section 8B - Propeller Shaft Models

Lubricants / Sealants / Adhesives	8B-2	Checks Made with Propeller Shaft	
Checks Made with Boat In Water	8B-3	Removed from Boat	8B-7
Checks Made with Boat Out of Water		Strut	8B-7
and Shaft Installed	8B-5		

POWER STEERING

Section 9A - Pump And Related Components

Torque Specifications	9A-2	Power Steering Pump	9A-5
Lubricants / Sealants / Adhesives	9A-2	Removal	9A-5
Description	9A-2	Installation	9A-6
Exploded Views	9A-3	Checking Fluid Level	9A-8
Power Steering Pump	9A-3	Filling and Bleeding	9A-8
Related Components	9A-4		

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

IMPORTANT INFORMATION

Section 1A - General Information

**1
A**

Table of Contents

Introduction	1A-3	Engine Break-In	1A-6
How to Use This Manual	1A-3	Initial Break-In Procedure	1A-6
Page Numbering	1A-3	Mercury/Quicksilver Lubricants, Sealants	
Engine Serial Number / Decal Locations .	1A-4	And Adhesives	1A-7
Operation / Duty Cycle	1A-5		

THIS PAGE IS INTENTIONALLY BLANK

NOTICE

For information and procedures on Troubleshooting, refer to SECTION 1C.

NOTICE

Refer to appropriate Sterndrive Service Manual for transom assembly and sterndrive unit repair.

Introduction

This comprehensive overhaul and repair manual is designed as a service guide for the models previously listed. It provides specific information, including procedures for disassembly, inspection, assembly and adjustment to enable dealers and service mechanics to repair and tune these engines.

Before attempting repairs, it is suggested that the procedure first be read through to gain knowledge of the methods and tools used and the cautions and warnings required for safety.

How to Use This Manual


This manual is divided into sections that represent major components and systems.

Some sections are further divided into parts that more fully describe the component.


Page Numbering

Two number groups appear at the bottom of each page. The following is an example and description.

Page 1A-3




90-860074--1 FEBRUARY 2002



- a** - Section Number
- b** - Section Part
- c** - Page Number
- d** - Manual Number
- e** - Revision Number 1
- f** - Month Printed
- g** - Year Printed

Engine Serial Number / Decal Locations



Typical Sterndrive (MCM) Engine Shown - Inboard (MIE) Similar

- a** - Serial Number Plate
- b** - Manufacturer's Serial Number (Stamped in Block)
- c** - Exhaust Gas Emissions Certificate Number (Example)
- d** - MerCruiser Specification Decal

Operation / Duty Cycle

It is the operator's responsibility to operate within the following specified operational capability, or duty cycle, as applicable to engine and installation:

NOTE:

Pleasure duty rating applies to recreational planing craft used exclusively for pleasure and recreation.

Light duty rating applies to planing boats where the use of full rated power at maximum rated rpm is limited (as stated above). Examples of Light Duty applications include, but are not limited to: search and rescue craft, fast patrol boats, fire boats, dive boats, and limited season fishing boats such as sport-fish charter boats. Application to common commercial crafts having full-displacement or semi-displacement hulls exceeds the recommended operational capability, or duty cycle.

IMPORTANT: Damage caused by improper application or failure to operate within the operational capability, or duty cycle, will not be covered by the Mercury MerCruiser Diesel Limited Warranty.

PLEASURE DUTY RATING / DUTY CYCLE

D2.8L D-Tronic and D4.2L D-Tronic	
Specified Operating RPM Range	3600 - 3800
Wide Open Throttle (WOT) Operation	Limited to short periods of time.

LIGHT DUTY RATING / DUTY CYCLE

D2.8L D-Tronic and D4.2L D-Tronic	
Specified Operating RPM Range	3600-3800
Wide Open Throttle (WOT) Operation	Limited to less than 10% of operating time.
Continuous cruising RPM	Limited to 90% or less of wide open throttle RPM
Annual operating time	Not to exceed 500 hours

Engine Break-In

Initial Break-In Procedure












The following procedure must be used on new and rebuilt diesel engines. This break-in procedure allows the proper seating of the pistons and rings, which greatly reduces the likelihood of problems.











IMPORTANT: It is recommended that the boat not be accelerated hard until this procedure has been completed.

IMPORTANT: Never operate the starter motor longer than 15 seconds at a time, to avoid overheating the starter motor. If engine does not start, wait 1 minute to allow the starter motor to cool; then, repeat starting procedure.

1. Refer to appropriate Starting, Shifting and Stopping section in the Operation, Maintenance and Warranty Manual provided with the product and start the engine. Allow the engine to idle until it has reached normal operating temperature.
2. Operate the engine in gear for 3 minutes at each of the following rpms: 1200 rpm, 2400 rpm and 3000 rpm.
3. Operate the engine in gear for 3 minutes at each of the following rpms: 1500 rpm, 2800 rpm and 3400 rpm.
4. Operate the engine in gear for 3 minutes at each of the following rpms: 1800 rpm, 3000 rpm and WOT.

Mercury/Quicksilver Lubricants, Sealants And Adhesives

Tube Ref. #	Description	Container Size	Mercury Part Number	Quicksilver Part Number
 4	Needle Bearing Assy. Lubricant	8 oz (226.8 g) tube	N/A	92-802868A1
 6	Dielectric Grease	8 oz (226.8 g) can	N/A	92-823506-1
 7	Loctite 271 - Thread Locker	10 ml tube	N/A	92-809819
 9	Loctite 567 PST Pipe Sealant	50 ml tube	N/A	92-809822
 12	Loctite Master Gasket Kit		N/A	92-12564-2
 14	2 Cycle Premium Outboard Oil	1 US qt (0.94 L)	92-802813A1	92-802813Q1
 19	Perfect Seal	16 oz (0.45 kg) can	N/A	92-34227-1
 25	Liquid Neoprene	8 oz (226.8 g) can	N/A	92-25711-3
 27	Bellows Adhesive	1.5 oz (42.5 g) tube	N/A	92-86166Q1
 33	Loctite 680 Retaining Compound	10 ml tube	N/A	92-809833
 34	Special Lubricant 101	8 oz (226.8 g) tube	92-802865A1	92-802865Q1
 42	U-Joint and Gimbal Bearing Grease		92-802870A1	92-802870Q1
 51	Loctite 222 Thread Locker	10 ml tube	N/A	92-809818
 66	Loctite 242 Thread Locker	10 ml tube	N/A	92-809821
 79	4 Cycle 25W40 Engine Oil		92-802837A1	92-802837Q1
 82	Premium Gear Lubricant	1 US qt (0.94 L)	92-802846A1	92-802846Q1
 87	High Performance Gear Lube	1 US qt (0.94 L)	92-802854A1	92-802854Q1
 91	Engine Coupler Spline Grease	14 oz (0.39 kg) cartridge	92-802869A1	92-802869Q1
 94	Anti-Corrosion Grease	8 oz (226.8 g) tube	92-802867A1	92-802867Q1
 95	2-4-C with Teflon	8 oz (226.8 g) tube	92-802859A1	92-802859Q1
 110	4 Stroke 10W30 Outboard Oil	1 US qt (0.94 L)	92-802833A1	92-802833Q1
 114	Power Trim & Steering Fluid	8 oz (226.8 g)	92-802880A1	92-802880Q1

Tube Ref. #	Description	Container Size	Mercury Part Number	Quicksilver Part Number
 115	Premium Plus 2 Cycle TC-W3 Outboard Oil	1 US qt (0.94 L)	92-802824A1	92-802824Q1
 116	RTV 587 Silicone Sealer	3 oz (85.05 g)	N/A	92-809825
 117	Loctite 7649 Primer N	4.5 oz (127.57 g)	N/A	92-809824
 118	Storage Seal Rust Inhibitor	12 oz (325 ml) spray can	92-802878-56	92-802878Q56
 119	Corrosion Guard	12 oz (325 ml) spray can	92-802878 55	92-802878Q55
 120	15W40 4-cycle Diesel Engine Oil	1.06 US gal.(4 L)	92-877695K1	92-877695Q1
 121	Extended Life Antifreeze/Coolant	1 US gal. (3.78 L)	92-877770K1	92-877770K1
 122	Marine Engine Coolant	1.33 US gal. (5 L)	N/A	92-813054A2
 123	Fuel System Treatment and Stabilizer Concentrate	16 oz (437 ml)	92-802876A1	92-802876Q1
 124	Heat Transfer Compound	1.5 oz (42.5 g) tube	N/A	92-805701 1
 125	Liquid Gasket		N/A	92-808137
 126	T442 Sealant		N/A	92-862258
 127	Loctite 5900 Ultra Black RTV Silicone Sealant	13 oz (371 g) tube	N/A	92-809826
 128	Loctite Gasket Remover	18 oz (532 ml) spray can	N/A	92-809828 1
 129	Sealer Kit, Two Part Epoxy		N/A	92-65150 1
	Dexron III Automatic Transmission Fluid		Obtain Locally	Obtain Locally
	Loctite 592		Obtain Locally	Obtain Locally
	Loctite Quick Tite		Obtain Locally	Obtain Locally
	Isopropyl Alcohol		Obtain Locally	Obtain Locally
	Hot Glue		Obtain Locally	Obtain Locally
	Loctite 609		Obtain Locally	Obtain Locally
	Loctite 405		Obtain Locally	Obtain Locally
	Cyanacrylate Adhesive		Obtain Locally	Obtain Locally
	3M Permabond #3M08155		Obtain Locally	Obtain Locally
	Loctite 262		Obtain Locally	Obtain Locally

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

IMPORTANT INFORMATION

Section 1B - Maintenance

1 B

Table of Contents

Torque Specifications	1B-3	Throttle Cable	1B-39
Special Tools	1B-3	Shift Cable	1B-39
Tools	1B-3	Engine Coupler / U-joint Shaft Splines	1B-40
Lubricants / Sealants / Adhesives	1B-3	U-joints	1B-41
Engine Specifications	1B-4	Drive Shaft Extension Models	1B-42
Sterndrive (MCM) Engines	1B-4	Sterndrive Unit and Transom Assembly	1B-42
Inboard (MIE) Engines	1B-5	Continuity Circuit	1B-43
Capacities	1B-6	Continuity Circuit (continued)	1B-44
Engines	1B-6	MerCathode	1B-45
Drives	1B-6	Engine Mounts	1B-45
Transmissions	1B-6	Electrical System	1B-45
Maintenance Schedules	1B-7	Power Steering	1B-46
Maintenance Intervals	1B-7	Checking Fluid Level	1B-46
Sterndrive (MCM) Engines	1B-8	Filling and Bleeding	1B-48
Inboard (MIE) Engines	1B-11	Transmission	1B-49
Engine External Views	1B-13	Checking Fluid Level	1B-49
Starboard Side View	1B-13	Power Trim	1B-50
Front View	1B-14	Checking Fluid Level	1B-50
Port Side View	1B-15	Filling	1B-51
Rear View	1B-16	Gear Lube Monitor	1B-52
Engine Oil	1B-17	Checking Fluid Level	1B-52
Oil Level	1B-17	Filling	1B-52
Changing Engine Oil and Oil Filter	1B-19	Seawater Strainer	1B-53
Fuel	1B-21	Air Filter	1B-54
Precautions	1B-21	Removal	1B-54
General Information	1B-22	Inspection	1B-54
Diesel Fuel In Cold Weather	1B-22	Cleaning	1B-55
Fuel Filter	1B-23	Installation	1B-55
Closed Cooling System	1B-28	Drive Belts	1B-56
Coolant Requirement	1B-28	General Information	1B-56
Checking Level	1B-29	Inspection	1B-57
Draining	1B-30	Engine Water Circulating Pump Belt	1B-57
Filling	1B-32	Alternator Belt	1B-58
Sacrificial Anodes	1B-33	Power Steering Pump Belt	1B-60
Removal	1B-33	Vacuum Pump Belt	1B-62
Inspection	1B-33	Battery	1B-64
Disassembly	1B-34	Charging System	1B-64
Reassembly	1B-34	Corrosion and Corrosion Protection	1B-64
Installation	1B-34	Saltwater Operation	1B-64
Flushing Seawater System	1B-35	Freezing Temperature and Cold Weather Operation	1B-65
SternDrive (MCM) Models	1B-35	Cold Weather or Extended Storage	1B-66
Inboard (MIE) Models	1B-36	Power Package Layout	1B-66
Inspect Water Pickups	1B-38	Draining	1B-67
SternDrive Gear Housing	1B-38	Recommissioning	1B-73
Inboard Through the Hull Pickup	1B-38		
Lubrication	1B-39		

THIS PAGE IS INTENTIONALLY BLANK

Torque Specifications

Description		Nm	lb-in.	lb-ft
Rear Engine Mounts		51		38
Alternator Tensioning Or Mounting Bolt		28		21
Power Steering Tensioning Or Mounting Bolt		21		15
Vacuum Pump Tensioning Or Mounting Bolt		21		15
Heat Exchanger End Covers				
	Upper	14-15	120-132	
	Lower	11	108-120	

Special Tools

Description	Part Number
Crankcase Oil Pump	90265A2
Flushing Attachment	44357T 2
Reference Electrode and Test Meter	91-76675T1

Tools

Description	Part Number
Water Tap Hose Adapter To Water Inlet Fitting	Obtain Locally
Typical Hand-operated Grease Gun	

Lubricants / Sealants / Adhesives

Description	Part Number
Mercury Diesel Engine Oil	92-877695K1
Liquid Neoprene	92-25711--3
Loctite 567 PST Pipe Sealant	92-809822
Engine Coupler Spline Grease	92-816391A4
U-Joint and Gimbal Bearing Grease ¹	92-828052A2
2-4-C Marine Lubricant With Teflon	92-802861Q1
Exxon Unirex EP2 Grease	Obtain Locally
SAE 30W Engine Oil	Obtain Locally

¹ Except on Bravo X Drive U-joint crosses and bearings - use Exxon Unirex EP2 Grease.

Engine Specifications

Sterndrive (MCM) Engines

Description		Specification - Sterndrive (MCM)	
		D2.8L D-Tronic	D4.2L D-Tronic
Crankshaft Kilowatts (Horsepower) ¹		123 (165)	186 (250)
Propeller Shaft Kilowatts (Horsepower) ¹		112 (150)	168 (225)
Engine Type		In-Line 4 Cylinder Diesel	In-Line 6 Cylinder Diesel
Displacement		2.8 liter (169 cu. in.)	4.2 liter (254 cu. in.)
Firing Order		1 - 3 - 4 - 2	1 - 5 - 3 - 6 - 2 - 4
Bore		94 mm (3.700 in.)	
Stroke		100 mm (3.937 in.)	
Compression Ratio		16.5:1	
Valve Clearance - Intake / Exhaust		Hydraulic	
Maximum Pressure Difference Between Cylinders		500 kPa (72 psi)	
Maximum High Idle No Load rpm		4200 ± 50	
Governed rpm Setting (Begins At:)		3850 ± 50	
Rated rpm at Wide-Open-Throttle ²		3800	
Low Idle rpm		700 ³	
		600 ⁴	
Oil Pressure:	750 rpm	1.5 - 3.1 bar [152-310 kPa] (22-45 psi)	
	3800 rpm	3.5 - 5.6 bar [345-556 kPa] (50-80 psi)	
Oil Temperature		100 - 110 degrees C (212 - 230 degrees F)	
Thermo-stats:	Water: (2 Total)	70 degrees C (160 degrees F)	
	1 at temperature:	82 degrees C (180 degrees F)	
	Oil:	95 degrees C (203 degrees F)	
Coolant Temperature		80 - 85 degrees C (176 - 185 degrees F)	
Electrical System		12-volt Negative (-) Ground	
Alternator Rating		949W, 14.6v, 65 Amp.	
Recommended Battery Rating		750 cca, 950 mca, or 180 Ah	
Starter		12v, 2.7 kW	

¹ Power rated in accordance with NMMA Procedure - ISO 3046 (Technically Identical to ICOMIA 28-83).

² Refer to Conditions Affecting Operation - Propeller Selection for additional information.

³ Mercury Serial Number 0L343084 and Below on D2.8L D-Tronic Engines. Mercury Serial Number 0L343703 and Below on D4.2L D-Tronic Engines.

⁴ Mercury Serial Number 0L343085 and Above on D2.8L D-Tronic Engines. Mercury Serial Number 0L343704 and Above on D4.2L D-Tronic Engines.

Inboard (MIE) Engines

Description		Specification - Inboard (MIE)	
		D2.8L D-Tronic	D4.2L D-Tronic
Crankshaft Kilowatts (Horsepower) ¹		123 (165)	186 (250)
Propeller Shaft Kilowatts (Horsepower) ¹		119 (160)	179 (240)
Engine Type		In-Line 4 Cylinder Diesel	In-Line 6 Cylinder Diesel
Displacement		2.8 liter 169 cu. in.	4.2 liter (254 cu. in.)
Firing Order		1 - 3 - 4 - 2	1 - 5 - 3 - 6 - 2 - 4
Bore		94 mm (3.700 in.)	
Stroke		100 mm (3.937 in.)	
Compression Ratio		16.5:1	
Valve Clearance - Intake / Exhaust		Hydraulic	
Maximum Pressure Difference Between Cylinders		500 kPa (72 psi)	
Maximum High Idle No Load rpm		4200 ± 50	
Governed rpm Setting (Begins At:)		3850 ± 50	
Rated rpm at Wide Open Throttle ²		3800	
Low Idle rpm		700 ³	
		600 ⁴	
Oil Pressure:	750 rpm	1.5 - 3.1 bar (152-310 kPa) [22-45 psi]	
	3800 rpm	3.5 - 5.6 bar (345-556 kPa) [50-80 psi]	
Oil Temperature		100 - 110 degrees C (212 - 230 degrees F)	
Thermostats:	Water: (2 Total)	70 degrees C (160 degrees F)	
	1 at temperature:		
	1 at temperature:	82 degrees C (180 degrees F)	
Oil: (1 Total)		95 degrees C (203 degrees F)	
Coolant Temperature		80 - 85 degrees C (176 - 185 degrees F)	
Electrical System		12-volt Negative (-) Ground	
Alternator Rating		949W, 14.6v, 65 Amp.	
Recommended Battery Rating		750 cca / 950 mca / 180 Ah	
Starter		12v, 2.7 kW	

¹ Power rated in accordance with NMMA Procedure - ISO 3046 (Technically Identical to ICOMIA 28-83).

² Refer to "Conditions Affecting Operation - Propeller Selection" for additional information.

³ Mercury Serial Number 0L343084 and Below on D2.8L D-Tronic Engines. Mercury Serial Number 0L343703 and Below on D4.2L D-Tronic Engines.

⁴ Mercury Serial Number 0L343085 and Above on D2.8L D-Tronic Engines. Mercury Serial Number 0L343704 and Above on D4.2L D-Tronic Engines.

Capacities

NOTICE

All capacities are approximate fluid measures.

Engines

NOTICE

Unit Of Measurement: Liters (U.S. Quarts).

Model		D2.8L D-Tronic	D4.2L D-Tronic
Total Oil Capacity ¹		10 (8-1/2)	12 (12-3/4)
Oil Drainage	Oil Pan	8 (6-1/2)	10 (10-3/4)
	Oil Filter	1 (1)	
	Oil Cooler	1 (1)	
Closed Cooling Circuit		11 (11-2/3)	13 (13-3/4)

¹ Always use dipstick to determine exact quantity of oil required

Drives

NOTICE

Unit Of Measurement: Liters (U.S. Quarts).

Item		Specification
Drive Unit Oil Capacity (With Gear Lube Monitor)	Bravo One	2.6 (2.75)
	Bravo Two	3 (3.2)
	Bravo Three	2.9 (3)

Transmissions

IMPORTANT: It may be necessary to adjust oil levels depending on installation angle and cooling systems (heat exchanger and fluid lines).

NOTICE

Unit Of Measurement: Liters (U.S. Quarts).

Make And Model		Specification ¹	Fluid Type
Hurth	630A	3 (3-1/4)	Dexron III Automatic Transmission Fluid
	630V	4 (4-1/2)	

¹ Always use dipstick to determine exact quantity of oil required

NOTICE

For information and procedures on Troubleshooting refer to SECTION 1C.

Maintenance Schedules

NOTE: Refer to appropriate Mercury MerCruiser Sterndrive Service Manual for information and procedures on sterndrive maintenance.

**WARNING**

Avoid injury or death, product damage, fire or explosion. The electrical system is capable of violent and damaging short circuits or severe electrical shocks. When performing any activity where any electrical terminals could possibly be grounded or touched, the battery cables should be disconnected at the battery.

Maintenance Intervals

Maintenance intervals and the tasks to be performed are generally based on an average boating application and environment. However, individual operating habits and personal maintenance preferences can have an impact on the suggested intervals. In consideration of these factors, Mercury MerCruiser has adjusted some maintenance intervals and corresponding tasks. In some cases, this may allow for more tasks to be performed in a single visit to the dealer, rather than multiple visits. Therefore, it is very important that the boat owner and servicing dealer discuss the Maintenance Schedule and develop appropriate maintenance intervals to coincide with individual operating habits, the environment and maintenance requirements.

Sterndrive (MCM) Engines

Routine Maintenance *				
	Each Day Start	Each Day End	Weekly	Every Two Months
Check crankcase oil (interval can be extended based on experience).	•			
If operating in salt, brackish or polluted waters, flush cooling system after each use.		•		
Drain any water from fuel filter after each use (If operating in freezing temperatures).			•	
Check drive unit oil level, trim pump oil level and power steering pump fluid level.			•	
Check water pickups for debris or marine growth. Check water strainer and clean. Check coolant level.			•	
Inspect drive unit anodes and replace if 50 percent eroded.			•	
Check battery connections and fluid level.				•
Lubricate propeller shaft and the retorque nut (if operating in only freshwater, this maintenance may be extended to every four months).				•
Operating in Saltwater Only: treat engine surface with corrosion guard.				•
Clean air filter every 50 hours of operation.				•
Ensure that the gauges and the wiring connections are secure. Clean the gauges. ¹				•

* Only perform maintenance which applies to your particular power package.

¹ Or every 50 hours, whichever occurs first. If operating in saltwater, interval is reduced to every 25 hours or 30 days whichever occurs first

Sterndrive (MCM) Engines (Continued)

Scheduled Maintenance *

	After First 20 hours	Annu- ally	Every 100 hours or Annually ◆	Every 200 hours or 3 years ◆	Every 300 hours or 3 years ◆	Every 2 years	Every 5 years	Every 500 hours or 5 years ◆	Every 1000 hours or 5 years ◆
Change crankcase oil and filter.	•		•						
Touch-up paint power package and spray with corrosion guard.		•							
Change drive unit oil and retorque connection of gimbal ring to steering shaft.			•						
Replace fuel filter(s).			•						
Check steering system and remote control for loose, missing or damaged parts. Lubricate cables and linkages.			•						
Inspect U-joints, splines, and bellows. Check clamps. Check engine alignment. Lubricate U-joints and splines.			•						
Lubricate gimbal bearing and engine coupler ⁸			•						
Check continuity circuit for loose or damaged connections. Test MerCathode® unit output on Bravo Models.			•						
Retorque engine mounts.			•						
Check electrical system for loose, damaged or corroded fasteners.			•						

* Only perform maintenance which applies to your particular power package.

◆ Whichever Occurs First

⁸ Lubricate engine coupler every 50 hours if operated at idle for prolonged periods of time.

Sterndrive (MCM) Engines (Continued)

Scheduled Maintenance * (Continued)

	After First 20 hours	Annu- ally	Every 100 hours or Annually ◆	Every 200 hours or 3 years ◆	Every 300 hours or 3 years ◆	Every 2 years	Every 5 years	Every 500 hours or 5 years ◆	Every 1000 hours or 5 years ◆
Lubricate drive shaft U-joints and tailstock input and output bearings.			•						
Inspect condition and tension of belts.			•						
Check cooling system and exhaust system hose clamps for tightness. Inspect both systems for damage or leaks.			•						
Disassemble and inspect seawater pump and replace worn components.			•						
Clean seawater section of closed cooling system. Clean, inspect and test pressure cap. Check anodes.			•						
Replace coolant.						•			
Replace air filter.				•					
Clean aftercooler core.								•	
Clean fuel tank.									•

* Only perform maintenance which applies to your particular power package.

◆ Whichever Occurs First

Inboard (MIE) Engines

Routine Maintenance *

	Each Day Start	Each Day End	Weekly	Every Two Months
Check crankcase oil (interval can be extended based on experience).	•			
If operating in salt, brackish or polluted waters, flush cooling system after each use.		•		
Drain any water from fuel filter after each use (if operating in freezing temperatures).			•	
Check transmission fluid.			•	
Check water pickups for debris or marine growth. Check water strainer and clean. Check coolant level.			•	
Check battery connections and fluid level.				•
Clean air filter every 50 hours of operation.				•
Operating in Saltwater Only: treat engine surface with corrosion guard.				•
Ensure that the gauges and the wiring connections are secure. Clean the gauges. ¹				•

* Only perform maintenance which applies to your particular power package.

¹ Or every 50 hours, whichever occurs first. If operating in saltwater, interval is reduced to every 25 hours or 30 days whichever occurs first

Inboard (MIE) Engines (Continued)


Scheduled Maintenance *								
	After First 20 hours	Annu- ally	Every 100 hours or Annually ◆	Every 200 hours or 3 years ◆	Every 2 years	Every 500 hours or 5 years ◆	Every 1000 hours or 5 years ◆	Per OEM
Change crankcase oil and filter.	•		•					
Touch-up paint power package and spray with corrosion guard.		•						
Change transmission fluid.			•					
Replace fuel filter(s).			•					
Check steering system and remote control for loose, missing or damaged parts. Lubricate cables and linkages.			•					
Retorque engine mounts.			•					
Check electrical system for loose, damaged or corroded fasteners.			•					
Inspect condition and tension of belts.			•					
Check cooling system and exhaust system hose clamps for tightness. Inspect both systems for damage or leaks.			•					
Disassemble and inspect seawater pump and replace worn components.			•					
Clean seawater section of closed cooling system. Clean, inspect and test pressure cap. Check anodes on diesel models.			•					
Replace coolant.					•			
Replace air filter.				•				
Clean aftercooler core.						•		
Clean fuel tank.							•	
Check engine-to-propeller shaft alignment.								•

* Only perform maintenance which applies to your particular power package.

◆ Whichever Occurs First

Engine External Views

Starboard Side View




78409

Typical In-Line D-Tronic Diesel

- 1** - Exhaust Riser, or Elbow If Equipped
- 2** - Intercooler Air Duct
- 3** - Fluid Cooler
- 4** - Shift Plate
- 5** - Intercooler
- 6** - Sacrificial Anode
- 7** - Power Steering Fluid Reservoir
- 8** - Thermostat Housing
- 9** - Heat Exchanger
- 10** - Engine Oil Cooler
- 11** - Power Steering Pump
- 12** - Front Engine Mount
- 13** - Oil Pan
- 14** - Starter Motor
- 15** - Wastegate

Front View




78310

Typical In-Line D-Tronic Diesel

- 1** - Sacrificial Anode
- 2** - Pressure Cap
- 3** - Heat Exchanger
- 4** - Engine Oil Cooler
- 5** - Seawater Pump Outlet Hose
- 6** - Alternator
- 7** - Seawater Pump Inlet Hose
- 8** - Seawater Pump
- 9** - Oil Pan
- 10** - Crankshaft Pulley
- 11** - Engine Water Circulating Pump Pulley
- 12** - Power Steering Pump
- 13** - Front Engine Mount
- 14** - Oil Thermostat
- 15** - Oil Filter
- 16** - Exhaust Elbow

Port Side View




75298

Typical In-Line D-Tronic Diesel

- 1** - Oil Fill Cap
- 2** - Engine Cover
- 3** - Fuel Injector
- 4** - Fuel Filter
- 5** - Gear Lube Monitor
- 6** - PCV / Oil Separator
- 7** - Air Filter
- 8** - MerCathode Controller
- 9** - Rear Engine Mount
- 10** - Flywheel Housing (Rear Portion)
- 11** - 5 Amp. ECM Fuse
- 12** - Electrical Box
- 13** - Engine Block Ground Stud
- 14** - Fuel Delivery Pump
- 15** - Oil Pan
- 16** - Engine Control Module (ECM)
- 17** - Throttle Position Sensor
- 18** - Vibration Damper And Crankshaft Pulley
- 19** - Seawater Pump
- 20** - Heat Exchanger

Rear View



74305

Typical In-Line D-Tronic Diesel

- 1** - Air Filter
- 2** - Turbocharger
- 3** - Exhaust Elbow
- 4** - Rear Engine Mount
- 5** - Engine Coupler
- 6** - Flywheel Housing (Rear Portion)
- 7** - Electrical Box

Engine Oil

⚠ CAUTION

ENVIRONMENTAL HAZARD! Discharge of oil or oil waste into the environment is restricted by law. Do NOT spill oil or oil waste into the environment when using or servicing your boat. Contain and dispose of oil or oil waste as defined by local authorities.

To help obtain optimum engine performance and to provide maximum protection, the engine requires engine oil with a rating of HD-SAE-API CG-4 and CH-4.

We strongly recommend the use of:

MERCURY DIESEL ENGINE OIL	QUICKSILVER HEAVY DUTY ENGINE OIL
---------------------------	-----------------------------------

These oils are both specially blended 15W-40 oil with Marine Additives, for all temperature operation. They both exceed requirements for API CH-4, CF-4, CG-4 and CF-2 oils.

Other recommended oils:

SHELL MYRINA	TEXACO URSA SUPER TD	VEEDOL TURBOSTAR
MOPAR	WINTERSHALL MULTI-REKORD	WINTERSHALL VIVA 1

These oils are approved by Mercury Marine and Marine Power Europe. For all temperature operation use 15W-40 oil.

Oil Level

OVERFILLED ENGINE CRANKCASE

An overfilled crankcase can cause a fluctuation or drop in oil pressure on Mercury MerCruiser engines. The over-full condition results in the engine crankshaft splashing and agitating the oil, causing it to become aerated. The aerated oil causes a loss of engine performance and an increase in crankcase backpressure. An extreme overfill condition could result in large amounts of oil being drawn into the intake.

Care must be taken when checking engine oil level. Oil level must be maintained between the minimum oil level mark and the maximum mark on the dipstick. To ensure that you are not getting a false reading, observe the following before checking the oil level.

- Boat at rest in the water, or if boat is on a trailer, raise or lower bow until the boat is setting like it does at rest in the water.
- Allow ten minutes for oil to drain into the oil pan if engine has just been operated or oil has just been added.

CHECKING / FILLING

IMPORTANT: Engine crankcase oil must be checked at intervals specified in Maintenance Schedule. It is normal for an engine to use a certain amount of oil in the process of lubricating and cooling the engine. The amount of oil consumed is greatly dependent upon engine speed, with consumption being highest at WOT and decreasing substantially as engine speed is reduced.


5. Check engine oil daily before first start-up.

⚠ CAUTION


Avoid possible injury, or damage to oil dipstick and internal engine components. Do NOT remove crankcase oil dipstick when engine is running. Stop the engine completely before removing or inserting dipstick.

If it becomes necessary to check oil level during operation, stop the engine and allow approximately 10 minutes for oil to drain into pan.

6. Remove oil dipstick. Wipe clean and install into dipstick tube.
7. Remove dipstick and observe oil level. Oil must be between marks on dipstick.



8. If oil level is low, remove oil filler cap. Add specified oil to bring level up to, but not over, maximum oil level mark on dipstick.




a - Oil Filler Cap

9. Install oil filler cap.

Changing Engine Oil and Oil Filter

IMPORTANT: Change oil when engine is warm from operation. Warm oil flows more freely, carrying away more impurities. Use only recommended engine oil (see Specifications).

1. Start engine and allow it to reach normal operating temperature.
2. Stop the engine and allow approximately 10 minutes for oil to drain into oil pan.
3. Remove threaded fitting from crankcase oil drain hose.
4. Install crankcase oil pump (90265A2) onto threaded fitting of oil drain hose.




- a** - Oil Drain Hose
- b** - Threaded Fitting
- c** - Crankcase Oil Pump

5. Pump oil out of crankcase into drain pan.
6. Remove crankcase oil pump.
7. Install threaded fitting on crankcase oil drain hose.

75298

8. Remove and discard oil filter and seal.
9. Coat seal on new filter with engine oil and install filter. Hand tighten only, do NOT use a filter wrench.



75297

a - Oil Filter
b - Seal

10. Remove oil fill cap and refill engine with new engine oil.

⚠ CAUTION

Do NOT overfill the engine with oil. Too much engine oil will cause a loss of engine performance and an increase in crankcase back-pressure.

11. Add specified oil to bring level up to, but not over, maximum oil level mark on dipstick.
12. Install oil filler cap.
13. Supply cooling water to water inlet.
14. Start the engine and allow it to reach normal operating temperature.

IMPORTANT: Always use dipstick to determine how much oil is required.

⚠ CAUTION

Avoid possible injury or damage to oil dipstick and internal engine components. Do NOT remove crankcase oil dipstick when engine is running. Stop the engine completely before removing or inserting dipstick.

15. Stop engine and allow approximately 10 minutes for oil to drain into oil pan.
16. Remove dipstick and observe oil level. Oil must be between the marks on the dipstick.
17. Start engine and check for leaks.

Fuel

Precautions

WARNING

Always disconnect battery cables from battery BEFORE working on fuel system to prevent fire. This eliminates the engine wiring as a potential source of ignition.

WARNING

FIRE HAZARD: Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death. Careful periodic inspection of entire fuel system is mandatory, particularly after storage. All fuel components including fuel tanks - whether plastic, metal or fiberglass - fuel lines, primers, fittings and fuel filters should be inspected for leaks, softening, hardening, swelling or corrosion. Any sign of leakage or deterioration requires replacement before further engine operation.

WARNING

Electrical system components on this engine are not external ignition protected. **DO NOT STORE OR UTILIZE GASOLINE ON BOATS EQUIPPED WITH THESE ENGINES, UNLESS PROVISIONS HAVE BEEN MADE TO EXCLUDE GASOLINE VAPORS FROM ENGINE COMPARTMENT (REF: 33 CFR).** Failure to comply could result in fire, explosion and/or severe personal injury.

IMPORTANT: Use of improper or water contaminated diesel fuel can cause serious engine damage. Use of improper fuel is considered misuse of engine, damage caused thereby will not be covered by warranty.

WARNING

Under *no circumstances* should gasoline, gasohol and/or alcohol be mixed with diesel fuel for any reason. This mixture of gasoline, gasohol and/or alcohol with diesel fuel is highly flammable and produces a significant risk to the user.

General Information

Grade 2-D diesel fuel is required, meeting ASTM Standards D975 (or fuel rated Diesel DIN 51601) and having a minimum cetane rating of 45.

The cetane number is a measure of the ignition quality of diesel fuel. Increasing the cetane number will not improve overall engine performance, but it may be necessary to raise the cetane rating for low temperature or high altitude use. A lower cetane number could cause hard starting and slower warm-up and could increase engine noise and exhaust emissions.

NOTE: *If your engine suddenly becomes noisy after a fuel fill, you may have received substandard fuel with a low cetane rating.*

CAUTION

Avoid fuel system damage. Use of fuels not recommended by Mercury MerCruiser may cause hard-starting and other various troubles such as premature wear of the injection pump plungers and injection nozzles resulting from the deposit of carbon residue and other contaminants.

Sulphur content of the above fuel is rated at 0.50% by weight, maximum (ASTM). Limits may vary in countries outside of the United States.

On intermittent use engines, high sulphur content diesel fuel will greatly increase:

- Corrosion on metal parts.
- Deterioration of elastomer and plastic parts.
- Corrosion and extensive damage, and excessive wear of internal engine parts, particularly bearings.
- Starting and operating difficulties.

Diesel Fuel In Cold Weather

Unaltered diesel fuels thicken and gel in cold temperatures unless treated. Virtually all diesel fuels are climatized to allow their use in the particular region for that time of the year. It is the owner/operator's responsibility, if it becomes necessary, to further treat diesel fuel, by adding a commercial standard brand anti-gel diesel fuel additive. Follow product directions.

Fuel Filter

PRECAUTIONS

WARNING

Be careful when draining, filling or replacing water separating fuel filter; diesel fuel is flammable. Ensure that the ignition key is OFF. Do NOT smoke or allow sources of open flame in the area while changing fuel system components. Wipe up any spilled fuel immediately. Do NOT allow fuel to come into contact with any hot surface which may cause it to ignite.

WARNING

Dispose of fuel-soaked rags, paper, etc., in an appropriate air tight, fire retardant container. Fuel-soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

WARNING

Make sure no fuel leaks exist before closing engine hatch.

CAUTION

Absolute cleanliness is required for work on the fuel injection system, since the injection pump and fuel injectors have very close tolerances. Even minute particles of dirt or small amounts of water can impair the function of the fuel injection system.

DRAINING

NOTICE


Refer to Precautions BEFORE proceeding.

The filter can be drained of water and small dirt particles by opening the water drain cap (bleed valve).

IMPORTANT: To ensure complete draining, in warm weather, open the drain cock before starting daily operations. In cold weather, when there is a possibility that the condensed water will freeze, drain the filter shortly after the end of daily operations.

NOTE: Place a suitable container under fuel filter to catch contaminated fuel and/or water

1. Using a suitable container to catch contaminated fuel and/or water, open drain cap at bottom of filter by turning the drain counterclockwise (as viewed from the bottom of the filter).
2. Drain until fuel is clear in appearance.



74726

a - Fuel Filter

b - Drain Cap

3. Close drain by turning clockwise.
4. Fill fuel filter as outlined in Filling.

FILLING


NOTICE

Refer to Precautions BEFORE proceeding.

Follow this procedure after installing a new filter or if fuel has been completely drained from the filter checking for water.

NOTE: Place a suitable container under fuel filter to catch contaminated fuel and/or water

1. Loosen bleed screw on fuel filter bracket.
2. Move plunger knob on pump/primer up and down repeatedly, until an air free stream of fuel flows from bleed screw. Filter is full when this occurs.



75301

a - Plunger Knob
b - Bleed Screw

3. Securely tighten bleed screw.
4. Supply cooling water to water inlet.
5. Start the engine, check for fuel leaks. If leaks exist stop engine immediately. Recheck filter installation.


REMOVAL

NOTICE

Refer to Precautions BEFORE proceeding.

NOTE: Place a suitable container under fuel filter to catch contaminated fuel and/or water

1. Twist locking ring by hand. Remove water separating fuel filter and sealing ring from mounting bracket. Do NOT use a filter wrench.



75579

a - Locking Ring


b - Filter Element

IMPORTANT: Element cannot be cleaned and reused. It must be replaced.

2. Remove the drain cap and O-ring from bottom of the existing filter. Note position of O-ring seal.
3. Inspect and replace damaged components.

INSTALLATION


1. Install O-ring and drain cap on new filter.



70160

- a** - O-ring Seal
b - Drain Cap

2. Lubricate seal with clean engine oil.
3. Align filter to bracket. Twist locking ring by hand to secure filter to bracket. Do NOT use a filter wrench.



74731

- a** - Filter Header
b - Locking Ring
c - Seal
d - Fuel Filter

4. Fill fuel filter as previously outlined.

Closed Cooling System

Coolant Requirement

CAUTION

Alcohol or methanol based anti-freeze or plain water are not recommended for use in the closed cooling section of cooling system at any time.

Because diesel engines are high compression engines and related higher engine operating temperatures are created, the closed cooling system and engine must remain as clean as possible to provide adequate engine cooling. This can only be assured by using the proper anti-freeze, water, additives and inhibitors. It is recommended that the closed cooling section of the cooling system be filled with a low silicate formula of ethylene glycol anti-freeze in solution with deionized water. A low silicate formula prevents anti-freeze separation, which causes a silicate gelatin to form. This gelatin will block engine and heat exchanger passages causing engine overheating.

The coolant, if not premixed, should be mixed before being added to the closed cooling system using anti-freeze and deionized water. Common tap water or softened water contains unwanted minerals, which can leave large deposits in the system restricting the cooling system efficiency. In addition, additives and inhibitors introduced into acceptable coolant solutions will form a protective film on internal passages and provide protection against internal cooling system erosion.

The closed cooling section should be kept filled year-round with an acceptable coolant solution. Do NOT drain closed cooling section for storage, this will promote rusting of internal surfaces. If engine will be exposed to freezing temperatures, ensure that closed cooled section is filled with a properly mixed anti-freeze/coolant solution to protect engine and closed cooling system to lowest temperature to which they will be exposed.


IMPORTANT: The anti-freeze/coolant used in these marine engines must be a low silicate ethylene glycol, containing special additives and deionized, purified water. Using other types of engine coolant may cause fouling of the heat exchangers and overheating of the engine. Do NOT combine different types of coolants without knowing that they are compatible. Refer to the coolant manufacturer's instructions.

Some acceptable types of anti-freeze/coolants are listed in the following table. Refer to Maintenance Schedules for change intervals.

Description	Part Number
Premixed Marine Engine Coolant	92-813054A2
Fleetguard Compleat (Product 91-50663 with DCA4 additive)	Obtain Locally

Checking Level

1. Coolant level must be between the bottom ADD mark and top FULL Hot mark on coolant recovery bottle with the engine at normal operating temperature.



72520


- a** - Coolant Recovery Reservoir
- b** - Bottom ADD Mark
- c** - Top FULL Hot Mark

2. Add specified coolant to the coolant recovery bottle as required.

⚠ WARNING

Allow engine to cool before removing pressure cap. Sudden loss of pressure could cause hot coolant to boil and discharge violently causing severe injury.

3. Remove pressure cap.
4. Coolant level must be to the bottom edge of the fill neck with the engine cool.



75299

- a** - Fill Neck

5. If coolant is low, check the coolant system for malfunction.

IMPORTANT: When installing pressure cap, tighten it until it contacts locking tabs on filler neck.

6. Install pressure cap.

Draining

NOTICE

For instructions on Draining Seawater Section refer to Cold Weather or Extended Storage in this SECTION 1B.

IMPORTANT: Observe the following:

- Insert a wire into drain holes to ensure that foreign material is not obstructing the drain holes.
- Ensure engine is as level as possible to promote complete draining of cooling system.
- Closed cooled section must be kept filled year round with recommended coolant. If engine will be exposed to freezing temperatures, make sure closed cooled section is filled with an ethylene glycol anti-freeze and water solution properly mixed to protect engine to lowest temperature to which it will be exposed.
- Do NOT use Propylene Glycol anti-freeze in the closed cooled section of the engine.


⚠ WARNING

Allow engine to cool before removing pressure cap. Sudden loss of pressure could cause hot coolant to boil and discharge violently causing severe injury.

1. Allow engine to cool. After engine has cooled, turn cap 1/4 turn to allow any pressure to escape slowly, then push down and turn cap all the way off of heat exchanger/coolant tank.

NOTE: Drain coolant into a suitable container. Dispose of old coolant properly.


2. Drain coolant from intake/exhaust manifold by opening the drain valves.



Typical

a - Intake/Exhaust Manifold Drain Valve

3. –Drain coolant from the engine block by opening the drain valve.

**Typical**

a - Engine Block Drain Valve

4. After coolant has drained completely, securely close drain valves.
5. Empty the coolant recovery bottle.
6. If required, clean the closed cooled system. Refer to SECTION 6A.
7. Fill system with required coolant, as outlined in Filling.

Filling

1. Slowly fill with coolant through heat exchanger fill neck.
2. Continue filling until coolant level is at bottom of fill neck.

CAUTION

Overheating from insufficient cooling water will cause engine and drive system damage. Ensure that there is sufficient water always available at water inlet during operation.

3. Supply cooling water to water inlet.
4. With the pressure cap off, start the engine and run at fast idle (1500-1800 rpm). Add coolant to heat exchanger, as required, to maintain coolant level 1 in. (25 mm) below fill neck.
5. After engine has reached normal operating temperature (thermostats are fully open), and coolant level remains constant, fill heat exchanger to bottom of fill neck.
6. Install pressure cap.
7. Observe engine temperature gauge to make sure that engine operating temperature is normal. If gauge indicates excessive temperature, stop engine immediately and examine for cause.
8. Remove cap from coolant recovery bottle and fill to a level between the ADD and FULL marks with coolant solution. Reinstall cap.
9. With engine still operating, check hose connections, fittings and gaskets for leaks.



Sacrificial Anodes

Sacrificial anode locations:

- Starboard, aft-side of the heat exchanger.
- Top of the intercooler end cover.

Removal


1. Allow the engine to cool.
2. Remove anode plugs and sacrificial anodes.



- a** - Heat Exchanger
- b** - Intercooler End Cover
- c** - Anode Plug And Sacrificial Anode

Inspection

1. Replace anode assembly when deteriorated 50%.
 - Length When New - 19 mm (3/4 in.)
 - Diameter When New - 16 mm (5/8 in.)
2. Discard sealing washer.




- a** - Anode Plug
- b** - Sacrificial Anode
- c** - Length
- d** - Diameter
- e** - Sealing Washer

Disassembly

NOTE: Sacrificial anodes are available as an assembly. Replace both the plug and anode, if so desired.

1. Unscrew sacrificial anode from anode plug by holding plug hex head and turning anode.




71367

- a** - Plug
b - Anode

Reassembly

1. Clean interior threads of anode plug.
2. Apply Loctite Pipe Sealant with Teflon to threads of new sacrificial anode and install into anode plug. Tighten securely.




71367

- a** - Plug
b - Anode

Installation

1. Install new sealing washer.
2. Install anode plug, with sacrificial anode and washer into heat exchanger or intercooler end cover. Tighten securely.



71368

- a** - Plug And Anode
b - Sealing Washer

3. Fill closed cooled system with required coolant, as outlined in Filling.

Flushing Seawater System


If engine is operated in salty, polluted or mineral-laden water, flush seawater section of cooling system (preferably after each use) to reduce corrosion and prevent the accumulation of deposits in the system. Thoroughly flush seawater section prior to storage.

SternDrive (MCM) Models

⚠ WARNING

When flushing, be certain the area around propeller is clear and no one is standing nearby. To avoid possible injury, remove propeller.

1. Install Flushing Attachment (or equivalent) over water pickup openings in gear housing.
2. Attach a hose between the flushing attachment and a water source.



72012

- a** - Flushing Attachment
b - Hose

3. Lower sterndrive unit to full DOWN/IN position.

⚠ CAUTION

Do NOT run engine above 1500 rpm when flushing. Suction created by seawater pickup pump may collapse flushing hose, causing engine to overheat.

4. Partially open water tap (approximately 1/2 maximum capacity). DO NOT use full water pressure.
5. Place remote control in NEUTRAL, IDLE speed position and start engine.
6. Operate engine at IDLE speed in NEUTRAL for 10 minutes, then stop engine.
7. Shut off water tap.
8. If boat is in the water, raise sterndrive unit to TRAILER position.
9. Remove hose and flushing attachment.

Inboard (MIE) Models


⚠ WARNING

When flushing, be certain the area around propeller is clear, and no one is standing nearby. To avoid possible injury, remove propeller.

⚠ CAUTION

If boat is in the water, seacock (water inlet valve), if equipped, must be closed until engine is to be re-started, to prevent water from flowing into the boat and/or back into the cooling system. If boat is not fitted with a seacock, water inlet hose must be disconnected and plugged (to prevent water from flowing into the boat and/or back into the cooling system). As a precautionary measure, attach a tag to the ignition switch or steering wheel of the boat with the warning: Open seacock or reconnect water inlet hose before starting engine.

1. If the boat is in the water, close the seacock, if equipped, or plug the seawater inlet hose to prevent seawater from entering the boat.
2. Disconnect the seawater inlet hose from the seawater pump connector fitting.




75299

Typical

- a** - Inlet Hose
- b** - Connector Fitting

3. Using an adapter, connect a hose between the water inlet hose or connector fitting and a water tap.



- a** - Inlet Hose
- b** - Adapter
- c** - Hose To Water Tap

75299

4. Partially open the water tap, approximately 1/2 maximum capacity. Do NOT use full water pressure.
5. Place the remote control in NEUTRAL, IDLE speed position, and start the engine.

⚠ CAUTION

Do NOT run engine above 1500 rpm when flushing. Suction created by seawater pickup pump may collapse flushing hose, causing engine to overheat.

6. Operate the engine at IDLE speed in NEUTRAL for 10 minutes, or until discharge water is clear.
7. Stop the engine.
8. Shut off the water tap.
9. Remove the hose and the adapter from the seawater pump connector fitting.

⚠ CAUTION


If boat is in the water, the seacock (water inlet valve), if equipped, must remain closed until engine is to be re-started, to prevent water from flowing back into the cooling system and/or the boat. If the boat is not fitted with a seacock, the water inlet hose must be disconnected and plugged (to prevent water from flowing back into cooling system and/or boat). As a precautionary measure, attach a tag to the ignition switch or steering wheel of the boat with the warning: Open seacock or reconnect water inlet hose before starting engine.

10. Reconnect the water inlet hose.

Inspect Water Pickups

SternDrive Gear Housing

1. Ensure that the gear housing water inlet holes are clean and not obstructed.




73186

Typical

a - Water Inlet Holes

Inboard Through the Hull Pickup

1. Ensure that the seawater pickup water inlet holes (slots) are clean and not obstructed.



70355


Typical

a - Water Inlet Holes (Slots)

Lubrication

Throttle Cable

1. Lubricate pivot points and guide contact surfaces with SAE 30W engine oil.




75332

Single Cable Shown (Dual Similar)

- a** - Pivot Points
- b** - Guide Contact Surfaces

Shift Cable


1. Lubricate pivot points and guide contact surfaces with SAE 30W engine oil.



22245

Typical Sterndrive Model Shift Cable

- a** - Pivot Points
- b** - Guide Contact Surface



73587


Typical Inboard Model Shift Cable and Transmission Linkage

Engine Coupler / U-joint Shaft Splines

NOTE: Refer to the appropriate Mercury MerCruiser Sterndrive Service Manual for sterndrive unit removal and installation, if necessary.

IMPORTANT: These engines are equipped with a sealed engine coupler. The sealed coupler and the shaft splines can be lubricated without removing the sterndrive unit.

1. Lubricate the engine coupler splines through the grease fittings on the coupler by applying approximately 8-10 pumps of Engine Coupler Spline Grease from a typical hand-operated grease gun. If the boat is operated at idle for prolonged periods of time, the coupler should be lubricated on **Bravo Models** - every 50 hours.



73346


Bravo Drive Couplers

a - Grease Fitting

U-joints

NOTE: Bravo Models - The crosses and the bearings on the sterndrive U-joint will need to be lubricated through the grease fittings. The sterndrive unit must be removed to grease these fittings.

1. Remove the sterndrive unit; refer to the appropriate Mercury MerCruiser Sterndrive Service Manual for sterndrive unit removal and installation.
2. Apply U-joint And Gimbal Bearing Grease (Except on Bravo X Drives - use Exxon Unirex EP2 Grease [Obtain Locally]) from a typical hand-operated grease gun until a small amount of grease begins to push out.
3. Lubricate the U-joint shaft splines using Engine Coupler Spline Grease.




72531

Typical Bravo Drive


- a** - Coupler Splines
- b** - Grease Fitting

Drive Shaft Extension Models

1. Apply 3-4 pumps of U-joint And Gimbal Bearing Grease to drive shaft grease fittings.




- a** - Transom End Fittings
b - Engine End Fittings



71347

Sterndrive Unit and Transom Assembly

1. Apply approximately 8-10 pumps of U-joint And Gimbal Bearing Grease to the gimbal bearing.




- a** - Gimbal Bearing
b - Hinge Pins

70558

Continuity Circuit


The transom assembly and the sterndrive unit are equipped with ground circuit wires to ensure good electrical continuity between the engine, the transom assembly and the sterndrive components. Good continuity is essential for the Anode and the MerCathode System to function most effectively.

1. Inspect the following ground circuit components for loose connections, broken or fraying wires.




22028

a - Steering Lever Ground Wire




22650



77079

a - Inner Transom Plate To Gimbal Housing Ground Wire

b - Driveshaft Housing To Gear Housing Ground Plate (Inside Anode Cavity)




77100

a - Gimbal Housing To Gimbal Ring Ground Wire


b - Gimbal Ring To Trim Cylinder Ground Wires

Continuity Circuit (continued)




22028

- a** - Flywheel Housing Grounding Stud
- b** - Ground Wire
- c** - Inner Transom Plate Grounding Screw




22755




22031

- a** - Gimbal Ring To Bell Housing Ground Wire
- b** - Sterndrive Unit To Bell Housing Ground Plate




70575




22230

- a** - Driveshaft Housing To Gear Housing Anodic Plate
- b** - Hydraulic Connector Block To Gimbal Housing Ground Washer



50383



22079

- a** - U-joint Bellows Ground Clip
- b** - Exhaust Bellows Ground Clips

MerCathode

If the boat is equipped with a Quicksilver MerCathode System, the system should be tested to ensure that it is providing adequate output to protect the underwater metal parts on the boat. The test should be made where the boat is moored, using Quicksilver Reference Electrode and Test Meter.

Refer to the appropriate Mercury MerCruiser Sterndrive Service Manual for testing procedures.

Engine Mounts

1. Torque the rear engine mounts to 51 Nm (38 lb-ft). Refer to SECTION 2.

Electrical System

NOTE: Refer to SECTION 4 for specific procedures.

Inspect the entire electrical system for loose, damaged or corroded fasteners.


Power Steering

Checking Fluid Level

IMPORTANT: Use only Power Trim and Steering Fluid or automatic transmission fluid (ATF) Dexron III in power steering system.

ENGINE WARM

1. Stop engine and center the sterndrive unit.
2. Remove the dipstick from the power steering fluid reservoir and observe the fluid level.
3. The fluid level should be between the full hot mark and the full cold mark on dipstick.




- a** - Dipstick
- b** - Fluid Reservoir
- c** - Full Hot Mark
- d** - Full Cold Mark

4. If the fluid level is below marks, but fluid is visible in reservoir, add fluid to bring the level up to the full hot mark on the dipstick. Do NOT overfill.
5. If fluid is not visible in reservoir, a leak exists in the power steering system. Find and correct the cause.

ENGINE COLD

1. With engine stopped, center sterndrive unit.
2. Remove dipstick from power steering fluid reservoir and observe fluid level.
3. The level should be between the full cold mark and the bottom of the dipstick.



73326

- a** - Dipstick
- b** - Fluid Reservoir
- c** - Full Cold Mark
- d** - Bottom Of Dipstick

4. If the fluid level is below the bottom of dipstick, but fluid is still visible in the reservoir, add required amount of fluid to bring level up to full cold mark on dipstick. DO NOT overfill.
5. If fluid is not visible in the reservoir, a leak exists in the power steering system. Find and correct the cause.

Filling and Bleeding

1. With engine stopped, center sterndrive unit.
2. Remove dipstick from power steering reservoir.

IMPORTANT: Use only Power Trim and Steering Fluid or Dexron III automatic transmission fluid (ATF) in power steering system.

3. Add fluid to bring the fluid level up to full cold mark on dipstick.

IMPORTANT: All air must be removed from the system or fluid in pump may foam during operation and be discharged from pump reservoir. Foamy fluid also may cause power steering system to become spongy, which may result in poor boat control.

4. With engine stopped, turn the steering wheel at a moderate rate, to end of travel in each direction, pausing a few seconds at end of travel. Do this a minimum of 5 complete cycles, then recheck fluid level and add fluid, if necessary.
5. Install dipstick.
6. Supply cooling water to water inlet.
7. Start engine and operate at IDLE until engine reaches normal operating temperature. During this time, slowly turn steering wheel to end of travel in each direction several times.

IMPORTANT: Sterndrive unit must be centered and power steering fluid must be hot to accurately check fluid level.

8. With engine stopped, center sterndrive unit. Remove dipstick fluid reservoir. Allow any foam in reservoir to disperse, then check fluid level. Do NOT overfill.
9. If fluid is still foamy in Step 8., repeat Steps 6. and 7. until fluid does not foam and level remains constant.
10. Install dipstick.

Transmission

Checking Fluid Level


IMPORTANT: To accurately check fluid level, the engine must be operated at 1500 rpm for 2 minutes immediately prior to checking level.

1. Start engine and run at 1500 rpm for 2 minutes to fill all circuits, lines, and cooler.

2. **For Hurth Transmissions -**

IMPORTANT: Do NOT screw dipstick in; press it firmly in and remove to obtain an accurate reading.

- a. Stop the engine and quickly remove the dipstick to check level.
- b. If fluid is below top (full) line, add Dexron III Automatic Transmission Fluid through dipstick hole. Do NOT overfill.
- c. If fluid level is below minimum fluid level line, check transmission case, cooler, and hoses for leaks.



71383

- a** - Full Fluid Level Line
b - Minimum Fluid Level Line

- d. Install dipstick securely.

IMPORTANT: Use automatic transmission fluid (ATF) Dexron III.


Power Trim

Checking Fluid Level


1. Place sterndrive unit in full DOWN/IN position.

IMPORTANT: Some trim pump reservoir fill caps have a small vent hole. Occasionally ensure vent is not restricted.

2. Unscrew reservoir cap.
3. Remove and discard cap plug if present.




4. Observe oil level. Level must be up to, but not over, bottom edge of reservoir fill neck.



Filling

1. Add Power Trim and Steering Fluid or SAE 10W-30 engine oil to bring oil to proper level.
2. Install reservoir cap.



77348

- a** - Reservoir Fill Neck
b - Reservoir Cap

Gear Lube Monitor

Checking Fluid Level


NOTE: Fluid level in gear lube monitor will fluctuate during operation. Level should be checked with engine cold.

1. Check for water at bottom of monitor, or milky-tan appearance. Both conditions indicate a water leak somewhere in the sterndrive unit. Find and correct the cause.
2. Check gear lube monitor oil level. Keep oil level at or near "OPERATING RANGE (FULL)" line and never below the "ADD" line.

Filling

1. Remove cap.
2. Add High Performance Gear Lube to gear lube monitor as needed.

IMPORTANT: If more than 57 grams (2 oz.) of High Performance Gear Lube are required to fill drive unit, a seal may be leaking. Damage to the unit may occur due to a lack of lubrication.



Gear Lube Monitor

- a - Monitor Bottle
- b - Cap
- c - OPERATING RANGE (FULL) Line
- d - ADD Line

Seawater Strainer

1. Visually inspect seawater strainer through glass top.


⚠ CAUTION

When cleaning seawater strainer, close seacock, if equipped. If boat is not equipped with a seacock, remove and plug seawater inlet hose to prevent a siphoning action that may occur, allowing seawater to flow from the drain holes or removed hoses.

⚠ CAUTION

Do NOT overtighten cover screws or cover will warp and leak.

2. With engine off, close seacock (if equipped) or remove and plug seawater inlet hose if no seacock exists.
3. Remove screws, washers, and cover.
4. Remove strainer, drain plug and washer.
5. Clean all debris from strainer housing; flush both strainer and housing with clean water.
6. Check gasket and replace when necessary (if it leaks).
7. Reinstall strainer, drain plug and washer.
8. Reattach cover with screws and washers.
9. After starting engine, check for leaks and/or air in system, which would indicate an external leak.




- a** - Screws and Washers
- b** - Cover, with glass
- c** - Strainer
- d** - Housing
- e** - Drain Plug and Sealing Washer Gasket

78157

Air Filter

Removal

1. Disconnect crankcase vent hose from end of air intake screen housing mounted on turbocharger inlet.




73323

Typical

- a** - Intake Screen Housing
- b** - Crankcase Vent Hose

2. Carefully remove air cleaner foam element from around air intake screen housing.



71267

- a** - Screen Housing
- b** - Air Cleaner Element

Inspection

1. Inspect the air cleaner element for tears or holes.
2. Replace the air cleaner element according to maintenance schedules or if it is deteriorated or torn.

IMPORTANT: Refer to Maintenance Schedules for replacement interval under normal conditions.

Cleaning

1. Wash air cleaner element in warm water and detergent until clean.

IMPORTANT: No treatment (such as partial oil saturation) is required or recommended on air cleaner foam element prior to use. Use element clean and dry for proper filtration.

2. Allow air cleaner element to completely dry before use.

Installation

1. Install air cleaner element around air intake screen.
2. Connect crankcase vent hose to end of intake screen housing. Tighten hose clamp securely.

IMPORTANT: To prevent unfiltered air from entering the engine be certain that all of the air intake screen is covered by the foam element when installed.

3. Inspect installation to ensure engine draws in filtered air only.

Drive Belts

General Information

Belt and pulley replacement guidelines:


- During belt assembly, do NOT force belt into pulley grooves by prying with a screwdriver, pry bar or similar. This will damage belt side cords, which will cause belt to turn over in pulley grooves, and result in complete destruction of belt.
- Do NOT use belt dressing.
- Always check condition of remaining belts. Replace belt if worn, cracked, grease-soaked or oil-soaked.
- When replacing belt and pulley, pulley alignment must be checked under tensioned condition (brackets securely clamped). A misalignment that can be detected by visual inspection is detrimental to belt performance.
- Except for belts controlled by an automatic tensioner, if a belt is disturbed for any reason, it must be tensioned to the correct tension.
- Replace pulleys if worn or clean if still suitable for service.
- On some engines it may be necessary to remove other drive belts to gain access to a particular belt during replacement. Refer to appropriate sections for information concerning individual drive belts and proceed accordingly.

Inspection

WARNING

Avoid possible serious injury. Ensure engine is shut off and ignition key is removed before inspecting belts.

1. Visually inspect all drive belts for cracks, glazing, fraying or separation.
2. Check drive belts for proper tension by pressing midpoint between the pulleys on the longest belt span. Belts must not deflect more than 5 mm (3/16 in.).



73190

71588

Typical

a - Drive Belts

b - Deflection Measurement

Engine Water Circulating Pump Belt

Refer to Alternator Belt instructions.


Alternator Belt

NOTE: On some engines it may be necessary to remove other drive belts to gain access to a particular belt during replacement. Refer to appropriate sections for information concerning individual drive belts and proceed accordingly.

⚠ CAUTION

Before removing the seawater pump hoses, close the seacock, if equipped. If boat is not equipped with a seacock, remove and plug the seawater inlet hose to prevent a siphoning action that may occur, allowing seawater to enter the boat.

1. Close the seacock, if equipped. If boat is not equipped with a seacock, remove and plug the seawater inlet hose.
2. Remove seawater pump inlet and outlet hoses.




78310

Typical

- a** - Inlet Hose
- b** - Outlet Hose

3. Loosen alternator mounting and tensioning bolts.
4. Pivot the alternator to loosen belt.
5. Remove old belt.
6. Install new belt.

7. Pivot the alternator. Adjust belt deflection to be 5 mm (3/16 in.) measured at midpoint between the pulleys on the longest belt span.
8. Torque tensioning and mounting bolts 28 Nm (21 lb-ft).

**Typical**


- a** - Deflection: 5 mm (3/16 in.)
- b** - Tensioning Bolt
- c** - Mounting Bolt

9. Install the seawater pump inlet and outlet hoses.
10. Open the seacock, if equipped. If boat is not equipped with a seacock, remove the plug and connect the seawater inlet hose.

Power Steering Pump Belt

NOTE: On some engines it may be necessary to remove other drive belts to gain access to a particular belt during replacement. Refer to appropriate sections for information concerning individual drive belts and proceed accordingly.

1. Loosen the two mounting bolts and the tensioning bolt on power steering pump.
2. Pivot the power steering pump to loosen belt.



70113


- a** - Mounting Bolts (1 Not Shown)
b - Tensioning Bolt

CAUTION

Before removing the seawater pump, close the seacock, if equipped. If boat is not equipped with a seacock, remove and plug the seawater inlet hose to prevent a siphoning action that may occur, allowing seawater to enter the boat.

3. Remove or loosen seawater pump nuts sufficiently to allow belt to pass between crankshaft balancer and water pump housing.

NOTE: Refer to SECTION 6A - Seawater Pump Removal if necessary.




23161

Typical

- a** - Hex Nut With Washer (4)


4. Remove old belt.
5. Install new belt.
6. Pivot the power steering pump. Adjust belt deflection to be 5 mm (3/16 in.) measured at midpoint between the pulleys on the longest belt span.
7. Torque tensioning and mounting bolts to 21 Nm (15 lb-ft).



- a** - Mounting Bolts (1 Not Shown)
- b** - Tensioning Bolt
- c** - Deflection: 5 mm (3/16 in.)

IMPORTANT: There is an o-ring seal on the seawater pump.

8. Ensure that the o-ring seal is in the proper position before installing the seawater pump. Also, ensure the pump and keyway align.
9. Install the seawater pump.



- a** - O-ring
- b** - Key And Keyway
- c** - Hex Nut With Washer


10. Install the seawater pump inlet and outlet hoses.
11. Open the seacock if equipped, or remove plug from seawater inlet hose and reconnect hose.

Vacuum Pump Belt

NOTE: On some engines it may be necessary to remove other drive belts to gain access to a particular belt during replacement. Refer to appropriate sections for information concerning individual drive belts and proceed accordingly.

1. Remove or loosen seawater pump nuts sufficiently to allow belt to pass between crankshaft balancer and water pump housing.


NOTE: Refer to SECTION 6 - Seawater Pump Removal if necessary.



23161

a - Hex Nuts With Washers

2. Loosen the vacuum pump mounting and tensioning bolts, behind the bracket.




74085

a - Mounting Bolt
b - Tensioning Bolt
c - Vacuum Pump Bracket

3. Pivot the vacuum pump to loosen the belt.
4. Remove old belt.
5. Install new belt

6. Pivot the vacuum pump. Adjust belt deflection to be 5 mm (3/16 in.) measured at midpoint between the pulleys on the longest belt span.
7. Torque tensioning and mounting bolts to 21 Nm (15 lb-ft).




74085

- a** - Mounting Bolt
- b** - Tensioning Bolt
- c** - Deflection: 5 mm (3/16 in.)

IMPORTANT: There is an O-ring seal on the seawater pump.

8. Ensure that the O-ring seal is in the proper position before installing the seawater pump. Also, ensure the pump and keyway align.
9. Install the seawater pump.



23161

- a** - O-ring
- b** - Keyway
- c** - Hex Nuts With Washers

Battery

1. Ensure battery connections are clean and tight.
2. Keep exterior surfaces of battery wiped clean with a water/baking soda solution.
3. Ensure battery is securely fastened in place.
4. Refer to battery manufacturer's recommendations for fluid level and charging.

Charging System

CAUTION

Remove all battery cables from battery (before conducting the following check) to prevent accidentally causing a short circuit in the electrical system.

1. Inspect entire charging system for loose, damaged or corroded connectors.
2. Check wiring for frayed or worn insulation.
3. Check alternator mounting bolts for adequate tightness.
4. Check alternator drive belt for excessive wear, cracks, fraying and glazed surfaces.

Corrosion and Corrosion Protection

1. After first cleaning all surfaces, check all metal surfaces and touch up with Paint.
2. To maintain a protective coating on all metal surface areas, spray with Corrosion Guard.

NOTICE

For additional information on sterndrive unit corrosion protection and external corrosion protection refer to appropriate Mercury MerCruiser Sterndrive Service Manual.

Saltwater Operation

Seawater section must be flushed after each saltwater use. Refer to SECTION 1B Flushing Seawater System.

Freezing Temperature and Cold Weather Operation

IMPORTANT: If boat is operated during periods of freezing temperature, precautions must be taken to prevent freeze damage to power package. Refer to the following and to Cold Weather or Extended Storage for related information and draining instructions.

CAUTION

Seawater (raw water) section of cooling system **MUST BE COMPLETELY** drained for winter storage or immediately after cold weather use, if the possibility of freezing temperatures exist. Failure to comply may result in trapped water causing freeze and/or corrosion damage to engine.

CAUTION

If boat is in the water, seacock (water inlet valve), if equipped, must be left closed until engine is to be started to prevent water from flowing back into cooling system and/or boat. If boat is not fitted with a seacock, water inlet hose must be left disconnected and plugged to prevent water from flowing back into cooling system and/or boat. As a precautionary measure, attach a tag to the ignition switch or steering wheel of the boat with the warning: Open seacock or reconnect water inlet hose before starting engine.

1. At the end of operations each day, **COMPLETELY** drain seawater section of the cooling system and the seawater strainer to protect against damage by freezing. Refer to SECTION 1B.
2. At the end of operation each day, drain water from water separating fuel filter.
3. Fill fuel tank at end of operation each day to prevent condensation.
4. Closed cooling section of engine must be filled with Premixed Marine Engine Coolant, a mixture of anti-freeze / deionized water solution sufficient to prevent freezing to the coldest temperature of the area.
5. Ensure that proper cold weather lubrication oil is used.
6. Make certain that the battery is of sufficient size and is fully charged. Ensure that all other electrical equipment is in optimum condition.
7. At temperatures of -20°C (-4°F) and below, it is recommended that you use the crankcase mounted coolant heater to improve cold starting.
8. If operating in arctic temperatures of -29°C (-20°F) or lower, consult your dealer for information about special cold weather equipment and precautions.

Cold Weather or Extended Storage

Power Package Layup

IMPORTANT: Mercury MerCruiser strongly recommends that this service be performed by an Authorized Mercury MerCruiser Dealer. Damage caused by freezing IS NOT covered by the Mercury MerCruiser Limited Warranty.

CAUTION

The engine must be prepared for long storage periods to prevent internal corrosion and severe damage.

CAUTION

Overheating from insufficient cooling water will cause engine and drive system damage. Ensure that there is sufficient water always available at water inlet holes during operation.

IMPORTANT: If boat has already been removed from water, before starting engine a source of water must be supplied to water inlet holes. Refer to Flushing Cooling System.

1. Provide sufficient water supply to water inlet holes.
2. Start the engine and operate until it reaches normal operating temperature.
3. Stop the engine.
4. Change the engine oil and filter.
5. Start the engine and operate for about 15 minutes. Ensure there are no oil leaks.
6. Flush cooling system. Refer to SECTION 1B - Flushing Seawater System.
7. Drain seawater section of cooling system and prepare for cold weather or extended storage as outlined.

Draining

IMPORTANT: Drain only the seawater section of the cooling system. Closed cooling section must be kept filled year-round with specified coolant.

1. Ensure that the engine is as level as possible to promote complete draining of the cooling system.

⚠ CAUTION


If boat is to remain in the water, seacock, if equipped, must be closed until engine is to be restarted to prevent water from flowing back into seawater cooling system. If boat is not fitted with a seacock, water inlet hose must be disconnected and plugged to prevent water from flowing into cooling system and/or boat. As a precautionary measure, attach a tag to the ignition switch or steering wheel with the warning that the valve must be opened or the water inlet hose reconnected prior to starting the engine.

2. Close seacock, or disconnect and plug seawater inlet hose, if boat is to remain in the water.

IMPORTANT: Drain only the seawater section of the cooling system. Closed cooling section must be kept filled year-round with specified coolant.

3. Do NOT open either of these two drain valves in the closed cooled section.

75297




Typical

- a** - Exhaust Manifold Drain Valve
- b** - Engine Block Drain Valve

4. Remove the end covers from BOTH port and starboard ends on upper and lower sections of heat exchanger tank.
5. Drain tank completely.
6. Sponge out or soak up any water that remains in the bottom part of upper and lower heat exchanger sections, until all water passage tubes are completely free of standing water.

⚠ CAUTION


Avoid damage to heat exchanger and subsequent possible engine damage. Remove all water from heat exchanger sections. Failure to do so could cause corrosion or freeze damage to heat exchanger water passage tubes.



- a** - Upper Section End Cover
- b** - Lower Section End Cover

NOTE: In the following it may be necessary to lower or bend the hoses to allow water to drain completely.


7. **On Sterndrive (MCM) Engines:** Disconnect seawater outlet hose at aft end of power steering fluid cooler. Lower hose and drain completely.



Typical

- a** - Power Steering Fluid Cooler
- b** - Seawater Hose

8. **On Inboard (MIE) Engines:** Disconnect seawater outlet hose at aft end of transmission fluid cooler. Lower hose and drain completely.




73335

Typical

- a** - Transmission Fluid Cooler
b - Seawater Hose


9. Remove the drain plug from the aft end cover of the intercooler.



74303

- a** - Drain Plug
b - Intercooler

10. Remove seawater pump outlet hose from top of seawater pump and drain.




75301

- a** - Seawater Pump Outlet Hose

11. Repeatedly clean out drain holes using a stiff piece of wire. Do this until entire system is drained.

12. **Sterndrive (MCM) Only:** Insert a small wire (repeatedly) to make sure that speedometer pitot tube, trim tab/anode cavity vent hole and trim tab/anode cavity drain passage are unobstructed and drained.



71217

Typical Bravo Drive Unit

- a** - Speedometer Pitot Tube
- b** - Vent Hole
- c** - Drain Passage


13. After seawater section of cooling system has been drained completely:
- a. Coat threads of intercooler drain plug with Perfect Seal and reinstall. Tighten securely.
 - b. Reconnect hoses. Tighten hose clamps securely.

NOTE: Renew end cover gaskets if worn or deteriorated.

- c. Install all four end cover gaskets and covers on the heat exchanger tank.
- d. Torque the end covers on the upper heat exchanger section to 14-15 Nm (120-132 lb-in.).
- e. Torque the end covers on the lower heat exchanger section to 11 Nm (108-120 lb-in.).

IMPORTANT: Mercury MerCruiser recommends that propylene glycol antifreeze (nontoxic and biodegradable, which makes it friendly to lakes and rivers) be used in seawater section of the cooling system for cold weather or extended storage. Make sure that the propylene glycol antifreeze contains a rust inhibitor and is recommended for use in marine engines. Be certain to follow the propylene glycol manufacturer's recommendations.

14. Fill a container with approximately 5.6 liter (6 U.S. quarts) of propylene glycol antifreeze and tap water mixed to manufacturer's recommendation to protect engine to the lowest temperature to which it will be exposed during cold weather or extended storage.
15. Disconnect hose from seawater pump connector fitting. Using an adaptor, temporarily connect an appropriate length piece of hose to seawater pump and place the other end of the hose into container of coolant.



75299

Typical



- a** - Inlet Hose
- b** - Connector Fitting

16. Start the engine and operate, at IDLE speed, until antifreeze mixture has been pumped into engine seawater cooling system.
17. Stop the engine.
18. Clean the engine.
19. Coat the engine with Quicksilver Corrosion Guard or equivalent corrosion inhibiting oil.
20. Lubricate all items outlined in Lubrication.
21. Remove and store battery in a cool, dry place. Do NOT store on a concrete surface, or on the ground. Place on a dry, wood board or a thick plastic base. Refer to battery manufacturer's instructions.
22. Perform all checks, inspections, lubrication and fluid changes outlined in the Maintenance Schedules.

23. Remove seawater pump impeller for storage:

- a. Remove seawater pump cover mounting screws, and remove cover and gasket.
- b. Ease impeller off pump shaft with two screwdrivers.
- c. Reinstall cover for storage.

NOTE: Pump shown removed for visual clarity only.



Typical

- a - Seawater Pump Housing
- b - Cover Screws
- c - Cover
- d - Gasket
- e - Impeller

IMPORTANT: It is recommended that others be informed to NOT operate the engine.

24. Place a CAUTION TAG at instrument panel and in engine compartment stating that the seawater pump is out - Do NOT operate engine.

⚠ CAUTION

Sterndrive unit should be stored in full DOWN / IN position. Universal Joint bellows may develop a set if unit is stored in raised position and may fail when unit is returned to service.

25. Place sterndrive unit in the full DOWN / IN position.

Recommissioning

NOTICE
Refer to Cold Weather Extended Storage - Precautions, BEFORE proceeding.


1. Reinstall seawater pump components as follows:

- a. Place impeller in pump housing, turning clockwise while simultaneously pushing firmly inward onto pump shaft.

NOTE: Use new gasket. Install in correct position - wide surface on side of cam.

- b. Install pump cover with new gasket in noted position.
- c. Install the seawater pump cover mounting screws. Tighten securely.

NOTE: Pump shown removed for visual clarity only.



71366

- a** - Impeller
- b** - Seawater Pump Housing
- c** - Gasket (Wide Surface On Cam Side)
- d** - Cover
- e** - Cover Screws

2. Ensure that all cooling system hoses are in good condition, connected properly, and hose clamps are tight. Verify that all drain valves and drain plugs are installed and tight.
3. Inspect all drive belts.
4. Perform all lubrication and maintenance specified for completion Annually in Maintenance Schedule, except items that were performed at time of engine layup.
5. Fill fuel tanks with fresh diesel fuel. Old fuel should not be used. Check fuel lines and connections for leaks and general condition.
6. Replace fuel filter
7. For drive unit, refer to appropriate Mercury MerCruiser Sterndrive Service Manual.

⚠ CAUTION

When installing battery, connect POSITIVE (+) battery cable to POSITIVE (+) battery terminal FIRST, and NEGATIVE (-) battery cable to NEGATIVE (-) battery terminal LAST. If battery cables are reversed, or connection order is reversed, electrical system damage will result.

8. Install a fully charged battery. Clean the battery cable clamps and terminals. Reconnect the cables (see **CAUTION** listed above). Secure each cable clamp when connecting. Coat terminals with a battery terminal anti-corrosion spray to help retard corrosion.
9. Perform all checks on OPERATION CHART in the STARTING PROCEDURE column found in the Operation, Maintenance and Warranty Manual provided with the product.

⚠ CAUTION

Overheating from insufficient cooling water will cause engine and drive system damage. Ensure that there is sufficient water always available at water inlet holes during operation.

10. Supply cooling water to the water inlet openings.
11. Start the engine and closely observe instrumentation. Ensure that all systems are functioning correctly.
12. Carefully inspect the engine for fuel, oil, fluid, water and exhaust leaks.
13. Check the steering system, shift and throttle control for proper operation.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

IMPORTANT INFORMATION

SECTION 1C - Troubleshooting

1
C

Table of Contents

Precautions	1C-3	Turbocharger	1C-18
Poor Boat Performance and/or Poor Maneuverability	1C-5	Engine Noise	1C-19
Improper Full Throttle Engine RPM	1C-6	Valve Cover Area	1C-20
RPM Too High	1C-6	Cylinder Area	1C-20
RPM Too Low	1C-6	Camshaft Area	1C-21
Engine Cranks Over But Will Not Start Or Starts Hard	1C-7	Crankshaft Area	1C-22
Electrical	1C-7	Miscellaneous	1C-23
Fuel System	1C-7	Oil Pressure	1C-23
Miscellaneous	1C-9	Low Oil Pressure	1C-25
Engine Will Not Crank Over or Starter Inoperative	1C-9	High Oil Pressure	1C-25
Glow Plugs Inoperative	1C-10	Excessive Oil Consumption	1C-26
Charging System Inoperative	1C-11	Water / Coolant in Engine	1C-27
Noisy Alternator	1C-11	Important Information	1C-27
Engine Operates Poorly at Idle	1C-12	Water / Coolant In Crankcase Oil	1C-27
Engine Operates Poorly At High Rpm ...	1C-13	Water / Coolant On Top Pistons	1C-28
Poor Fuel Economy	1C-14	Engine Overheats	1C-29
Engine Smoking	1C-15	Cooling System	1C-29
Black Smoke	1C-15	Mechanical	1C-30
Blue Smoke	1C-16	Power Steering	1C-31
White Smoke	1C-16	Poor, Erratic or No Assist	1C-31
Exhaust Gas Temperature	1C-17	Noisy Pump	1C-32
High	1C-17	Fluid Leaks	1C-32
Low	1C-17	Insufficient Water Flow From Belt Driven Seawater Pump	1C-33
		ZF / Hurth Hydraulic Transmission	1C-34

THIS PAGE IS INTENTIONALLY BLANK

Precautions

WARNING

Always disconnect battery cables from battery before working around electrical system components to prevent injury to yourself or damage to electrical system.

WARNING

Be careful when changing fuel system components; diesel fuel is flammable. Ensure that ignition key is OFF. Do NOT smoke or allow sources of spark or flame in the area while changing fuel system components. Wipe up any spilled fuel immediately. Do NOT allow fuel to come into contact with any hot surface which may cause it to ignite.

WARNING

Avoid diesel fuel fire. Improper installation of brass fittings or plugs into fuel filter base can crack casting and/or cause a fuel leak. Follow specific procedure, given in SECTION 4 of this manual, for all fuel line connections.

WARNING

FIRE HAZARD: Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death. Careful periodic inspection of entire fuel system is mandatory, particularly after storage. All fuel components including fuel tanks, whether plastic, metal or fiberglass, fuel lines, primers, fittings, and fuel filters should be inspected for leakage, softening, hardening, swelling or corrosion. Any sign of leakage or deterioration requires replacement before further engine operation.

WARNING

Dispose of fuel-soaked rags, paper, etc., in an appropriate air tight, fire retardant container. Fuel-soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

⚠ WARNING

Make sure no fuel leaks exist before closing engine hatch.

⚠ WARNING

When running engine with boat out of water, be certain that area in vicinity of propeller is clear and that no person is standing nearby. As a precautionary measure, it is recommended that the propeller be removed.

⚠ WARNING

Do NOT leave helm unattended while performing idle speed adjustment.

⚠ WARNING

Safety glasses should be worn while working on fuel injection system. The fuel injection pump will generate pressures in excess of 2000 psi (13790 kPa). Use caution when removing injectors, injector lines, or bleeding air from injection system.

⚠ CAUTION

Do NOT operate engine without water being supplied to seawater pickup pump on engine, or pump impeller may be damaged and subsequent overheating damage to engine may result. Engine may be operated with boat out of water, if instructions for running engine with boat out of water, below, are followed.

⚠ CAUTION

Do NOT run engine above 1500 rpm, as suction created by seawater pickup pump may collapse water supply hose and cause engine to overheat

Poor Boat Performance and/or Poor Maneuverability

Symptom	Cause
1. Bow too low	1. A. Improper drive unit trim angle B. Improper weight distribution C. Boat is underpowered D. Permanent or power hook in boat bottom E. False bottom full of water F. Improperly adjusted trim tabs (after planes)
2. Bow too high	2. A. Improper drive unit trim angle B. Propeller pitch too great C. Dirty boat bottom (marine growth) D. Poor running engine E. Improper weight distribution F. Rocker in boat bottom G. False bottom full of water H. Improperly adjusted trim tabs (after planes)
3. Propeller ventilating	3. A. Drive unit installed too high on transom B. Dirty or rough boat bottom C. Damaged propeller; pitch too small; diameter too small D. Keel located too close to propeller or too deep in the water E. Water pickup or accessories located too close to propeller F. Hook in boat bottom G. Propeller plugged up with weeds

Improper Full Throttle Engine RPM

RPM Too High

Cause	Special Information
1. Operation	3. Unit trimmed out too far
2. Propeller	1. Damaged; pitch too low; diameter too small; propeller hub slipping
3. Boat	2. A. Water pickup or accessories mounted too close to propeller (ventilation) B. Keel located too close to propeller and/or too deep in the water (ventilation) C. Drive installed too high on transom D. Wrong gear ratio
4. Engine coupler slipping	

RPM Too Low

Cause	Special Information
1. Operation	3. Unit trimmed in too far
2. Propeller	1. Damaged; pitch too great; diameter too great
2. Boat	2. A. Dirty or damaged bottom B. Permanent or power hook in bottom C. False bottom full of water D. Drive installed too low E. Excessive boat load

Engine Cranks Over But Will Not Start Or Starts Hard

Electrical

Cause	Special Information
1. Battery, electrical connections, damaged wiring, Lanyard Stop Switch	1. Ensure ECM 5 Amp. fuse in electrical box is not defective (blown)
2. Ignition switch	
3. Glow plugs (if equipped) inoperative	
4. Injection timing	4. May crank over hard. Refer to SECTION 5A, 5D, and/or 5E for EDI diagnosis

Fuel System

Cause	Special Information
1. Empty fuel tank	
2. Fuel shut off valve closed (if equipped)	
3. Anti-siphon valve stuck closed (if equipped)	3. Restricting fuel supply
4. Low grade, stale fuel or water in fuel	
5. Fuel waxing or frozen water separator (cold weather)	
6. Plugged fuel suction line or filter	
7. Air leaks, suction side fuel line or water separator	7. Sucks air into fuel system reducing fuel volume
8. Plugged or pinched fuel line (feed or return)	

Fuel System (continued)

Cause	Special Information
9. Fuel tank vent plugged	9. Engine will start initially. After a short time running, engine will stall and will not restart for a period of time. Can verify if it is a vent problem by running engine with filler cap loose. Filler cap will act as a vent.
10. Injection pump solenoid valve	10 Refer to SECTION 5. Check lanyard stop switch engaged or defective
11. Fuel supply pump	11. Low supply pump pressure. Refer to SECTION 5A, 5D, and/or 5E for EDI diagnosis

Miscellaneous

Cause	Special Information
1. Low grade or stale fuel	
2. Water in fuel	
3. Incorrect starting procedure	3. Refer to Owners Manual
4. Internal mechanical damage (bent rods, etc.)	
5. Low compression	5. Worn valves, rings, cylinder or head gasket
6. Valve timing incorrect	6. Timing gears improperly installed or cam slipped in drive gear
7. Restricted or plugged exhaust	

Engine Will Not Crank Over or Starter Inoperative

Cause	Special Information
1. Remote control lever not in neutral position	
2. Battery charge low; damaged wiring; loose electrical connections	
3. Circuit breaker tripped	
4. Defective (blown) fuse	
5. Ignition switch	
6. Slave solenoid	

Engine Will Not Crank Over or Starter Inoperative (continued)

Cause	Special Information
7. Faulty neutral start safety switch	7. Open circuit
8. Starter solenoid	
9. Starter motor	
10. Engine mechanical malfunction	

Glow Plugs Inoperative

Cause	Special Information
1. Battery discharged	
2. Circuit breaker tripped	2. On dash or in electrical box
3. Poor battery connections	
4. Glow plug(s) defective (burned out)	
5. Relay defective or inoperative	5. Check Main or Auxiliary Relay in electrical box. Refer to SECTION 4C and/or 5E for EDI Diagnosis
6. Pre-glow circuit of controller inoperative	6. In electrical box
7. ECT malfunction or inoperative	7. Refer to SECTION 5E for EDI diagnosis
8. Ignition switch inoperative	
9. Broken or disconnected wire in glow plug circuit	

Charging System Inoperative

Cause	Special Information
1. Loose or broken drive belt	
2. Engine rpm too low on initial start	2. Rev engine to 1500 rpm
3. Loose or corroded electrical connections	
4. Faulty battery gauge	4. Best way to test is to replace gauge
5. Battery will not accept charge	5. Low electrolyte or failed battery
6. Faulty alternator or regulator	
7. Refer to Charging System SECTION 4B for complete diagnostic procedures	

Noisy Alternator

Cause	Special Information
1. Loose mounting bolts	
2. Drive belt	2. Worn, frayed, loose
3. Loose drive pulley	
4. Worn or dirty bearings	
5. Faulty diode trio or stator	
6. Faulty armature	6. Rubbing, broken wire

Engine Operates Poorly at Idle

Cause	Special Information
1. Clogged air cleaner	
2. Plugged fuel suction line or filter	
3. Air leaks: suction side fuel line, water separating fuel filter or loose intake manifold	
4. Water in fuel	4. Refer to SECTIONS 1B and 5A
5. Low grade or stale fuel	
6. Fuel waxing or frozen water separating fuel filter (cold weather)	
7. Valve timing	7. Cam slipped in drive gear
8. Restricted or plugged exhaust	
9. Injectors not functioning properly	9. Refer to SECTION 5E for EDI Diagnosis
10. Injection pump timing incorrect	10. Refer to SECTION 5E for EDI Diagnosis
11. Low compression	11. Also check for defective (blown) head gasket
12. Water leaking into cylinders	12. Defective head gasket, exhaust manifold, cracked head or intercooler
13. Loose or broken engine mounts	
14. Refer to SECTION 5 for complete diagnostic procedures for EDI	

Engine Operates Poorly At High Rpm

Cause	Special Information
1. Refer to Poor Boat Performance And / Or Poor Maneuverability	
2. Crankcase overfilled with oil	2. Check oil level with boat at rest in the water
3. Malfunction of anti-siphon valve (if equipped)	3. Restricting fuel supply
4. Plugged fuel tank vent	
5. Low fuel supply	
6. Clogged fuel filter	
7. Low grade of fuel or water in the fuel	
8. Obstructed or kinked fuel lines	
9. Injectors not functioning properly	9. Refer to SECTION 5C and / or 5E for EDI Diagnosis
10. Engine overheating	10. Refer to Engine Overheats
11. Low compression	11. Worn valves, rings, cylinders, etc.
12. Restricted or plugged exhaust	
13. Refer to SECTION 5 for complete diagnostic procedures for EDI	

Poor Fuel Economy

Cause	Special Information
1. Fuel leaks	
2. Operator habits	2. Prolonged idling; slow acceleration; failure to cut back on throttle once boat is on plane; boat over loaded; uneven weight distribution
3. Engine laboring	3. Bent, damaged, or wrong propeller. Water test boat for proper operating rpm at wide open throttle
4. Clogged air cleaner	
5. Engine compartment sealed too tight	5. Not enough air for engine to operate properly
6. Boat bottom	6. Dirty (marine growth), hook, rocker
7. Turbocharger malfunction	
8. Improper fuel	
9. Crankcase ventilation system not working	
10. Engine operating too hot or too cold	
11. Plugged or restricted exhaust	
12. Engine	12. Low compression
13. Injectors not functioning properly	13. Refer to SECTION 5E for EDI diagnosis
14. Injection pump timing incorrect	14. Refer to SECTION 5E for EDI diagnosis

Engine Smoking

Black Smoke

Cause	Special Information
1. Overload	
2. Restricted air cleaner and /or intercooler	
3. Excessive fuel delivery	3. Refer to SECTION 5E for EDI diagnosis
4. Faulty injector(s)	4. Refer to SECTION 5C and / or 5E for EDI diagnosis
5. Restricted or plugged exhaust	
6. Insufficient coolant temperature	
7. Excessive idle time (injector coking)	
9. Leaking head gaskets	
10. Worn piston rings	

Blue Smoke

Cause	Special Information
1. Worn piston rings	1. Check compression
2. Sticking piston rings	2. Check compression
3. Crankcase overfilled - incorrect dipstick reading	
4. Leaking head gaskets	

White Smoke

Cause	Special Information
1. Injection pump timing incorrect	1. Refer to SECTION 5D
2. Faulty injector(s)	2. Refer to SECTION 5C
3. Low compression	
4. Plugged fuel suction line or filter	
5. Air leaks, suction side fuel line or water separating fuel filter	
6. Questionable fuel quality	6. Low cetane
7. Restricted fuel return/excessive return line pressure	
8. Leaking head gaskets	
9. Inoperative glow plug system	9. Refer to SECTION 4C and/or 5E for EDI diagnosis

Exhaust Gas Temperature

High

Cause	Special Information
1. Excessive load	
2. Injection pump timing incorrect	2. Refer to SECTION 5D
3. Faulty wastegate device	

Low

Cause	Special Information
1. Injection pump timing incorrect	1. Refer to SECTION 5D
2. Excessive idling time/light loads	

Turbocharger

Ensure that troubles are not due to engine components, especially to injection system, before troubleshooting turbocharger and/or carrying out corrective action on turbocharger.

Cause	Special Information
1. Smoke from exhaust	1. A. Not enough air getting to engine air intake B. Clogged air filter C. Boost pressure too low D. Refer to Engine Smoking - Black, Blue and/or White
2. Loss of power	2. A. Not enough air getting to engine air intake B. Clogged air cleaner C. Boost pressure too low D. Poor lubrication of turbocharger E. Defective wastegate valve F. Rubbing of compressor or turbine impellers against housing G. Defective engine gaskets allowing air or fuel escape into exhaust or intake system
3. Unusual noises and vibrations at turbocharger	3. A. Poor lubrication of turbocharger B. Rubbing of compressor or turbine impellers against housing C. Defective engine gaskets allowing air or fuel escape into exhaust or intake system
4. Rubbing of compressor or turbine impellers against housing	4. A. Poor lubrication of turbocharger B. Low oil pressure at turbocharger C. Defective bearings in turbocharger
5. Oil leakage from compressor side	5. A. Clogged air cleaner B. Boost pressure too low

Engine Noise

No definite rule or test will positively determine source of engine noise; therefore, use the following information only as a general guide to engine noise diagnosis.

1. Use a timing light to determine if noise is timed with engine speed or one-half engine speed. Noises timed with engine speed are related to crankshaft, rods, pistons, piston pins, and flywheel. Noises timed to one-half engine speed are valve train related.
2. The use of a stethoscope can aid in locating a noise source; however, because noise will travel to other metal parts not involved in the problem, caution must be exercised.
3. Try to isolate the noise to location in engine: front to back, top to bottom. This can help determine which components are at fault.
4. Sometimes noises can be caused by moving parts coming in contact with other components. Examples are: flywheel or coupler; exhaust flappers rattling against exhaust pipe; crankshaft striking (pan, pan baffle, or dipstick tube); rocker arm striking valve cover; and loose flywheel cover. In many cases if this is found to be the problem, a complete engine teardown is not necessary.
5. When noise is isolated to a certain area and component, removal and inspection will be required. Refer to proper SECTIONS of service manual for information required for service.
6. If noise cannot be distinguished between engine and drive unit, remove drive from boat. Run a water supply directly to engine. Run engine without the drive to determine if noise is still there.

Valve Cover Area

Location	Possible Cause
1. Valve cover area, timed to one-half engine speed, noise could be confined to one cylinder or may be found in any multitude of cylinders	1. A. Rocker arm striking valve cover B. Hydraulic lifter C. Worn rocker arm D. Bent push rod E. Worn camshaft F. Sticking valve

Cylinder Area

Location	Possible Causes
1. Cylinder area, may be confined to one cylinder or found in more than one cylinder, timed to engine speed	1. A. Sticking valve B. Carbon build-up C. Connecting rod installed wrong D. Bent connecting rod E. Piston F. Piston rings G. Piston pin H. Cylinder worn
2. Engine knocking	2. A. Faulty injector (white smoke) B. Worn delivery valve C. Wrong injection timing D. Incorrect valve lifter E. Tight piston pin

Camshaft Area

Location	Possible Causes
1. Camshaft area, front of engine, timed to engine speed	1. A. Camshaft timing gear B. Injection pump C. Fuel pump D. Valve lifter - camshaft wear E. Cam bearings
2. Camshaft area, center of engine, timed to engine speed	2. A. Fuel pump B. Valve lifter - camshaft wear C. Cam bearings
3. Camshaft area, rear of engine, timed to engine speed	3. A. Valve lifter - camshaft wear B. Cam bearings
4. Camshaft area, throughout engine, timed to engine speed	4. A. Loss of oil pressure B. Valve lifter - camshaft wear C. Cam bearings

Crankshaft Area

Location	Possible Causes
1. Crankshaft area, front of engine, timed to engine speed	1. A. Crankshaft timing gear B. Oil Pump C. Rod bearing D. Main bearing
2. Crankshaft area, center of engine, timed to engine speed	2. A. Crankshaft striking pan or pan baffle B. Rod bearing C. Main bearing
3. Crankshaft area, rear of engine, timed to engine speed	3. A. Loose flywheel cover B. Loose coupler or drive plate C. Loose flywheel D. Rod bearing E. Main bearing
4. Crankshaft area, throughout engine, timed to engine speed	4. A. Loss of oil pressure B. Rod bearings C. Main bearings

Miscellaneous

Location	Possible Causes
1. Hissing	A. Leaking exhaust (manifolds or pipes) B. Loose cylinder heads C. Blown head gasket
2. Whistle	2. A. Vacuum leak B. Dry or tight bearing in an accessory
3. Squeaks or squeals	3. A. Drive belt slipping B. Dry or tight bearing in an accessory C. Parts rubbing together

Oil Pressure

Item	Special Information
1. Measuring oil pressure	1. Use a good automotive oil pressure test gauge. Do not rely on the oil pressure gauge in the boat.
2. Check engine oil level with boat at rest in the water	2. Oil level should be between the ADD and FULL marks
3. Oil level in crankcase above FULL mark	3. May cause loss of engine rpm, oil pressure gauge fluctuation, drop in oil pressure, and hydraulic valve lifter noise at high rpm
4. Oil level in crankcase below ADD mark	4. Low oil pressure; oil pressure gauge fluctuation; internal engine noise and/or damage
5. Change in oil pressure	5. This may be a normal condition. Oil pressure may read high in the cooler times of the day, and when engine is not up to operating temperature. As the air temperature warms up and engine is running at normal opening temperature, it is normal for oil pressure to drop.

Oil Pressure (continued)

Item	Special Information
6. Low engine oil pressure at idle	6. With modern engines and engine oils, low oil pressure readings at idle do not necessarily mean there is a problem. If valve lifters are not noisy at idle, there is a sufficient volume of oil to lubricate all internal moving parts properly. The reason for the drop in oil pressure is that engine heat causes an expansion of the internal tolerances in the engine and, also, the oil will thin out somewhat from heat.
7. Low engine oil pressure at idle after running at a high rpm	7. Refer to Number 5. and 6. preceding
8. Boats with dual engines	8. It is not uncommon to see different oil pressure readings between the two engines, as long as both engines fall within specifications. Differences in oil pressure can be attributed to differences in engine tolerances, gauges, wiring, senders, etc.
9. Boats with dual stations	9. Refer to Number 8. preceding

Low Oil Pressure

Cause	Special Information
1. Low oil level in crankcase	
2. Defective oil pressure gauge and/or sender	2. Verify with an automotive test gauge.
3. Thin or diluted oil	3. Oil broken down; contains water or fuel; wrong viscosity; engine running too hot or too cold; excessive idling in cold water (condensation)
4. Oil pump	4. Relief valve stuck open; pickup tube restricted; worn parts in oil pump; air leak on suction side of oil pump or pickup oil tube
5. Oil leak can be internal or external	5. Oil passage plugs leaking, cracked or porous cylinder block
6. Excessive bearing clearance	6. Cam bearings, main bearings, rod bearings

High Oil Pressure

IMPORTANT: Oil pressure slightly higher than normal does not always indicate a problem. Oil viscosity, and weather conditions could cause high oil pressure.

Cause	Special Information
1. Oil too thick	1. Wrong viscosity, oil full of sludge or tar
2. Defective oil pressure gauge and/or sender	2. Verify with an automotive test gauge
3. Clogged or restricted oil passage	
4. Oil pump relief valve stuck closed	

Excessive Oil Consumption

NOTE: One quart of oil consumed in 15 hours of operation at WOT, especially in a new or rebuilt engine, is normal

Cause	Special Information
1. Normal consumption	1. One quart of oil consumed in 15 hours of operation at wide-open-throttle (especially in a new or rebuilt engine) is normal
2. Oil leaks	2. Clean bilge, run engine with clean white paper on bilge floor, locate oil leak(s)
3. Oil too thin	3. Oil diluted or wrong viscosity
4. Oil level too high	
5. Drain holes in cylinder head plugged	5. Oil will flood valve guides
6. Defective valve stem seals (if equipped)	
7. Worn valve stems or valve guides	
8. Defective oil cooler (if equipped)	8. Crack in cooler tubes
9. Defective piston rings	9. Glazed, scuffed, worn, stuck, improperly installed; ring grooves worn; improper break-in; wrong end gap
10. Defective cylinders	10. Out of round, scored, tapered, glazed; excessive piston to cylinder clearance; cracked piston
11. Excessive bearing clearance	

Water / Coolant in Engine

Important Information

IMPORTANT: First determine location of water in engine. This information can be of great help when trying to determine where the water came from and how it got into the engine. The three most common problems are water on top of pistons, water in crankcase oil, water in crankcase oil and on top of pistons.

The first step, after locating water, is to remove all the water from the engine by removing all glow plugs or injectors and pumping cylinders out by cranking engine over. Next change oil and filter. Now, start engine and see if problem can be duplicated. If problem can be duplicated, there more than likely is a mechanical problem. If the problem cannot be duplicated, the problem is either an operator error or a problem that exists only under certain environmental conditions.

If water is contained to cylinder(s) only, it is usually entering through the intake system, exhaust system, or head gasket.

If the water is contained to crankcase only, it is usually caused by a cracked or porous block, a flooded bilge, or condensation.

If the water is located in both the cylinder(s) and the crankcase, it is usually caused by water in the cylinders getting past the rings and valves, or complete submersion.

Checking for rust in the intake manifold or exhaust manifolds is a good idea. Rust in these areas will give clues if the water entered these areas.

Water / Coolant In Crankcase Oil

Cause	Special Information
1. Water in boat bilge	1. Boat has been submerged or bilge water was high enough to run in through dipstick tube
2. Water seeping past piston rings or valves	2. Refer to Water/Coolant On Top of Pistons
3. Engine running cold	3. Defective thermostat, missing thermostat; pro-longed idling in cold water
4. Intake manifold leaking near a water passage	
5. Cracked or porous casting	5. Check cylinder head, cylinder block, and intake manifold

Water / Coolant On Top Pistons

Cause	Special Information
1. Rain water running onto air cleaner	1. Hatch cover
2. Backwash through the exhaust system	
3. Improper engine or exhaust hose installation	3. Refer to exhaust specifications
4. Cracked exhaust manifold	
5. Improper manifold to elbow gasket installation	
6. Loose cylinder head bolts	
7. Blown cylinder head gasket	7. Check for warped cylinder head or cylinder block
8. Cracked and leaking intercooler	8. Defective O-rings or tubes
9. Porous or cracked casting	9. Check cylinder heads/valve bridge, cylinder block, and intake manifold

Engine Overheats

Cooling System

Cause	Special Information
IMPORTANT: The first step is to verify if the engine is actually overheating or if the temperature gauge or sender is faulty	
1. Seacock (seawater shut off valve) partially or fully closed (if equipped)	
2. Low coolant level	
3. Antifreeze incorrect type or not mixed properly	3. Use low silicate type with special additives
4. Loose or broken drive belt	
5. Clogged or improperly installed sea strainer	
6. Loose hose connections between seawater pickup and seawater pump inlet	6. Pump will suck air; pump may fail to prime or will force air bubbles into cooling system
7. Seawater inlet hose kinked or collapsed	7. Inlet hose must be wire reinforced to prevent collapsing, and positioned to prevent kinks or restrictions.
8. Seawater pickup clogged	
9. Obstruction on boat bottom causing water turbulence	9. Obstruction will be in front of seawater pickup, causing air bubbles to be forced into cooling system
10. Defective thermostat(s)	
11. Exhaust elbow water outlet holes plugged	
12. Insufficient seawater pump operation	12. Worn pump impeller

Cooling System (continued)

Cause	Special Information
13. Obstruction in cooling system such as casting flash, sand, rust, salt, etc.	13. Refer to water flow diagram for engine type being serviced
14. Engine water circulating pump defective	
18. Heat exchanger core or tubes plugged	
15. Also refer to Engine Overheats (Mechanical)	

Mechanical

Cause	Special Information
1. Engine rpm below specifications at wide-open-throttle (engine laboring)	1. Damaged or wrong propeller; growth on boat bottom; false bottom full of water
2. Incorrect injection pump timing	2. Injection pump timing too far advanced or retarded
3. Seawater pump impeller slipping	
4. Exhaust restriction	
5. Valve timing off	5. Jumped timing chain, or gears improperly installed
6. Insufficient lubrication to moving parts of engine	6. Defective oil pump, plugged oil passage, low oil level

Power Steering

Poor, Erratic or No Assist

Cause	Special Information
1. Drive belt	1. Worn, broken or out of adjustment
2. Low fluid level	
3. Air in system	3. Air leak in lines, pump, or air from installation. Refer to SECTION 9A for bleeding procedure.
4. Leaking hoses	4. Refer to SECTION 9A for bleeding procedure.
5. Steering cables and/or steering helm	5. Cable or helm partially frozen from corrosion or rust; cable over-lubricated; improper cable installation
6. Binding in sterndrive unit	6. Refer to appropriate Mercury MerCruiser Sterndrive Service Manual
7. Restriction in hydraulic hoses	7. Causes a loss of pressure
8. Control valve not positioned properly, not balanced properly, or the mounting nut is loose	
9. Mounting bracket adjusting screw loose or mounting tube is loose	
10. Faulty pump	10. Flow control valve may be sticking
11. Worn piston ring or scored housing bore in cylinder	11. Causes loss of pressure
12. Leaking valve body or loose fitting spool	

Noisy Pump

Cause	Special Information
1. Drive belt	1. Check belt tension
2. Low fluid level	
3. Air in fluid	3. Air leak in lines, pump, or air from installation
4. Faulty Pump	4. Use stethoscope to listen for noise in pump
5. Restricted fluid passages	5. Kinks or debris in hoses or debris in passages
6. Stop nut adjusted improperly	6. Refer to appropriate Mercury Mer-Cruiser Sterndrive Service Manual
7. Steering cables installed that do not meet ABYC standards	7. Refer to appropriate Mercury MerCruiser Sterndrive Service Manual

Fluid Leaks

Cause	Special Information
1. Loose hose connections	1. Refer to SECTION 9A for bleeding instructions
2. Damaged hose	
3. Oil leaking from top of pump	3. System overfilled; fluid contains water; fluid contains air
4. Cylinder piston rod seal	
5. Faulty seals in valve	
6. Faulty seals in O-rings in pump	
7. Cracked or porous metal parts	

Insufficient Water Flow From Belt Driven Seawater Pump

Cause	Special Information
1. Drive belt	1. Loose, worn or broken
2. Seawater shut off valve partially or fully closed	
3. Clogged or improperly installed sea strainer	
4. Loose hose connections between seawater pickup and seawater pump inlet	4. Pump will draw in air, pump may fail to prime or will force air bubbles into cooling system
5. Seawater inlet hose kinked or plugged	
6. Seawater pickup plugged	
7. Obstruction on boat bottom causing water turbulence	7. Obstruction will be in front of seawater pickup, causing air bubbles to be forced into cooling system
8. Faulty seawater pump	

ZF / Hurth Hydraulic Transmission

Trouble	Possible Cause	Remedy
1. Transmission gears cannot be shifted	1. A. Shifting lever loose B. Remote control does not permit lever travel required for testing C. Remote control faulty D. No shifting pressure available	1. A. Tighten clamping screw on shifting lever B. Lift remote control off, if gears can be shifted by hand, correct remote control C. Repair remote control D. Refer to Number 7
2. Gears are shifted sluggishly	2. Lever travel of remote control is too short; lever shift just short of minimum traveling distance	2. Lift remote control off, if gears can be shifted by hand, correct remote control
3. Clutch is slipping; propeller speed too low as compared to engine speed	3. A. Incorrect fluid used B. Fluid contains water C. Shifting pressure too low D. Wear on clutch discs E. Piston rings in clutch are damaged	3. A. Drain and refill with correct fluid, flush transmission while engine runs in neutral position, drain fluid, refill transmission B. Refer to Number 9 C. Refer to Number 6 D. Disassemble transmission replace clutch discs E. Disassemble transmission replace clutch

ZF / Hurth Hydraulic Transmission (continued)

Trouble	Possible Cause	Remedy
4. Transmission is blocked	4. A. Medium piston ring in input shaft in control block is faulty	4. A. Remove control block, replace piston ring, replace control block if worn
5. Output shaft turns in neutral position	5. A. Rotary slide valve in control block is worn B. Faulty needle bearing on input shaft C. Dished discs due to over-heating of slipping clutch	5. A. Replace control block B. Disassemble transmission and input shaft, replace bearing C. Refer to Number 3
6. Shifting pressure too low	6. A. Fluid filter dirty B. Fluid level in transmission is too low C. Fluid pump is worn out D. Piston rings in input shaft in control block are faulty E. Piston rings in clutch are faulty	6. A. Replace fluid filter B. Fill with fluid; check for fluid loss transmission, cooler and pipelines lines for leaks also refer to steps Number 10 to Number 13 C. Replace control block together with fluid pump D. Remove control block and replace piston rings. also replace control block E. Disassemble transmission, replace clutch

ZF / Hurth Hydraulic Transmission (continued)

Trouble	Possible Cause	Remedy
7. No shifting pressure	7. A. Direction of engine rotation does not agree with arrow on transmission B. No fluid in transmission C. Fluid filter is dirty D. Fluid level in transmission is too low E. Fluid pump is worn out F. Fitting key in input shaft for fluid pump drive is broken G. Shifting pressure relief valve spring is broken	7. A. Replace with L.H. rotation engine B. Refill with fluid C. Replace fluid filter D. Fill with fluid; check for fluid loss in transmission, cooler and pipelines lines for leaks also refer to steps 10 to 13 E. Replace control block together with fluid pump F. Remove control block. Replace fitting key and any other faulty parts G. Replace control block

ZF / Hurth Hydraulic Transmission (continued)

Trouble	Possible Cause	Remedy
8. Excessive fluid temperature	8. A. Excessive fluid in transmission B. Fluid cooler is dirty on water side C. Worn fluid pump in control block D. Faulty piston rings in input shaft in control block E. Clutch is slipping F. Clutch does not open completely due to worn clutch discs G. Clutch does not open completely due to broken clutch cup springs H. Low water flow from seawater pump	8. A. Remove excessive fluid with commercial fluid pump B. Remove coolant lines and clean fluid cooler on water side C. Replace control block and fluid pump D. Remove control block, replace piston rings in input shaft. Check control block and replace if damaged from faulty piston rings E. Refer to Number 3 F. Dismount transmission, replace inner disc all faulty parts G. Disassemble transmission, replace inner disc support and/or clutch H. Repair or replace seawater pump
9. Water in fluid, fluid looks milky	9. A. Fluid cooler faulty B. High water level in engine compartment, water entering at output shaft seal	9. A. Repair leakage at cooler or replace cooler and replace cooler B. Remedy cause for water level in engine compartment, change transmission fluid

ZF / Hurth Hydraulic Transmission (continued)

Trouble	Possible Cause	Remedy
10. Fluid leakage at input shaft	10. A. Breather clogged by paint or dirt B. Shaft seal faulty	10. A. Remove dirt or paint from breather B. Disassemble transmission, replace seal. If seal location on input shaft is worn repair surface
11. Fluid leakage at output shaft	11. A. Breather clogged by paint or dirt B. Shaft seal faulty	11. A. Remove dirt or paint from breather B. Disassemble transmission, replace seal. If seal location on input shaft is worn repair surface
12. Fluid leakage at venting filter	12. A. Excessive fluid in transmission	12. A. Pump out excessive fluid with commercial hand pump
13. Fluid leakage at joints or screw connections	13. A. Bolts are not tight B. Seals on bolts have been reused several times	13. A. Tighten bolts to specified torque B. Replace seals, tighten bolts to specified torque
14. Fluid leakage at filter cap or breather	14. A. Filter cap not flush or tight B. Filter cap O-ring damaged C. Fluid level too high	14. A. Reinstall filter cap flush with housing and tighten B. Replace O-ring C. Correct fluid level

ZF / Hurth Hydraulic Transmission (continued)

Trouble	Possible Cause	Remedy
15. Transmission noise changes, becomes louder	15. A. Fluid level too low so that pump sucks in air B. Damage starting on flexible coupling due to wear or fatigue, possible due to misalignment between engine and transmission C. Beginning damage of bearings in transmission; torsional vibrations, running without fluid, overload, wrong alignment of transmission, excessive engine output D. Beginning damage of gearings; torsional vibrations, running without, fluid, overload E. Fluid baffle on transmission has come loose F. Fluid suction pipe in transmission has come loose	15. A. Top off fluid to fill mark B. Replace flexible coupling. Check alignment between engine and transmission C. Disassemble transmission, replace bearings concerned and other faulty parts D. Disassemble transmission, remove faulty parts E. Disassemble transmission, attach baffle plate F. Disassemble transmission, fix fluid suction pipe
16. Chattering transmission noise mainly at low speed	16. A. The engine or propeller generate torsional vibrations, which produce a chattering noise in the transmission B. Misaligned cardan shafts on input or output shafts	16. A. Mount a flexible coupling with another stiffness factor between engine and transmission; a coupling with a higher stiffness factor might be sufficient B. Mount and align cardan shaft strictly according to instructions issued by cardan shaft manufacturer

THIS PAGE IS INTENTIONALLY BLANK

REMOVAL AND INSTALLATION

Section 2A - Sterndrive (MCM) Models

Table of Contents

2 A

Torque Specifications	2A-3	Throttle Cable Installation and	
Special Tools	2A-3	Adjustment	2A-21
Lubricants / Sealants / Adhesives	2A-4	Shift Cable Installation and	
Removal	2A-4	Adjustment	2A-23
Installation	2A-7	Troubleshooting Shift Problems	2A-28
Engine Installation / Alignment	2A-7	Battery Cables	2A-30
Engine Connections	2A-15		

THIS PAGE IS INTENTIONALLY BLANK

NOTICE

For information and procedures on Troubleshooting, refer to SECTION 1C.

Torque Specifications

Description	Nm	lb-in.	lb-ft
Drive Unit Shift Cable or Power Shift Output Cable End Guide Attaching Nut	Tighten Nut Until It Contacts Flat Washer; then, Loosen Nut 1/2 Turn		
Remote Control Throttle Cable End Guide Attaching Nut	Tighten Nut Until It Contacts Flat Washer; then, Loosen Nut 1/2 Turn		
Remote Control Throttle and Shift Cable Barrel Attaching Nut	Securely		
Rear Engine Mounts	51		37
Power Steering Fluid Hose Fittings (at Control Valve)	31		23
Sterndrive Unit Fasteners	68		50
Transom Assembly Fasteners	31		23
Seawater Pickup (Inlet) Fitting (On Gimbal Housing)	5	45	
Drive Unit Gear Lube 90 Degree Barb Fitting (If Equipped)	9	80	
Steering Cable Pivot Bolts			25 (34)
Steering Cable Coupler Nut			35 (47)

Special Tools

Description	Part Number
Engine Alignment Tool	91-805475A1

Lubricants / Sealants / Adhesives

Description	Part Number
Liquid Neoprene	92-25711--2
Perfect Seal	92-34227--1
Engine Coupler Spline Grease	91-816391A4
Battery Terminal Sealant	Obtain Locally

Removal

CAUTION

It is good practice to ventilate the engine compartment prior to servicing any engine components to remove any fuel vapors which may cause difficulty breathing or be an irritant.

7. Disconnect battery cables from battery.
8. Disconnect battery cables from engine.
9. Remove engine cover.

IMPORTANT: Sterndrive unit must be removed prior to engine removal. Refer to appropriate Mercury MerCruiser Sterndrive Service Manual.

10. Remove sterndrive unit.
11. Disconnect extension harness connector plug from engine harness connector.
12. Disconnect gear lube monitor wiring.
13. Remove engine mounted gear lube monitor.

⚠ WARNING

FIRE HAZARD: Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death.

⚠ WARNING

Be careful when working on fuel system components; diesel fuel is flammable. Be sure that the ignition key is OFF. Do NOT smoke or allow sources of open flame in the area while working on fuel system components. Wipe up any spilled fuel immediately. Do NOT allow fuel to come into contact with any hot surface which may cause it to ignite.

⚠ WARNING

Dispose of fuel-soaked rags, paper, etc., in an appropriate air tight, fire retardant container. Fuel-soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

14. Close fuel shut off valve, if equipped.

15. Disconnect and suitably plug fuel lines to prevent fuel in tank from leaking into bilge.

16. Disconnect throttle cable from engine.

NOTE: After wires are disconnected be sure to loosen them from clamps or tie straps retaining them to engine or hoses.

17. Disconnect trim sender wire connections from engine harness.

18. Disconnect MerCathode controller wires.

19. Close seacock if equipped, or disconnect and plug seawater inlet hose, if boat is to remain in the water.

⚠ CAUTION

Before removing seawater inlet hose, close seacock, if equipped. If boat is not equipped with a seacock, remove and plug seawater inlet hose to prevent a siphoning action that may occur, allowing seawater to flow from the drain holes or removed hoses.


20. Disconnect seawater inlet hose.

21. Disconnect exhaust system hoses.
22. Remove both shift cables from shift plate.
23. **On Engines With Power Shift:** Disconnect vacuum hose from power shift cylinder.
24. Disconnect any grounding wires and accessories that are connected to engine.
25. Disconnect and suitably plug fluid hoses from power steering control valve on transom.

⚠ CAUTION

DO NOT allow lifting sling to hook or compress engine components or damage will occur.

26. Support engine with suitable sling through lifting eyes on engine.

**Typical**


- f** - Front Lifting Eye
- g** - Rear Lifting Eye
- h** - Suitable Sling

27. Remove front and rear engine mounting bolts. Retain fasteners.
28. Carefully remove engine. Do NOT damage power steering control valve.

Installation

Engine Installation / Alignment

1. **On Engines Where Engine Mounts WERE NOT Disturbed:** Proceed to Step 3.
2. **On Engines Where Engine Mounts WERE Disturbed:** Ensure front mount adjusting nuts are positioned midway on studs so that adequate up and down adjustment exists for engine alignment.
3. Lubricate coupler splines with Engine Coupler Spline Grease.





75592

Typical

a - Coupler Splines


4. Attach a suitable sling to lifting eyes on engine and adjust so that engine is level when suspended. Refer to Removal for location of engine lifting eyes.
5. Lift engine into position in boat, using an overhead hoist.

6. Align rear engine mounts with inner transom plate mounts while simultaneously aligning exhaust system. DO NOT relieve hoist tension.



IMPORTANT: Engine attaching hardware must be installed in sequence shown.

7. Install both rear engine mounting bolts and hardware as shown. Torque to 47-54 Nm (35-40 lb-ft).




22032

- a** - Rear Engine Mount
- b** - Inner Transom Plate Mount
- c** - Bolt
- d** - Washer
- e** - Spacer
- f** - Fiber Washer
- g** - Double-Wound Lockwasher
- h** - Locknut (Not Shown)

⚠ CAUTION

When lowering engine into position Do NOT set engine on shift cable. Shift cable outer casing can be crushed causing difficult or improper shifting.

8. Set engine on stringers.
9. Relieve hoist tension and disconnect sling from engine lifting eyes.
10. Install a separate sling between front lifting eyes to help equalize load on hoist during alignment procedure.



- a** - Sling In Starboard Lifting Eye
b - Sling In Port Lifting Eye

11. Attach a suitable hoist to the separate sling.

⚠ CAUTION


Do NOT use an alignment tool from another manufacturer. Alignment tools other than Quicksilver Alignment Tool, may cause improper alignment and damage to gimbal bearing and/or engine coupler.

⚠ CAUTION

To avoid damage to gimbal bearing, engine coupler, or alignment tool:

- Do NOT attempt to force alignment tool!
- Do NOT raise or lower engine with alignment tool inserted (or partially inserted) in gimbal bearing or engine coupler.

12. Attempt to insert the solid end of the alignment tool through the gimbal bearing and into the engine coupler splines.



70013

- a** - Alignment Tool (Use Only Recommended Quicksilver Alignment Tool)
b - Insert This End Of Alignment Tool Through Gimbal Housing Assembly


13. If the alignment tool does not fit, remove it and carefully adjust engine mounts as necessary:

- a. **To Adjust Engine Up or Down:** Loosen locknut on mounts. Turn adjusting nuts as necessary. Retighten locknuts.

IMPORTANT: Large diameter of mount trunion **MUST NOT** extend over 19 mm (3/4 in.) from edge of mount bracket to centerline of mount stud.

- b. **To Move Engine Left or Right:** Loosen trunion clamping bolts on both front mounts and move engine as necessary. Do NOT over-extend mount trunion. Retighten locking nuts.

NOTE: A small amount of side-to-side adjustment can be obtained from the slots on the engine mount pads.



23161


Typical

- a - Locknut
- b - Bracket
- c - Mount Adjustment Nut
- d - Lag Bolts
- e - Clamp
- f - Clamp Spread-Screw
- g - Nuts

14. Attempt to insert the solid end of the alignment tool.

- a. Repeat step 13. and 14. until the alignment tool installs easily (**SLIDES FREELY WITH TWO FINGERS**) all the way into and out of engine coupler splines. Do not check by turning.

NOTE: This may require tapping the sides of the tool. Do NOT check by turning. By greasing the splines you can identify which side has interference.



- a** - Alignment Tool
- b** - Gimbal Bearing
- c** - Engine Coupler

15. Front engine mounts must rest on boat stringer. Adjust front engine mounts if necessary.


16. Relieve hoist tension entirely.

17. On port front mount do as follows:

- a. Position ECM assembly mounting bracket holes directly over front, port engine mount holes.

NOTE: It may be necessary to lower, or raise, the ECM assembly and bracket in slotted hole, depending upon the final configuration of the power package, to position ECM on front mount.

- b. Fasten ECM mounting bracket and front mount assembly to boat stringer using appropriate hardware (lag bolts or through bolts etc.).



- a - ECM Assembly Mounting Bracket
- b - Front, Port Engine Mount
- c - Stringer
- d - Slotted Hole For Raising Or Lowering ECM Assembly

18. Tighten both front mounts onto boat stringers using appropriate hardware.


19. Recheck alignment with alignment tool. Tool must enter coupler splines freely. If not, readjust front mounts.

NOTE: Turn mount adjustment nut left to lower, and right to raise, the front of the engine. Loosen nuts on mount clamping bolts to move bracket side-to-side.

75301

20. When alignment is correct, tighten locknuts and jam nuts securely.

NOTE: Coat both nuts and threaded portion of mount with *Perfect Seal* if used in a saltwater environment to reduce rust and ease of serviceability.



23161

Typical

- a** - Locknut
- b** - Bracket
- c** - Mount Adjustment Nut
- d** - Lag Bolts
- e** - Clamp
- f** - Nuts
- g** - Clamp Spread-Screw

21. Remove alignment tool.

22. Remove chain sling from lifting eyes.


23. Install sterndrive unit. Refer to appropriate Mercury MerCruiser Sterndrive Service Manual.

Engine Connections

1. Connect power steering hoses to control valve as shown.

IMPORTANT: Make hydraulic connections as quickly as possible to prevent oil leakage.


IMPORTANT: Be careful not to cross-thread or overtighten hose fittings.



74249

- a** - Rear Fitting (Pressure Hose)
- b** - Front Fitting (Return Hose)

2. Tighten exhaust tube hose clamps securely.




Typical

- a** - Exhaust Tube
- b** - Hose Clamps (4)

3. Connect continuity circuit wire from engine to transom assembly. Tighten screw securely.


IMPORTANT: Do not attach any accessory ground (-) wires to transom plate ground point.



73567

- a** - Flywheel Housing Screw
- b** - Continuity Circuit Wire
- c** - Inner Transom Plate Grounding Screw

4. Connect any grounding wires and accessories that were connected to engine.
5. Connect seawater inlet hose to engine water inlet fitting. Tighten hose clamp securely.




75299

Typical

- a** - Seawater Inlet Hose
- b** - Connector Fitting


6. Connect coolant recovery bottle hose to heat exchanger and secure with clamp.




70548

- a** - Hose
b - Clamp

7. Connect MerCathode wires to MerCathode controller mounted on engine. Apply a thin coat of Liquid Neoprene to ALL electrical connections.




22232



71709

- a** - ORANGE Wire - From Electrode On Transom Assembly
b - RED/PURPLE Wire - Connect (other end) To Positive (+) Battery Terminal
c - BLACK Wire - From Engine Harness
d - BROWN Wire - From Electrode On Transom Assembly
e - Controller Assembly Location


8. Connect the trim position sender bullet connectors, from the gimbal housing, to the engine harness.



24841

- a** - From Engine Harness
b - From Gimbal Housing

9. Mount the gear lube monitor in the engine bracket. Secure with strap.
10. Connect gear lube monitor wires to corresponding engine harness wires. The TAN/BLU wire connects to ORANGE engine harness wire. BLACK wire connects to BLACK wire. Ensure that bullet connectors are fully seated.




75301

Typical

- a** - Gear Lube Monitor
b - Strap
c - Bullet Connectors

11. Connect instrument extension harness ends to engine harness ends. Connector collars must be fully engaged and secure. Tighten *threaded* connector collar of extension harness onto connector on side of electrical box.



Standard And 21-Pin Deutsch™ Connections


- a** - Extension Harness From Instruments
- b** - Engine Harness and Connector End
- c** - Connector Collar
- d** - Location of Electrical Box
- e** - Electrical Box - With Standard Connectors
- f** - Electrical Box - With 21-Pin Deutsch™ Connector

12. After all wires are connected, secure them with clamps or tie straps which may have been retaining them to engine or hoses prior to removal.

⚠ WARNING

Be careful when working on fuel system components; diesel fuel is flammable. Be sure that the ignition key is OFF. Do NOT smoke or allow sources of open flame in the area while working on fuel system components. Wipe up any spilled fuel immediately. Do NOT allow fuel to come into contact with any hot surface which may cause it to ignite.


13. Connect flexible fuel line to inlet fitting on fuel pump. Secure with hose clamp.



75298

- a** - Fuel Line
- b** - Hose Clamp
- c** - Inlet Fitting

14. Connect flexible return fuel line to injection pump return line fitting. Secure with hose clamp.



75579

- a** - Return Fuel Line
- b** - Hose Clamp
- c** - Return Fitting

⚠ WARNING


Dispose of fuel-soaked rags, paper, etc., in an appropriate air tight, fire retardant container. Fuel-soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

15. **On Engines with Power Shift:** Attach vacuum hose from power shift cylinder to vacuum pump fitting. Tighten hose clamp securely.

Throttle Cable Installation and Adjustment

IMPORTANT: When installing throttle cables, be sure that cables are routed in such a way as to avoid sharp bends and/or contact with moving parts. Do NOT fasten any items to throttle cables.

1. Unless previously installed, install throttle cable end guide anchor stud in middle hole of throttle position sensor lever.




75301

- a** - Throttle Position Sensor
- b** - Throttle Cable End Guide Anchor Stud Location

2. Place remote control lever(s) in NEUTRAL/IDLE position.
3. Unless previously installed, install the throttle cable barrel end guide anchor stud in the cable barrel end bracket hole that is closest to the distance of 181 mm (7-1/8 in.) from the center of the throttle position sensor anchor stud.

4. Install the cable end guide on the throttle lever, then push cable barrel end lightly toward throttle lever end. This will place a slight preload on the shift cable to avoid slack in the cable when moving remote control lever.
5. Adjust barrel on throttle cable to align with stud in anchor bracket. Ensure the hole in the barrel positions the cable as shown.
6. Install the cable and secure with hardware as shown.
7. Tighten locknuts until they bottom and loosen 1/2 turn.



75332

- a** - Throttle Cable End Guide
- b** - Cable Barrel
- c** - Anchor Stud
- d** - Flat Washer and Locknut
- e** - Spacer (If Required)


8. Place remote control lever in full forward, wide open throttle (WOT) position.
9. Check to ensure throttle position sensor lever is contacting internal override spring. Be certain that the cable is not causing the throttle position sensor to be over-pulled. Check to ensure that remote control and cable are providing proper output.
10. Place remote control lever in NEUTRAL / IDLE position and, if necessary, readjust throttle cable barrel.
11. Recheck that (when operated) throttle position sensor lever contacts internal override spring, indicating WOT or 100% throttle position.

Shift Cable Installation and Adjustment

NOTE: Shift Cable Adjustment Tool (91-12427) allows the shift cables to be installed and adjusted, with or without the sterndrive attached.

IMPORTANT: The direction of propeller rotation (RH or LH) for this drive unit is determined by the following method.


1. Determine desired propeller rotation according to a., b., or c.:
 - a. All Bravo One / Two - If shift cable end guide moves in direction "A" when control lever is placed in FORWARD, remote control is setup for RIGHT HAND (RH) propeller rotation.
 - b. All Bravo One / Two - If shift cable end guide moves in direction "B" when control lever is placed in FORWARD, remote control is setup for LEFT HAND (LH) propeller rotation.



71656

All Bravo One / Two

- c. All Bravo Three - Front propeller on drive unit is always LH Rotation and rear propeller is always RH Rotation. Shift cable end guide must move in direction "A," when control lever is placed in FORWARD gear position.




71656

All Bravo Three

IMPORTANT: When installing shift cables, be sure that cables are routed in such a way as to avoid sharp bends and/or contact with moving parts. Do NOT fasten any items to shift cables.

2. Install shift cable into remote control. Refer to appropriate remote control instructions.
3. Loosen stud and move it to dimension as shown. Re-tighten stud.




23345

a - Stud

b - 76 mm (3 in.) - Center of Pivot Bolt to Center of Stud

4. Install drive unit shift cable. Tighten locknut until it contacts end guide, then loosen 1/2 turn. Insert cotter pin from the top and spread both ends.




23345

a - Washers (2)

b - Locknut


c - Cotter Pin

5. Place adjustment tool over drive unit shift cable. Hold tool in place, using a piece of tape over the barrel retainer.



23242

- a. Shift remote control to NEUTRAL.
- b. Push in on shift cable end with enough pressure to remove play, and mark position "a" on tube.
- c. Pull out on shift cable end with enough pressure to remove play, and mark position "b" on tube.
- d. Measure distance between marks "a" and "b" and mark position "c" half-way between marks "a" and "b."



22024


IMPORTANT: Be sure to keep center mark "c" aligned with remote control shift cable end guide edge when making the following adjustment.

6. Adjust remote control shift cable as follows:
 - a. Temporarily install shift cable end guide into shift lever, and insert anchor pin.
 - b. Adjust shift cable barrel so that hole in barrel centers with vertical centerline of stud. Ensure that backlash center mark is aligned with edge of control cable end guide.

⚠ CAUTION

Do NOT attempt to install or remove remote control shift cable barrel from stud, without first removing end guide anchor pin from shift lever, and removing cable. Attempting to bend shift cable to install or remove barrel, will place undue stress on cable end guide and shift lever, and damage to both could occur.


- c. Remove shift cable end guide from shift lever by removing anchor pin.



23242

- a** - Remote Control Shift Cable End Guide
- b** - Anchor Pin
- c** - Backlash Center
- d** - Remote Control Shift Cable Barrel
- e** - Stud

7. Install remote control shift cable. Tighten locknut until it contacts cable end guide. Insert cotter pin from the top and spread both ends.



23242


- a** - Locknut
- b** - Washers - Both Sides of Barrel
- c** - Anchor Pin
- d** - Cotter Pin (Not Visible)

8. Remove adjustment tool.
9. Shift remote control lever into full forward position. Place end of adjustment tool in barrel retainer.

Rh Rotation - All Bravo One, Two, And Three Models: Rear slot in tool should fit over shift lever stud.


Lh Rotation - All Bravo One And Two Models: Forward slot in tool should fit over shift lever stud.

If slot does not fit over stud, loosen shift lever stud and slide stud either direction, until slot in tool fits over stud. When adjustment is correct, retighten stud.



23242

RH Rotation - All Bravo One, Two, Three



23242

LH Rotation - All Bravo One And Two

- a** - Adjustment Tool
- b** - Barrel Retainer
- c** - Shift Lever Stud
- d** - Shift Lever Adjustment Slot


10. Remove adjustment tool.
11. Lubricate shift cable pivot points with 30W engine oil.

Troubleshooting Shift Problems


NOTE: The following information is provide to assist an installer in troubleshooting, if hard shifting or chucking/racheting is encountered when shifting into forward gear.

1. When installing the control box in the side panel of the boat, ensure that the cables have enough clearance to operate. This is necessary because the cables move up and down when the shift handle is moved. If the control box is mounted too far back towards any fiberglass structure, the cables will be interfered with, this will cause very hard shifting.

NOTE: The control box housing can be rotated in 30° increments to improve cable routing.




Proper Cable Bend



Improper Cable Bend

2. Ensure that when the shift cable from the control box is lead through the side gunnel of the hull, that it does not have any extremely sharp bends in it as this will cause the stiff shifting.

3. Before installing the shift cable into the control box, extend the stainless rod eye end of the cable and grease it with 2-4-C Marine Lubricant with Teflon. Move it back and forth to allow even distribution of the grease.



22005

4. Do not strap or clamp the control cables to any other cables or rigid structure within 9 m (3 ft) of the control box.
5. Ensure that the cable is not permanently kinked.
6. Make sure there is proper clearance for cable movement when the control box is installed in the side panel. The cables must have room to move up and down when the control handle is shifted into either forward or reverse.
7. Check to make sure that the engine was not set down on the intermediate shift cable during installation, this will crush the inner cable tubing and cause improper and/or stiff shifting.
8. Do NOT fasten the shift cable with straps or clamps to any other cable within 1.5 m (5 ft) of the shift plate.
9. Do NOT fasten the shift cable to the transom with any type of plastic clips or fasteners within 1.5 m (5 ft) of the shift plate.
10. Do NOT overtighten the throttle or shift cable attaching nuts at the engine end. Barrel and cable end must be free to rotate on the mounting stud.

Battery Cables

1. Connect battery cables to engine:
 - a. Make sure that grounding stud and starter solenoid terminal are free of paint and any other material that could cause a poor electrical connection.
 - b. After battery cables are connected, apply a thin coat of Liquid Neoprene to the terminals.
 - c. Be sure to slide rubber boot over the positive (+) terminal after Liquid Neoprene dries.
2. Connect battery cables to battery by FIRST connecting positive (+) battery cable (usually red) to positive (+) battery terminal. Tighten clamp securely. Then, connect negative (–) battery cable (usually black) to negative (–) battery terminal. Tighten clamp securely.

NOTE: *Spray terminals with a battery connection sealant to help retard corrosion.*

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

REMOVAL AND INSTALLATION

Section 2B - Inboard (MIE) Models

Table of Contents

Torque Specifications	2B-3	Engine Final Alignment	2B-11
Tools/Lubricants/Adhesives	2B-3	Engine Connections	2B-18
Removal	2B-4	Throttle Cable Installation and	
Engine Removal	2B-4	Adjustment	2B-21
Installation	2B-7	Shift Cable Installation And	
Engine Installation and Initial		Adjustment	2B-21
Alignment	2B-7	Battery Cables	2B-21

THIS PAGE IS INTENTIONALLY BLANK

NOTICE

For information and procedures on Troubleshooting, refer to SECTION 1C.

Torque Specifications

Description	Nm	lb-in.	lb-ft
Coupler to Flywheel	34		25
Transmission Flange to Flywheel Housing	68		50
Trunnion Clamp Bolt	68		50
Front Engine Mount Bracket to Engine Block	75		55
Transmission Mount Bracket to Transmission Housing	75		55
Rear Engine Mount Rubber Bushing Center Bolt	61		45
Engine Mount Locking (Jam) Nuts	80		59
Transmission Output Flange to Propeller Shaft Coupler Bolts	68		50
Remote Control Throttle and Shift Cable Barrel Attaching Nut	Securely		
Remote Control Throttle and Shift Cable End Guide Attaching Nut	Tighten Nut Until It Contacts Flat Washer; then, Back Nut Off 1/2 Turn		

Lubricants/Sealants/Adhesives

Description	Part Number
Liquid Neoprene	92-25711-3
Battery Terminal Sealant	Obtain Locally

Removal

Engine Removal

CAUTION

It is good practice to ventilate the engine compartment prior to servicing any engine components to remove any fuel vapors which may cause difficulty breathing or be an irritant.

3. Disconnect battery cables from battery.
4. Disconnect battery cables from engine.
5. Disconnect extension harness connector plug from engine harness connector.

WARNING

FIRE HAZARD: Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death.

WARNING

Be careful when working on fuel system components; diesel fuel is flammable. Ensure that the ignition key is OFF. Do NOT smoke or allow sources of open flame in the area while changing fuel system components. Wipe up any spilled fuel immediately. Do NOT allow fuel to come into contact with any hot surface which may cause it to ignite.

WARNING

Dispose of fuel-soaked rags, paper, etc., in an appropriate airtight, fire-retardant container. Fuel-soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

6. Close fuel shut off valve, if equipped.
7. Disconnect and suitably plug fuel lines to prevent fuel in tank from leaking into bilge.

8. Disconnect throttle cable from engine.
9. Disconnect shift cable from transmission.
10. Close seacock if equipped, or disconnect and plug seawater inlet hose, if boat is to remain in the water.

⚠ CAUTION

Before removing seawater inlet hose, close seacock, if equipped. If boat is not equipped with a seacock, remove and plug seawater inlet hose to prevent a siphoning action that may occur, allowing seawater to flow from the drain holes or removed hoses.


11. Disconnect seawater inlet hose.
12. Disconnect exhaust system hoses.
13. Disconnect any grounding wires and accessories that are connected to engine.
14. Disconnect coolant recovery bottle hose from heat exchanger.
15. Disconnect propeller shaft coupler from transmission output flange. On models with V-Drive transmissions, remove propeller shaft coupler.

NOTE: *It may be necessary to remove the propeller shaft prior to engine removal on engines with V-Drive transmissions.*


⚠ CAUTION

Do NOT allow lifting sling to hook or compress engine components or damage will occur.

16. Support engine with suitable sling through lifting eyes on engine.



75298




71706


Typical

- e**-Front Lifting Eye
- f**-Rear Lifting Eye
- g**-Suitable Sling

17. Remove front and rear engine mounting bolts. Retain fasteners.



23161



75301

Typical Front Mounts Shown (All Similar)

- a**-Starboard Mounting Bolt
- b**-Port Mounting Bolt

18. Carefully remove engine with transmission.

Installation

Engine Installation and Initial Alignment


1. Engine mount or mount adjustment **WAS NOT DISTURBED** during engine service: Proceed to following Step 3.

2. Engine mount or mount adjustment **WAS DISTURBED** during engine service:


IMPORTANT: Engine mounts must be adjusted, as explained in the following, to center mount adjustment and establish a uniform height on all mounts.

Ensure that:

- All mounts are in the center of their up-and-down adjustment.
- Large diameter of mount trunnion extended no more than 19 mm (3/4 in.).
- Each mount base is downward. Tighten clamping screws and nuts slightly to prevent moving in or out. Mounts must be free to pivot when installing engine.




Typical Front Mount



Typical Rear Mount

- a-**Trunnion Clamping Bolt and Nut
b-Mount Trunnion Extension

- d. Ensure rear engine mount rubber bushings are positioned so that slots in bushing are positioned horizontally. If necessary, loosen center bolt and turn bushing. Torque to 41-61 Nm (30-45 lb-ft).



50688

- a**-Rubber Bushing
- b**-Slots
- c**-Bolt

3. Attach a suitable sling to lifting eyes on engine and adjust so that engine is level when suspended. Refer to Removal for location of engine lifting eyes.


⚠ CAUTION

Do NOT allow lifting sling to hook or compress engine components or damage will occur.

MODELS WITH 8° DOWN ANGLE TRANSMISSIONS

1. Lift engine into boat and position on engine bed so that transmission output flange and propeller shaft coupler are visibly aligned (no gap can be seen between coupling faces when butted together). **Adjust engine bed height** if necessary to obtain proper alignment. Do NOT use mount adjustments to adjust engine position at this time.

IMPORTANT: Engine bed must position engine so that a minimum of 6 mm (1/4 in.) up and down adjustment still exists on all 4 mounts after performing initial alignment. This is necessary to allow for final engine alignment.



74546

Typical Transmission Shown


- a**-Propeller Shaft
- b**-Propeller Shaft Coupler
- c**-Transmission Output Flange

2. Ensure that all four mounts are still positioned properly, then fasten mounts to engine bed with appropriate lag bolts or screws and hardware. Tighten lag bolts or screws securely.
3. Disconnect and remove sling. Proceed to Engine Final Alignment section.

MODELS WITH V-DRIVE TRANSMISSIONS


1. Lift engine into boat and position so that enough propeller shaft protrudes through transmission and output flange for propeller shaft coupler to be attached. Then install coupler and position engine (no gap can be seen between coupling faces when butted together). **Adjust engine bed height** if necessary to obtain proper alignment. Do NOT use mount adjustments to adjust engine position at this time.

IMPORTANT: Engine bed must position engine so that a minimum of 6 mm (1/4 in.) up and down adjustment still exists on all 4 mounts after performing final alignment. This is necessary to allow for final engine alignment.




75534

Velvet Drive



50608



50608

Hurth 630V

- a**-Propeller Shaft
- b**-Propeller Shaft Coupler
- c**-Transmission Output Flange
- d**-No Gap Allowed

2. Ensure that all four mounts are still positioned properly, then fasten mounts to engine bed with appropriate lag bolts or screws and hardware. Tighten lag bolts or screws securely.
3. Disconnect and remove sling. Proceed to Engine Final Alignment section following.

Engine Final Alignment


CAUTION

To avoid vibration, noise and damage to transmission output shaft oil seal and bearings, engine must be properly aligned.

IMPORTANT: Engine alignment **MUST BE RECHECKED** with boat in the water, fuel tanks filled and with a normal load on board.

Engine must be aligned so that transmission output flange and propeller shaft coupler centerlines are aligned and coupling faces are parallel within 0.07 mm (0.003 in.). This applies to installations with solid couplings, as well as flexible couplings.


1. Ensure that mating surfaces on transmission output flange and propeller shaft coupler faces are clean and flat.
2. Center propeller shaft in shaft log as follows:
 - a. Push down and then lift shaft as far as it will move. Then place shaft in the middle of the movement.
 - b. Move shaft to port and then to starboard as far as shaft will move. Then place shaft in the middle of the movement.
 - c. With shaft in center of shaft log, as determined by above procedures a. and b. align engine to shaft.




72595

- a**-Propeller Shaft
- b**-Propeller Shaft Coupler
- c**-Transmission Output Flange


3. Ensure that coupling centerlines align, by butting propeller shaft coupler against transmission output flange. Shoulder on propeller shaft coupler should engage recess on transmission output flange face with no resistance.



INCORRECT




CORRECT



INCORRECT

72597


NOTE: Some propeller shaft couplers may not have a shoulder on mating face. On these installations, use a straight edge to check centerline alignment.




72598

- a**-Feeler Gauge
- b**-Transmission Coupling
- c**-Propeller Shaft
- d**-Straight Edge

4. Check for angular misalignment, by hand holding coupling faces tightly together and checking for a gap between coupling faces with a 0.07 mm (0.003 in.) feeler gauge at 90 degree intervals.



50688



50608


Typical Down Angle Transmission (All Similar)

- a**-Propeller Shaft Coupler
- b**-Feeler Gauge
- c**-Transmission Output Flange
- d**-Check Point Intervals

Typical V-Drive

5. If coupling centerlines are not aligned or if coupling faces are more than 0.07 mm (0.003 in.) out of parallel, adjust engine mounts as follows:
 - a. TO ADJUST ENGINE UP OR DOWN: Loosen locking nut on mounts requiring adjustment and turn both front mount or rear mount adjusting nuts equally.

IMPORTANT: Both front mount or rear mount adjusting nuts must be turned equally to keep engine level from side to side.



23161


Front Mount Shown (All Similar)

- a**-Locking (Jam) Nut
- b**-Adjusting Nut


- b. TO MOVE ENGINE TO THE LEFT OR RIGHT: Loosen clamping screw and nut on all four mount brackets; move engine to the left or right as necessary to obtain proper alignment. Torque clamping screws and nuts to 68 Nm (50 lb-ft).

NOTE: A small amount of side-to-side adjustment can also be obtained from the slots on the engine mount pad (front pads only). Loosen lag bolts (which fasten mounts to engine bed) and move engine, as required. Tighten lag bolts securely.

IMPORTANT: Large diameter of mount trunnion **MUST NOT** extend over 19 mm (3/4 in.) from mount brackets on any of the mounts.



Front Mounts



Rear Mounts


- a-**Clamping Bolts and Nuts
b-Mount Trunnion Maximum Extension

c. After engine has been properly aligned, relieve hoist tension entirely. Secure mounts to stringers using appropriate hardware. On port front mount do as follows:

(1.) Position ECM assembly mounting bracket holes directly over front, port engine mount holes.

NOTE: It may be necessary to lower, or raise, the ECM assembly and bracket, depending upon the final configuration of the power package, to position ECM on front mount.

(2.) Fasten ECM mounting bracket and front mount assembly to boat stringer using appropriate hardware (lag bolts or thru-bolts etc.).



75301

a-ECM Assembly Mounting Bracket

b-Front, Port Engine Mount


c-Stringer

d-Slotted Hole For Raising Or Lowering ECM Assembly

6. Connect propeller shaft coupler to transmission output flange following instructions a. or b.:

IMPORTANT: All coupler bolts must be Metric Grade 10.9 (SAE Grade 8) or better, with a shoulder (grip length) sufficient to pass through the mating face plane of couplers.

- a. **All Couplings Without Propeller Shaft Set Screws:** Secure coupling together with bolts, lockwashers and nuts. Torque to 68 Nm (50 lb-ft).




Hurth 8 Degree Down Angle Transmission Shown (All Similar)

- a-**Propeller Shaft Coupler
- b-**Bolts (4)
- c-**Lockwasher and Nut (4)
- d-**Transmission Output Flange

b. Couplings with Propeller Shaft Set Screws:

- (1.) If propeller shaft coupler has set screws, remove set screws and mark (dimple) locations using a transfer punch.




50609

Hurth V-Drive Shown (All Similar)

- a-**Set Screw Location
b-Transfer Punch

- (2.) Remove propeller shaft coupler and drill shallow dimples at locations marked with punch.
- (3.) Reinstall propeller shaft coupler and torque bolts to 68 Nm (50 lb-ft). Install set screws and tighten securely. Safety wire set screws to ensure they Do NOT back out.



50608

Hurth V-Drive Shown (All Similar)

- a-**Propeller Shaft Couple
b-Bolts (4), with Lockwashers and Nuts (4)
c-Set Screws
d-Safety Wire
e-Transmission Output Flange


Engine Connections

⚠ CAUTION

It is good practice to ventilate the engine compartment prior to servicing any engine components to remove any fuel vapors which may cause difficulty breathing or be an irritant.

IMPORTANT: When routing all wire harnesses and hoses, ensure they are routed and secured to avoid coming in contact with hot spots on engine and avoid contact with moving parts.

1. Connect instrument extension harness ends to engine harness ends. Connector collar must be fully engaged and secure. Tighten *threaded* connector collar of extension harness onto connector on side of electrical box.



Harness Connections


- a**-Extension Harness From Instruments
- b**-Engine Harness and Connector End
- c**-Connector Collar
- d**-Location of Electrical Box
- e**-Electrical Box - With Standard Connectors
- f**-Electrical Box - With 21-Pin Connector

2. Connect any ground wires or accessories that were disconnected from engine.

⚠ WARNING

Be careful when working on fuel system components; diesel fuel is flammable. Ensure that the ignition key is OFF. Do NOT smoke or allow sources of open flame in the area while changing fuel system components. Wipe up any spilled fuel immediately. Do NOT allow fuel to come into contact with any hot surface which may cause it to ignite.


3. Connect flexible fuel line to inlet fitting on fuel pump. Secure with hose clamp.



75298

- a**-Fuel Line
- b**-Hose Clamp
- c**-Inlet Fitting
- d**-Fuel Pump

4. Connect flexible return fuel line to injection pump fuel return line fitting. Secure with hose clamp.




75579

- a**-Return Fuel Line
- b**-Return Fitting
- c**-Hose Clamp

⚠ WARNING

Dispose of fuel-soaked rags, paper, etc., in an appropriate airtight, fire-retardant container. Fuel-soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

5. After all wires are connected secure them with clamps or tie straps, which may have been retaining them to engine or hoses prior to removal.
6. Connect exhaust elbow, riser or water lift muffler, if equipped, to exhaust system hose using at least two hose clamps at each connection. Tighten hose clamps securely.
7. Connect seawater inlet hose to seawater pump connector fitting. Tighten hose clamp securely.




75299

Typical

- a**-Seawater Inlet Hose
- b**-Connector Fitting


8. If removed previously, connect seawater inlet hose to seawater strainer and tighten hose clamps securely.



71362

- a**-Seawater Inlet Hose
- b**-Seawater Strainer
- c**-Hose Clamps (2)

9. Connect coolant recovery bottle hose to heat exchanger and secure with clamp.



70548

a-Hose
b-Clamp

Throttle Cable Installation and Adjustment

Refer to SECTION 2A.

Shift Cable Installation And Adjustment

Refer to SECTION 8A.

Battery Cables

1. Connect battery cables to engine:
 - a. Make sure that grounding stud and starter solenoid terminal are free of paint and any other material that could cause a poor electrical connection.
 - b. After battery cables are connected, apply a thin coat of liquid neoprene to the terminals.
 - c. Slide rubber boot over the positive (+) terminal after liquid neoprene dries.
2. Connect battery cables to battery by FIRST connecting positive (+) battery cable (usually red) to positive (+) battery terminal. Tighten clamp securely. Then, connect negative (–) battery cable (usually black) to negative (–) battery terminal. Tighten clamp securely.

NOTE: Spray terminals with a battery connection sealant to help retard corrosion.

THIS PAGE IS INTENTIONALLY BLANK

ENGINE

Section 3A - Engine Mechanical


Table of Contents

Identification	3A-3	Installation	3A-34
Torque Specifications	3A-4	Water Manifold	3A-37
Tools	3A-6	Exploded Views	3A-37
Special Tools	3A-6	Removal	3A-38
Special Tools (continued)	3A-7	Cleaning	3A-38
Snap-On Tools	3A-8	Inspection	3A-38
Kent-Moore Tools	3A-8	Installation	3A-39
Lubricants/Sealants/Adhesives	3A-9	Cylinder Heads	3A-40
Engine Specifications	3A-10	Exploded Views	3A-40
Piston Rings	3A-10	Removal	3A-42
Cylinder Liner Diameter	3A-10	Disassembly	3A-44
Cylinder Liner Protrusion	3A-11	Cleaning	3A-44
Head Gaskets	3A-11	Inspection	3A-45
Cylinder Head	3A-11	Repair	3A-50
Oil Pump	3A-12	Expansion Plugs	3A-50
Camshaft	3A-12	Assembly	3A-52
Valve Lifter	3A-12	Installation -	
Rocker Arm	3A-13	Using Early Model Gaskets	3A-55
Valve Adjustment	3A-13	Installation -	
Valve	3A-13	Using Late Model Gaskets	3A-62
Valve Seat	3A-13	Rocker Arm	3A-71
Valve Guide	3A-14	Removal	3A-71
Valve Spring	3A-14	Cleaning	3A-71
Crankshaft	3A-15	Inspection	3A-71
Crankshaft (continued)	3A-16	Assembly	3A-72
Connecting Rods	3A-17	Installation	3A-73
Connecting Rod Crank Pin Bore	3A-17	Timing Gear Cover	3A-77
Connecting Rod Bushings	3A-17	Exploded View	3A-77
Pistons	3A-17	Removal	3A-78
Flywheel	3A-17	Cleaning	3A-78
Precautions	3A-18	Inspection	3A-78
General Information	3A-19	Installation	3A-79
Engine Rotation	3A-19	Oil Pump	3A-81
Engine Firing Order	3A-19	Removal	3A-81
Late Model Cylinder Head Gasket -		Cleaning	3A-81
Torque Sequence and Specifications	3A-20	Inspection	3A-82
Early Model Cylinder Head Gasket -		Reassembly	3A-83
Torque Sequence and Specifications	3A-25	Installation	3A-83
Lubrication System - All Models	3A-28	Oil Pressure Relief Valve	3A-84
Examples of Bearing Failures	3A-29	Removal	3A-84
Compression Testing Procedure	3A-30	Disassembly	3A-85
Engine Cover	3A-31	Cleaning	3A-85
Removal	3A-31	Inspection	3A-86
Cleaning	3A-31	Assembly	3A-86
Inspection	3A-31	Installation	3A-87
Installation	3A-31	Oil Pan and Oil Pick-Up Tube Assembly	3A-88
Valve Covers	3A-32	Removal	3A-88
Removal	3A-32	Cleaning	3A-89
Cleaning	3A-33	Inspection	3A-89
Inspection	3A-33	Installation	3A-89

Table of Contents (continued)

Adapter / Oil Thermostat	3A-91	Cleaning	3A-109
Removal	3A-91	Inspection	3A-109
Disassembly	3A-92	Assembly	3A-113
Cleaning and Inspection	3A-92	Installation	3A-114
Testing	3A-92	Rear Oil Seal	3A-116
Installation	3A-93	Removal	3A-116
Camshaft	3A-95	Installation	3A-117
Exploded View	3A-95	Crankshaft and Main Bearings	3A-118
Testing - Measuring Lobe Lift	3A-96	Removal	3A-118
Removal	3A-96	Cleaning	3A-123
Inspection	3A-98	Inspection	3A-124
Installation	3A-99	Installation	3A-127
Camshaft Bearings	3A-100	Cylinder Liners	3A-136
Inspection	3A-100	Removal	3A-136
Removal	3A-100	Identification	3A-137
Installation	3A-101	Cleaning and Inspection	3A-138
Valve Lifters	3A-102	Installation	3A-139
Removal	3A-102	Flywheel Housing, Coupler / Drive Plate And	
Cleaning	3A-103	Flywheel	3A-144
Inspection	3A-103	Exploded View	3A-144
Installation	3A-104	Flywheel Housing	3A-148
Valve Push Rods	3A-105	Sterndrive (MCM) Coupler / Inboard (MIE)	
Removal	3A-105	Drive Plate	3A-150
Cleaning	3A-105	Flywheel	3A-151
Inspection	3A-105	Engine Mounts	3A-152
Installation	3A-105	Front Mounts	3A-152
Connecting Rod / Piston Assembly	3A-106	MIE (Inboard) Transmission Mounts .	3A-153
Measuring Rod Bearing Clearance ..	3A-106	Engine 20-Hour Break-In Period	3A-154
Removal	3A-107	After Break-in Period	3A-154
Disassembly	3A-108		

Identification



Typical Sterndrive (MCM) Engine Shown - Inboard (MIE) Similar

- a** - Serial Number Plate
- b** - Manufacturer's Serial Number

The engine model and serial numbers are located on a sticker attached to the port side of the engine. The manufacturer's serial number is stamped in the cylinder block.

Torque Specifications

Description		Nm	lb-in.	lb-ft
Alternator Bracket Bolt	M12x1.75	68.6		50
Alternator Brace To Timing Cover		45-50		34-37
Camshaft Flange Mounting Screw	M8x1.25	27.5		20
Connecting Rod Bolt	M11x1	29.4 + 60 degrees		21 + 60 degrees
Crankshaft Pulley Nut ³	M24x1.5	196.2		144
Cylinder Head Bolts				
		14mm Dia. ²	See ¹ .	
		12mm Dia. ²		
Engine Mount	M10x1.5	68.6		50
Flywheel Housing				
	To Block	M10x1.5	50	37
	Rear Main Bearing Carrier Nut	M8x1.25	27.5	20
	Rear Portion	M10x1.5	50	37
Flywheel ²	M12x1.25	110		81
Glow Plug		23		17
Idler Gear Mounting Screw	M 8 x 1.25	27.5		20

¹ : Along with the application of conventional torque, all D2.8L D-Tronic and D4.2L D-Tronic diesel engines will require cylinder head torque with a suitable wrench using a Torque Angle Gauge (obtain locally). Refer to Late Model Cylinder Head Gasket - Torque Sequence and Specifications, Early Model Cylinder Head Gasket - Torque Sequence and Specifications, or Cylinder Head section.

² : Bolts may be used a maximum of 3 times within the prescribed torque limits.

³ : Use Loctite 222 on threads.

Torque Specifications (Continued)

Description		Nm	lb-in.	lb-ft
Main Bearing Carrier Halves Bolt ¹	M10x1.5	44.1		32
Main Bearing Carrier Locating Hollow Bolt	M14x1.5	53.9		39
Inboard (MIE) Drive Plate		72		53
Sterndrive MCM Coupler		30		22
Oil Drain Plug	M22x1.25	78.5		57
Oil Pan Screws	M6x1.0	12.7	112	
Oil Pressure Relief Valve Assembly		53.9		39
Oil Pump Screw	M8x1.25	27.5		20
Oil Pick-up Tube Screw		11	97	
Oil Adapter / Thermostat Housing Fitting		60		44
Power Steering Pump Mounting Bolt		21		15
Rocker Arm Support Flanged Nut	M8x1.25	34		25
Timing Gear Cover				
	M6x1.0	10.8	95	
	M8	10.8	95	
Valve Cover	M6x1.0	11.5	101	
Vibration Damper (Balancer)	M10x1.5	83.4		61
Water Manifold	M6x1.0	11.8	104	
Water Pump	M8x1.25	24.5		18
Water Pump Pulley	M8x1.25	27.5		20

¹ : Bolts may be used a maximum of 3 times within the prescribed torque limits.

Tools

Special Tools

Description	Part Number
Compression Tester Adaptor	91-881737
Crankshaft Pulley Puller	91-801333507
Crankshaft Gear Puller	91-801333503
Crankshaft Installer	91-801333504
Crankshaft Tool (Rotating)	91-814827
Cylinder Head Guide Pin	91-801333501
Cylinder Liner Puller	91-801333502
Dial Indicator	91-58222A1
Flywheel Holder	91-801333506
Flywheel Seal Installer	91-801111260
Front Main Bearing and Camshaft Bearing Puller	91-801333508
Injection Pump Adaptor Tool ¹	91-854220
Injection Pump Gear Puller ¹	91-818372
Liner Gauge Bar, Metric ²	91-801333509
Liner Gauge Bar, SAE ³	91-814812A1
Graduated Disc (Timing) ⁴	91-801333500
Piston Ring Expander	91-24697
Support Block	91-814812A1

¹ : For use on D2.8L D-Tronic and D4.2L D-Tronic

² : For use with millimeter dial gauge.

³ : For use with SAE dial gauge.


⁴ : Some modification may be required for use on some models.

Special Tools (continued)

Description	Part Number
Cylinder Head Service Tool Kit (For Special Cylinder Head Bolts) ⁵	806563A1

⁵ : Refer to the following special information about modification of this tool.

NOTE: The 12 mm Triple Square special tool for cylinder head torque can be modified to allow the oil feed line to the rocker arms to remain installed during retorquing of the cylinder heads.



76067

- a** - 12 Point Triple Square
- b** - Modified Area
- c** - 12.8 mm (0.50 in.) Across Flats Hex
- d** - 12.8 mm (0.50 in.)
- e** - 11.9 mm (0.47 in.)
- f** - 37.6 mm (1.48 in.)
- g** - 66.6 mm (2.62 in.)
- h** - 24.4 mm (0.96 in.)
- i** - 25.2 mm (0.99 in.)
- j** - 15.2 mm (0.60 in.)
- k** - 42.7 mm (1.68 in.)

Snap-On Tools

Snap-On Tools 2801 80th Street Kenosha, WI 53141 See Snap-On Catalog for your regions distributor phone number.	
Description	Part Number
Compression Gauge	MT33B
Torque Angle Gauge (Degree Wheel Torquing)	TA360

Kent-Moore Tools

Kent-Moore Tools, Inc. 29784 Little Mack Roseville, MI 48066 Phone: (313) 774-9500	
Description	Part Number
Valve Spring Compressor	J-8062
Piston Ring Compressor	J-8307

Lubricants/Sealants/Adhesives

Description	Part Number
Loctite Master Gasket	92-12564-2
Loctite 271 Thread Locker	92-809819
Needle Bearing Assembly Lubricant	92-802868A1
Loctite 242	Obtain Locally
Loctite 620	
Molykote	
SAE 30W Engine Oil	
Loctite 290	

Engine Specifications

IMPORTANT: Specifications are for all models, unless otherwise listed.

NOTICE	
UNIT OF MEASUREMENT: mm (in.)	

Piston Rings

Description		Measurement
Groove Width	1st Compression (Tapered)	3.0 (.1181)
	2nd Compression	2.06 - 2.08 (.0811 - .0818)
	Oil Control	4.03 - 4.05 (.1586 - .1594)
Ring Thickness	1st Compression (Tapered)	3.0 (.1181)
	2nd Compression	1.978 - 1.99 (.0779 - .0783)
	Oil Control	3.978 - 3.990 (.1566 - .1570)
End Gap	1st Compression	0.25 - 0.50 (.010 - .020)
	2nd Compression	0.25 - 0.45 (.0098 - .0177)
	Oil Control	0.25 - 0.58 (.0098 - .0228)
Ring to Groove Clearance	1st Compression	Not applicable - Tapered
	2nd Compression	0.070 - 0.102 (.0027 - .0040)
	Oil Control	0.040 - 0.075 (.0016 - .0029)

Cylinder Liner Diameter

NOTE: Measurements are made at a depth of 108 mm (4.25 inches) down from the top edge of the liner.

Description		Measurement
Standard	Class A	93.995 - 94.015 (3.7007 - 3.7011)
Maximum Out of Round		0.008 (.0003)

Engine Specifications (continued)

NOTICE

UNIT OF MEASUREMENT: mm (in.)

Cylinder Liner Protrusion

Liner Recess BELOW Block (Without Shim)	Shim to Be Used (Thickness)	Liner Protrusion ABOVE Block (With Shim)
0.14 - 0.09 (.0055 - .0035)	0.15 (.0059)	0.01 - 0.06 (.0004 - .0023)
0.19 - 0.14 (.0074 - .0055)	0.20 (.0078)	
0.22 - 0.17 (.0086 - .0066)	0.23 (.0090)	

Head Gaskets

IMPORTANT: When replacing head gaskets observe the following:

- If replacing only one head gasket, use the same size gasket as was removed.
- All head gaskets must be the same size on the same engine.

Piston Protrusion Above Cylinder Block	Gasket Size To Be Used
0.63 - 0.74 (.024 - .029)	1.42 (0.56)
0.73 - 0.82 (.028 - .032)	1.52 (0.60)
0.83 - 0.92 (.031 - .037)	1.62 (0.64)

Cylinder Head

Description		Measurement
Height		89.95 - 90.05 (3.541 - 3.545)
Height of Cylinder Head End Spacers	With Early Model Cylinder Head Gaskets	91.26 - 91.34 (3.593 - 3.596)
	With Late Model Cylinder Head Gaskets	89.96 (3.542)

Engine Specifications (continued)

NOTICE

UNIT OF MEASUREMENT: mm (in.)

Oil Pump

Description	Measurement
External Rotor End Float and Internal Rotor End Float	0.030 - 0.087 (.0011 - .0034)
External Rotor Clearance to Housing	0.13 - 0.23 (.005 - .009)
Clearance Between Pump Support and Gear (Axial)	.0059 - .0098 (0.15 - 0.25)

Camshaft

Description		Measurement
Lobe Lift	Exhaust	7.303 (.287)
	Intake	7.019 (.276)
Journal Diameter	Front	53.495 - 53.510 (2.1061 - 2.1066)
	Center	53.450 - 53.470 (2.1043 - 2.1051)
	Rear	53.480 - 53.500 (2.1055 - 2.1062)
Bearing Clearances	Front	0.030 - 0.095 (.0011 - .0037)
	Center	0.070 - 0.140 (.0027 - .0055)
	Rear	0.040 - 0.110 (.0015 - .0043)
Camshaft Thrust Plate Thickness		3.95 - 4.05 (.155 - .159)

Valve Lifter

Description	Measurement
Lifter Diameter	14.965 - 14.985 (.5891 - .5899)
Diameter of Lifter Bore	15.010 - 15.035 (.5909 - .5919)
Assembly Clearance	0.025 - 0.070 (.0010 - .0027)
Clearance Wear Limit	0.100 (.0039)

Engine Specifications (continued)

NOTICE

UNIT OF MEASUREMENT: mm (in.)

Rocker Arm

Description	Measurement
Journal Diameter	24.97 - 25.00 (.983 - .984)
Bushing Inner Diameter	25.021 - 25.020 (.985 - .985)
Maximum Clearance	0.062 (.002)

Valve Adjustment

Valve	Exhaust	Intake
Clearance	Hydraulically Controlled	

Valve

Valve	Exhaust	Intake
Head Diameter	38 (1.49)	40.9 (1.61)
Stem Diameter	7.93 (.3122)	7.95 (.3129)
Face Width	2.64 - 2.99 (.1039 - .1177)	3.57 - 3.85 (.1405 - .1515)
Margin (New)	1.73 (.068)	1.82 (.071)
Margin (After Grinding)	1.30 (.051)	
Face Angle (New)	44 degrees 30 minutes	29 degrees 30 minutes

Valve Seat

Valve	Exhaust	Intake
Seat Angle	45 degrees	30 degrees
Seat Width	2.00 (.078)	3.25 (.127)
Seat Outer Diameter	39 (1.53)	42 (1.653)
Seat Height	7.90 (.311)	7.80 (.307)
Head Surface To Seat	2.05 - 2.25 (.080 - .088)	2.17 - 2.37 (.085 - .093)
Valve Recession (Max.)	0.03 (.001)	0.03 (.001)

Engine Specifications (continued)

NOTICE

UNIT OF MEASUREMENT: mm (in.)

Valve Guide

Valve Guide	Exhaust	Intake
Maximum Clearance	0.093 (.0036)	0.073 (.0028)
Height Above Spring Counterbore	7.921 - 7.939 (.311 - .312)	7.940 - 7.960 (.312 - .313)

Valve Spring

Valve Spring	Height	Pressure
Free Standing	44.65 (1.757)	0.0 kg (0 lb)
Valve Closed	38.60 (1.460)	32 - 36 kg (71 - 79 lb)
Valve Open	28.20 (1.110)	92.5 - 96.2 kg (204 - 212 lb)

Engine Specifications (continued)

NOTICE

UNIT OF MEASUREMENT: mm (in.)

Crankshaft

D2.8L D-TRONIC - SERIAL NUMBER 0L098203 AND BELOW, AND D4.2 L D-TRONIC - SERIAL NUMBER 0L099524 AND BELOW

Description		Measurement
Main Journal Outside Diameter	Front	62.985 - 63.005 (2.4797 - 2.4805)
	Center	63.005 - 63.020 (2.4805 - 2.4810)
	Rear	69.985 - 70.000 (2.7553 - 2.7559)
Main Bearing Clearance	Front	0.055 - 0.095 (.0022 - .0037)
	Center	0.030 - 0.088 (.0012 - .0034)
	Rear	0.060 - 0.125 (.0024 - .0049)
Main Bearing Inside Diameter	Front	63.060 - 63.080 (2.4827 - 2.4835)
	Center	63.050 - 63.093 (2.4822 - 2.4840)
	Rear	70.060 - 70.110 (2.7583 - 2.7602)
Maximum Main Bearing Wear		0.1 (.0039)
Connecting Rod Journal Outside Diameter		53.940 - 53.955 (2.1236 - 2.1242)
Connecting Rod Bearing Clearance		0.030 - 0.064 (.0011 - .0025)
Connecting Rod Bearing Inside Diameter		53.977 - 54.016 (2.1250 - 2.1266)
Maximum Rod Bearing Journal Wear		0.1 (.0039)
Crankshaft End Play (Axial Clearance)		0.153 - 0.304 (0.06 - .011)
Thrust Washers	Standard	2.311 - 2.362 (.0909 - .0929)
	1st Oversized	2.411 - 2.462 (.0949 - .0969)
	2nd Oversized	2.511 - 2.562 (.0988 - .101)

Engine Specifications (continued)

NOTICE

UNIT OF MEASUREMENT: mm (in.)

Crankshaft (continued)

D2.8L D-TRONIC - SERIAL NUMBER 0L098204 AND ABOVE, AND D4.2 L D-TRONIC - SERIAL NUMBER 0L099525 AND ABOVE

IMPORTANT: The engines included in this serial number range had dimensional changes to the crankshaft, rear main bearing, rear main bearing carrier, thrust washers, O-ring seal, flywheel thrust spacer and flywheel seal. Ensure by serial number that the specifications and parts are the correct ones for the engine.

Description		Measurement
Main Journal Outside Diameter	Front	62.985 - 63.005 (2.479 - 2.4805)
	Center	63.005 - 63.020 (2.4805 - 2.4810)
	Rear	79.985 - 80.000 (3.1490 - 3.1496)
Main Bearing Clearance	Front	0.055 - 0.095 (.0022 - .0037)
	Center	0.030 - 0.088 (.0011 - .0034)
	Rear	0.045 - .085 (0.0018 - 0.0033)
Main Bearing Inside Diameter	Front	63.060 - 63.080 (2.4827 - 2.4835)
	Center	63.050 - 63.093 (2.4822 - 2.4840)
	Rear	80.045 - 80.070 (3.1514 - 3.1524)
Maximum Main Bearing Wear		0.1 (.0039)
Connecting Rod Journal Outside Diameter		53.940 - 53.955 (2.1236 - 2.1242)
Connecting Rod Bearing Clearance		0.030 - 0.064 (.0011 - .0025)
Connecting Rod Bearing Inside Diameter		53.977 - 54.016 (2.1250 - 2.1266)
Maximum Rod Bearing Journal Wear		0.1 (.0039)
Crankshaft End Play (Axial Clearance)		0.080 - 0.280 (0.0031 - 0.0110)
Thrust Washers	Standard	2.310 - 2.360 (0.0909 - 0.0929)
	1st Oversized	2.410 - 2.460 (0.0949 - 0.0969)
	2nd Oversized	2.510 - 2.560 (0.0988 - 0.1008)

Engine Specifications (continued)

NOTICE

UNIT OF MEASUREMENT: mm (in.)

Connecting Rods

Description	Measurement
Weight ¹	1250 grams (44.09 ounces)

¹ : All service connecting rods are median weight and class.

Connecting Rod Crank Pin Bore

Description	Measurement
Inner Diameter	57.563 - 57.582 (2.2662 - 2.2670)
Maximum Allowable Wear or Taper	0.02 (.0008)

Connecting Rod Bushings

Description	Measurement
Piston Pin Outer Diameter	29.990 - 29.996 (1.1807 - 1.1809)
Connecting Rod Bushing Inner Diameter	30.035 - 30.050 (1.1824- 1.1830)
Minimum and Maximum Clearance	0.039 - 0.060 (.0015 - .0023)

Pistons

Description	Measurement
Diameter - Standard	Class A 93.925 (3.6978)

Flywheel

Description	Measurement
Runout - Face	0.10 (.004)
Runout - Bore	0.10 (.004)

Precautions

WARNING

Always wear safety glasses when using compressed air.

WARNING

Some tests in this SECTION involve the use of electricity and intense heat. Failure to follow appropriate procedures or warnings can cause burns or shock which can result in severe personal injury or death. While performing the following test, observe these general precautions:

- Wear personal protective clothing such as rubber gloves, a non-flammable apron, and eye protection - preferably full face shield or safety glasses.
- Work area should include the use of rubber floor mats. Use insulated tools.
- The appropriate heat source should only be electric. Heat source should be operated by a qualified person. Follow all instructions of the manufacturer of the heat source. The heat source should be checked each time it is used to ensure it is functioning properly.
- The thermometer used in the test should be a high-temperature thermometer with a maximum reading of at least 150° C (300° F). Under no circumstances should the operator allow temperatures to exceed test specifications.
- Perform test only in a well ventilated area.
- Use a suitable container to hold the test medium, such as metal. Avoid use of glass containers unless the operator first confirms for him/herself that the glass container is an appropriate high-temperature vessel.
- Because the components will reach high temperatures Do NOT handle materials or components until COMPLETELY cooled.

General Information


Some repairs, that are listed in this section, must be completed with engine removed from boat. Engine removal depends upon type of repair and boat design. Place engine on repair stand for major repairs.

NOTE: This section contains disassembly and assembly procedures of the cylinder block and cylinder heads only. Refer to other sections for disassembly and assembly of various other components.

IMPORTANT: Do NOT use any sealers or adhesives containing silicone. Silicone can cause blockage in the cooling/heat exchanger systems.

Engine Rotation


NOTE: Engine rotation is described when observed from the rear of the engine (transmission end) looking forward (water pump end).



75303

Left-hand Rotation - All Models

Engine Firing Order




D2.8L D-TRONIC	D4.2L D-TRONIC
Firing Order: 1-3-4-2	Firing Order: 1-5-3-6-2-4

Late Model Cylinder Head Gasket - Torque Sequence and Specifications

IMPORTANT: Cylinder head bolts may be installed as many as three times, and then must be replaced. Replace bolts if any doubt exists.

IMPORTANT: Observe the following assembly notes:

- Lubricate the underside of all 14 mm center bolt heads and threads with Molykote.
- Lubricate the underside of all 12 mm side bolt heads and threads with clean engine oil (SAE 30 W).
- Position cylinder heads, one at a time. Install cylinder head end spacers, formed spacer-washers and bolts. Temporarily finger tighten the bolts.
- Hand tighten intake / exhaust manifold to cylinder heads to align sides of cylinder heads. Then, recheck for proper coverage of gaskets.



75515

Cylinder Head Assembly Diagram

- a** - End Spacer
- b** - Formed Spacer-Washers
- c** - Center Bolt Set
- d** - Side Bolt Set

TORQUE PROCEDURE DURING ASSEMBLY

3. Torque the center bolt set as indicated.

a. First pass:


Engine	Sequence	Torque
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	30 Nm (22 lb-ft)
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	30 Nm (22 lb-ft)

b. Second pass:


Engine	Sequence	Torque Angle
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	+ 65 Degrees
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	+ 65 Degrees

c. Third pass:

Engine	Sequence	Torque Angle
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	+ 65 Degrees
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	+ 65 Degrees



77114



77113

Center Bolt Torque Sequence Diagram

a - 4 Cylinder Engine


b - 6 Cylinder Engine

4. Torque the side bolt set as indicated.
- a. First pass:

Engine	Sequence	Torque
D2.8L Side Bolts	11-12-13-14-15-16-17-18	30 Nm (22 lb-ft)
D4.2L Side Bolts	15-16-17-18-19-20-21-22-23-24-25-26	30 Nm (22 lb-ft)

- b. Second pass:

Engine	Sequence	Torque Angle
D2.8L Side Bolts	11-12-13-14-15-16-17-18	+ 85 Degrees
D4.2L Side Bolts	15-16-17-18-19-20-21-22-23-24-25-26	+ 85 Degrees



Side Bolt Torque Sequence Diagram

a - 4 Cylinder Engine

b - 6 Cylinder Engine

TORQUE PROCEDURE AFTER 20-30 MINUTE BREAK-IN

⚠ CAUTION


Avoid component or engine failure. Cylinder heads require additional angular torque and conventional torque application after the first 20-30 minute break-in.

1. Operate the engine at idle until water temperature reaches 70 degrees C (158 degrees F.). Then operate the engine at 2000 rpm for approximately 20-30 minutes at normal operating temperature.
2. Let the engine cool down completely (inoperative overnight, if possible).
3. One at a time loosen each center bolt and torque as indicated.
 - a. First pass:


Engine	Sequence	Torque
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	30 Nm (22 lb-ft)
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	30 Nm (22 lb-ft)

- b. Second pass:

Engine	Sequence	Torque Angle
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	+ 120 Degrees
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	+ 120 Degrees



77114





77113

Center Bolt Torque Sequence Diagram

- a** - D2.8L D-Tronic Engine
b - D4.2L D-Tronic Engine

4. Without loosening, torque each side bolt as indicated.

Engine	Sequence	Torque
D2.8L Side Bolts	11-12-13-14-15-16-17-18	90 Nm (66 lb-ft)
D4.2L Side Bolts	15-16-17-18-19-20-21-22-23-24-25-26	90 Nm (66 lb-ft)



Side Bolt Torque Sequence Diagram

- a - D2.8L D-Tronic Engine
- b - D4.2L D-Tronic Engine

Early Model Cylinder Head Gasket - Torque Sequence and Specifications


IMPORTANT: Cylinder head bolts may be installed as many as three times, and then must be replaced. Replace if any doubt exists.

IMPORTANT: Observe the following assembly notes:

- Lubricate the underside of all 14 mm (center) bolt heads and threads with Molykote. Lubricate the underside of all 12 mm (side) bolt heads and threads with clean SAE 30 W engine oil.
- Position cylinder heads, one at a time, ensuring that the gaskets are completely covered by the cylinder heads themselves. Install cylinder head end spacers, formed spacer-washers and bolts. Temporarily finger tighten the bolts.
- Hand tighten intake/exhaust manifold to cylinder heads to align sides of cylinder heads. Then, recheck for proper coverage of gaskets.

TORQUE PROCEDURE DURING ASSEMBLY

1. In sequence torque 14 mm bolts to 30 Nm (22 lb-ft). Repeat using same specification (to ensure better preload).
2. In sequence tighten each 14 mm bolt through an angle of 70 degrees.
3. In sequence tighten each 14 mm bolt through ANOTHER angle of 70 degrees.
4. In sequence torque port and starboard 12 mm bolts to 30 Nm (22 lb-ft).
5. In sequence tighten STARBOARD 12 mm bolts through an angle of 85 degrees (± 5 degrees)
6. In sequence tighten PORT 12 mm bolts through an angle of 85 degrees (± 5 degrees)



Cylinder Head Assembly And Torque Sequence Diagram


- a** - Center Bolt Set
- b** - Side Bolt Set
- c** - End Spacer

TORQUE PROCEDURE AFTER 20-30 MINUTE BREAK-IN

⚠ CAUTION

Avoid component or engine failure. Cylinder heads require additional angular torque and conventional torque application after the first 20-30 minute break-in and then, after the first 100 hours or first operating season whichever occurs first.

1. Operate the engine at idle until water temperature reaches 70 degrees C (158 degrees F.). Then operate the engine at 2000 rpm for approximately 20-30 minutes at normal operating temperature.
2. Let the engine cool down completely (inoperative overnight, if possible).
3. In sequence, and operating on only one bolt at a time, loosen each 14 mm center bolt and then retorque to 30 Nm (22 lb-ft). Continue by tightening the bolt through an angle of 65 degrees and then through ANOTHER 65 degrees (130 degrees total).
4. In sequence and without loosening, check torque on port and starboard 12 mm side bolts to be 90 Nm (66 lb-ft)



75515

Torque Sequence Diagram

- a** - Center Bolt Set
b - Side Bolt Set


TORQUE PROCEDURE AFTER 100 HOURS OF OPERATION, OR FIRST OPERATING SEASON, WHICHEVER OCCURS FIRST

⚠ CAUTION

Avoid component or engine failure. Cylinder heads require additional angular torque and conventional torque application after the first 100 hours or first operating season, whichever occurs first.

IMPORTANT: Engine must be have been operated 100 hours or for one operating season, whichever occurs first.

1. Let engine cool down completely (inoperative overnight, if possible).
2. In sequence and without loosening, tighten 14 mm center bolts through an angle of 15 degrees.
3. In sequence and without loosening, tighten port and starboard 12 mm side bolts through an angle of 15 degrees.




75515

Torque Sequence Diagram

- a** - Center Bolt Set
- b** - Side Bolt Set


Lubrication System - All Models



D4.2L D-Tronic Flow Diagram Shown (D2.8L D-Tronic Similar)


- 1** - Oil Pan
- 2** - Oil Pump
- 3** - Pressure Relief Valve
- 4** - Oil Thermostat In Oil Filter Header
- 5** - Oil Filter
- 6** - Engine Oil Cooler (Lower Portion of Heat Exchanger/Coolant Tank)
- 7** - Rocker Arms
- 8** - Camshaft Bearings
- 9** - Piston Oil Jets
- 10** - Crankshaft Main Bearing Carrier and Bearing
- 11** - Turbocharger

Examples of Bearing Failures




Scratched By Dirt

- a** - Scratches
- b** - Dirt Imbedded Into Bearing Material




Lack Of Oil

- c** - Overlay Wiped Out
- d** - Bright (Polished) Sections




Improper Seating

70436




Tapered Journal

- a** - Overlay Gone From Entire Surface
- b** - Radius Ride
- c** - Craters Or Pockets



Radius Ride



Fatigue Failure

70436

Compression Testing Procedure

Periodically check engine compression pressure. Lowering of pressure causes loss of power, greater fuel consumption, smoke at the exhaust, low acceleration, unsteady slow idle, difficulty in starting and bearing seizure because of engine overheating.

1. Refer to SECTION 5C - Fuel Injectors, and while observing precautions listed, remove all fuel injectors.


IMPORTANT: To achieve the cranking rpms needed (300 rpm minimum) for a proper compression test, it will be necessary to remove all of the injectors prior to testing.

2. Clean injector bore and install Compression Tester Adapter Tool 91-881737.
3. Torque the injector clamp to 24 Nm (18 lb-ft).
4. Connect gauge to Compression Adapter Tool and set gauge to zero.
5. Ensure that battery is fully charged.
6. Operate the starter. The engine should be cranking at approximately 300 rpm. Check compression gauge reading. Compression should be 30-32 bar (435-464 psi). Maximum pressure difference between cylinders should not exceed 500 kPa (72 psi).
7. Readings lower than specified, or differences between cylinders greater than specified, indicate engine problems may exist (such as faulty rings, valves, cylinders and pistons). Repair as needed.
8. If readings are within specifications, refer to SECTION 5C - Fuel Injectors, and install injectors in heads from which removed previously.
9. Purge air from injectors. Refer to SECTION 5C - Fuel Injectors.

Engine Cover

Removal

1. Remove the four cover retaining screws and hardware.
2. Remove oil filler cap to allow cover to be removed.
3. Lift cover from engine.
4. To protect engine, temporarily install oil filler cap during service work.



- a** - Engine Cover
b - Retaining Screw and Hardware
c - Oil Fill Cap

75504

Cleaning

1. Clean the cover with warm soapy water.
2. Air dry the cover.

Inspection

1. Inspect engine cover for cracks or deterioration.
2. Inspect rubber isolation grommets for deterioration.
3. Inspect hardware used with each grommet.
4. Replace damaged parts.


Installation

1. Remove oil filler cap from engine to allow cover to be installed.
2. Place cover on engine. Position fastener hardware.
3. Install and securely tighten the four retaining screws.

Valve Covers

Removal

1. Remove engine cover.
2. Remove vent hose.
3. Remove oil fill cap extension tube and sealing washer.
4. Remove engine cover support bar.
5. Remove electrical box support bracket.



75374


Typical

- a** - Valve Cover
- b** - Vent Hose
- c** - Oil Fill Cap Extension Tube and Sealing Washer
- d** - Engine Cover Support Bar
- e** - Electrical Box Support Bracket

6. Remove fuel injectors as follows:
 - a. Clean the area around the injectors and pipes.
 - b. Remove injector fuel supply pipes.
 - c. Remove injector fuel return pipe.
 - d. Remove securing nut and injector nozzle hold-down clamp.

NOTE: To aid in removal of injectors, it is sometimes helpful to slightly rotate the injector clockwise and counterclockwise to loosen any seal caused by paint or debris.

e. Withdraw the injectors.



75336

Typical

- a** - Supply Pipes
- b** - Return Pipe
- c** - Clamp
- d** - Injector

7. Remove the screws retaining the valve cover to the cylinder head.

NOTE: The two screws holding the electrical box support bracket to the valve cover are 8 mm (approx. 5/16 in.) longer than the other screws. Do NOT mix fasteners.

IMPORTANT: On 6 cylinder engines remove both covers at the same time.

8. Using a rubber mallet, tap against side of valve cover to loosen.

9. Lift the cover, or covers, from the heads.

10. **On 6 Cylinder Engines:** pull valve covers apart. Discard the two old O-rings on the connector between the valve covers.

Cleaning

IMPORTANT: Do NOT drop anything into cylinder head openings.

1. Clean gasket material from cylinder heads.
2. Remove old gasket material and clean valve covers.

Inspection

1. Inspect sealing surfaces for deep nicks and scratches.
2. **On 6 Cylinder Engines:** inspect valve cover connector for damage.
3. Inspect plastic plugs for cylinder head screw hole covers.
4. Replace or repair parts as needed.


Installation

1. Follow instructions a. or b.:

NOTE: A small amount of Loctite Master Gasket can be used to hold gaskets on valve covers.

a. **On D2.8L D-Tronic Engines:**

- (1.) Install valve cover gaskets.
- (2.) Install valve covers on cylinder heads.
- (3.) Position the two longer screws through the electrical support bracket and spacers. Install as shown.
- (4.) Install remaining screws
- (5.) Torque valve cover screws evenly in a diagonal pattern to 11.5 Nm (101 lb-in.).
- (6.) Install plastic plugs into cylinder head screw holes.
- (7.) Install oil fill cap extension tube with sealing washer. Tighten tube securely.




75102

- a - Gasket
- b - Valve Cover
- c - Screw (M6 x 80)
- d - Screw (M6 x 88)
- e - Spacer
- f - Bracket
- g - Plastic Plug
- h - Extension Tube With Sealing Washer

b. On D4.2L D-Tronic Engines:

- (1.) Install 2 new O-rings on connector before pushing valve covers together. Push covers together.
- (2.) Install valve cover gaskets.
- (3.) Position the two longer screws through the electrical support bracket and spacers. Install as shown. Install remaining screws Torque screws evenly in a diagonal pattern to 11.5 Nm (101 lb-in.).
- (4.) Install plastic plugs into cylinder head screw holes.
- (5.) Install oil fill cap extension tube with sealing washer on front valve cover as shown. Install oil fill cap with sealing washer on aft valve cover. Tighten both securely.




75103

- a** - O-ring
- b** - Connector
- c** - Gasket
- d** - Valve Cover
- e** - Screw (M6 x 80)
- f** - Screw (M6 x 88)
- g** - Spacer
- h** - Bracket
- i** - Plastic Plug
- j** - Extension Tube With Sealing Washer
- k** - Oil Fill Cap (Aft Cover)

2. Install oil separator vent hose.

3. Install engine cover support bar. Torque screws to 27.5 Nm (20 lb-ft).


**Typical**

- a** - Vent Hose
- b** - Clamp
- c** - Engine Cover Support Bar

4. Install engine cover and oil fill cap.


Water Manifold

Exploded Views



75440

D2.8L D-Tronic




75108

D4.2L D-Tronic

- a** - Hose Clamp
- b** - Banjo Bolt and Sealing Washer
- c** - Screws with Washers
- d** - Water Manifold
- e** - Vent Pipe (To Turbocharger Fitting)
- f** - Vent Hose (To Heat Exchanger Fitting)
- g** - Gasket, End Cover or Manifold Pieces
- h** - Cylinder Head Gaskets
- i** - Hose and Clamp (To Exhaust Manifold End Cover)

Removal

1. Drain engine coolant.
2. Loosen hose clamp at rear of water manifold.
3. Remove banjo bolts, pipes and vent hoses.
4. Remove retaining screws and washers.



75108

Typical

- a** - Hose Clamp
- b** - Banjo Bolt And Sealing Washers
- c** - Vent Hose
- d** - Vent Pipe
- e** - Screws With Washers
- f** - Water Manifold Assembly

5. Using a rubber mallet, tap against side of manifold to loosen.

Cleaning

IMPORTANT: Do NOT drop anything into cylinder head openings.

1. Discard old sealing washers.
2. Clean gasket material from cylinder heads and manifold flanges.
3. Clean manifold pieces with solvent and dry with compressed air.


Inspection

1. Inspect sealing surfaces for deep nicks and scratches.
2. Inspect castings for cracks or corrosion that might prevent proper seal.
3. Replace or repair parts as needed.

Installation

1. Use a new gasket and install end cover on manifold pieces. Torque screws with washers to 11.8 Nm (104 lb-in.).
2. Align manifold pieces with a straight edge device and torque screws to 11.8 Nm (104 lb-in.).

IMPORTANT: When replacing the gasket between manifold pieces, align flanges using a straight edge as shown.



70660

Typical

- a** - Typical End Cover
- b** - Gasket
- c** - Straight Edge Device
- d** - Bolts (4, Two Not Shown)

3. Place new gaskets in position on cylinder heads.

NOTE: A small amount of Loctite Master Gasket can be used to hold gaskets in place.

4. Install water manifold while simultaneously positioning the water hose onto rear of manifold. Torque screws with washers to 11.8 Nm (104 lb-in.) in a diagonal pattern from centermost to outer ends.
5. Install banjo bolt and banjo fittings using new sealing washers. Securely tighten the bolt while simultaneously positioning the fittings.
6. Install vent hose if previously removed.
7. Tighten hose clamp on hose at rear of water manifold.

CYLINDER HEAD AND RELATED COMPONENTS



CYLINDER HEAD AND RELATED COMPONENTS (CONTINUED)

- 1** - Rocker Pedestal Nut
- 2** - Valve Cone (Keeper 2)
- 3** - Spring Retainer
- 4** - Valve Spring
- 5** - Plate Washer
- 6** - Valve Guide (Standard, or 0.10 mm Oversize Available)
- 7** - Cylinder Head
- 8** - Plug (2)
- 9** - Cylinder Head Code Identification Stamping Location
- 10** - Intake Valve Seat
- 11** - Intake Valve
- 12** - Exhaust Valve Seat
- 13** - Exhaust Valve
- 14** - Engine Coolant Temperature (ECT) Sensor, Coolant Temperature Audio Warning Switch (Depends on Location of Head)
- 15** - Plug (Depends on Location of Head)
- 16** - Valve Cover Stud
- 17** - Rocker Pedestal Stud
- 18** - Rocker Pedestal
- 19** - Rocker Arm
- 20** - Rocker Arm Bushing
- 21** - 12 mm Cylinder Head Bolt (1 per head)
- 22** - 12 mm Cylinder Head Bolt (1 per head)
- 23** - 14 mm Cylinder Head Bolts (4 per head)
- 24** - Formed Spacer Washer (Terminal Bridge) (1)
- 25** - Formed Spacer Washer (Terminal Bridge) (1)
- 26** - Formed Spacer Washers (Terminal Bridges) (2)
- 27** - End Spacers (First and Last Cylinder Head)
- 28** - Oil Pipe
- 29** - Oil Pipe to Cylinder Head Banjo Bolt
- 30** - Starboard Side Of D-Tronic Head
- 31** - Plug (Unless Equipped With Optional Glow Plug Kit)


LUBRICANTS / SEALANTS / ADHESIVES

Description		Part Number
A	Molykote	Obtain Locally
B	SAE 30W Engine Oil	Obtain Locally

Removal


IMPORTANT: Mark the location of each rocker arm assembly and cylinder head to ensure that they are reassembled in the same location.

1. Mark the position of the rocker arm assemblies and cylinder heads for reassembly.
2. Remove rocker arm oil feed line banjo bolts with sealing washers. Remove line from cylinder heads and from rear (starboard) of cylinder block.




- a** - Oil Feed Pipe
b - Banjo Bolts With Sealing Washers

3. Unscrew rocker arm retaining nuts.



- a** - Retaining Nuts

4. Remove the rocker arm assemblies, by lifting upward.




- a** - Retaining Nuts
b - Rocker Arm Assembly

5. Withdraw the valve push rods. Store them so as to place them back in their original locations upon reassembly.
6. Remove the water manifold.
7. Remove the intake / exhaust manifold.

IMPORTANT: To avoid distorting cylinder heads, remove heads only when engine is cold.

8. Take note of shape and location of formed spacer washers. Starting at one end of the engine, remove head bolts.



D4.2L D-Tronic

D2.8L D-Tronic


a - Formed Spacer Washers

9. Using a rubber hammer, tap on side of cylinder heads to loosen. Remove the cylinder heads.

IMPORTANT: Retain fuel Injectors with their original heads to aid in diagnosis of problems. Faulty fuel injectors can actually melt the aluminum cylinder heads.

Disassembly

1. Using valve spring compressor, carefully remove keepers, retainers, springs and spring plates. Place valves in numbered rack according to their position in the engine or label the parts in order for reassembly to the original location.



- a** - Typical Valve Spring Compressor
b - Valve Spring and Related Components

Cleaning

1. Clean carbon from valves.
2. Being careful not to damage aluminum heads, clean all carbon from combustion chambers and valve ports.
3. Clean gasket material from cylinder head mating surfaces.
4. Thoroughly clean valve guides with valve guide cleaner.
5. Wash cylinder head and components in cleaning solvent.
6. Put on safety glasses.
7. Dry with compressed air.
8. Clean cylinder head bolt holes in cylinder block.

Inspection


GENERAL

1. Inspect expansion plugs for leakage or damage.
2. Inspect glow plug seats for damage.
1. Inspect injector seats for damage.
2. Inspect all gasket surfaces for deep grooves or pitting.
3. Inspect valve seats for cracks, excessive wear and looseness in counterbore.
4. Inspect valves for cracks, excessive wear or bent stems.
5. Inspect valve springs for discoloration due to excessive heat.
6. Inspect valve guides for cracks or chips.
7. Inspect valve guide bores for seizure marks, carbon deposits or scoring.
8. Inspect valve guide height.
9. Inspect valve spring keepers, retainers and washer for wear, distortion, or cracks.
10. Inspect for melting of aluminum by faulty fuel injectors.
11. Inspect rocker arm support journals for scoring.
12. Inspect rocker arm bushings for excessive wear.

EXPANSION PLUGS

1. Remove expansion plugs if leaking or damaged.

NOTE: These plugs may be removed with a sharp punch, or they may be drilled and pried out




a - Expansion Plugs

75101


VALVE GUIDES

1. Remove valve stem seals.
2. Insert new valve into guide.
3. Measure valve stem clearance as follows:
 - a. Attach a dial indicator to cylinder head. Position it against the valve stem and close to the valve guide.
 - b. While holding the valve head off of the seat by about 2 mm (1/16 in.), move valve stem back and forth in directions shown. Compare stem clearance with specifications.



70435


Valve Guide	Exhaust	Intake
Maximum Clearance	0.093 mm (.0036 in.)	0.073 mm (.0028 in.)



- a** - Intake Valve Guide I. D. Measurement: 7.99 - 8.00 mm (.3145 - .3149 in.)
- b** - Exhaust Valve Guide I. D. Measurement: 7.99 - 8.00 mm (.3145 - .3149 in.)

VALVE SEATS

1. Measure exhaust and intake valve seats. Refer to valve seat specifications.
2. If measured values are not as specified repair or replace the valve seats.





Exhaust Valve Seat Specifications

- a** - Valve Recession (Max.): 0.03 mm (.001 in.)
- b** - Head Surface to Seat: 2.05 -2.25 mm (.080 - .088 in.)
- c** - Counterbore Inner Diameter: (Measurement Not Available At Time Of Printing)
- d** - Seat Outer Diameter: 39 mm (1.53 in.)
- e** - Seat Height: 7.90 mm (.311 in.)
- f** - Seat Width: 2.00 mm (.078 in.)
- g** - Seat Angle: 60 Degrees

Intake Valve Seat Specifications

- a** - Valve Recession (Max.): 0.03 mm (.001 in.)
- b** - Head Surface to Seat: 2.17 -2.37 mm (.085 - .093 in.)
- c** - Counterbore Inner Diameter: (Measurement Not Available At Time Of Printing)
- d** - Seat Outer Diameter: 42 mm (1.653 in.)
- e** - Seat Height: 7.80 mm (.307 in.)
- f** - Seat Width: 3.25 mm (.127 in.)
- g** - Seat Angle: 45 Degrees


VALVES

**41 mm Intake Valve****38 mm Exhaust Valve**

- a** - Stem O. D. Measurement: 7.95 mm(.3129 in.)
- b** - Face Width Measurement: 3.57 - 3.85 mm (.1405 - .1515 in.)
- c** - Margin (After Grinding) Measurement: 1.82 mm (.071 in.)
- d** - Face Angle : 29 Degrees and 30 Minutes
- e** - Stem O. D. Measurement: 7.93 mm (.3122 in.)
- f** - Face Width Measurement: 2.64 - 2.99 mm (.1039 - .1177 in.)
- g** - Margin (After Grinding) Measurement: 1.30 mm (.051 in.)
- h** - Face Angle: 44 Degrees and 30 Minutes

VALVE SPRINGS


1. Use a vernier caliper to measure the valve spring free height. Replace spring if less than specified limit.
2. Measure the springs distortion. If the measured value exceeds the specified limit, the valve spring must be replaced.



a - Free Standing Height Measurement: 44.65 mm (1.757 in.)

b - Distortion Measurement: Maximum 2 mm (.079 [5/64] in.)


3. Use a spring tester to measure the valve spring height under tension. Replace spring if less than specified limit.



Closed Valve

a - Applied Pressure: 32-36 kg (71-79 lb)

b - Height Measurement: 38.60 mm (1.460 in.)



Open Valve


a - Applied Pressure: 92.5-96.2 kg (204-212 lb)

b - Height Measurement: 28.20 mm (1.110 in.)

Repair

Expansion Plugs

1. Apply Loctite 290 to outer diameter of expansion plugs.
2. Install plugs flush to outer surface of cylinder head.



75101

a - Expansion Plugs

VALVE SEAT RECONDITIONING

Several different types of equipment are available for reconditioning valve seats. Equipment manufacturer's recommendations should be followed carefully to attain proper results.

Regardless of type of equipment, however, it is essential that valve guide bores be free from carbon or dirt to insure proper centering of pilot in valve guide.

Machine valve seat angles to the following specifications:

Valve Seat	Machine Angle
Intake	30 degrees
Exhaust	45 degrees

VALVE SEAT REPLACEMENT

1. To replace the seats, heat the head in an oven to 150 degrees C (300 degrees F). Remove old seat. Do NOT damage counterbore.

⚠ CAUTION

To avoid distortion or melting of aluminum heads, Do NOT use a torch to replace valve seats.

2. Clean dirt from counterbore. Check counterbore for nicks and scratches.
3. Reheat head in oven to 150 degrees C (300 degrees F).
4. Cool new seat in liquid nitrogen and install in counterbore. Seat should fit without using pressure. Allow to cool.


VALVE GUIDE REPLACEMENT

1. Remove valve stem seals.
2. Heat head in oven to 85 degrees C (185 degrees F). Using a suitable drift, drive out old guide from underside of head.

⚠ CAUTION

To avoid distortion or melting of aluminum heads, Do NOT use a torch to replace valve guides.

3. With head temperature at 85 degrees C (185 degrees F), press new guide in to obtain measurement as shown.



a - Spring Seat Counterbore

b - Intake Guide Height Measurement: 7.94 - 7.96 mm (.312 -.313 in.)

c - Exhaust Guide Height Measurement: 7.92 - 7.94 mm (.311 to .312 in.)

IMPORTANT: If the valve guide has been removed, both the valve and the valve guide must be replaced as a set.

VALVE REFACING

Pitted valves can be refaced to proper angle on a valve grinder, thus insuring correct relation between cylinder head seat and valve mating surface. Replace valves with excessive wear on stems or valves which are warped excessively. When an excessively-warped valve head is refaced, a knife edge will be ground on part or all of the valve head, due to amount of metal that must be removed to completely reface. Knife edges lead to breakage or burning. After grinding, measure valves and replace if out of specifications.

Various equipment is available for refacing valves. Manufacturer's recommendations should be carefully followed to attain proper results.

Refer to Specifications for valve specifications.

CYLINDER HEAD RESURFACING


The cylinder heads on these marine diesel engines are treated with a protective nickel coating to resist corrosion and should not be resurfaced. Resurfacing would remove the nickel coating. Do NOT resurface the cylinder heads.

Assembly

VALVES

NOTE: Valve stem seals are used on intake and exhaust valves.

1. Lubricate valve guides and valve stems with clean SAE 30W engine oil.
2. Install each valve in the port from which it was removed or to which it was fitted.
3. Install valve guide seals over valve stem and push down on the seal until seated securely around top of guide.




75386

- a** - Valve Stem Seal
- b** - Seal Installed On Guide

NOTE: Grease may be used to hold keepers in place while releasing compressor tool.

4. Install plate washer, valve spring, and retainer on valve stem. Using valve spring compressor tool, carefully compress spring and insert keepers into valve stem groove.



70275


- a** - Plate Washer
- b** - Valve Spring
- c** - Retainer
- d** - Keepers

5. Release compressor tool, making sure keepers seat properly in groove of valve stem.

CYLINDER HEAD STUDS

IMPORTANT: All long cylinder head studs are not the same length. Some studs are longer than others and are used for attaching accessories. These studs must be in the correct location before exhaust manifold is installed.

When replacing cylinder heads, remove studs and install in new head in same location.



70273

a - Long Cylinder Head Studs (Lengths Vary)

⚠ CAUTION


Head gasket thickness is very important on diesel engines. If head gaskets are too thin, the pistons will hit the valves or heads, causing severe damage. All head gaskets on one engine must be the same thickness or exhaust manifold and water manifold will not fit correctly.

When cylinder heads are removed for service but pistons and cylinder liners are not disturbed, use the same thickness gaskets that were removed. Refer to Head Gasket Identification.

Refer to Determining Head Gasket Thickness during a complete engine rebuild or when pistons and liners are being replaced.

DETERMINING HEAD GASKET THICKNESS


1. Use dial indicator 91-58222A1 and liner gauge bar 91-801333509 to measure piston height above the cylinder block with piston at Top Dead Center.
2. Place liner gauge bar with dial indicator attached, across liner as shown (parallel to cylinder centerline).



70277

- a** - Liner Gauge Bar
- b** - Dial Indicator
- c** - Liner


3. Set dial indicator to zero at point shown on cylinder block.



75524

- a** - Dial Indicator Zero Point

4. Move dial indicator to point shown on piston. Record measurement.



75524

- a** - Measurement Point


5. Measure all piston heights and use largest reading to determine which gaskets to use for all cylinders.
6. Refer to Engine Specifications - Head Gaskets, to determine correct head gasket thickness.

Installation - Using Early Model Gaskets

HEAD GASKET IDENTIFICATION

NOTE: All engines with early model gaskets (head gasket fits a single-cylinder) use the same type of cylinder head gaskets in one of three thickness as previously determined and shown following.

The 1.52 mm (.060 in.) gasket has two notches while the 1.62 mm (.064 in.) gasket has one notch where indicated. The 1.42 mm (.056 in.) gasket is plain, without notches.



75516

- a** - 1.62 mm (.064 in.) Gasket, With One Notch
- b** - 1.52 mm (.060 in.) Gasket, With Two Notches
- c** - 1.42 mm (.056 in.) Gasket, Without Notches

INSTALLATION

1. Before installing cylinder heads follow instructions a. - c.:
 - a. Clean out bolt holes in cylinder block. Be certain no contaminants (dirt, old oil or coolant) remain in holes.
 - b. Clean gasket surfaces on block and heads.
 - c. Oil cylinder bores with Quicksilver 4 cycle engine oil.

2. Prepare hardware following instructions a. - d.:


IMPORTANT: Cylinder head bolts may be installed as many as three times, and then must be replaced with new bolts. Replace if any doubt exists.

- Thoroughly clean all cylinder head bolts and washers, including all formed spacer-washers (terminal bridges, three types) and cylinder head spacers (for ends of first and last cylinder heads).
- Using clean SAE 30W engine oil, lubricate the bolt threads and underside of bolt heads of all 12 mm cylinder head bolts.
- Lubricate the threads and underside of bolt heads on all 14 mm cylinder head bolts with Molykote (obtain locally).
- Place all parts on a clean surface or lint-free shop cloth.

IMPORTANT: Head gaskets must be installed DRY - Do NOT use any sealer on gaskets.

IMPORTANT: Install head gaskets ONLY as shown.


3. Ensure head gaskets are installed as shown.



70280

- a** - Manufacturers Name - Facing Up
b - Part Number - Facing Up

4. Using a screwdriver install two Cylinder Head Guide Pins 91-801333501, into 12 mm bolt holes in cylinder block at cylinder number 1 location, as shown.



70437


- a** - Guide Pin, Bolt Hole Locations (Two at each cylinder)
b - Guide Pins Installed

IMPORTANT: There is limited space between the cylinder heads after installation. IF all heads were removed, start installation with cylinder number 1 and proceed in numerical order. Ensure that when placed on cylinder block each head and corresponding gasket are properly positioned. Align using a straight edge placed alongside the head and gasket (Port-to-Starboard) until **NO PORTION** of the gasket FIRE RING metal is visible, prior to **HAND** tightening 12 mm Cylinder Head Bolts (as in the following steps).

⚠ CAUTION


The following steps must be carried out properly to prevent misalignment of cylinder heads or head gaskets which could result in failure of the cylinder head gaskets or cylinder heads causing severe engine damage.

5. Beginning with cylinder number 1, with gasket facing UP (as previously shown) install new cylinder head gasket and cylinder head, being certain that **NO PORTION** of the cylinder head gasket FIRE RING metal as shown, is visible or extends out from under the head. Refer to preceding **IMPORTANT** precaution.



70280

a - Cylinder Head Gasket FIRE RING Metal




70724

a - Cylinder Head

b - Cylinder Head Gasket (NO FIRE RING metal visible)



6. *ONE AT A TIME*, remove Guide Pins and install oiled 12 mm cylinder head bolts with washers **HAND** tight. Do **NOT** disturb head placement.
7. Repeat Steps 5. and 6., for each cylinder head and corresponding cylinder, proceeding in numerical order from cylinder number 1.
8. Install all lubricated 14 mm cylinder head bolts, including the proper formed spacer-washers (terminal bridges, three types) and cylinder head spacers for ends of first and last cylinder heads, as shown in the following.



75515

- a** - Spacers. First and Last Cylinder Head Ends
b - Formed Spacer-Washers (Terminal Bridges, Three Types)

9. Lightly HAND tighten bolts in torque sequence.





75515

Torque Sequence Diagrams

- a** - D4.2L D-Tronic
b - D2.8L D-Tronic

10. Temporarily install intake / exhaust manifold *without gaskets* and FINGER-tighten each nut with locking washer.
11. Slightly loosen 12 mm and 14 mm bolts as needed, to allow cylinder heads to ALIGN as you HAND tighten exhaust manifold nuts.
12. HAND TIGHTEN all 14 mm and 12 mm cylinder head bolts in torque sequence.
13. In torque sequence tighten 14 mm cylinder head bolts to 30 Nm (22 lb-ft). Refer to Torque Sequence Diagrams. Repeat using the same specification, to ensure the best preload, before proceeding.

14. Following the same sequence tighten each 14 mm bolt through an angle of 70 degrees using a Torque Angle Gauge.
15. In sequence tighten PORT and STARBOARD 12mm cylinder head bolts to 30 Nm (22 lb-ft).
16. In sequence tighten only the STARBOARD 12mm cylinder head bolts through an angle of 85 ± 5 degrees using a Torque Angle Gauge.
17. In sequence tighten only the PORT 12mm cylinder head bolts through an angle of 85 ± 5 degrees using a Torque Angle Gauge.



75515

Torque Sequence Diagrams

- a** - D4.2L D-Tronic
b - D2.8L D-Tronic

18. Tighten each 14 mm bolt through **ANOTHER** 70 degrees following the same sequence.

CAUTION

Avoid component or engine failure. Cylinder heads require additional angular torque and conventional torque application after the first 20-30 minute run-in and then, after the first 100 hours or first operating season whichever occurs first.

19. Remove exhaust manifold.
20. Refer to the appropriate sections and install the following:
 - a. Lifters and retainers.
 - b. Push rods.
 - c. Rocker arm assemblies.
21. Install rocker arm oil feed line using 2 new sealing washers at each banjo fitting and bolt. Torque each banjo bolt to 12.7 Nm (112 lb-in.).
22. Install water manifold strip with new gaskets on cylinder heads. Torque bolts with washers to 11.8 Nm (104 lb-in.) in a diagonal pattern from centermost to outer ends.
23. Complete engine assembly.

24. **AFTER COMPLETE ENGINE ASSEMBLY AND INSTALLATION**, follow these additional cylinder head angular torque instructions:

- a. Operate engine at idle until water temperature reaches 70° C (158° F) and then operate engine at 2000 rpm for approximately 20-30 minutes at operating temperatures. Let the engine cool down completely (inoperative overnight, if possible).
- b. Remove valve covers.
- c. Retorque the cylinder head bolts, as follows:
 - (1.) In torque sequence, and operating on only one bolt at a time, loosen each 14 mm (center) bolt and then retorque to 30 N·m (22 lb-ft). Continue by tightening the bolt through an angle of 65 Degrees and then through ANOTHER 65 Degrees (130 Degrees total).
 - (2.) In sequence and without loosening, check torque on port and starboard 12 mm (side) bolts to be 90 N·m (66 lb-ft)
- d. Install valve covers.

⚠ CAUTION

Avoid component or engine failure. Cylinder heads require additional angular torque and conventional torque application after the first 100 hours or first operating season, whichever occurs first.

25. **AFTER 100 HOURS, OR THE FIRST OPERATING SEASON, WHICHEVER OCCURS FIRST**, follow instructions a. - d.:

- a. Remove valve covers.
- b. In torque sequence and without loosening, tighten the 14mm (center) cylinder head bolts through an angle of 15 degrees.
- c. In sequence and without loosening, torque the 12mm (side) cylinder head bolts through an angle of 15 degrees.
- d. Install valve covers.

Installation - Using Late Model Gaskets

NOTE: Early model D2.8L D-Tronic and D4.2L D-Tronic diesel engines can be retrofitted with late model cylinder head gaskets if the cylinder head spacers (for ends of first and last cylinder heads) are replaced with new size spacers.

HEAD GASKET IDENTIFICATION


The following in-line diesel engines now use a new, late model cylinder head gasket which seals more than one individual cylinder and eliminates the 100-hour re-torque that was required for early model gaskets.

Description		Gasket Thickness in. (mm)
D2.8L D-Tronic - Serial Number 0L098059 And Above	Gasket seals all 4 cylinders	0.056 (1.42)
		0.060 (1.52)
		0.064 (1.62)

Description		Gasket Thickness in. (mm)
D4.2L D-Tronic - Serial Number 0L098232 And Above	Gasket seals front 3 cylinders	0.056 (1.42)
		0.060 (1.52)
		0.064 (1.62)
	Gasket seals rear 3 cylinders	0.056 (1.42)
		0.060 (1.52)
		0.064 (1.62)

Hold the gasket with the push rod holes up towards the top. Identification marks will be in the lower right hand corner.

- No holes indicates a thickness of 0.056 in. (1.42 mm)
- 2 holes indicates a thickness of 0.060 in. (1.52 mm)
- 1 hole indicates a thickness of 0.064 in. (1.62 mm)



Late Model Gasket (1.52 mm Thickness Shown - 2 Holes)

a - Two Holes

INSTALLATION

1. Before installing the cylinder heads, follow instructions “a” - “c”:
 - a. Clean out bolt holes in cylinder block. Be certain no contaminants (dirt, old oil or coolant) remain in holes.
 - b. Clean gasket surfaces on block and heads.
 - c. Oil the cylinder bores with Quicksilver 4 cycle engine oil.

2. Prepare the hardware following instructions “a” - “d”:


IMPORTANT: Cylinder head bolts may be installed as many as three times, and then must be replaced with new bolts. Replace if any doubt exists.

- a. Thoroughly clean all cylinder head bolts and washers, including all formed spacer-washers (terminal bridges, three types) and cylinder head spacers (for ends of first and last cylinder heads).
- b. Using clean SAE 30W engine oil, lubricate the bolt threads and underside of bolt heads of all 12mm cylinder head bolts.
- c. Lubricate the threads and underside of bolt heads on all 14mm cylinder head bolts with Molykote (obtain locally).
- d. Place all parts on a clean surface or lint-free shop cloth.

IMPORTANT: Head gaskets must be installed DRY - Do NOT use any sealer on gaskets.

IMPORTANT: Install head gaskets ONLY as shown.

3. Position the 4 cylinder head gasket, or both 6 cylinder head gaskets, on the cylinder block as shown.




78174

D4.2L D-Tronic Head Gaskets Shown (D2.8L D-Tronic Similar)

a - Late Model Cylinder Head Gaskets

4. Using a screwdriver install two Cylinder Head Guide Pins (91-801333501) into 12 mm bolt holes in cylinder block at cylinder number 1 location.
5. **On D2.8L D-Tronic Engines:** Using a screwdriver install two Cylinder Head Guide Pins into 12 mm bolt holes in gasket and cylinder block at cylinder number 4 location. These pins will keep the gasket aligned.
6. **On D4.2L D-Tronic Engines:** Using a screwdriver install two Cylinder Head Guide Pins 91-801333501, into 12mm bolt holes in gasket and cylinder block at cylinder number 3 location. These pins will keep the gasket aligned.




78143

D4.2L D-Tronic Guide Pin Locations Shown (D2.8L Similar)

- a** - Guide Pin, Bolt Hole Locations (Two at each cylinder)
- b** - Guide Pins Installed

7. Beginning with cylinder number 1, install a cylinder head over the guide pins.
8. *ONE AT A TIME*, remove Guide Pins and install the oiled 12mm cylinder head bolts with washers *HAND* tight. Do NOT disturb head placement.
9. Using a screwdriver install two Cylinder Head Guide Pins, into 12 mm bolt holes in cylinder block for the next cylinder in numerical order.
10. **On D2.8L D-Tronic Engines:** Repeat for each cylinder head and corresponding cylinder 2 through 4.
11. **On D4.2L D-Tronic Engines:** Repeat for each cylinder head and corresponding cylinder 2 through 3.
12. **On D4.2L D-Tronic Engines:** Repeat the installation process for the gasket and each cylinder head corresponding to cylinder 4 through 6.


13. Install all lubricated 14 mm cylinder head bolts, including the proper formed spacer-washers (terminal bridges, three types) and cylinder head spacers, for ends of first and last cylinder heads, as shown in the following.



75515

- a** - Spacer(s). First and Last Cylinder Head Ends
b - Formed Spacer-Washers (Terminal Bridges, Three Types)

14. Lightly HAND tighten bolts in torque sequence.




75515

Torque Sequence Diagrams

- a** - D4.2L D-Tronic (6 Cylinder)
b - D2.8L D-Tronic (4 Cylinder)

15. Temporarily install exhaust manifold *without gaskets* and FINGER-tighten each nut with locking washer.



16. Slightly loosen 12 mm and 14 mm bolts as needed, to allow cylinder heads to ALIGN as you HAND tighten exhaust manifold nuts.
17. HAND TIGHTEN all 14 mm and 12 mm cylinder head bolts in torque sequence.

18. Torque the center bolt set as indicated.

a. First pass:


Engine	Sequence	Torque
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	30 Nm (22 lb-ft)
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	30 Nm (22 lb-ft)

b. Second pass:

Engine	Sequence	Torque Angle
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	+ 65 Degrees
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	+ 65 Degrees


c. Third pass:

Engine	Sequence	Torque Angle
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	+ 65 Degrees
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	+ 65 Degrees



77114

D2.8L D-Tronic Torque Sequence Diagram



77113

D4.2L D-Tronic Torque Sequence Diagram

a - Center Bolt Set

b - Side Bolt Set


19. Torque the side bolt set as indicated.

a. First pass:

Engine	Sequence	Torque
D2.8L Side Bolts	11-12-13-14-15-16-17-18	30 Nm (22 lb-ft)
D4.2L Side Bolts	15-16-17-18-19-20-21-22-23-24-25-26	30 Nm (22 lb-ft)


b. Second pass:

Engine	Sequence	Torque Angle
D2.8L Side Bolts	11-12-13-14-15-16-17-18	+ 85 Degrees
D4.2L Side Bolts	15-16-17-18-19-20-21-22-23-24-25-26	+ 85 Degrees



77114

D2.8L D-Tronic Torque Sequence Diagram



77113

D4.2L D-Tronic Torque Sequence Diagram

- a - Center Bolt Set
- b - Side Bolt Set

TORQUE PROCEDURE AFTER 20-30 MINUTE BREAK-IN

⚠ CAUTION


Avoid component or engine failure. Cylinder heads require additional angular torque and conventional torque application after the first 20-30 minute break-in.

1. Operate the engine at idle until water temperature reaches 70 degrees C (158 degrees F.). Then operate the engine at 2000 rpm for approximately 20-30 minutes at normal operating temperature.
2. Let the engine cool down completely (inoperative overnight, if possible).
3. One at a time loosen each center bolt and torque as indicated in a. and b.
 - a. First pass:

Engine	Sequence	Torque
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	30 NM (22 lb-ft)
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	30 NM (22 lb-ft)


- b. Second pass:

Engine	Sequence	Torque Angle
D2.8L Center Bolts	3-2-1-4-5-8-9-10-7-6	+ 120 Degrees
D4.2L Center Bolts	11-12-13-14-10-9-8-4-3-2-1-5-6-7	+ 120 Degrees



77114

D2.8L D-Tronic Center Bolt Torque Sequence Diagram




77113

D4.2L D-Tronic Center Bolt Torque Sequence Diagram

a - Center Bolt Set


4. Without loosening, torque each side bolt as indicated.

Engine	Sequence	Torque
D2.8L Side Bolts	11-12-13-14-15-16-17-18	90 NM (66 lb-ft)
D4.2L Side Bolts	15-16-17-18-19-20-21-22-23-24-25-26	90 NM (66 lb-ft)



77114

D2.8L D-Tronic Side Bolt Torque Sequence Diagram



77113

D4.2L D-Tronic Side Bolt Torque Sequence Diagram

a - Side Bolt Set

Rocker Arm

Removal

NOTE: When servicing the rocker arms of only one cylinder, bring that cylinder to TDC before removing rocker arms. When servicing all rocker arms, bring cylinder number 1 piston up to TDC before removing rocker arms.

1. Remove valve arm covers.

IMPORTANT: Rocker arm assemblies and push rods must be reassembled in their original locations.


2. Remove rocker arm assemblies and push rods. Place in a numbered rack according to their position in the engine or label the parts in order for reassembly to the original location.

Cleaning

1. Wash all parts in cleaning solvent.
2. Dry parts with compressed air.

Inspection


1. Inspect parts for excessive wear, cracks or damage.
2. Using a micrometer, measure outside diameter of rocker arm support journals.



75349

a - Rocker Arm Support Journal Outside Diameter Measurement - 24.97-25.00 mm (.9830 - .9842 in.)

3. Using an inside micrometer, measure inside diameter of rocker arm bushing.



75346


a - Rocker Arm Bushing Inside Diameter Measurement - 25.020 - 25.021 mm (.9850 - .9851 in.)

4. Replace rocker arm bushing if difference between bushing inside diameter and journal outside diameter. is greater than 0.062 mm (.0024 in.).

Assembly

IMPORTANT: When installing rocker arms and valve push rods, coat bearing surfaces with engine oil.


1. Lubricate rocker arm bushings and support journals with SAE 30W engine oil.



75349

- a** - Rocker Arm Bushings
- b** - Rocker Arm Support Journals


2. Install rocker arms on support. Position as shown.



75101

- a** - Rocker Arms (Positioned Correctly)
- b** - Rocker Arm Support

3. Install strap. Make sure strap is not spread open or valve cover will not fit.



75101

- a** - Rocker Arm Assembly
- b** - Strap


Installation

ESTABLISHING TOP DEAD CENTER (TDC)

NOTE: Screw plugs in glow plug holes or glow plugs, if equipped, may be removed to release compression when turning crankshaft.

Rocker arm assemblies should be installed when each cylinder is at TDC to avoid damaging the valve train components. If the position of the crankshaft has moved since parts were removed, it may be necessary to establish TDC, if not already known, BEFORE installing the rocker arm assemblies.

1. Remove 3 opposing retaining bolts from the vibration damper (balancer).
2. Using balancer bolts or suitable, attach crankshaft tool 91-814827 to crankshaft balancer.




70485

a - Crankshaft Tool

3. Align crankshaft and timing mark as follows:
 - a. Temporarily insert a push rod into both cylinder number 1 lifters.
 - b. Slowly rotate the crankshaft **CLOCKWISE** while watching the first valve push rod (front-most is cylinder number 1 intake valve). Continue to rotate the engine until after the intake valve has opened (valve push rod moved up) and then **CLOSED** (valve push rod moved down).


- c. Continue to rotate engine CLOCKWISE until the notch on the pulley aligns with mark on timing gear cover. Cylinder number 1 piston is at Top Dead Center (TDC) on its compression stroke at this point.



- a** - TDC Notch On Pulley
b - Timing Cover Mark


NOTE: Some modification to the graduated disc tool may be required for use on some models.

4. Attach graduated disc 91-801333500 to crankshaft pulley or tool. Position the disc with Zero degrees as shown.



- a** - Graduated Disc
b - Crankshaft Tool
c - Zero Degrees

- Using wire, make a pointer and attach it to a suitable location on engine. Align wire pointer to Zero ("0") as shown.



70664

a - Wire Pointer


- Using crankshaft tool, turn crankshaft clockwise as needed (6 cylinder - 120 degrees or 4 cylinder - 180 degrees) to bring next cylinder in firing order up to TDC.

Firing Order	
D2.8L D-Tronic	1-3-4-2
D4.2L D-Tronic	1-5-3-6-2-4

INSTALLING THE ASSEMBLIES

NOTE: Screw plugs in glow plug holes or glow plugs, if equipped, may be removed to release compression when turning crankshaft.

- Rotate the crankshaft to place each cylinder at TDC, before installing the assembly for that cylinder. Refer to Establishing Top Dead Center (TDC).
- Install valve push rods in their original locations. Ensure push rods seat in lifter sockets.




75401

Typical Cross-Section View

a - Push Rod
b - Lifter Socket

3. Install rocker assembly onto studs. Simultaneously align valve push rods with rocker arm sockets.



75401

Typical Cross-Section View

- a** - Push Rod
- b** - Lifter Socket
- c** - Rocker Arm Socket


4. Install both flanged nuts on rocker arm support. Torque evenly to 34 Nm (25 lb-ft).

IMPORTANT: No valve adjustment is required. Valve lash is automatically set when rocker arm nuts are torqued as specified.

5. Refer to appropriate procedures and reassemble remaining components.

Timing Gear Cover

Exploded View



73778

- 1** - Cover
- 2** - Gasket
- 3** - Pin (2)
- 4** - Cover
- 5** - Washer
- 6** - Screw (1)
- 7** - Washer (1)
- 8** - Screw (13)
- 9** - Seal (Apply Oil to Inner Lips of Seal Upon Installation)
- 10** - O-ring
- 11** - Crankshaft Pulley
- 12** - Vibration Damper
- 13** - Nut
- 14** - Screw (6)
- 15** - Lockwasher (6)

Description		Part Number
A	Loctite Master Gasket	92-12564-2
B	Clean SAE 30W engine Oil	Obtain Locally

Removal

1. If equipped, remove power steering pump and vacuum pump belt.
2. Remove alternator belt and upper alternator bracket screw, spacer and hardware from timing gear cover.

CAUTION

When removing seawater hoses or seawater pump, close seacock, if equipped. If boat is not equipped with a seacock, remove and plug seawater inlet hose to prevent a siphoning action that may occur, allowing seawater to flow from the drain holes or removed hoses and enter boat.

3. Refer to SECTION 6A - Seawater Cooling System, and remove seawater pump inlet hose and outlet hose. Then, remove seawater pump.
4. Install flywheel holding tool 91-801333506.
5. Remove six allen-head bolts and remove crankshaft vibration damper.
6. Using a suitable socket remove the large crankshaft pulley nut.
7. Using Puller 91-801333507, remove crankshaft pulley
8. Remove fasteners, including one at alternator bracket, and remove timing cover. Note size and position of fasteners for reassembly.

Cleaning

1. Remove old gasket material from block and timing cover. Be careful not to gouge or nick flanges.
2. Wash all parts in cleaning solvent and dry with compressed air.
3. If oil seal is removed for replacement, clean the seating surface in the cover.

Inspection


1. Inspect parts for cracks or damage.
2. Check oil seal for wear or damage. Using a suitable tool remove and replace oil seal if needed.

NOTE: Bore in timing cover for oil seal must not be worn. Oil seal must fit securely in cover.

Installation

NOTE: While timing cover is removed renew O-ring if crankshaft and pulleys show signs of oil leakage from center.


1. Ensure that the crankshaft O-ring seal between timing gear and crankshaft pulley is still in place and in good condition.
2. Coat new timing gear cover gasket with Loctite Master Gasket. Install gasket on engine.
3. Install the timing cover as follows:
 - a. Lightly lubricate the timing cover seal with clean SAE 30W engine oil.
 - b. Install the timing cover.
 - c. Torque the M6 x 1.0 screws evenly, in a diagonal pattern, to 10.8 Nm (95 lb-in.).
 - d. Install the single M8 screw (left, mid-point on cover) with the serrated, cupped washer. Torque the screw to 10.8 Nm (95 lb-in.).
4. Ensure that the crankshaft pulley woodruff key is installed.
5. Ensure that the woodruff key remains in proper position and install the crankshaft pulley.
6. Apply Loctite 222 Thread Locker to pulley nut threads.
7. Install the pulley nut. With flywheel holder tool 91-801333506 in place, torque nut to 196.2 Nm (144 lb-ft).
8. If equipped, ensure power steering and vacuum pump belts are in proper positions.
9. Install the vibration damper and torque M10 x 1.5 screws to 83.4 Nm (61 lb-ft).



75106

- a** - Crankshaft O-ring Seal
- b** - Gasket
- c** - Timing Cover
- d** - Timing Cover Seal
- e** - M6 Screws
- f** - M8 Screw with Serrated, Cupped Washer
- g** - Crankshaft Pulley
- h** - Vibration Damper
- i** - Pulley Nut
- j** - M10 Screw

10. Remove flywheel holder tool.
11. Install seawater pump using a new O-ring seal.
12. Install alternator brace to timing cover, using the bolt, washer, spacer and nut removed during disassembly. Torque nut to 45-50 Nm (34-37 lb-ft).



75106


- a** - Brace
- b** - Timing Cover
- c** - Screw
- d** - Washer
- e** - Spacer
- f** - Flange Nut

13. Tension the alternator belt, power steering belt, and vacuum pump belt, if equipped. Torque drive belt related mounting and tensioning bolts to specifications.
14. Install seawater pump inlet hose and outlet hose. Tighten hose clamps securely.
15. Open the seacock if equipped, or remove plug from seawater inlet hose and reconnect seawater inlet hose to inlet of seawater strainer.

Oil Pump

Removal


1. Remove the timing gear cover.
2. Remove the screws securing oil pump.



70292

- a** - Screws (3)
b - Oil Pump

3. Remove the oil pump from bore in block.



70287


- a** - Oil Pump

Cleaning

1. Dismantle and wash all parts in cleaning solvent.
2. Put on safety glasses.
3. Dry parts with compressed air.

Inspection

1. Using appropriate gauging devices, measure the following:
 - a. Clearance between rotors. Maximum: 0.152 mm (.006 in.).
 - b. Clearance between housing and outer rotor: 0.105 - 0.106 mm (.00413 - .00417 in.). Maximum: 0.500 mm (.01968 in.).
 - c. Diameter of rotor housing: 58.105 - 58.130 mm (2.287 - 2.288 in.).



70282

- a** - Rotor
- b** - Outer Rotor
- c** - Clearance Between Rotors
- d** - Clearance Between Housing and Outer Rotor
- e** - Diameter of Rotor Housing


- d. Depth of rotor housing: 32.403 - 32.406 mm (1.2757 - 1.2758 in.).
 - e. Axial clearance between pump driven gear and pump body: 0.050 - 0.070 mm (.002 - .003 in.).
2. If measurements are not within specifications the pump is faulty, and must be replaced as a complete unit.

Reassembly

1. Install the bevelled end of the outer rotor towards the pump gear.
2. Ensure that the rotor and gear coupling resists a rolling torque of 9 kgm (32.4 oz.).

Installation

1. Install oil pump in cylinder block. Torque screws to 27.5 Nm (20 lb-ft).



70292

a - Screws (3)

b - Oil Pump

2. Install timing gear cover.


Oil Pressure Relief Valve

The oil pressure relief valve (oil pressure regulator valve) is installed vertically in the underside of the crankcase.

Removal

1. Remove oil pan.
2. Clean old gasket material from area around relief valve.
3. Unscrew the valve assembly seat/body from the crankcase using a suitable tool. The tool should engage the two slots opposite each other on the edge of the valve assembly.

NOTE: Locking compound is used during installation of the oil pressure relief valve assembly. Area around the assembly may need to be heated to aid in removal.



70298

Typical

- a** - Example Of Suitable Tool
- b** - Valve Assembly
- c** - Slots


Disassembly

1. Lock the pressure relief valve assembly in a soft-jawed vise.

⚠ WARNING

Use caution when removing or installing snap-ring. There is high spring pressure against cap. Wear safety glasses.

2. Put on safety glasses.
3. Push cap in and hold. Remove snap-ring. Release spring pressure slowly.




70285

- a** - Cap
- b** - Snap-Ring
- c** - Valve Assembly (Seat/Body)

4. Remove cap, spring or springs, and relief valve from bore of the valve assembly.

NOTE: Some oil pressure relief valves have only one spring.



70283

- a** - Cap
- b** - Spring (Inner - Present If Dual Spring Equipped)
- c** - Spring
- d** - Relief Valve

Cleaning


1. Clean gaskets from cylinder block and pan flanges.
2. Wash all parts in cleaning solvent and dry with compressed air.

Inspection

1. Replace complete valve assembly if spring is broken.
2. Replace complete valve assembly if valve is badly worn or sticking in bore.
3. The valve can be lapped into its seat using a grinding paste, if necessary to restore pressure.
4. Ensure that valve slides freely in seat/body when coated with oil.

Assembly


1. Coat inside of oil pressure relief valve seat/body bore with SAE 30W engine oil. Liberally oil coat remaining components.
2. Assemble valve, spring(s) (inner and outer springs, if dual spring equipped) and cap as shown. Install parts into valve seat/body.



3. Push cap into bore and install snap-ring.

Installation

1. Apply Loctite 242 to threads when replacing complete oil pressure relief valve assembly. Screw the complete assembly into the crankcase.




70285

70298

- a** - Valve Assembly
- b** - Apply Sealant to Threads

2. Using a suitable tool, torque relief valve assembly to 53.9 Nm (39 lb-ft).



70298

Typical

- a** - Example Of Suitable Tool
- b** - Valve Assembly
- c** - Slots


3. Install oil pan and related hardware.

Oil Pan and Oil Pick-Up Tube Assembly

Removal

1. Disconnect oil drain tube from oil pan. Remove oil pan.
2. Remove screws retaining baffle, oil pick-up (suction) tube, and oil pick-up tube elbow to block.

NOTE: This view is representative of all models. Your specific pick-up tube assembly may differ slightly in appearance.




70288

Typical

- a** - Baffle
- b** - Oil Pick-up Tube
- c** - Elbow
- d** - Inlet (Strainer End)

3. Remove old O-ring from suction tube. Remove old O-ring from elbow on engines with two piece suction tube.



70286

- a** - Pickup Tube
- b** - Elbow
- c** - O-rings, Two Piece Suction Tube

Cleaning


1. Wash all parts in cleaning solvent and dry with compressed air.
2. Clean old gasket from cylinder block and oil pan flange.

Inspection

1. Inspect the oil pan for fatigue cracks.
2. Check all welds for leaks.
3. Inspect oil pick-up assembly for fatigue cracks or damage.
4. Replace parts with those for your specific model.

Installation


1. **On Engines With Two Piece Suction Tube:**
 - a. Renew O-rings on oil pick-up tube and elbow.



70286

- a** - O-ring, Oil Pick-up (Suction) Tube
b - O-ring, Oil Pick-up (Suction) Tube Elbow


- b. Install elbow on oil pick-up tube.
2. **On Engines With One Piece Suction Tube:** Renew O-ring on oil pick-up tube.



75107

- a** - O-ring
b - Oil Pick-up

3. Install oil pick-up tube assembly, with baffle, on cylinder block. Torque screws to 11 Nm (97 lb-in.).
4. Using a new gasket, install oil pan and related hardware. Torque oil pan screws evenly, in a diagonal pattern, to 12.7 Nm (112 lb-in.).




- a** - Baffle
- b** - Oil Pick-up Tube
- c** - Tube Elbow (Except On One-Piece Tube)
- d** - Screws
- e** - Oil Pan and Related Hardware

Adapter / Oil Thermostat

Removal

1. Disconnect wire from oil temperature audio warning switch.
2. Using a suitable container to catch oil, completely loosen hose fittings retaining oil lines to adapter / oil thermostat. Make matching marks on hoses to assist in reassembly.
3. Completely loosen hex head screw fitting retaining adapter to cylinder block.




75385

Typical

- a** - Oil Temperature Audio Warning Switch
- b** - Hose Fitting
- c** - Adapter / Oil Thermostat
- d** - Screw Fitting

4. Lift adapter and screw fitting from engine. Remove fitting and sealing washer.
5. If not already accomplished, remove old O-ring from groove on adapter (on underside when adapter is mounted).




75528

- a** - Adapter / Oil Thermostat
- b** - Sealing Washer
- c** - Screw Fitting
- d** - O-Ring Seal

6. Refer to appropriate procedures to continue engine disassembly if rebuilding, or proceed if only oil thermostat or adapter and related parts are being serviced.

Disassembly

1. Remove hex head plug with sealing washer, O-ring, spring and thermostat from filter head.



75528

- a** - Thermostat
- b** - Spring
- c** - O-ring Seal
- d** - Sealing Washer
- e** - Hex Head Plug
- f** - Adapter / Oil Thermostat

Cleaning and Inspection


2. Clean parts in solvent.
3. Dry with compressed air.
4. Inspect components for cracks or damage. Replace as needed. Refer to Testing to verify if thermostat is functional.

Testing

NOTICE

Read **WARNING** about testing in Precautions at the front of this SECTION before proceeding with tests.

1. Thermostat pin should be retracted as shown when cold. If not, thermostat is faulty and must be replaced.




71085

- a** - Thermostat
- b** - Thermostat Pin (Retracted)

2. Observe the preceding precautions and place thermostat in container of water. Water must cover thermostat. Suspend a thermometer in the water. Do NOT allow thermometer to touch the bottom of the pan.
3. Heat water and observe thermostat pin.
4. Pin must begin to extend (push up) as shown, when water temperature reaches 90 degrees C (195 degrees F.). At 100 degrees C (212 degrees F.) pin should be extended approximately 5-7 mm (3/16 - 5/16 in.) more than when it was cold.

NOTE: Thermostat shown removed from test water for visual clarity. Do NOT handle until cool.




71084

a - Thermostat Pin (Extended)

5. If pin does not extend (push out), thermostat is faulty and must be replaced.

Installation



1. Coat threads of hex head plug with Loctite Pipe Sealant with Teflon.
2. Install thermostat, spring, new O-ring, and plug with new sealing washer into thermostat housing bore of adapter. Tighten plug securely.



75528

- a** - Thermostat
- b** - Spring
- c** - O-ring Seal
- d** - Sealing Washer
- e** - Hex Head Plug
- f** - Adapter / Oil Thermostat

3. Install large hex head fitting with new sealing washer through adapter.
4. Install a new O-ring in adapter groove where it seats on block.
5. Install adapter and torque the fitting to 44 lb-ft (60 Nm).
6. Observe markings made earlier and connect oil hoses to adaptor. Tighten fittings securely.
7. Connect audio warning wire ring terminal to switch. Tighten nut securely. Coat terminals with Quicksilver Liquid Neoprene.




- a** - Adapter
- b** - Hex Head Fitting
- c** - Sealing Washer
- d** - O-ring Seal
- e** - Oil Temperature Audio Warning Switch Connection
- f** - Hose Fitting

8. Fill engine to proper level with recommended engine oil.
9. Start engine and closely observe instrumentation. Ensure that all systems are functioning correctly. Check for leaks.

Camshaft

Exploded View



75105

Typical Camshaft and Related Components

- 1** - Bearings
- 2** - Camshaft
- 3** - Thrust Plate
- 4** - Injection Pump Drive Gear
- 5** - Crankshaft Drive Gear
- 6** - Idler Gear
- 7** - Camshaft Gear
- 8** - Mounting Screw
- 9** - Lockwasher
- 10** - Woodruff Key

Testing - Measuring Lobe Lift

1. Remove all rocker arm assemblies.
2. Secure dial indicator 91-58222A1 to head so indicator plunger rests inside push rod cup.
3. Turn crankshaft so camshaft lobe is at the bottom of its travel and zero dial indicator.
4. Turn crankshaft two complete revolutions while reading dial indicator. Refer to specifications.
5. Measure all lobes of camshaft in the same manner.


IMPORTANT: Camshaft replacement will be necessary if lobe dimensions are less than 0.05 mm (.0019 in.) of the values indicated in the specification charts.

Removal

1. Turn crankshaft to cylinder number 1 TDC of its compression stroke.
2. Remove:
 - a. Timing Gear Cover
 - b. Fuel Pump

IMPORTANT: Place rocker arm assemblies, push rods and lifters in a rack for reassembly in their original locations.

- c. Valve Push Rods
 - d. Retainers and Roller Lifters
3. Remove camshaft thrust plate mounting screws and lockwashers.




70289

- a** - Camshaft Gear
b - Camshaft Thrust Plate Mounting Screw with Lockwasher

4. Carefully withdraw the camshaft. Take care not to damage the camshaft bearings.

5. Remove the idler gear If complete engine disassembly is required, or if idler gear is worn or damaged.

IMPORTANT: Mark retaining screws for reassembly in their original locations.



70292

- a** - Idler Gear
b - Retaining Screw With Lockwasher


Inspection

1. Measure camshaft shaft run-out.
2. Measure lobe lift. If lobe lift is less than specified limit, the camshaft must be replaced.
3. Measure camshaft journal dimensions.
4. Inspect camshaft bearings. Replace as needed. Refer to Camshaft Bearings.
5. Inspect valve lifters and push rods. Replace if needed.

IMPORTANT: Camshaft gear is a press-fit on shaft. If removal is needed, upon reassembly gear must be heated in an oven to 180-200 degrees C (360-390 degrees F.) and pressed on the shaft. After installing proper thrust plate and positioning the key, press the gear until gear is tight against shoulder.

6. Measure clearance between thrust plate and camshaft. Camshaft assembly Clearance should be 0.030-0.095 mm (.0012-.0037 in.). Wear limit is 0.200 mm (.0078 in.).

If measured value exceeds specification inspect thrust plate thickness at four opposite points. Replace plate if less than specified at any point.



70357

a - Measurement: Greater Than 3.95-4.05 mm (.1555-.1594 in.)


b - Thickness Dimension At Four Opposite Points

Installation

1. Install idler gear, if previously removed, so marks align with crankshaft gear as shown. Torque screws to 27 Nm (20 lb-ft).

⚠ CAUTION

Avoid possible severe engine damage. Installation of a screw longer than 16 mm (5/8 in.) will partially block oil gallery in cylinder block causing a lack of lubrication. Be certain retainer screw "c" as shown, is NOT longer than 16 mm (5/8 in.).




70293

- a** - Idler Gear
- b** - Retaining Screws with Lockwashers
- c** - Retaining Screw Must NOT Be Longer Than 16 mm (5/8 in.)
- d** - Marks Aligned Properly

2. Lubricate camshaft lobes with a mixture of 20% SAE 30W engine oil and 80% Needle Bearing Lubricant.
3. Lubricate camshaft bearings with SAE 30W engine oil.
4. Carefully insert camshaft.

5. Align camshaft gear marks with idler gear marks as shown. Torque camshaft flange mounting screws to 27.5 Nm (20 lb-ft).



70289

- a** - Camshaft Gear
- b** - Idler Gear
- c** - Marks Aligned Properly
- d** - Mounting Screws With Lockwashers

6. Complete the engine assembly.

Camshaft Bearings

Inspection


With camshaft removed:

1. Visually inspect bearings. Renew if worn or damaged.
2. Measure inner diameter of bearings. Refer to specifications. Renew bearings if not within specifications.

Removal

NOTE: Camshaft bearings can only be removed and installed with crankshaft removed.

1. Using special tool 91-801333508 with appropriate hardware, remove camshaft bearings into receiver end of tool (not shown in this view).



70438

- a** - Cylinder Block
- b** - Special Tool
- c** - Camshaft Bearing Bore


Installation

1. Clean camshaft bearing bores in cylinder block with solvent and blow out with compressed air. Ensure drilled oil passages are clean.
2. Lubricate outer surface of new camshaft bearings with engine oil to ease installation.

⚠ CAUTION

Avoid engine damage. Oil feed holes in bearings MUST align with drilled oil passages in cylinder block or severe engine damage will result.

3. Align camshaft bearing oil feed holes with drilled oil passages in cylinder block.
4. Using Special Tool 91-801333508 with appropriate hardware, install new camshaft bearings.



70354

- a** - Special Tool
- b** - Bearing
- c** - Oil Feed Hole (MUST BE Aligned With Drilled Passages In Block)

5. Check position of oil hole in each bearing and drilling in block, to ensure bearings are positioned correctly.
6. Recheck bearing inner dimensions to verify proper installation.
7. Install camshaft.
8. Complete engine assembly.

Valve Lifters

CAUTION

If the camshaft is replaced, the valve lifters (roller tappets) must also be replaced or serious component failure and engine damage could result.

The hydraulically operated roller-tipped valve lifters are held in position and prevented from rotation by special retainers. There is one retainer for each head. Care should be exercised when installing the retainers to ensure that the flat portions of the lifters are properly positioned in the retainers.

Removal

1. Remove engine cover.
2. Remove valve covers.


IMPORTANT: Place rocker arm assemblies, push rods, and lifters in a rack for reassembly in their original locations.

3. Remove rocker arm assemblies and push rods.

IMPORTANT: Lifters must be reassembled in the exact same position on the camshaft lobes so that the roller will operate in the same direction on the same lobe, if reused.

4. Make matching marks on all retainers and lifters as to the location and orientation in the bores.
5. Lift the retainer piece away from around the top of the lifters. Do NOT disturb lifters at this time.

6. Remove lifters, being certain to keep them in order.



75383

75103

- a** - Push Rod
- b** - Retainer
- c** - Lifter
- d** - Roller

Cleaning

1. Wash all parts in cleaning solvent.
2. Dry with compressed air.


Inspection

1. Inspect lifters carefully. If any parts are damaged or worn, the entire lifter assembly should be replaced. Refer to Specifications.
2. If outer lifter body wall is scuffed or worn, inspect cylinder block lifter bore.
3. If roller is worn or damaged, inspect camshaft lobe.
4. If push rod seat is scuffed or worn, inspect push rod.

Installation

IMPORTANT: Do NOT install used valve lifters if a new camshaft has been installed.

1. Before installing lifters, coat entire valve lifter with engine oil. Pour an additive containing EP lube over lifters and camshaft lobes if all are new.
2. Install lifters in bores in order of removal. Align matching marks made prior to disassembly.
3. Install retainers around the square top of the lifters to prevent them from rotating.
4. Install push rods. Ensure push rods seat in lifter socket.



- a** - Lifter
b - Retainer
c - Push Rod

5. Install rocker arm assemblies. Torque nuts to 34 Nm (25 lb-ft).
6. Install valve cover(s) using new gaskets and new O-rings on 6 cylinder connector piece). Torque screws to 11.5 Nm (101 lb-in.).

IMPORTANT: It is recommended that the engine oil be changed and a new oil filter be installed whenever servicing valve lifters or camshaft.

7. Change engine oil and filter.
8. Start engine and check for leaks.

Valve Push Rods

Removal

1. As previously outlined, remove valve covers.

IMPORTANT: Keep rocker arms, rocker arm components, valve push rod and hydraulic lifter from each valve together as a matched set. Mark or store them so they can be reinstalled in the same location later.

2. Remove rocker arm assemblies.
3. Lift push rod from seat in lifter cup.

Cleaning

1. Clean all parts with solvent.
2. Clean oil passages of old oil and sludge.
3. Dry parts with compressed air.

Inspection

1. Inspect all contact surfaces (spherical tips) for wear.
2. Check run-out (straightness) of each push rod.
3. Replace all damaged or worn parts.

Installation

IMPORTANT: When installing lifters and rocker arms, coat rocker arm bearing surface, rocker arm and push rod ball and seat with engine oil.

1. Install push rods in order of removal. Ensure push rods seat in lifter socket.
2. Install rocker arm assemblies. Torque nuts to 34 Nm (25 lb-ft).
3. Install rocker arm covers using new gaskets, and new O-rings on the 6 Cylinder's connector piece between the valve covers. Torque screws to 11.5 Nm (101 lb-in.).


Connecting Rod / Piston Assembly

Measuring Rod Bearing Clearance

1. Remove oil pan and oil pick-up tube assembly.
2. Turn crankshaft to gain access to connecting rod bolts.
3. One cylinder at a time, remove rod caps and inspect bearings. Refer to Bearing Failure.
4. Measure crank pin with a micrometer for out-of-round, taper, or excessive wear. If not within specifications, replace or recondition crankshaft.
5. Measure new or used bearing clearances with Plastigage or its equivalent as follows:
 - a. Clean oil from crank pin.
 - b. Install bearing in connecting rod.
 - c. Place a piece of gauging plastic the full width of crank pin (parallel to crankshaft).
 - d. Install rod cap with bearing. Torque bolts to 29.4 Nm + 60 degrees (21 lb-ft + 60 degrees).

IMPORTANT: Do NOT turn crankshaft while gauging plastic is in place.

- e. Remove rod cap and, using scale on gauging plastic envelope, measure gauging plastic width at widest point.



72358

Typical


- a** - Compressed Gauging Plastic
b - Graduated Scale

6. If clearance exceeds specifications, on used bearings, replace bearings and recheck clearance. With new bearings, if correct clearance is not possible, recheck crank pin (journal) dimensions. If new bearings and replacement (or reconditioned crankshaft) will not yield proper measurement, it will be necessary to remove connecting rod/piston assembly (refer to following section) to check dimension of connecting rod crank pin bore.
7. After obtaining the correct clearance, coat crank pin with SAE 30W engine oil. Coat bearing surface with oil and install rod cap. Torque to 29.4 Nm + 60 degrees (21 lb-ft + 60 degrees).

Removal

1. Remove cylinder heads.
2. Remove oil pan and oil pick-up tube.
3. Use a reamer to remove the ridge or any deposits from upper end of cylinder bore.
4. Install crankshaft tool, 91-814827. Turn crankshaft to gain access to connecting rod bolts.

NOTE: Connecting rods are numbered similar to as shown. Record the numbers and cylinder location for reassembly.



70297

a - Connecting Rod Number Placement


5. Remove connecting rod cap and rod bearings.

IMPORTANT: Mark or identify each connecting rod assembly to ensure placement in original location during reassembly, if to be reused.

6. Push piston and connecting rod out of cylinder.
7. Retain rod cap and bearings with connecting rod/piston assembly. Do NOT mix components.


Disassembly

1. Clamp connecting rod in a soft jawed vise as shown.



70290

2. Use Piston Ring Expander 91-24697 to remove the 2 compression rings.
3. Using same tool, remove lower (oil control) ring and spring.




70291

a - Lower (Oil Control) Ring

b - Spring

4. Remove snap rings retaining piston pin. Push pin out of connecting rod and piston.




70294

a - Snap Ring

b - Piston Pin

Cleaning

1. Clean all parts with solvent.
2. Clean oil passages of old oil and sludge.
3. Put on safety glasses.
4. Dry parts with compressed air.
5. Clean varnish from piston skirts and pins with a suitable cleaning solvent. Do NOT WIRE BRUSH ANY PART OF PISTON. Clean ring grooves. Make sure oil ring holes are clean.




70229

- a** - Ring Grooves
b - Oil Ring Holes

Inspection


CONNECTING ROD AND PIN

1. Wash connecting rods in cleaning solvent and dry with compressed air.
2. Check for twisted or bent rods and inspect for nicks or cracks. Replace damaged connecting rods.
3. Measure connecting rod bushing I.D. and piston pin O. D. Replace bushing if clearance is excessive. Refer to specifications.



- a** - Rod Bushing I.D.
b - Piston Pin O. D.

4. Measure connecting rod crank pin bore with a dial bore gauge or inside micrometer for out-of-round or excessive wear. Crank pin bore must be 57.563-57.582 mm (2.2662-2.2670 in.). Replace connecting rod if measurement exceeds allowable dimension by 0.02 mm (.0008 in.).




70397

a - Rod Crank Pin Bore

PISTONS

IMPORTANT: The D-Tronic Engines should have only Class A pistons. Determine the Class of piston by looking on top of piston (as shown following) or by examining the underside of the cylinder liner Refer to Cylinder Liner - Identification for reference details.




70296

a - Location for Class A Designation

1. Inspect piston for cracked ring lands, skirts or pin bosses, wavy worn ring lands, scuffed or damaged skirts or eroded areas at top of piston. Replace pistons which are damaged or show signs of excessive wear. (Refer to Step 6, following.)
2. Inspect grooves for nicks or burrs that might cause rings to hang up.
3. Except on upper ring groove of pistons (refer to Step 5. following), insert edge of rings into respective piston ring groove and roll ring entirely around the groove to make sure that ring is free. If binding occurs at any point, determine cause. If caused by ring groove, remove by dressing with a fine cut file. Do NOT remove excess material. Verify with a feeler gauge and compare to specifications. If binding is thought to be a distorted ring, check with a new ring.

4. Measure piston outer diameter about 13 mm (1/2 in.) from bottom of skirt.



70229

a - Outer Diameter Measurement Point - 13 mm (1/2 in.)


5. Proper clearance of piston ring in its piston ring groove is very important to provide proper ring action and reduce wear.

Keep in mind that while the second (scraper) compression ring and the oil control ring are typical in nature, the first (upper) compression ring is "trapezoidal" (tapered) in design. That is, it has a 15 degree taper on both upper and lower surfaces.

Correspondingly, the first compression ring groove is tapered 15 degrees on top and bottom.


Note also, that the upper ring's edge (parallel to cylinder liner) is not a straight cut. It is rounded, or arced, in design.

IMPORTANT: Do NOT mistake these tapered or different design characteristics for unusual wear patterns.



- a** - First Compression Ring - Trapezoidal (Tapered)
b - First Compression Ring Groove - (Tapered)
c - Outer Edge of Upper Compression Ring - (Arced)


As always, when fitting serviceable or new rings, clearances between all ring and groove surfaces should be measured. Refer to Specifications.



- a** - First Compression Ring
- b** - Second Compression Ring
- c** - Oil Control Ring
- d** - Ring Clearance

CHECKING RING END GAP

1. Select rings comparable in size to piston being used.
2. Slip compression ring in cylinder bore, then press ring down into cylinder bore about 6 mm (1/4 in.) below ring travel. Ensure that ring is square with cylinder wall.
3. Measure gap between ends of ring with a feeler gauge as shown. Refer to Specifications.




70295

Checking Ring End Gap

4. If gap between ends of ring is below specifications, remove ring and try another for fit.
5. Fit each compression ring to cylinder in which it is going to be used.

Assembly


1. Coat inside of connecting rod bushing, piston pin bore, and piston pin with SAE 30W engine oil.
2. Assemble piston to connecting rod with the combustion chamber recess aligned with rod numbers.



70296

- a** - Combustion Chamber Recess
- b** - Rod Numbers

3. Insert piston pin and install snap ring.
4. Clamp in a soft jawed vise as shown.




70290

NOTE: Always install rings with ring markings facing the top of piston.

5. Install spring in lower piston groove.
6. Install oil control ring.
7. Squeeze ring into groove to seat spring and check for binding.

8. Using Piston Ring Expander 91-24697, install the second compression ring in the center piston groove. Scraper side of ring must face bottom of piston.



70299


a - Scraper Side Toward Bottom Of Piston

IMPORTANT: On all engines the word - TOP - appears on the upper surface of the first compression ring, and MUST FACE UP.

9. Using piston ring expander, install first compression ring in upper piston groove.

Installation

1. Before installing pistons into cylinders, ring gaps must be positioned as follows:
 - a. First compression ring (trapezoidal) gap, 30 degrees to the right of combustion chamber recess.
 - b. Second compression ring gap, directly opposite the combustion chamber recess.
 - c. Lower (oil control) ring gap, 30 degrees to the left of combustion chamber recess.



78416


Typical

- a** - First Ring Gap
- b** - Second Ring Gap
- c** - Lower (Oil Control) Ring Gap

2. Lubricate cylinder bore and piston rings with SAE 30W engine oil.
3. Each piston and connecting rod assembly must be installed in the cylinder from which it was removed.

IMPORTANT: The combustion chamber recess and numbers on connecting rod must face injector and camshaft side of the engine.

4. Turn crankshaft to position crank pin away from cylinder so connecting rod will not damage it during installation.
5. Using ring compressor, install piston by tapping on piston-top with a suitable device.



70300

a - Ring Compressor

6. Insert bearing shells into connecting rod and matching rod cap. Lubricate bearings and crank pin with a mixture of 20% SAE 30W engine oil and 80% Needle Bearing Assembly Lubricant.
7. Align connecting rod with crankshaft journal and tap on piston top until rod bearing contacts journal. Do NOT scratch or nick crankshaft journal.
8. Ensure that corresponding numbers on rod cap and connecting rod are the same and are on the same (camshaft) side.
9. Install rod cap, lubricate bolt threads with Needle Bearing Assembly Lubricant. Torque bolts evenly to 29.4 Nm + 60 degrees (21 lb-ft + 60 degrees).
10. Ensure that connecting rod assembly and crank pin are not binding and that there is proper side-to-side movement.
11. Install remaining piston and connecting rod assemblies.
12. Measure for head gasket thickness as previously outlined.
13. Refer to appropriate Sections and complete the engine assembly.

Rear Oil Seal

IMPORTANT: The later, D2.8L D-Tronic - serial number 0L098204 and above and D4.2L D-Tronic - serial number 0L099525 and above, engines had dimensional changes to the crankshaft, rear main bearing, rear main bearing carrier, thrust washers, O-ring seal, thrust plate (flywheel spacer) and flywheel seal. Ensure by serial number that the specifications and parts are the correct ones for the engine.


The rear main oil seal rides on both the flywheel and the crankshaft thrust plate (flywheel spacer).

Removal

1. Remove the flywheel housing rear portion.
2. **On Sterndrive (MCM) Models:** Remove the engine coupler.
3. **On Inboard (MIE) Models:** Remove the drive plate.
4. Remove the six flywheel retaining bolts and the flywheel.
5. Remove the thrust plate (flywheel spacer)

IMPORTANT: Do NOT damage main bearing carrier or thrust washers, in the following step.

6. CAREFULLY pry out the old seal using a suitable device.



- a** - Flywheel Housing (Rear Portion)
- b** - Flywheel Housing (Cylinder Block Portion)
- c** - Rear Main Bearing Carrier
- d** - Rear Oil Seal


Installation

IMPORTANT: Do NOT attempt to install rear main seal using a hammer or mallet. Damage to the seal or rear main bearing carrier could result. The seal is made of special compounds, Do NOT touch or handle the lips of the seal.

1. Lubricate outer surfaces of seal with clean engine oil.
2. Install new seal in carrier using tool 91-801111260 which will evenly PRESS the seal into position. Seal will stop (bottom-out) when seated.

IMPORTANT: Whenever thrust plate is removed renew O-ring.

3. Inspect crankshaft thrust plate (flywheel spacer). Be certain there are no scratches, nicks, cracks, or seizure marks on plate. Renew plate if any are found. (Only minor grooves or indentations can be removed.)
4. Install new O-ring into groove of thrust plate.



70304

- a** - Thrust Plate
b - O-Ring

5. Install thrust plate with O-ring towards crankshaft. Tighten thrust plate retaining screw securely.
6. Install the flywheel.

IMPORTANT: Flywheel bolts may be used a maximum of 3 times within the prescribed torque limits.

7. Lubricate threads of flywheel bolts (6) with clean engine oil and install. Torque bolts to 110 Nm (81 lb-ft).
8. **On Sterndrive (MCM) Models:** Install the coupler. Torque bolts to 30 Nm (22 lb-ft).
9. **On Inboard (MIE) Models:** Install the drive plate. Torque bolts to 72 Nm (53 lb-ft).
10. Install flywheel housing rear portion. Torque bolts to 50 Nm (37 lb-ft).
11. Complete the engine assembly.

Crankshaft and Main Bearings


IMPORTANT: The later, D2.8L D-Tronic - serial number 0L098204 and above and D4.2L D-Tronic - serial number 0L099525 and above, engines had dimensional changes to the crankshaft, rear main bearing, rear main bearing carrier, thrust washers, O-ring seal, thrust plate (flywheel spacer) and flywheel seal. Ensure by serial number that the specifications and parts are the correct ones for the engine.

Removal

1. Remove the pistons.
2. Remove the timing gear cover.
3. Remove the camshaft and lifters.
4. Remove the oil pump.
5. Proceed as outlined.

REAR MAIN BEARING CARRIER AND BEARINGS


1. Remove the flywheel housing (rear portion).
2. **On Sterndrive (MCM) Models:** Remove the engine coupler.
3. **On Inboard (MIE) Models:** Remove the drive plate.
4. Remove the six flywheel retaining bolts and the flywheel.
5. Remove 9 bolts and 6 nuts with washers retaining flywheel housing.
6. Remove cylinder block portion of flywheel housing.



70301

- a** - Flywheel Housing
- b** - Bolts With Washers
- c** - Nuts With Lockwashers
- d** - Vacant Holes (Not used)


7. Mark position of rear main bearing carrier in relation to block.



70302

- a** - Rear Main Bearing Carrier
- b** - Cylinder Block
- c** - Reference Mark


8. Remove the screw locking thrust plate to crankshaft.



70302

- a** - Locking Screw
- b** - Thrust Plate

9. To assist in removing the bearing carrier, temporarily reinstall the flywheel housing using only the nuts on the carrier.
10. Tap evenly around the housing as shown. The carrier and thrust plate will be pulled from the cylinder block.




70303

- a** - Nuts On Carrier (6)
- b** - Flywheel Housing
- c** - Plastic Hammer

11. Remove nuts temporarily holding the flywheel housing to the rear bearing carrier, and proceed to next appropriate section.

CRANKSHAFT AND MAIN BEARING CARRIERS


1. For proper installation during reassembly, note position of special locating screw retaining oil sender in cylinder block.
2. Remove main bearing oil feed locating screws which hold main bearing carriers in block.



70305

- a** - Main Bearing Oil Feed Locating Screws
- b** - Special Locating Screw
- c** - Oil Sender

3. Install Crankshaft Installer Tool 91-801333504 over timing gear.



70306


- a** - Crankshaft Installer Tool
- b** - Timing Gear

4. Turn engine vertical with front facing down.
5. Using a hoist and a suitable sling attached to crankshaft, lift crankshaft out of block.

MAIN BEARING CARRIERS AND BEARINGS

IMPORTANT: Before removing bearing carriers from crankshaft, number or mark them according to journal upon which they are fitted. Also make matching marks on both bearing carrier halves for correct reassembly. Do NOT mix parts.

1. After marking carriers, remove bolts and separate carrier halves. Remove carriers with bearings from crankshaft journals.




70307

- a** - Bolts with Washers
- b** - Bearing Carrier
- c** - Main Bearings

FRONT MAIN BEARING

NOTE: If bearings are being inspected prior to replacement, refer to Inspection, in this section, before removing front main bearing. If all bearings are being replaced proceed.

1. Assemble Bearing Puller 91-801333508 into front main bearing, as shown.



70308


- a** - Bearing Puller Tool
- b** - Front Main Bearing

2. Remove front main bearing.

TIMING GEAR

NOTE: Replace timing gear only if worn or damaged.

1. Install Crankshaft Gear Puller 91-801333503 and Crankshaft Pulley Puller 91-801763590 onto timing gear, as shown.
2. Remove the timing gear.
3. Remove the spacer if equipped.



70309

- a** - Gear Puller
- b** - Pulley Puller
- c** - Timing Gear
- d** - Spacer, If Equipped (Not Shown)

Cleaning

1. Immerse crankshaft in a solvent bath and clean.
2. Put on safety glasses.
3. Clear oil passages with compressed air.
4. Dry with compressed air.

Inspection

CRANKSHAFT

1. Visually inspect crankshaft for scratches, nicks, cracks and seizure marks. Replace if damaged.

IMPORTANT: No material may be removed, either by hand or machine grinding, from thrust faces of crankshaft.


2. Replace crankshaft if machined surfaces on front and rear ends or threaded areas of crankshaft ends are out-of-round, worn or damaged.
3. After a seizure, over-heating or grinding, crankshaft must be Magnafluxed to verify no surface cracks are present.

NOTE: It will be necessary to measure inner diameter of bearings in carriers and outer diameter of matching crankshaft journal to determine maximum clearance. Refer to the following section - Main Bearings (Measurement).

4. Measure journals of crankshaft to determine if replacement or grinding is necessary. Refer to specifications.

MAIN BEARINGS (MEASUREMENT)


1. Inspect bearings. Refer to Examples of Bearing Failures.
2. To check clearance of center main bearings:
 - a. Install bearings in original carrier halves, if removed.
 - b. Observing marks made earlier, assemble carriers. Torque bolts with washers to 42 Nm (31 lb-ft).
 - c. Measure inner diameter of bearing as shown.



70310

Measuring Inner Diameter Of Bearing

- d. Measure outer diameter of matching crankshaft journal as shown.




70311

Measuring Outer Diameter Of Journal

- e. Calculate difference between measurement taken in step c. and d. (clearance) and refer to specifications for maximum clearance of bearing being checked.

3. Measure rear main bearing clearance in the same manner as the center main bearings (no assembly of carrier is required).
4. To check clearance of front main bearing:
 - a. Measure crankshaft front main bearing journal.
 - b. Measure I.D. of front main bearing in cylinder block as shown.



70312

- c. Calculate difference between measurement taken in step a. and b. (clearance) and refer to specifications for maximum clearance.


TIMING GEAR

1. Ensure timing gear teeth are not worn or damaged.
2. Remove slight indentations with a very fine grade Carborundum stone.

Installation

FRONT MAIN BEARING

1. Align oil passage with hole of new bearing.




70313

- a** - Oil Passage
- b** - Bearing Hole

2. Place new bearing on Puller/Installer Tool 91-801333508 as shown. Tool will install bearing to the correct depth. Oil passage **MUST BE** aligned.

NOTE: To aid installation retain bearing halves on tool with a rubber band or similar.



70402


- a** - Tool 91-801333508
- b** - Bearing Halves (On Tool)

TIMING GEAR

IMPORTANT: The early model crankshaft gear has been superseded to a new gear. A spacer is required behind the new gear to install.

Description	D2.8L D-Tronic	D4.2L D-Tronic
Serial Numbers Breaks: for engines using late model gear and spacer	0L344916 And Above	0L344986 and Above

1. Warm the gear in a suitable oven to 180 - 200 degrees C (356 - 392 degrees F.).
2. Ensure timing reference dots are facing the FRONT of the engine.
3. Ensure crankshaft keyway and woodruff key are aligned.
4. On early models, install the timing gear. On later models or if replacing the early gear, install the new spacer and timing gear.




70309

- a** - Timing Gear
b - Spacer, If Equipped (Not shown)

MAIN BEARING CARRIERS AND BEARINGS

1. Install new bearing shells into matching carrier halves.
2. Lubricate bearings with clean engine oil.




70307

- a** - Main Bearing Shells
b - Main Bearing Carrier - Matching Halves

IMPORTANT: Piston oil jet MUST FACE FRONT (pulley end) of engine when installed.


- a. Identify piston oil jet location on all main bearing carriers.
- b. If not already accomplished, stake (peen) each oil jet in its bore in three places. Especially check the rear main bearing carrier oil jet and stake marks.



70382

- a** - Bearing Carrier
- b** - Piston Oil Jet Location
- c** - Stake (Peen) Marks

3. Ensure that all carriers are positioned so that piston oil jet faces FRONT of engine, as shown, when installing on journal. Install matching carrier halves (marked earlier) on crankshaft journals in their original locations. Lubricate bolts and washers with clean engine oil. Torque to 44.1 Nm (32 lb-ft).




70404

- a** - Piston Oil Jets (Face Front of Engine)
- b** - Arrow Indicates To Front Of Engine

CRANKSHAFT


1. Lubricate main bearing bores in crankcase with Molykote.



75389

- a** - Brush Dipped In Molykote
b - Main Bearing Bore

2. Install Crankshaft Installation Tool 91-801333504 on front gear to protect front main bearing.




70404

- a** - Tool 91-801333504

3. Position engine crankcase horizontal with oil pan flange facing up.
4. Carefully insert crankshaft, with main bearing carriers attached, into cylinder block.


5. Rotate all bearing carriers so that the ROUND hole through the casting faces as shown, toward oil pan flange. Ensure that piston oil jets are directed toward FRONT of engine.



70434

a - Bearing Carrier ROUND Hole

6. Install new sealing washers on all main bearing carrier locating hollow bolts and HAND THREAD CAREFULLY (to avoid damaging carrier threads) into bearing carriers. Where previously noted, install locating bolt for oil sending unit (after removing sending unit and adaptor nozzle from bolt, to allow torquing). Torque all bolts to 53.9 Nm (39 lb-ft).



70386


a - Carrier Locating Hollow Bolts
b - Sealing Washer(s)

7. Reinstall adaptor nozzle and oil sending unit on special locating screw. Tighten both securely.

REAR MAIN BEARING

IMPORTANT: Be certain to press bearing so as to prevent damage to notch arrangement in carrier where bearing tab aligns.

1. Using a suitable mandrel press bearing out of carrier.
2. When pressing new bearing into carrier, bearing tab and notch in carrier **MUST BE** aligned as shown.




70382

- a** - Bearing Tab
b - Notch In Carrier

REAR MAIN BEARING CARRIER


1. Refer to Rear Oil Seal - Installation and install new seal in carrier.



70406

- a** - Rear Main Oil Seal
b - Rear Main Bearing Carrier


2. Install standard size thrust washers into flywheel side of carrier as shown. (Use Quicksilver Needle Bearing Lubricant to help keep washers positioned.)



70407

a - Thrust Washers (Standard Size), Flywheel Side


3. Install standard size thrust washers into front (crankshaft) side of carrier. (Use Quicksilver Needle Bearing Lubricant to help keep washers positioned.)



70408

a - Thrust washers (Standard Size), Front (Crankshaft) Side


4. Install new O-ring into groove around carrier. Coat with clean engine oil to assist during installation.



70408

a - O-ring


5. Lubricate crankshaft journal and bearing with clean engine oil. Install rear main bearing carrier into cylinder block, align marks previously made. Always be certain lubrication holes on block and carrier align, especially when or if marks are not present.



70409

- a** - Rear Main Bearing Carrier
- b** - Marks Aligned

6. Install new O-ring into groove of thrust plate (crankshaft side).




70304

- a** - Thrust Plate
- b** - O-ring

7. Install thrust plate with O-ring towards crankshaft. Tighten retaining screw securely.

8. Install new O-ring into groove of flywheel housing as shown.



70410

a - O-ring


9. Install flywheel housing. Torque the 9 bolts with washers to 50 Nm (37 lb-ft). Then, torque the 6 rear main bearing carrier nuts with washers to 27 Nm (20 lb-ft).

IMPORTANT: Flywheel bolts may be used a maximum of 3 times within the prescribed torque limits.

10. Lubricate threads of flywheel bolts with clean engine oil and install flywheel. Torque bolts to 110 Nm (81 lb-ft).

CRANKSHAFT END-PLAY (AXIAL) CLEARANCE

1. Attach Dial Indicator 91-58222A1 to cylinder block to check installed crankshaft end-play (axial) clearance. Reading can be taken off of counter weight as shown. Move crankshaft fore and aft in block to obtain reading. Clearance should be 0.121-0.323 mm (.005-.013 in.).




70411

2. If clearance is incorrect, calculate the necessary thickness of thrust washers needed (from sizes listed in parts manual). Install different thickness thrust washers and recheck. Do this until proper clearance is obtained.

Cylinder Liners

Removal


1. Remove components as needed, including pistons.
2. Remove plate from Cylinder Liner Puller 91-801333502.



- a** - Cylinder Liner Puller Tool
b - Plate

IMPORTANT: Mark liners in a suitable fashion as to the cylinder number (to avoid mismatching to pistons upon reassembly) and orientation in block (reference to prechamber bore of head).

3. Install puller tool into cylinder and attach plate to tool at bottom of liner. Remove liner(s) as shown. Note location of shim between liner and crankcase bore relief. Also, note O-rings on liner lower part.




Identification

⚠ CAUTION

For D-Tronic Engines the cylinder liners are provided in one standard size and correspond to the tolerance class: **Class A**. Failure to use only the **Class A** liner designated for your engine, with matching **Class A** piston, will result in severe engine damage.

1. As shown in the following, inspect underside of liner for tolerance class identification reference mark (a small radial line). **NO MARK** should be present. The liner is a standard size **Class A** liner.
2. If a **MARK** is present the liner is a size **Class B** liner and is NOT for use on D-Tronic engines.
3. Refer to specifications - Liner I.D. for exact dimensions.




a - Cylinder Liner

b - Tolerance Size Class B Reference Mark -NOT For Use With D-Tronic Engines

Cleaning and Inspection

CYLINDER LINERS

1. Clean liners, especially at areas as shown, and where O-rings fit.




70414

a - Areas for Special Cleanliness

2. Check liners for abnormal wear or cracks. Replace as needed with those parts for your specific model.
3. Measure liners for out-of-round or taper with a dial or bore gauge, taking readings at three different vertical positions and at opposite sides of the liner bore. Refer to specifications.
4. When cylinder liner wear is within specifications light honing of the liner bore is allowed. Replace if liners are not within specifications.

CYLINDER BLOCK (LINER) BORES

1. Thoroughly clean the cylinder block with suitable solvent and blow dry with compressed air. Inspect for cracks or flaws.
2. Check cylinder head mating surfaces of block and area around cylinder liner bores for abnormal wear or damage.
3. Check block bores for damage and cleanliness, especially the flanges and counterbores for cylinder liners as shown.



70415

a - Areas for Special Cleanliness

4. If any checks or inspections reveal unacceptable conditions replace parts as needed with those for your specific model.

Installation

Cylinder liners on all engines are required to protrude (or rise above the surface of the block) 0.01 - 0.06 mm (.0004 - .0023 in.). By using one of three shims available (placed between the liner flange and the block during installation of liner) it is possible to obtain the correct protrusion.


1. To determine the correct shim thickness needed for each liner follow instructions a. - e.:

⚠ CAUTION

Ensure cylinder liners are fully seated in block in the following instructions or incorrect measurements will occur causing engine performance problems or severe engine damage.

NOTE: *Liners will spin freely in bore when the block and liner are completely clean and ready for assembly.*

- a. Unless being replaced, install liners in same cylinder block bore as marked or noted upon disassembly **WITHOUT shims or O-rings**.
- b. Using a precision depth gauge measure and record the amount of recess (depth below block surface) of each liner as shown.




- a** - Liner Recess (Depth of Liner in Block)
- b** - Cylinder Liner
- c** - Cylinder Block
- d** - Cylinder Head Mounting Surface of Block

70476

- c. Refer to the following chart to determine and select the shim thickness required:

Liner Recess BELOW Block (Without Shim)	Shim To Be Used (Thickness)	Liner Protrusion ABOVE Block (With Shim)
0.14 - 0.09 (.0055 - .0035)	0.15 (.0059)	0.01 - 0.06 (.0004 - .0023)
0.19 - 0.14 (.0074 - .0055)	0.20 (.0078)	
0.22 - 0.17 (.0086 - .0066)	0.23 (.0090)	


- d. Remove liner and install shim selected and refit liner.
e. Measure protrusion. Adjust using alternate shim if required.



70475

- a** - Cylinder Liner Protrusion (Height Above Block Surface)
b - Cylinder Liner
c - Cylinder Block
d - Shim


2. Tighten liners, with appropriate shims, to 30 Nm (22 lb-ft) and formed spacer-washers as shown.



75015

- a** - Liner
- b** - Suitable Bolt
- c** - Formed, Spacer-Washer


3. Recheck-liners for proper amount of protrusion using liner gauge bar 91-184812A1 (SAE) or 91-801333509 (Metric) and appropriate dial gauge as shown. If not as specified, adjust protrusion as previously outlined until each liner is protruded 0.01 - 0.06mm (.0004 - .0023 in.) above block.



75551

4. Remove liners in order, keeping appropriate shims matched to liners.

5. Install two BLACK O-rings in the grooves near the neck of the liner and one BROWN O-ring in groove at the bottom, as shown.




- a** - Shim
b - Black O-Rings (2)
c - Brown O-Ring (1)

6. Lubricate LOWER centering collars in cylinder block (those areas where lower liner O-rings seal against the bore) with Needle Bearing Lubricant 92-42649A1 or clean engine oil as shown.

IMPORTANT: Do NOT lubricate upper bore area.


NOTE: Liner shown fitted *ONLY* for visual clarity. Do NOT install liners in this step.



- a** - Lubricate This Area Of Cylinder Block (Lower Centering Collars)

7. Apply Loctite Master Gasket 92-12564--1 or Loctite 620 (obtain locally) to liner surfaces AS SHOWN.


IMPORTANT: Do NOT apply Loctite to shim or shim contact surfaces.



70414

a - Loctite Applied To These Areas ONLY

8. Install liners in block, being careful not to damage O-rings or distort shim. Hold liners securely in position with suitable bolts and head bolt formed, spacer-washers as shown. Torque bolts to 50 Nm (37 lb-ft). Allow Loctite to dry. (Do NOT release liners for approximately 1-1/2 to 2 hours.)



75015

a - Liner
b - Suitable Bolt
c - Formed, Spacer-Washer


9. Once again, verify cylinder liner protrusion and make corrections if required.
10. Continue engine assembly. Refer to appropriate procedures.

Flywheel Housing, Coupler / Drive Plate And Flywheel

Exploded View

STERNDRIVE (MCM) MODELS

NOTE: Some engines are equipped with a solid (Single Stage) coupler, in place of the Dual Stage coupler found on others.




73791

STERNDRIVE (MCM) MODELS (CONTINUED)

- 1** - Continuity Wire
- 2** - Washer
- 3** - Screw
- 4** - Rear Portion of Flywheel Housing - Sterndrive (MCM)
- 5** - Screw
- 6** - Lockwasher
- 7** - Grease Fitting
- 8** - Bravo Coupler Assembly
- 9** - Screw (6)
- 10** - Washer (6)
- 11** - Second Stage Coupler
- 12** - Screw and Washer
- 13** - Turbocharger Bracket
- 14** - Flat Washer and Lockwasher
- 15** - Turbocharger Mounting Screw (2)
- 16** - Screw, Flat Washer and Lockwasher (9)
- 17** - Flywheel Ring Gear
- 18** - Thrust Plate / Guide Ring O-ring Seal
- 19** - Set Screw and Thrust Plate / Guide Ring
- 20** - Flywheel With Ring Gear
- 21** - Flywheel Bolt (6)
- 22** - RPM Speed Sensor
- 23** - Wave Washer and Allen Head Screw
- 24** - O ring Seal
- 25** - Starter Stud, Washer, and Nut
- 26** - Flywheel Housing
- 27** - Lockwasher (6 mm)
- 28** - Screw, M6 x 1 x 20 (6)
- 29** - First Stage Coupler
- 30** - Two-Stage Coupler Assembly

Description		Part Number
A	Clean SAE 30W Engine Oil	Obtain Locally
B	Loctite 271 Thread Locker	92-809819

INBOARD (MIE) MODELS



INBOARD (MIE) MODELS (CONTINUED)

- 1** - Screw
- 2** - Washer
- 3** - Rear Portion of Flywheel Housing - Inboard (MIE)
- 4** - Drive Plate Screw
- 5** - Washer
- 6** - Typical Early Drive Plate (Later Plate Not Shown)
- 7** - Flywheel Screws
- 8** - Flywheel
- 9** - Set Screw
- 10** - Thrust Plate / Guide Ring
- 11** - Guide Ring O-ring
- 12** - Ring Gear
- 13** - Turbocharger Screw
- 14** - Lockwasher
- 15** - Washer
- 16** - Turbocharger Bracket
- 17** - Screw and Washer
- 18** - Flywheel Housing To Cylinder Block Screw
- 19** - RPM Speed Sensor
- 20** - Wave Washer and Allen Head Screw
- 21** - Starter Stud, Washer and Nut
- 22** - O-ring for Flywheel Housing
- 23** - Flywheel Housing


Description		Part Number
A	Clean SAE 30W Engine Oil	Obtain Locally
B	Loctite 271 Thread Locker	92-809819

IMPORTANT: The later, D2.8L D-Tronic - serial number 0L098204 and above and D4.2L D-Tronic - serial number 0L099525 and above, engines had dimensional changes to the crankshaft, rear main bearing, rear main bearing carrier, thrust washers, O-ring seal, thrust plate (flywheel spacer) and flywheel seal. Ensure by serial number that the specifications and parts are the correct ones for the engine.

Flywheel Housing

REMOVAL

1. Remove the starter.
2. Remove rear portion of flywheel housing.
3. **On Sterndrive (MCM) Models:** Remove engine coupler.
4. **On Inboard (MIE) Models:** Remove drive plate.
5. Remove the six flywheel retaining bolts and the flywheel.
6. Remove 9 bolts and 6 nuts, with respective washers, retaining flywheel housing.
7. Disconnect and remove the rpm speed sensor.
8. Remove flywheel housing.



70301

- a** - Bolts With Washers
- b** - Nuts With Lockwashers
- c** - Vacant Holes (Not used)

CLEANING


1. Remove old O-ring in groove of flywheel housing.
2. Clean all parts with solvent.
3. Put on safety glasses.
4. Dry parts with compressed air.

INSPECTION

1. Visually inspect rear portion of flywheel housing and flywheel housing for cracks, holes, and excessive wear.
2. Inspect O-ring on rpm speed sensor.
3. Replace if necessary.

INSTALLATION

1. Install new O-ring into groove of flywheel housing.



70410

a - O-ring

IMPORTANT: Flywheel housing fasteners and hardware must be installed from where removed.

2. Install flywheel housing. Torque the 9 bolts with washers to 50 Nm (37 lb-ft). Then, torque the 6 rear main bearing carrier nuts with washers to 27 Nm (20 lb-ft).

IMPORTANT: Flywheel bolts may be used a maximum of 3 times within the prescribed torque limits.

3. Lubricate threads of flywheel bolts with clean engine oil and install flywheel. Torque bolts to 110 Nm (81 lb-ft).
4. **On Sterndrive (MCM) Models:** Install engine coupler. Apply Loctite 271 to threads and torque bolts to 30 Nm (22 lb-ft).
5. **On Inboard (MIE) Models:** Install drive plate. Apply Loctite 271 to threads and torque bolts to 72 Nm (53 lb-ft).
6. Install rear portion of flywheel housing. Torque bolts to 50 Nm (37 lb-ft).
7. Using the screw and wave washer, install and connect the rpm speed sensor.
8. Install the starter and other components previously removed.


Sterndrive (MCM) Coupler / Inboard (MIE) Drive Plate

REMOVAL

1. Remove rear portion of flywheel housing.
2. **On Sterndrive (MCM) Models:** Remove engine coupler.
3. **On Inboard (MIE) Models:** Remove drive plate.

INSPECTION

1. Inspect splines in drive plate or coupler for wear.
2. **On Sterndrive (MCM) Models with two-stage couplers:** the first stage piece of the coupler can be replaced. Remove as necessary.



78383


- a** - Two Stage Coupler Assembly
b - Coupler (First Stage Piece)

3. Inspect drive plate or coupler for warping.
4. Replace as necessary.

INSTALLATION

1. On Sterndrive (MCM) Models with two-stage couplers:

- a. Install first stage piece if being replaced.
- b. Apply Loctite 271 to threads and torque 6M bolts with lockwashers to 16 Nm (12 lb-ft).



78383

- a** - Two Stage Coupler Assembly
b - Coupler (First Stage Piece)
c - 6M Bolts With Lockwashers

2. **On Sterndrive (MCM) Models:** Install engine coupler. Apply Loctite 271 to bolt threads. Torque bolts to 30 Nm (22 lb-ft).
3. **On Inboard (MIE) Models:** Install drive plate. Apply Loctite 271 to bolt threads. Torque bolts to 72 Nm (53 lb-ft).
4. Install rear portion of flywheel housing. Torque bolts to 50 Nm (37 lb-ft).
5. Install other components previously removed.

Flywheel

REMOVAL

Refer to Flywheel Housing in this SECTION 3A.

CLEANING

1. Clean mating surfaces of flywheel and thrust plate. Remove any burrs. Mating surfaces must be clean bare metal.

INSPECTION

1. Check flywheel ring gear for worn and missing teeth.
2. Replace as necessary.

INSTALLATION


Refer to Flywheel Housing in this SECTION 3A.

Engine Mounts

Front Mounts

IMPORTANT: There are two different types of mounts being used on the D2.8L D-Tronic. Serial numbers 0L343125 and below use an early front mount. Serial numbers 0L343126 and above use a later front mount. Follow these serial number breaks if a front mount is being replaced. Only use the late front mounts on engines with the early serial numbers if the rear bushing are also replaced.


The front engine mounts can be installed two ways. Mark the mounts before removing them from cylinder block to ensure installation in same location.



50533

Front Mount Standard Position

NOTE: Reverse mount pad on front mounts by loosening clamp bolts and turning pad over.




50533

Front Mount Alternate Position

- a** - Mount Bracket
- b** - Bolts
- c** - Mount Pad
- d** - Clamp Bolt


MIE (Inboard) Transmission Mounts



27035

Transmission Mount Components


- a** - Base
- b** - Housing
- c** - Bushing
- d** - Trunion (Pin)
- e** - Snap Ring
- f** - Bracket
- g** - Clamping Bolt



50533

Standard Mount Position

- a** - Mount Bracket
- b** - Bolts



27035

Alternate Mount Position

Engine 20-Hour Break-In Period

The first 20 hours of operation is the engine (new or rebuilt) break-in period. During this period, it is extremely important that the engine is operated as outlined in the following.

1. Do NOT operate engine below 1500 rpm for extended periods of time during the first 10 hours. During this period, shift into gear as soon as possible after starting engine and advance throttle so that rpm is above 1500 (provided that conditions permit safe operation at this speed).
2. Do NOT operate at any one constant speed for extended periods of time.
3. Do NOT exceed 75% of full throttle during the first 10 hours except during the Engine Initial Break-In Procedure. During the next 10 hours, occasional operation at full throttle (5 minutes at a time maximum) is permissible.
4. AVOID full throttle accelerations from stopped position.
5. Do NOT operate at full throttle until engine reaches normal operating temperature.
6. OBSERVE INSTRUMENTATION carefully. If an abnormal reading occurs, stop engine immediately and determine cause.
7. FREQUENTLY CHECK crankcase oil level and add oil if necessary. It is normal for oil consumption to be somewhat high during the break-in period.
8. AT END OF THE 20-HOUR BREAK-IN PERIOD, drain oil from crankcase and replace oil and filter. Fill crankcase with correct grade and viscosity oil.

After Break-in Period

To help extend the life of your Mercury MerCruiser power package, the following recommendations should be considered;

- Use a propeller that allows the engine to operate at or near the top of the maximum rpm range when at full throttle with a normal boat load.
- Operation at 3/4 throttle setting or lower is recommended. Refrain from prolonged operation at maximum full throttle rpm.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

ELECTRICAL SYSTEM


Section 4A - Starting System

Table of Contents

Identification	4A-3	Testing Voltage	4A-6
Specifications	4A-3	Removal	4A-7
Torque Specifications	4A-3	Starter Motor	4A-7
Lubricants / Sealants / Adhesives	4A-3	Solenoid Switch	4A-8
Replacement Parts	4A-4	Installation	4A-9
Starting System Components	4A-4	Solenoid Switch	4A-9
Inspection	4A-6	Starter Motor	4A-10
Periodic Inspection	4A-6		

THIS PAGE IS INTENTIONALLY BLANK

Identification



70809

a - Identification Number Location On Starter

Specifications

IMPORTANT: The starter motor is designed to operate under great overload and produce a high horsepower for its size. It can do this only for a short time, since considerable heat accumulates and can cause serious damage. For this reason, the cranking motor must never be used for more than 15 seconds at any one time. Cranking should not be repeated without a pause of at least 2 minutes to permit the heat to escape.

Description	Specification
I.D. Number	0 001 362 3--
Engine Rotation	Left Hand (Counterclockwise)
Minimum Required Cranking Battery Size (4 and 6 cylinder)	750 cca, 950 mca or 180 Ah
No-Load Test	11.5 Volts, 125 Amps At 7000 rpm

Torque Specifications

Description	Nm	lb-in.	lb-ft
Starter Motor	68		50
Solenoid	Tighten Securely		

Lubricants / Sealants / Adhesives


Description	Part Number
Liquid Neoprene	92-25111--3
2-4-C Marine Lubricant With Teflon	92-802861Q1

Replacement Parts

⚠ WARNING

Electrical system components on this engine are not external ignition protected. Do NOT STORE OR UTILIZE GASOLINE ON BOATS EQUIPPED WITH THESE ENGINES, UNLESS PROVISIONS HAVE BEEN MADE TO EXCLUDE GASOLINE VAPORS FROM ENGINE COMPARTMENT (REF: 33 CFR) Failure to comply could result in fire, explosion and/or severe personal injury

Starting System Components



Typical

Starting System Components (continued)

- 1** - Ignition (Start) Switch, (Start/Stop)
- 2** - 20 Ampere Fuse
- 3** - Remote Control Neutral Safety Switch [MCM (Sterndrive)]
- 4** - Instrument/ Extension Harness Connector at Electrical Box
- 5** - Circuit Breaker
- 6** - Circuit Breaker
- 7** - Start Relay
- 8** - Main Relay
- 9** - ECM / Fuel System Harness Connector at Electrical Box
- 10** - ECM
- 11** - Battery
- 12** - Starter
- 13** - Electronic Shut-Off Solenoid

-  **1.** Wire routing on Sterndrive (MCM) engine and instrument harness with Neutral Safety Switch located in remote control.
-  **2.** Wire routing on Inboard (MIE) engine and instrument harness with Neutral Safety Switch located on transmission.
-  **3.** Shown for clarification of start and stop circuits.

Inspection

Periodic Inspection

Starter motor with solenoid is completely enclosed when mounted to the drive housing to prevent entrance of moisture and dirt. However, periodic inspection is required.

1. Inspect terminals for corrosion and loose connections.
2. Inspect wiring for frayed and worn insulation.
3. Ensure that mounting nuts are tight.
4. Ensure that mounting surfaces under the starter motor and the mounting bolts are free of paint and corrosion. Treat with lubricant to prevent corrosion.

Testing Voltage

Always test the voltage at the starter motor to ensure a minimum of 9.5 volts during cranking.

IMPORTANT: Voltage below 9.5 causes excessive heat build up, which can damage the starter motor and weld the starter solenoid contacts together.

1. Ensure that battery is fully charged.
2. Connect voltmeter positive (+) lead to the terminal on the starter solenoid.
3. Connect voltmeter negative (–) lead to the starter motor case. Ensure that there is good metal contact to prevent a false voltage reading.
4. Crank engine for 10 seconds and record voltmeter reading.
5. A reading of 9.5 volts or more verifies starter motor is getting sufficient voltage.

NOTE: *If the starter is getting at least 9.5 volts and the engine is not cranking properly, remove the glow plugs or hole plugs and try turning the engine over by hand. If the engine turns over freely by hand, the starter motor could have a problem.*

6. A reading below 9.5 volts suggests a voltage loss between the battery and the starter. Refer to Testing Voltage Drop.


Removal

Starter Motor

⚠ WARNING

Always disconnect battery cables from battery before working around electrical system components to prevent injury to yourself or damage to electrical system.

1. Disconnect battery cables from battery.
2. Disconnect wires from starter.
3. Remove starter mounting nuts and lockwashers.
4. Pull starter motor away from flywheel and remove from engine.




70810

- a** - Battery Cable
- b** - RED Wire
- c** - YELLOW/RED Solenoid Wire
- d** - Mounting Nuts with Lockwashers (2 Total, One Not Shown)

Solenoid Switch


1. Remove starter motor.
2. Remove nut from the field wire on the solenoid.



70811

a - Field Wire Nut


3. Remove screws retaining solenoid.



70812

a - Screws

4. Slide solenoid plunger off shift lever.



70813

a - Solenoid Plunger


b - Shift Lever

5. Remove solenoid from starter assembly.

Installation

Solenoid Switch


1. Apply a light coat 2-4-C Marine Lubricant with Teflon to the shift lever and sliding portion of the pinion.
2. Slide solenoid plunger onto shift lever.



70833

- a** - Solenoid Plunger
- b** - Shift Lever
- c** - Drive Gear


3. Install solenoid screws and tighten securely.



70812

- a** - Solenoid Screws

4. Install nut on the field wire terminal and tighten securely.




70811

- a** - Field Coil Wire
- b** - Hex Nut

Starter Motor


1. Apply a light coat of 2-4-C Marine Lubricant With Teflon to mounting surfaces and fasteners prior to installation.
2. Position starter motor on engine.
3. Install lockwashers and nuts. Torque nuts to 68 Nm (50 lb-ft).



70810

a - Lockwasher and Nut (1 Not Shown)

4. Connect wires to starter solenoid.



70810

a - RED Wire
b - YELLOW/RED Solenoid Wire
c - Positive (+) Battery Cable

5. Coat terminals with Liquid Neoprene sealer.
6. Slide rubber boot over positive (+) terminal connection.
7. Connect battery cables to battery.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

Electrical Systems

Section 4B - Charging System

Table of Contents


Identification	4B-3	Circuitry Test	4B-10
Replacement Parts Warning	4B-3	Output Circuit	4B-11
Specifications	4B-4	Excitation Circuit	4B-12
Torque Specifications	4B-4	Sensing Circuit	4B-13
Special Tools	4B-5	Current Output Test	4B-14
Lubricants/Sealers/Adhesives	4B-5	Exploded View	4B-16
Wire Color Code Abbreviations	4B-5	Removal	4B-17
Precautions	4B-6	Alternator	4B-17
General	4B-6	Alternator Bracket	4B-17
Electronic Diesel Injection (EDI)		Installation	4B-18
Electrical System Precautions	4B-6	Alternator Bracket	4B-18
Battery Precautions - Multiple EDI		Alternator	4B-18
Engines	4B-7	Battery Isolators	4B-19
Charging System Components	4B-8	Dual Battery Charging Systems	4B-19
Inspection	4B-9	Battery Isolator Diagram	4B-20
Troubleshooting Tests (Alternator on Engine)	4B-10		

THIS PAGE IS INTENTIONALLY BLANK

NOTICE

For information and procedures on Troubleshooting, refer to SECTION 1C.

Identification



72078

Mando 65 Amp Alternator

- a** - "EX" Terminal - Excitation Wire
- b** - "S" Terminal - Sensing Wire
- c** - Mando Part Number (Location Not Shown in This View)
- d** - "P" (AC) Terminal
- e** - "L₂" Terminal
- f** - "B" Terminal

Replacement Parts Warning

⚠ WARNING

Electrical, ignition and fuel system components on your Mercury MerCruiser are designed and manufactured to comply with U.S. Coast Guard Rules and Regulations to minimize risks of fire and explosion.

Use of replacement electrical, ignition or fuel system components, which do not comply with these rules and regulations, could result in a fire or explosion hazard and should be avoided.

Specifications

Description	Specification
Excitation Circuit	1.3-2.5 Volts
Current Output	65 Ampere
Voltage Output	13.9-14.7 Volts
Condenser Capacity	.5 MFD
V-Belt Tension	5 mm (3/16 In.) ¹

¹ : Depress belt with thumb at midway point between circulating pump pulley and alternator.

Torque Specifications

Description	Nm	lb-in.	lb-ft
Pulley Nut	58		33
Alternator Brace to Alternator	28		20
Alternator Brace to Engine Block	41		30
Alternator to Mounting Bracket	48		35
Alternator Mounting Bracket to Engine Block	41		30

Special Tools

Description	Part Number
Magneto Analyzer	91-76032
Bearing Removal and Installation Kit	91-31229A5
Universal Puller Plate	91-37241
Multi-Meter / DVA Tester	91-99750A1
Ammeter (0-70)	Obtain Locally

Lubricants / Sealers / Adhesives

Description	Part Number
Liquid Neoprene	92-25711--1

Wire Color Code Abbreviations

BLK	Black		PUR or PPL	Purple
BLU	Blue		RED	Red
BRN	Brown		TAN	Tan
GRY	Gray		WHT	White
GRN	Green		YEL	Yellow
ORN	Orange		LIT or LT	Light
PNK	Pink		DRK	Dark

Precautions

General

CAUTION

The following precautions **MUST BE** observed when working on the charging system. Failure to observe these precautions may result in serious damage to the alternator or charging system.

- **Do NOT** attempt to polarize the alternator.
- **Do NOT** short across or ground any of the terminals on the alternator, except as specifically instructed in the Troubleshooting Tests.
- **NEVER** disconnect the alternator output lead or battery cables when the alternator is operating
- **NEVER** disconnect regulator lead from alternator regulator terminal when the alternator is operating.
- **ALWAYS** remove negative (-) battery cable from battery before working on the charging system.
- When installing battery, connect battery cables to battery by **FIRST** installing positive (+) battery cable end on positive (+) battery terminal. Tighten clamp securely. **THEN** install negative (-) battery cable end on negative (-) battery terminal. Tighten clamp securely
- If a charger or booster battery is to be used, connect it in parallel with existing battery (positive to positive; negative to negative).

Electronic Diesel Injection (EDI) Electrical System Precautions

CAUTION

Avoid damage to the EDI electrical system and components. Refer to the following precautions when working on or around the EDI electrical harness or when adding other electrical accessories:

- Do NOT tap accessories into engine harness.
- Do NOT puncture wires for testing (Probing).
- Do NOT reverse battery leads.
- Do NOT splice wires into harness.
- Do NOT attempt diagnostics without proper, approved Service Tools.

Battery Precautions - Multiple EDI Engines

SITUATION

Alternators: Alternators are designed to charge the battery that supplies electrical power to the engine that the alternator is mounted on. When batteries for two different engines are connected, one alternator will supply all of the charging current for both batteries. Normally, the other engine's alternator will not be required to supply any charging current.

EDI Engine Control Module (ECM): The ECM requires a stable voltage source. During multiple engine operation, an onboard electrical device may cause a sudden drain of voltage at the engine's battery. The voltage may go below the ECM's minimum required voltage. Also, the alternator on the other engine may now start charging. This could cause a voltage spike in the engine's electrical system.

In either case, the ECM could shut off. When the voltage returns to the range that the ECM requires, the ECM will reset itself. The engine will now operate normally. This ECM shut down usually happens so fast that the engine just seems to have misfired.

RECOMMENDATIONS

Batteries: Boats with multi-engine EDI power packages require each engine be connected to its own battery. This ensures that the engine's Electronic Control Module (ECM) has a stable voltage source.

Battery Switches: Battery switches should always be positioned so each engine is operating off its own battery. Do NOT operate engines with switches in **BOTH** or **ALL** position. In an emergency, another engine's battery can be used to start an engine with a dead battery.


Battery Isolators: Isolators can be used to charge an auxiliary battery used only for accessories. Isolators should not be used to charge the battery of another engine in the boat.

Generators: The generator's battery should be considered another engine's battery.

Charging System Components

The alternator system consists of the alternator, battery, the ignition switch and the wiring which connects these components.

NOTE: The wire color codes vary between models and are not shown. Refer to SECTION 4E Wiring Diagrams for color code information.



75420

Typical

- a** - Battery Meter
- b** - Ignition Switch
- c** - Harness Plug and Connector
- d** - Alternator
- e** - Circuit Breaker
- f** - Starter Motor
- g** - Ground Stud
- h** - Battery

Inspection

CAUTION

Always disconnect battery cables from battery before working around the electrical system components to prevent injury to yourself or damage to electrical system.

1. Inspect entire alternator system for corroded or loose connectors.
2. Check wiring for frayed or worn insulation.
3. Check alternator drive belt for excessive wear, cracks, fraying and glazed surfaces. Also, check drive belt tension and adjust, if necessary, as explained under Drive Belt Tension Adjustment.
4. Check alternator mounting bolts for adequate tightness.

Troubleshooting Tests (Alternator on Engine)

Use the following tests in conjunction with the Troubleshooting in SECTION 1C. Before proceeding with the tests, however, perform the following checks to eliminate possible problem areas. Also observe Precautions, preceding, to prevent damage to alternator system.


1. If problem is an undercharged battery, check to ensure that undercharged condition has not been caused by excessive accessory current draw or by accessories which have accidentally been left on. Also, ensure that undercharged condition has not been caused by operating engine at too low a speed for extended periods of time.
2. Check physical condition and state of charge of battery. Battery **MUST BE** at least 75% (1.230 specific gravity) of fully charged to obtain valid results in the following tests. If not, charge battery before testing system.
3. Inspect entire alternator system wiring for defects. Check all connections for tightness and cleanliness, particularly battery cable clamps and battery terminals.
4. Check alternator drive belt for excessive wear, cracks, fraying and glazed surfaces and replace if necessary. Also, check drive belt tension and adjust if necessary, as outlined under Drive Belt Tension Adjustment.

Circuitry Test

Perform the following tests, using a 0-20 volt DC voltmeter, to ensure that all of the circuits between the alternator and the other components within the alternator system are in good condition.

Output Circuit

1. Ensure battery is fully charged with the hydrometer test.
2. Start the engine and increase rpm to approximately 1500 rpm.
3. Check voltage reading. the voltage should be between 13.8 and 14.2 volts. If the reading is below 13,8 volts:
4. Connect positive (+) voltmeter lead to alternator output terminal.
5. Connect negative (-) lead to a ground terminal on alternator.
6. Wiggle engine wiring harness while observing voltmeter. Meter should indicate approximate battery voltage and should not vary. If no reading is obtained, or if reading varies, check alternator output circuit for loose or dirty connections or damaged wiring.




72784

- a** - Output Wire - BLUE
- b** - Excitation Wire - PURPLE
- c** - Sensing Wire - RED/PURPLE
- d** - Voltmeter (0-20 Volts)
- e** - Ground

Excitation Circuit

1. Connect positive (+) voltmeter lead to tie strap/terminal on alternator and negative (–) lead to a ground terminal on alternator (Test 1).
2. Turn ignition switch to RUN position and note voltmeter reading. Reading should be 1.3 to 2.5 volts.
3. If no reading is obtained, an opening exists in alternator excitation lead or in excitation circuit of regulator. Unplug PURPLE lead from regulator. Connect positive voltmeter lead to PURPLE lead and negative voltmeter leads to ground (Test 2). If voltmeter now indicates approximate battery voltage, voltage regulator is defective and the alternator must be replaced. If no voltage is indicated, check excitation circuit for loose or dirty connections or damaged wiring.
4. If reading is between .75 and 1.1 volts, rotor field circuit probably is shorted or grounded.
5. If reading is between 6.0 and 7.0 volts, rotor field circuit probably is open.




72785

- a** - Excitation Wire - PURPLE
- b** - Sensing Wire - RED or GREEN
- c** - Tie Strap/Terminal
- d** - Voltmeter (0-20 Volts)
- e** - Ground

Sensing Circuit

1. Unplug RED or GREEN lead from voltage regulator.
2. Connect positive (+) voltmeter lead to RED or GREEN lead and negative (–) voltmeter lead to ground terminal.
3. Voltmeter should indicate battery voltage. If battery voltage is not present, check sensing circuit for loose or dirty connection or damaged wiring.



72786

- a** - Output Wire - BLUE
- b** - Excitation Wire - PURPLE
- c** - Sensing Wire - RED or GREEN
- d** - Voltmeter (0-20 Volts)
- e** - Ground


Current Output Test

Perform this test to check if alternator is capable of producing rated current output, using a 0-80 amp DC ammeter.

⚠ WARNING

Ensure engine compartment is well-ventilated and that there are no gasoline vapors present (during the test) to prevent the possibility of an explosion and/or a fire, should a spark occur.

1. Disconnect negative (–) battery cable from battery.
2. Disconnect BLUE lead from alternator output terminal and connect ammeter in series between lead and output terminal. Connect positive (+) side of ammeter toward output terminal.
3. Reconnect negative battery cable.
4. Turn on all accessories and turn ignition switch to RUN position, and allow glow plug system to operate through one cycle. Turn switch to OFF position. Turn off accessories.
5. Start engine and adjust engine speed to 1500-2000 rpm. Quickly observe ammeter. Reading should be at least 30 amps.
6. If reading is low, stop engine and connect a jumper wire between alternator output terminal and regulator terminal. Repeat Steps 4. and 5.
7. If reading is now within specifications, diodes are faulty. Replace the alternator.
8. If reading is still low with jumper wire connected, perform Voltage Output Test, following.




72787

- a** - Output Wire - BLUE
- b** - Ammeter (0-80 Amps)
- c** - Jumper Lead
- d** - Regulator Terminal
- e** - Ground

Perform this test to determine if voltage regulator is operating correctly, using a 0-20 volt DC voltmeter.

IMPORTANT: Battery MUST BE fully charged (1.260 or above specific gravity) to obtain proper voltage reading in this test. If necessary, charge battery with a battery charger or allow engine to operate a sufficient length of time to fully charge battery before taking reading.


1. Connect positive (+) voltmeter lead to positive battery terminal and negative (-) voltmeter lead to negative terminal.
2. Start engine and operate at fast idle until engine reaches normal operating temperature. Adjust engine speed to 1500-2000 rpm and observe voltmeter for highest reading. Reading should be between 13.9 and 14.7 volts.
3. If reading is high, check for a loose or dirty regulator ground lead connection. If connection is good (and sensing circuit checked out good in Circuitry Test), voltage regulator is faulty and the alternator must be replaced. Ensure that battery cables are disconnected before attempting to remove alternator.



72788

- a** - Excitation Wire - PURPLE
- b** - Sensing Wire - RED or GREEN
- c** - Ground Wire - BLACK
- d** - Output Wire - BLUE
- e** - Voltmeter (0-20 Volts)

Exploded View



74467


- 1 - Key
- 2 - Alternator
- 3 - Spacer (1 Shown, Some Models May Have 1 Upper and 1 Lower Spacer)
- 4 - Bracket
- 5 - Screw and Lockwasher (M14)
- 6 - Mounting Bolt (M8)
- 7 - Mounting Nut (M8)
- 8 - Alternator Brace
- 9 - Alternator Brace Spacer
- 10 - Brace Bolt, Washers and Nut (M10)
- 11 - Tensioning Bolt, Lockwasher and Flat Washer
- 12 - Pulley, Lockwasher and Nut
- 13 - Alternator V-Belt

Description		Part Number
A	Liquid Neoprene	92-25711--1

Removal

Alternator

1. Disconnect battery cables from battery.
2. Disconnect wiring harness from alternator.
3. Loosen alternator support bracket screw.
4. Remove the drive belt.
5. Remove the alternator brace attaching bolt and washer.
6. Remove the alternator mounting bolt, washer and nut.



78310

- a** - Alternator Brace
- b** - Brace Bolt
- c** - Alternator Mounting Bolt

7. Remove the alternator.

Alternator Bracket

1. Remove the alternator.
2. Remove the bracket mounting bolts. Note the position of the spacer, or of the upper and lower spacers.
3. Remove the bracket.

Installation


Alternator Bracket

IMPORTANT: If the mounting bracket has been removed, refer to the Exploded View. Be certain that the mounting spacer and proper length brace spacer are in position for the appropriate engine.

1. Position the spacer, or spacers, between the bracket and the engine block.
2. Install the bracket mounting bolts. Torque the bolts to 41 Nm (30 lb-ft).
3. Install the alternator.

Alternator


1. Position the alternator in the mounting bracket.
2. Install the mounting bolt.
3. Position spacer, if equipped, and fasten the alternator brace to the alternator.
4. Position the alternator drive belt on the pulleys and adjust the tension.
5. Torque the alternator brace to alternator bolt to 28 Nm (20 lb-ft).
6. Torque the alternator brace to engine block bolt to 41 Nm (30 lb-ft).
7. Torque the mounting bolt to 48 Nm (35 lb-ft).



74301

- a** - Alternator Bracket
- b** - Spacer
- c** - Brace
- d** - Brace To Alternator Bolt
- e** - Brace To Block Bolt
- f** - Mounting Bolt

8. Reconnect the wiring harness to the alternator. Coat terminals with liquid neoprene.



72838

- a** - Excitation Wire - PURPLE
- b** - Sensing Wire - RED or GREEN
- c** - Ground Wire - BLACK
- d** - Output Wire - BLUE
- e** - Charge Indicator Lamp Lead - BROWN

9. Connect battery cables to battery.

Battery Isolators

Dual Battery Charging Systems

NOTE: Mercury MerCruiser engines equipped with a 3-wire, belt driven alternator, can use a battery isolator.

Battery isolators allow the addition of an auxiliary (second) battery to the Mercury MerCruiser electrical system. The auxiliary battery is primarily used as a power source for various accessories installed on the boat. The battery isolator will allow the alternator to charge both the cranking and auxiliary batteries at the same time while preventing accessories, connected to the auxiliary battery, from drawing power from the cranking battery.


Mercury Marine does not manufacture any battery isolator systems. Battery isolators must be bought from an outside manufacturer. Mercury Marine suggests following the manufacturer's instructions carefully.

IMPORTANT: Alternators used on Mercury MerCruiser engines ARE NOT equipped with an isolation diode.

⚠ CAUTION

Follow battery isolator manufacturer's instructions for wire gauge. Battery isolator installation must conform to BIA Low Voltage Wiring Standard No. 125-79.

Battery Isolator Diagram



72934

Typical Alternator

- a** - Isolator
- b** - Alternator
- c** - Starter
- d** - Cranking Battery
- e** - Auxiliary Battery
- 1** - BLUE Wire From Alternator Battery Terminal
- 2** - 8 Gauge Minimum

1. Sufficient Gauge Wire Spliced To Connect As Shown.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

ELECTRICAL SYSTEMS

Section 4C - Glow Plug System

Table of Contents

Identification	4C-3	Inspection	4C-7
Specifications	4C-3	Installation	4C-8
Torque Specifications	4C-4	Glow Plug Actuator Relay and Auxiliary	
Lubricants / Sealants / Adhesives	4C-4	Relay	4C-9
Special Tools	4C-4	Testing	4C-9
Description	4C-4	Removal	4C-10
Precautions	4C-4	Cleaning	4C-10
Glow Plug Testing (Prior to Removal)	4C-5	Inspection	4C-10
Removal	4C-6	Installation	4C-10
Cleaning	4C-7	Glow Plug Circuit Diagram	4C-11

THIS PAGE IS INTENTIONALLY BLANK

Identification



75496

D2.8L D-Tronic and D4.2L D-Tronic Glow Plug

Specifications

NOTE: Glow plug system will work only when engine temperature is below 50 degrees C (22 degrees F.).

D2.8L D-TRONIC ENGINE

Description	Specification
Glow Plug Diameter and Thread	M12 x 1.25
Nominal Voltage	11 Volts
Current Draw after 30 Seconds of Operation	7.5 - 9.5 Amps
Preheat Time and Afterglow Time	Controlled by ECM
Voltage drop, with test current after 30 seconds	0.63 - 0.77 Volt

D4.2L D-TRONIC ENGINE

Description	Specification
Glow Plug Diameter and Thread	M12 x 1.25
Nominal Voltage	11 Volts
Current Draw after 30 Seconds of Operation	7.5 - 9.5 Amps
Preheat Time and Afterglow Time	Controlled by ECM
Voltage drop, with test current after 30 seconds	0.50 - 0.60 Volt

Torque Specifications

NOTE: Securely tighten all fasteners not listed below.

Description	Nm	lb-in.	lb-ft
Glow Plug	23		17

Lubricants / Sealants / Adhesives

Description	Part Number
Liquid Neoprene	92-25711--3

Special Tools

Description	Part Number
Volt / Ohm Meter	91-93572

Description

The D-Tronic engines are not equipped with glow plugs as standard equipment. Description and operation are explained in case the optional kit is installed.

This glow plug system consists of the ECT (Engine Coolant Temperature) sensor, the ECM, two power supply relays, glow plug harness and four or six glow plugs. The time period during which the glow plugs are turned ON (supplied 12 volts) depends directly on the temperature of the engine coolant as determined by the ECT sensor and the altitude of the engine as sensed by the BARO pressure sensor located inside the ECM. The ignition OFF time in which the engine can be restarted without the preheat cycle is about 20 seconds.

When the ignition switch is turned ON, a preheat indicator lamp will illuminate indicating that the system is activated. Once proper engine temperature is reached (approximately 60 degrees C [140 degrees F.]), the preheat indicator lamp goes out and an after-glow operation of the glow plugs continues depending on the ECM signal. This cyclic operation of the glow plugs provides for reduced white smoke during start-up, reduced cold engine noise and reduced emissions.


Precautions

WARNING

Always disconnect battery cables from battery before working around electrical system components to prevent injury, or damage to the electrical system.

Glow Plug Testing (Prior to Removal)

10. Disconnect battery cables from battery.
11. Remove hex nut and washer from glow plug terminal.
12. Remove voltage supply wire.
13. Remove glow plug connecting wire from glow plug terminal.




77940

- a** - Voltage Supply Wire
- b** - Glow Plug Terminal
- c** - Glow Plug Connecting Wire

14. Connect ohmmeter between engine ground and glow plug terminal. Continuity should exist. If no continuity exists, glow plug is faulty.

Removal

1. Disconnect battery cables from battery.
2. Remove hex nut and washer from glow plug terminal.
3. Remove voltage supply wire.
4. Remove glow plug connecting wire from glow plug terminal.



77940

- a** - Voltage Supply Wire
- b** - Glow Plug Terminal
- c** - Glow Plug Connecting Wire

IMPORTANT: Avoid contaminating cylinders. Clean any corrosion or debris away from around glow plug before removal.


5. Clean any dirt away from around glow plug and opening in cylinder head.
6. Remove glow plug.

Cleaning

1. Clean contact area of connecting wire ring terminals.
2. Clean the power supply wire terminal end.
3. Clean cylinder head glow plug seat area.
4. Clean the glow plug threaded areas, seat and heating element (tip).

Inspection

1. With glow plug removed, connect ohmmeter between glow plug terminal (+) and glow plug external (–) threads. Continuity should exist. If no continuity exists, glow plug is faulty.
2. Connect a VOM and check resistance between glow plug terminal (+) and glow plug external (–) threads. Refer to Specifications for value.



Typical

- a** - Terminal (+)
- b** - External Threads (–)


Installation

1. Install glow plug. Torque to 23 Nm (17 lb-ft).
2. Ensure contact areas are clean.

⚠ CAUTION

Avoid shorting electrical circuits. Some voltage supply wire ring terminal ends are large and could contact the cylinder head which is grounded (-). Be certain ring terminal is isolated to the glow plug terminal.

3. Attach connecting wire to glow plug terminal. Ensure that the voltage supply wire is present where previously removed. Supply wire must not contact the cylinder head when installed.



77940

Typical

- a** - Contact Areas
- b** - Voltage Supply Wire Ring Terminal End
- c** - Connecting Wire

4. Coat all connections with liquid neoprene.
5. Connect battery cables to battery.

Glow Plug Actuator Relay and Auxiliary Relay

For more information on circuit description and testing refer to SECTION 5E - Diagnostic Circuit Checks.

Testing

1. Ensure battery is fully charged.
2. Check the following before testing relays:
 - a. All wires in circuit are connected.
 - b. Plug-in connectors are fully engaged.
 - c. All connections are corrosion free.
 - d. Engine Coolant Temperature switch appears to be present and in usable condition.
 - e. Circuit breakers on electrical box are not open (tripped).
 - f. Fuse at instrument panel is not defective (blown).

3. The following information applies to operations/tests of the main Glow Plug Actuator Relay:

NOTE: *The relay numbers can be found on the bottom of the relay.*

- Terminal 30 is connected to battery voltage through a circuit breaker.
 - Terminal 86 is connected to terminal 30.
 - Terminal 87 is connected (a circuit is formed) to terminal 30 in the energized (ON) position. Terminal 87 then supplies battery voltage to one half of the engines glow plugs and to the glow Plug Auxiliary Relay.
 - Terminal 85 is grounded by the ECM, causing the relay to be energized.
4. The following information applies to operations/tests of the Glow Plug Auxiliary Relay:
 - Terminal 30 is connected to battery voltage through a circuit breaker.
 - Terminal 86 is connected to terminal 30.
 - Terminal 87 is connected (a circuit is formed) to terminal 30 in the energized (ON) position. Terminal 87 then supplies battery voltage to one half of the engines glow plugs.
 - Terminal 85 is grounded causing the relay to be energized.

Removal

1. Remove electrical box cover.
2. Detach relay from inside of electrical box.
3. Disconnect electrical harness connector and remove relay.

Cleaning

1. Clean exterior with a dry cloth.
2. Clean terminals with a suitable cleaner.

Inspection

1. Look for evidence of any physical damage to base or connector surfaces of relays.
2. Visually inspect electrical pins of ECT for straightness and no corrosion.
3. Visually inspect connectors on the wiring harness for corrosion and for terminals that may have backed out of the harness.

Installation

1. Insert electrical connector onto relay.
2. Attach relay to electrical box.
3. Install electrical box cover.

THIS PAGE IS INTENTIONALLY BLANK

ELECTRICAL SYSTEMS

Section 4D - Instrumentation

Table of Contents

Identification	4D-3	Oil Pressure	4D-11
Gauges	4D-3	Water Temperature - Primary Station ..	4D-13
Panels	4D-3	Primary Station Switches	4D-15
Special Tools	4D-4	Ignition Key Switch	4D-15
Tools	4D-4	Audio Warning Test and Panel Light	
Lubricants / Sealants / Adhesives	4D-4	Switch	4D-17
Wire Color Abbreviations	4D-4	Audio Warning System	4D-19
Precautions	4D-5	Alarm	4D-19
General Information	4D-6	Oil Pressure Switch	4D-20
Special Information	4D-6	Water Temperature Switch / Sender ..	4D-21
Tachometer	4D-6	Transmission Fluid Temperature	
QSI Series Gauge Lighting Options ...	4D-7	Switch	4D-24
Gauges	4D-8	Second Station Extension Harness	4D-26
Removal	4D-8	Remote Control / Neutral Start Safety	
Testing	4D-8	Circuit	4D-29
Installation	4D-11	Primary Station	4D-29
Senders	4D-11	Secondary Station	4D-30

THIS PAGE IS INTENTIONALLY BLANK

NOTICE



For information and procedures on Troubleshooting refer to SECTION 1C.

Identification

Gauges



QUICKSILVER INSTRUMENTS

NOTE: One of three distinct series of Quicksilver gauges may be installed. Aside from different gauge face appearances and styling, the back of the gauges and wiring connections are different.



72965

Typical QSI Series




77333

Typical Admiral Series (Back of Flagship Series Similar)

Panels

QUICKSILVER INSTRUMENTS



73546

Typical Quicksilver Instrumentation

- a** - Gauges
- b** - Engine System Monitor Panel

Special Tools

Description	Part Number
MultiMeter	91-99750A1
DMT 2000A Digital MultiMeter	91-854009A2
Equipment for performing tests (suitable container, thermometer, suitable heat source, sandblasting sand or equivalent and a 12 volt power source)	Obtain Locally
Diesel Timing Tool or suitable service tachometer	Obtain Locally

Tools

Kent-Moore Tools

Kent-Moore Tools, Inc. 29784 Little Mack Roseville, MI 48066 Phone: (313) 774-9500	
Description	Part Number
Connector Test Adapter Kit	J-35616-A

Lubricants / Sealants / Adhesives

Description	Part Number
Liquid Neoprene	92-25711--3
Loctite Pipe Sealant with Teflon	Obtain Locally

Wire Color Abbreviations

BLK	Black		PUR or PPL	Purple
BLU	Blue		RED	Red
BRN	Brown		TAN	Tan
GRY	Gray		WHT	White
GRN	Green		YEL	Yellow
ORN	Orange		LIT or LT	Light
PNK	Pink		DRK	Dark

Precautions

WARNING

Always disconnect battery cables from battery before working around electrical system components to prevent injury to yourself or damage to electrical system.

CAUTION

Avoid short circuits. It may be necessary to remove instrument panel from dashboard to gain access to instruments and switches. Do not allow wires to come in contact with metal or other wires.

WARNING

Switch and sender testing involves the use of intense heat. Failure to follow appropriate procedures or warnings can cause burns which can result in severe personal injury. While performing the following test, observe these general precautions:

- Wear personal protective clothing such as rubber gloves, a non-flammable apron and eye protection - preferably full face shield or safety glasses.
- The appropriate heat source should only be electric. Heat source should be operated by a qualified person. Follow all instructions of the manufacturer of the heat source. The heat source should be checked each time it is used to ensure it is functioning properly.
- The thermometer used in the test should be a high- temperature thermometer with a maximum reading of at least 150°C (300°F). Under no circumstances should the operator allow temperatures to exceed test specifications.
- Perform test only in a well ventilated area.
- Use a suitable container, such as metal, to hold the sand. Avoid use of glass containers unless the operator first confirms for himself/herself that the glass container is an appropriate high-temperature vessel.
- Because the components will reach high temperatures Do NOT handle materials or components until COMPLETELY cooled.

WARNING

Use only clean, dry sand such as used for general sandblasting purposes. Use of sand containing contaminants could result in hazards such as fire, short circuiting, hot-spots or other hazards.

General Information

IMPORTANT: If all instruments appear suspect, an electrical overload may have occurred. A fuse may be defective or a circuit breaker may be tripped open. The cause must be found and corrected before replacing fuse or resetting circuit breaker.

IMPORTANT: If all instruments appear suspect, check the main harness or electrical connector to ensure good contact.

Before testing individual instruments, check the following:

- Battery is fully charged.
- Circuit breaker is closed.
- All wires in circuit are connected.
- All connections are tight and corrosion free.
- Connectors are fully engaged.

CAUTION

Avoid short circuits. It may be necessary to remove instrument panel or Engine System Monitor panel from dashboard to gain access to instruments and switches. Do not allow wires to come in contact with metal or other wires.

Special Information

Tachometer

If using the Quicksilver Tachometer provided for the D2.8L D-Tronic and D4.2L D-Tronic Engines engine packages, the appropriate setting of the switch located on the back of the tachometer is given in the following chart.

Tachometer Switch Setting		
Model	Number of Cylinders	Switch Position
D2.8L D-Tronic	4	1
D4.2L D-Tronic	6	2


QSI Series Gauge Lighting Options

These gauges are equipped with optional illumination lighting. Light bulb socket can be removed and contacts can be aligned to be used with ignition switch lighting circuit +12 V or separate instrumentation lighting circuit LT.


Standard position on diesel products is for use with the separate Panel Lights/Audio Test switch.

IMPORTANT: Light socket must be removed from gauge and turned when adjusting lighting option to desired setting. Turning socket while still installed in gauge could result in damage to gauge or socket.

NOTE: For different lighting effects, colored sleeves are available through the Quicksilver Accessories and can be assembled to the bulb.



72969



72968

Separate Instrumentation Lighting Circuit Position (Standard Position)

Ignition Switch Lighting Circuit Position (Optional Position)

- c** - +12 V Power Supply from Ignition Switch
- d** - +12 V Power Supply from Panel Lights/Audio Test Switch

Gauges

IMPORTANT: If testing proves a gauge to be defective, it must be replaced as there is no repair available.


Removal

1. Disconnect battery cables.
2. Remove wires from back of gauge.
3. Disconnect light socket wiring, if separate.
4. Remove holding strap and remove gauge.

Testing

OIL PRESSURE AND WATER TEMPERATURE


1. Turn ignition switch to the "OFF" position.
2. Remove signal wire from terminal SEND ("S").



72819

a - Sender Wire Lead

3. Turn ignition switch to the "RUN" position. Gauge being tested must be at position A.




73288

Typical

a - Needle at Position A

4. Turn ignition switch to the "OFF" position.


5. Connect jumper wire from terminal G (GND) to terminal SEND ("S").



72748

a - Jumper Wire

6. Turn ignition switch to the "RUN" position. Gauge being tested must be at position B.




73289

Typical

a - Needle at Position B

CRUISELOG (ENGINE HOUR METER)

1. Remove cables from battery and fully charge battery.
2. Remove wires from back of gauge.
3. Connect positive (+) jumper lead from battery to gauge terminal + (12 V).
4. Connect negative (–) jumper lead from battery to gauge terminal "GND" (ground).




72750

72815

5. Observe gauge run indicator on face of gauge. If indicator is turning, the gauge is operable. If indicator is not turning, replace gauge

VOLT METER GAUGE


1. Remove cables from battery and fully charge battery.
2. Remove wires from back of gauge.
3. Connect negative (–) jumper lead from battery to gauge terminal G (GND).
4. Connect positive (+) jumper lead from a 12 Volt power source, or battery, to gauge terminal I or +12 V.



72750

- a** - Volt Meter
b - 12 Volt Power Source

5. Check gauge reading; if not indicating battery voltage, as shown, replace gauge.



73290

Typical

- a** - Needle Indicating Battery Voltage

TACHOMETER

1. If the gauge is not accurate, be certain the switch on the back of the tachometer is set properly. Refer to Special Information - Tachometer.
2. Replace if not within specifications.

Tachometer Type	Allowable Range
5000 rpm maximum	± 100 rpm

Installation

1. Position gauge assembly in appropriate mounting hole.
2. Install holding strap and nuts. Tighten nuts evenly and securely.

IMPORTANT: Do not distort case or bracket by over tightening.

3. Connect ground wire to ground terminal, if gauge is not mounted in metal panel.
4. Connect other wires to gauge as shown in SECTION 4E - Wiring Diagrams.
5. Install gauge light socket.
6. Coat all terminals with liquid neoprene.
7. Reconnect battery cables to battery.


Senders

NOTE: Refer to SECTION 5 for information on the Engine Coolant Temperature (ECT) switch.

Oil Pressure

REMOVAL

1. Remove harness wire from sender.
2. Using a suitable wrench to hold the adaptor fitting to prevent loosening of main bearing locating screw, unscrew the sender.



- a** - Harness Wire
- b** - Oil Pressure Sender
- c** - Adaptor Fitting
- d** - Main Bearing Locating Screw


74281

TESTING

IMPORTANT: Use the following test procedure for checking *accuracy* of oil pressure sender only. If oil pressure gauge indicates zero oil pressure, refer to **SECTION 1C - Troubleshooting**.

1. Remove harness wire from sender. Temporarily insulate the wire to avoid a possible short circuit.
2. Install a manual pressure gauge graduated in at least 100 kPa or 1 bar (10 psi) increments, using a suitable T-fitting arrangement with the existing sender and adaptor or fitting.
3. Connect an ohmmeter between sender terminal and sender case.

NOTE: Sender shown removed for visual clarity.



- a** - Oil Pressure Sender
b - Adaptor Fitting
c - Manual Pressure Gauge Installation Location

4. Check the resistance values of the sender at pressures as shown and verified on manual gauge with engine running. Replace sender if values are not correct.


Single Station Sender - 805267	
Oil Pressure kPa (psi)	Ohms Reading
0 (0)	$240 \pm 15 \Omega$
413.7 (60)	$103 \pm 15 \Omega$

5. When replacing sender, coat threads with Loctite Pipe Sealant with Teflon and install. Tighten securely.

Water Temperature - Primary Station

REMOVAL

1. Drain the closed cooling system.
2. Remove harness wiring from temperature switch located behind the electrical box bracket and accessible through a hole in the bracket, as shown.



75298

Typical

- a** - Harness Wiring
- b** - Water Temperature Sender
- c** - Sealing Washer


3. Counter-hold the adaptor with a separate wrench.
4. Remove the sender and sealing washer.

TESTING

IMPORTANT: Use the following test to determine the *accuracy* of the Water Temperature Sender gauge circuit. If gauge indicates **NO** temperature when running engine refer to the **SECTION 1C - Troubleshooting**.


NOTICE
Read WARNING about switch and sender testing in Precautions at front of this section before proceeding with tests.

1. Connect an ohmmeter between sender terminal G and switch hex (case) for ground (–) as shown.



70686

2. Using a suitable container, thermometer and heat source, suspend the sender with tip in sand in sand.
3. Heat sand and observe temperature on thermometer.
4. As temperature rises, ohmmeter readings must be within the ranges specified for each temperature.



70688

- a - Suitable Container
- b - Thermometer
- c - Heat Source
- d - Water Temperature Sender
- e - Ohmmeter Leads

Test Temperature	Ohms Reading
60 Degrees C (140 Degrees F.)	121 - 147
90 Degrees C (194 Degrees F.)	47 - 55
100 Degrees C (212 Degrees F.)	36 - 41

NOTE: While sand cools you may recheck ohmmeter readings.

5. Turn heat source OFF. Allow sand and components to cool.

INSTALLATION

1. Apply Perfect Seal to threads of sender.
2. Counter-hold the adaptor with a separate wrench and install the sender and sealing washer.
3. Torque the temperature sender to the adapter. Maximum torque is 25 Nm (18 lb-ft). Do NOT overtorque.
4. Connect harness wiring. Apply liquid neoprene to the terminals.
5. Refill closed cooling system.

Primary Station Switches


IMPORTANT: Disconnect battery cables from battery before testing switches with wires still connected to switches.

IMPORTANT: The decal, or decals, on the side of the toggle switches with the arrow and the word UP, refer to the position of the switch *when installed on the panel*.

Ignition Key Switch

REMOVAL

1. Disconnect battery cables from battery.
2. Remove nut retaining ignition key switch to Engine System Monitor Panel.



71891

- a** - Panel
- b** - Switch
- c** - Nut


3. Remove wires from back of switch.

TESTING

1. Before testing key switch, check all fuses and/or circuit breakers in electrical circuit that could prevent operation of starter.

IMPORTANT: Disconnect battery cables from battery before testing ignition key switch with wires still connected to switch.

2. Disconnect battery cables from battery, if proceeding to test switch with wires still connected. With key switch in the "OFF" position, there should be no continuity between switch terminals.
3. With key switch in the "RUN" position, continuity will exist between switch terminals B to I. There should be no continuity between terminal S and any other terminals.
4. With key switch in the "START", continuity will exist between terminals B to I and B to S.
5. Terminals are to make contact at angles shown and to stay in contact condition as switch is rotated toward the "START" position.
6. If ignition key switch tests bad, unscrew or unsolder wire connections and remove switch. Test switch again. If switch tests good, wiring in harness is bad. There should be no continuity between any switch harness wires with key switch removed.



74103

- a** - Key (Front) View
- b** - Back View
- c** - Key
- d** - OFF
- e** - Continuity B to I Terminals
- f** - RUN
- g** - Continuity, B to S Terminals
- h** - START

Position	B to I	B to S
OFF	No Continuity	No Continuity
RUN	Continuity	No Continuity
START	Continuity	Continuity

Audio Warning Test and Panel Light Switch


The switch provided for the audio warning test and panel (dash) lights is a three-position toggle switch. It must be wired and installed correctly to provide proper operation of the systems.

REMOVAL

1. Remove hex nut retaining switch to Engine System Monitor Panel.
2. Remove wires from back of switch.

TESTING

1. With switch lever toggled DOWN to its spring loaded AUDIO TEST position continuity should exist between terminal numbers 1 and 2 (as indicated by decals). If no continuity exists, replace switch.
2. With switch lever toggled UP to the panel light ON position, continuity should exist between terminal numbers 4 and 5 as indicated by decals. If no continuity exists, replace switch.




73369

- a** - Audio Test/Panel Light Switch
- b** - Spring-Loaded Audio Test Portion (Direction of Movement DOWN When Installed)
- c** - Terminal Number
- d** - Terminal

INSTALLATION

1. Using screws provided, connect the listed color coded wires to numbered switch terminals as shown.
2. Install switch in Engine System Monitor panel. Tighten hex nut securely to prevent switch from turning in its mounting hole. Do NOT overtighten.



- a - Audio Test/Panel Light Switch
- b - Spring-Loaded Audio Test Portion (Direction of Movement DOWN When Installed)
- c - Terminal Number
- d - Terminal
- e - Jam Nut
- f - Locking Washer
- g - Engine System Monitor Panel
- h - Hex Nut

D2.8L D-Tronic and D4.2L D-Tronic		
Harness Wire	Connect To:	Terminal Number
WHITE/RED And WHITE/YELLOW OR ¹ TAN/WHITE And TAN/BLACK	▶	1
BLACK	▶	2
PINK Or PURPLE ¹	▶	4
GREEN	▶	5

¹ Model dependent.

3. Make sure that all connections are secure. Seal terminals with liquid neoprene.

Audio Warning System

The Audio Warning System is divided into two separate circuits. Both circuits have an individual audio warning alarm that does NOT include any time delay.

One circuit consists of the engine water temperature switch and related wiring. If this switch is activated (*closed*) during the operation of the engine, the alarm will sound and the Engine System Monitor panel light will be illuminated until the problem is corrected or the electrical system is shut off (key switched "OFF").

The other circuit consists of the engine oil pressure switch, the transmission temperature switch (Inboard models) or the gear lube monitor bottle switch (Sterndrive models) and related wiring. These switches are connected to the audio warning alarm. Likewise, the Engine System Monitor panel light is illuminated whenever the respective switch is activated (*closed*) until the problem is corrected or the electrical system is shut off (key switched "OFF").

The function of an audio warning alarm can be tested by holding the toggle lever of the Audio Test switch, on the Engine System Monitor Panel, DOWN momentarily, with the key switch in the "RUN" position. If the alarm sounds it is operable.

Alarm

WARNING

The following test involves the use of electricity. Failure to follow appropriate procedures can cause burns or shock which can result in severe personal injury or death.

TESTING

1. If the alarm does not sound:
 - a. Disconnect bullet connectors from suspect alarm.
 - b. Connect a 12 volt positive (+) jumper wire to where the positive (+) wire was connected.
 - c. Connect the remaining wire to a clean, unpainted ground or negative (–) connection using a jumper wire.
 - d. If the alarm does not sound, replace it.
2. If the alarm worked in Step 1., reconnect the wires and do the following.
 - a. Remove the harness wires at the switches involved and briefly jumper the wire ends together. With the key switch in the RUN position, the alarm should sound.
 - b. If the alarm sounds, the problem is in the switch. Refer to Testing individual switches as follows, and test the suspect switch. Replace as instructed.
3. If the alarm did not sound in Step 2., refer to wiring diagrams and check wires or connectors to the individual switches.
4. Repair as needed.


Oil Pressure Switch

TESTING

When the engine is stopped the switch is normally *closed*.

1. Remove the harness wire from the switch. Insulate to avoid possible short circuit.
2. Connect continuity meter between switch terminal and switch case (negative –). With the engine stopped the meter should indicate full continuity.

NOTE: Sender shown removed for visual clarity.



74446

Typical

- a** - Oil Pressure Audio Warning Switch
- b** - Harness Wire
- c** - Continuity Meter And Connection Points

Oil Pressure kPa (psi)	Switch Condition
0 (0)	Closed
31 - 52 (4.5 - 7.5)	Open

INSTALLATION


1. Coat threads of switch with Loctite Pipe Sealant with Teflon.
2. Install switch and tighten securely.
3. Connect harness wire. Seal terminal with Liquid Neoprene.

Water Temperature Switch / Sender

When the engine is COLD the audio warning circuit is normally *open*.

REMOVAL

1. Drain the closed cooling system.
2. Remove harness wiring from temperature switch / sender located behind the electrical box bracket and accessible through a hole in the bracket, as shown.
3. Counter-hold the adaptor with a separate wrench.
4. Remove the sender and sealing washer.




75298

Typical

- a** - Harness Wiring
- b** - Water Temperature Switch / Sender
- c** - Sealing Washer

TESTING

1. With engine COLD, remove wiring from switch/sender terminals. Note position on switch/sender for terminal referred to as W.



78189

Top View

- a** - Water Temperature Switch/Sender
- b** - Terminal W - Audio Warning Switch Circuit


2. Refer to the proceeding and connect a continuity meter between switch terminal W and sender hex case.
 - a. No continuity should exist.
 - b. If continuity exists, replace sender.

NOTICE

Read WARNING about switch and sender testing in Precautions at front of this section before proceeding with tests.

3. To test switch circuit for closing (alarm ON), as if coolant temperature rises above operating specifications, follow instructions a. - g.
 - a. Remove the switch/sender.
 - b. Refer to top view of switch/sender in Step 1., and using suitable jumper leads connect alarm terminal – to switch terminal W.
 - c. Then, using suitable jumpers and being careful to avoid short circuits, connect the negative (–) of a 12 volt power source to sender case and the positive (+) to the + on the alarm , as shown following.
 - d. Using suitable container, thermometer and heat source, suspend switch with tip in sand.

- e. Heat sand and observe temperature on thermometer.



- a** - Suitable Container
b - Thermometer
c - Heat Source
d - Water Temperature Switch/Sender
e - 12 Volt Power Source and Jumper Leads
f - Audio Warning Alarm With Jumper Lead

- f. Replace switch / sender if it does not *close* (alarm ON) within the range of temperatures indicated in chart below.

Test Temperature	Switch Condition
102 - 106 Degrees C (215 - 220 Degrees F.)	Closed

- g. Turn heat source OFF. Allow sand and components to cool.

INSTALLATION


1. Apply Perfect Seal to threads of switch / sender.
2. Counter-hold the adaptor with a separate wrench and install the switch / sender and sealing washer.
3. Torque the switch / sender to the adaptor. Maximum torque is 25 Nm (18 lb-ft). Do NOT overtorque.
4. Connect harness wiring. Apply liquid neoprene to the terminals.
5. Refill closed cooling system.

Transmission Fluid Temperature Switch

When the transmission is COLD or at a temperature less than as shown (refer to Testing - Test Temperature Chart), the switch is *open*.

REMOVAL

1. Disconnect harness wires at switch.
2. Remove the switch and sealing washer.



72770


Typical Transmission

- a** - Transmission Fluid Temperature Switch with Sealing Washer
- b** - Harness Wires

TESTING

1. With the transmission COLD, connect one lead of an ohmmeter to one terminal of the transmission switch. Connect the other lead of ohmmeter to other terminal.

NOTE: Switch shown removed for visual clarity only.



72771


- a** - Ohmmeter Leads
- b** - Transmission Fluid Temperature Switch

2. Switch should show no continuity. Replace switch, if continuity exists.

NOTICE

Read WARNING about switch and sender testing in Precautions at front of this section before proceeding with tests.

3. With an ohmmeter connected as in Step 1., use a suitable container, thermometer and heat source and suspend sender with tip in sand.
4. Heat sand and observe thermometer.
5. As temperature rises, switch will *close* and ohmmeter will indicate continuity. Refer to chart below for specifications.



72772

- a** - Suitable Container
- b** - Thermometer
- c** - Heat Source
- d** - Transmission Fluid Temperature Switch
- e** - Ohmmeter Leads
- f** - Audio Warning Buzzer With Jumper Lead

Test Temperature	Switch Condition
126 - 138 Degrees C (258 - 282 Degrees F.)	Closed
103 - 117 Degrees C (218 - 242 Degrees F.)	Open

6. Turn heat source off. Allow sand to cool. Note thermometer reading to ensure switch *opens* at specified temperature while cooling.
7. Replace switch if switch fails to either open or close within the specified temperature.

INSTALLATION

1. Apply Perfect Seal to threads of switch.
2. Install switch and sealing washer in transmission. Tighten securely.
3. Reconnect harness wires and coat with liquid neoprene.
4. Check transmission fluid level.

Second Station Extension Harness


5. Connect and tighten threaded collars of instrument extension harnesses to second station instrument harness ends.

IMPORTANT: When routing any wiring harness ensure that the harnesses do not rub or get pinched.

NOTE: Refer to Wiring Diagrams - Wiring Harness Connections.


IMPORTANT: Connectors must be fully engaged and secure.

6. Connect second station instrument harness to Y-box or Y-harness connector, tagged or titled "2nd STATION".
7. Connect primary station instrument harness to Y-box or Y-harness connector, tagged or titled "MAIN STATION".
8. Connect extension harnesses from engine harness to Y-box or Y-harness connector.
9. Secure harnesses to boat at least every 460 mm (18 in.), using appropriate fasteners.



75871

Early Model Connector - Y-Box




77223

**Later Model 21 Pin Connector -
Y-Harness**


- a** - Primary Station Connector (Tagged Or Titled "MAIN STATION")
- b** - Second Station Connector (Tagged Or Titled "2nd STATION")
- c** - Engine Harness Connector

EARLY MODEL WIRING HARNESS CONNECTIONS

**Sterndrive Shown, Inboard Similar**

- a** - Second (2nd) Station Instrumentation
- b** - Second Station Instrument Harness
- c** - Primary Station Instrument Harness
- d** - Primary (MAIN) Station Instrumentation
- e** - Y-Box (Harness)
- f** - Extension Harness
- g** - To Engine

LATE MODEL WIRING HARNESS CONNECTIONS



77223

Typical

- a** - Primary (MAIN PANEL) Station Instrumentation and Harness
- b** - Primary Station Extension Harness
- c** - Second (2nd PANEL) Station Instrumentation and Harness
- d** - Second Station Extension Harness
- e** - Y-Harness
- f** - Extension ("ENGINE") Harness
- g** - To Engine

Remote Control / Neutral Start Safety Circuit

Primary Station

⚠ WARNING


Avoid injury or property damage. Starting an engine while the sterndrive unit or transmission is in gear could cause severe injury to people or animals in or near the boat, or property damage due to unexpected operation. Special circuitry and switches are necessary and must be used to prevent accidental starter engagement and subsequent engine operation while a sterndrive or transmission is in a gear.

STERNDRIVE (MCM) MODELS

Ensure neutral start safety circuit remote control connections are made before use.

IMPORTANT: The two bullet connectors on primary station harness YEL/RED wire, as shipped from the factory, have to be disconnected and reconnected to Neutral Start Safety Circuit wires from the remote control.

1. Disconnect the two YEL/RED bullet connectors.
2. Connect the YEL/RED wires from the Remote Control Neutral Start Safety Circuit to the YEL/RED wires disconnected in Step 1.



77413

Typical

- a**- Instrument Harness START Wires
- b**- YEL/RED Wires
- c**- Remote Control / Neutral Start Safety Circuit

Secondary Station


⚠ WARNING

Avoid injury or property damage. Starting an engine while the sterndrive unit or transmission is in gear could cause severe injury to people or animals in or near the boat, or property damage due to unexpected operation. Special circuitry and switches are necessary and must be used to prevent accidental starter engagement and subsequent engine operation while a sterndrive or transmission is in a gear.

STERNDRIVE (MCM) MODELS

IMPORTANT: The two bullet connectors on the YEL/RED wire must be disconnected. Also, the two bullet connectors on the YEL/WHT wire must be disconnected. After doing so, connect female YEL/WHT terminal and male YEL/RED terminal to Neutral Start Safety Circuit wires from remote control. Leave the other two connectors disconnected.

1. Disconnect the two bullet connectors on the YEL/RED wire.
2. Disconnect the two bullet connectors on the YEL/WHT wire.
3. Connect female YEL/WHT terminal and male YEL/RED terminal to neutral start safety circuit wires from remote control.
4. Leave the male YEL/WHT and female YEL/RED terminals disconnected. Keep wires separated. Tape each wire separately with at least two layers of electrical tape.



77776

- a** - Instrument Harness START Wires
- b** - Female YEL/WHT Terminal
- c** - Male YEL/RED Terminal
- d** - Remote Control / Neutral Safety Start Circuit
- e** - Male YEL/WHT Disconnected
- f** - Female YEL/RED Disconnected

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

ELECTRICAL SYSTEMS

Section 4E - Wiring Diagrams

Table of Contents

Wire Color Abbreviations	4E-3	MerCathode System Wiring Diagram .	4E-15
Tools	4E-3	Inboard (MIE) Models	4E-16
Lubricants / Sealants / Adhesives	4E-3	Engine Wiring - Starting and Charging	
General Information	4E-3	System	4E-16
Sterndrive (MCM) Models	4E-4	ECM and Fuel System Wiring	4E-20
Engine Wiring - Starting and Charging		Quicksilver Primary Instrumentation	
System	4E-4	Wiring	4E-22
ECM and Fuel System Wiring	4E-8	Models With Early Connectors	4E-26
Quicksilver Instrumentation Wiring ...	4E-10	Models With 21-Pin Deutsch TM	
Power Trim System Wiring Diagram ..	4E-14	Connector	4E-28

THIS PAGE IS INTENTIONALLY BLANK

Wire Color Abbreviations

BLK	Black		PUR or PPL	Purple
BLU	Blue		RED	Red
BRN	Brown		TAN	Tan
GRY	Gray		WHT	White
GRN	Green		YEL	Yellow
ORN	Orange		LIT or LT	Light
PNK	Pink		DRK	Dark

Special Tools

Description	Part Number
DMT 2000A Tachometer / Multi-Meter Kit	91-854009A3

Tools

Kent-Moore Tools

Kent-Moore Tools, Inc. 29784 Little Mack Roseville, MI 48066 Phone: (313) 774-9500	
Description	Part Number
DVOM	J-34029-A or Equivalent

Lubricants / Sealants / Adhesives


Description	Part Number
Liquid Neoprene	92-25711--2

General Information

NOTE: If using other than Quicksilver instrumentation and harnesses, refer to manufacturers' instructions.

Sterndrive (MCM) Models

Engine Wiring - Starting and Charging System - Page 1 of 4



76439

Early Model D2.8L D-Tronic and D4.2L D-Tronic With Standard Connector

Engine Wiring - Starting and Charging System - Page 2 of 4

- | | |
|--|---|
| 1 - ECM / Fuel System Harness Connector | 13 - MerCathode Controller |
| 2 - Electrical Box | 14 - 20 Amp Fuse and Holder |
| 3 - Main Relay | 15 - Starter |
| 4 - Start Relay | 16 - Engine Coolant Temperature Sender |
| 5 - Glow Plug Relay (Optional) | 17 - Glow Plugs (If So Equipped) |
| 6 - Glow Plug Relay (Optional) | 18 - Alternator |
| 7 - 60 Amp. Circuit Breaker | 19 - Gear Lube Monitor Bottle |
| 8 - 60 Amp. Circuit Breaker | 20 - Oil Pressure / Audio Warning Switch |
| 9 - 12 Volt Battery | 21 - Oil Pressure Sender |
| 10 - Engine Ground Stud | 22 - Diagnostic Connector |
| 11 - Trim Position Sender, Starboard | 23 - Engine Harness Connector |
| 12 - Trim Limit Switch, Port | 24 - 5 Amp Fuse |

 **1.** Wires to trim pump.

 **2.** Wires to MerCathode electrode.

ECM / FUEL SYSTEM HARNESS CONNECTOR

NOTE: Refer to Item Number , on Electrical Box, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PNK	5	BRN/BLK	9	RED
2	BRN/WHT	6	YEL/BLK	10	BLK
3	BLU/BLK	7	GRN	11	BLK
4	PPL	8	RED		

ENGINE HARNESS CONNECTOR

NOTE: Refer to Item Number 23 on Electrical Box, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PINK	7	BLK	13	YEL
2	BRN/WHT	8	LT BLU	14	PPL
3	PPL	9	ORN	15	PPL
4	BLK	10	GRY	16	GRN/WHT
5	BRN/BLK	11	WHT		
6	YEL/BLK	12	BRN		

DIAGNOSTIC CONNECTOR

NOTE: Refer to Item Number 22 on Electrical Box, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PPL	2	BLK	3	PNK (+)

R E S G X M D P K L J F C H W A B T N V U (23)



Later Model D2.8L D-Tronic and D4.2L D-Tronic With 21-Pin Deutsch™ Connector

Engine Wiring - Starting and Charging System - Page 4 of 4

- | | |
|--|---|
| 1 - ECM / Fuel System Harness Connector | 14 - 20 Amp Fuse and Holder |
| 2 - Electrical Box | 15 - Starter |
| 3 - Main Relay | 16 - Engine Coolant Temperature Sender |
| 4 - Start Relay | 17 - Glow Plugs (Optional) |
| 5 - Glow Plug Relay (Optional) | 18 - Alternator |
| 6 - Glow Plug Relay (Optional) | 19 - Gear Lube Monitor Bottle |
| 7 - 60 Amp. Circuit Breaker | 20 - Oil Pressure / Audio Warning Switch |
| 8 - 60 Amp. Circuit Breaker | 21 - Oil Pressure Sender |
| 9 - 12 Volt Battery | 22 - Diagnostic Connector |
| 10 - Engine Ground Stud | 23 - Engine Harness Connector (21-Pin) |
| 11 - Trim Position Sender, Starboard | 24 - 5 Amp Fuse |
| 12 - Trim Limit Switch, Port | 25 - Oil Temperature Overheat Sensor |
| 13 - MerCathode Controller | 26 - Wires Joined With Screw and Nut |
| | 27 - Idle Speed Setting Circuit |

 Wires to trim pump.

 Wires to MerCathode electrode.

ECM / FUEL SYSTEM HARNESS CONNECTOR

NOTE: Refer to Item Number 1 on Electrical Box, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PNK	5	BRN/BLK	9	RED
2	BRN/WHT	6	YEL/BLK	10	BLK
3	BLU/BWN	7	GRN	11	BLK
4	PPL	8	RED		

ENGINE HARNESS CONNECTOR

NOTE: Refer to Item Number 23 on Electrical Box, from preceding page.


Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code
A	YEL/RED	H	TAN	R	YEL/WHT
B	RED	J	LT BLU	S	ORN
C	TAN/BLK	K	BLU/TAN	T	GRN/WHT
D	BLK	L	BLK/YEL	U	(NOT USED)
E	GRN/RED	M	YEL	V	(NOT USED)
F	TAN/WHT	N	PPL/YEL	X	RED/YEL
G	PPL	P	GRY	W	BRN

DIAGNOSTIC CONNECTOR

NOTE: Refer to Item Number 22 on Electrical Box, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PPL/YEL	2	BLK	3	PPL (+)

ECM and Fuel System Wiring - Page 1 of 2



78407

Typical D2.8L D-Tronic and D4.2L D-Tronic Models

ECM and Fuel System Wiring - Page 2 of 2

- 1** - ECM (Electronic Control Module) / Fuel System Connector
- 2** - ECM
- 3** - Engine-Speed Sensor
- 4** - Throttle Position Sensor
- 5** - Engine Coolant Temperature Sensor (ECT to ECM)
- 6** - Electronic Distributor Injection Pump
- 7** - Electronic Shut Off Solenoid (ELAB)
- 8** - Manifold Absolute Pressure Sensor (MAP)
- 9** - Number 1 Cylinder Fuel Injector with Needle Motion Sensor (NBF)

ECM / FUEL SYSTEM HARNESS CONNECTOR

NOTE: Refer to Item Number 1 connected to Electrical Box, from preceding page.


Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PNK	5	BRN/BLK	9	RED
2	BRN/WHT	6	BLK/YEL	10	BLK
3	BLU/BLK	7	WHT RED	11	BLK
4	GRN/RED	8	RED	12	RED/ORN

ECM CONNECTOR

NOTE: Refer to Item Number 2 connected to ECM, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	BLK	23	RED	50	BLU/BLK
2	BRN/BLK	24	BLK	51	BLU
3	YEL/BLK	26	BRN/WHT	52	BLU/YEL
4	GRN/WHT	29	GRN	53	YEL
5	GRN/WHT	33	BLK	55	BLU/WHT
7	ORN	38	PNK	57	YEL/PNK
8	WHT	40	WHT/YEL	61	GRN/RED
11	BRN	41	GRN	63	BLU/RED
12	WHT	42	WHT/RED	64	GRN/BLK
14	WHT/BLK	45	RED	65	BRN/RED
15	ORN/WHT	46	BLK	68	RED
21	BRN	49	GRN/WHT	37	RED/ORN

Quicksilver Instrumentation Wiring - Page 1 of 4



76440

Early Model D2.8L D-Tronic and D4.2L D-Tronic With Standard Connector

Quicksilver Instrumentation Wiring - Page 2 of 4


- 1** - Oil Pressure Gauge
- 2** - Tachometer Gauge
- 3** - Trim Gauge
- 4** - Engine Coolant Temperature Gauge
- 5** - Voltmeter Gauge
- 6** - Cruise Log (Engine Hour Meter)
- 7** - Engine System Monitor Panel
- a** - Preheat Indicator Lamp
- b** - Charge Indicator Lamp
- c** - Oil Pressure Warning Lamp / Low Gear Lube Monitor Level Lamp
- d** - Coolant High Temperature Lamp
- e** - Malfunction Indicator Lamp
- 8** - Panel Lights/Audio Warning Test Switch
- 9** - Key Switch
- 10** - 20 Amp Fuse
- 11** - Audio Warning Alarms - Oil Pressure and Engine Coolant Temperature
- 12** - Neutral Start Safety Circuit For Sterndrive (MCM) Remote Control
- 13** - Instrument Harness Connector

 **1.** Bullet connectors shown. Alternately, if equipped, connect wires together with ring terminals using screws and hex nuts. Apply Liquid Neoprene to connections and slide rubber sleeves over connections.

The following circuits on some very early instrumentation harnesses may have alternate color codes as follows.

- Ignition (+) - PINK
- Positive(+) - PINK
- Key Switch "B" Terminal - ORANGE
- Key Switch "I" Terminal - PINK
- Key Switch "S" Terminal - YELLOW
- Sender Coolant Temperature - BLUE or GRAY
- Tachometer Signal - BROWN/BLACK

Quicksilver Instrumentation Wiring - Page 3 of 4



Later Model D2.8L D-Tronic and D4.2L D-Tronic With 21-Pin Deutsch™ Connector

Quicksilver Instrumentation Wiring - Page 4 Of 4

- 1** - Voltmeter Gauge
- 2** - Tachometer Gauge
- 3** - Water Temperature Gauge
- 4** - Oil Pressure Gauge
- 5** - Trim Position Gauge
- 6** - Engine System Monitor Panel
- 7** - Malfunction Indicator Lamp (Check Engine)
- 8** - Coolant High Temperature
- 9** - Oil Pressure Warning Lamp / Low Gear Lube Monitor Level Lamp
- 10** - Charge Indicator Lamp
- 11** - Preheat Indicator Lamp
- 12** - Panel Lights/Audio Warning Test Switch
- 13** - Key Switch
- 14** - Neutral Start Safety Circuit For Sterndrive (MCM) Remote Control
- 15** - Spare Wires (Optional Hour Meter Gauge)
- 16** - Audio Warning Alarm - Oil
- 17** - Audio Warning Alarm - Temperature
- 18** - Instrument Harness Connector (21-Pin Deutsch™)
- 19** - Fuel Gauge (Optional)
- 20** - Connector Without Relay (Relay To Be Installed if Second Station Equipped)
- 21** - Connector Jumper (If Single Station Only)
- 22** - 20 Amp Fuse
- 23** - Audio Warning Delay Relay (During Pre-Heat)
- 24** - Diode Pack

- 1.** Bullet connectors shown. Alternately, if equipped, connect wires together with ring terminals using screws and hex nuts. Apply Liquid Neoprene to connections and slide rubber sleeves over connections.
- 2.** Keep wires separated. Not used on this model. Tape each wire separately with at least two layers of electrical tape.
- 3.** Spare wire.


INSTRUMENT HARNESS CONNECTOR

NOTE: Refer to Item Number 18 from preceding page.

Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code
A	YEL/RED	H	TAN	R	YEL/WHT
B	RED	J	LT BLU	S	ORN
C	TAN/BLK	K	BLU/TAN	T	BRN/WHT
D	BLK	L	BLK/YEL	U	(NOT USED)
E	GRN/RED	M	YEL	V	(NOT USED)
F	TAN/WHT	N	PPL/ORN	X	RED/YEL
G	PPL	P	GRY	W	BRN

Power Trim System Wiring Diagram


- a** - 20 Amp Fuse
- b** - Ground Bolt (Floor Mount)
- c** - UP Solenoid
- d** - 110 Amp Fuse
- e** - DOWN Solenoid
- f** - Trailer Switch
- g** - Neutral Switch To Instrument Wiring Harness
- h** - Trim Limit Switch



73962

MerCathode System Wiring Diagram


- a** - Controller
b - 20 Amp Fuse
c - Electrode



BLK = BLACK
 BLU = BLUE
 BRN = BROWN
 GRY = GRAY
 GRN = GREEN
 ORN = ORANGE
 PNK = PINK
 PUR = PURPLE
 RED = RED
 TAN = TAN
 WHT = WHITE
 YEL = YELLOW
 LT OR LIT = LIGHT
 DRK = DARK

Inboard (MIE) Models

Engine Wiring - Starting and Charging System - Page 1 of 4



76451

Early Model D2.8L D-Tronic and D4.2L D-Tronic With Standard Connector

Engine Wiring - Starting and Charging System - Page 2 of 4

- | | |
|--|---|
| 1 - ECM / Fuel System Harness Connector | 12 - Engine Coolant Temperature Sender |
| 2 - Electrical Box | 13 - Glow Plugs (If Equipped) |
| 3 - Main Relay | 14 - Alternator |
| 4 - Start Relay | 15 - Transmission Neutral Safety Switch |
| 5 - Glow Plug Relay (Optional) | 16 - Transmission Temperature Switch |
| 6 - Glow Plug Relay (Optional) | 17 - Oil Pressure / Audio Warning Switch |
| 7 - 60 AMP Circuit Breaker | 18 - Oil Pressure Sender |
| 8 - 60 AMP Circuit Breaker | 19 - Diagnostic Connector |
| 9 - 12 Volt Battery | 20 - Engine Harness Connector |
| 10 - Engine Ground Stud | 21 - 5 Amp Fuse |
| 11 - Starter | 22 - Wires Not Used On This Model |

1. Keep wires separated. Not used on this model. Tape each wire separately with at least two layers of electrical tape.

ECM / FUEL SYSTEM HARNESS CONNECTOR

NOTE: Refer to Item Number 1 on Electrical Box, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PNK	5	BRN/BLK	9	RED
2	BRN/WHT	6	YEL/BLK	10	BLK
3	BLU/BLK	7	GRN	11	BLK
4	PPL	8	RED		

ENGINE HARNESS CONNECTOR

NOTE: Refer to Item Number 20 on Electrical Box, from preceding page.


Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PINK	7	BLK	13	YEL
2	BRN/WHT	8	LT BLU	14	PPL
3	PPL	9	ORN	15	PPL
4	BLK	10	GRY	16	GRN/WHT
5	BRN/BLK	11	WHT		
6	YEL/BLK	12	BRN		

DIAGNOSTIC CONNECTOR

NOTE: Refer to Item Number 19 on Electrical Box, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PPL	2	BLK	3	PNK (+)

Engine Wiring - Starting and Charging System - Page 3 of 4



78408

Later Model D2.8L D-Tronic and D4.2L D-Tronic With 21-Pin Deutsch™ Connector

Engine Wiring - Starting and Charging System - Page 3 of 4

- | | |
|--|--|
| 1 - ECM / Fuel System Harness Connector | 13 - Transmission Neutral Safety Switch |
| 2 - Electrical Box | 14 - Transmission Temperature Switch |
| 3 - Main Relay | 15 - Engine Coolant Temperature Sender |
| 4 - Start Relay | 16 - Starter |
| 5 - Glow Plug Relay (Optional) | 17 - Glow Plugs (If Equipped) |
| 6 - Glow Plug Relay (Optional) | 18 - Alternator |
| 7 - 60 AMP Circuit Breaker | 19 - Oil Pressure / Audio Warning Switch |
| 8 - 60 AMP Circuit Breaker | 20 - Oil Pressure Sender |
| 9 - 12 Volt Battery | 21 - Diagnostic Connector |
| 10 - Engine Ground Stud | 22 - 5 Amp Fuse |
| 11 - Wires Not Used On This Model | 23 - Engine Harness Connector (21-Pin Deutsch™) |
| 12 - Wires Not Used On This Model | 24 - Idle Speed Setting Circuit |

1. Keep wires separated. Not used on this model. Tape each wire separately with at least two layers of electrical tape.

ECM / FUEL SYSTEM HARNESS CONNECTOR

NOTE: Refer to Item Number 1 on Electrical Box, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PNK	5	BRN/BLK	9	RED
2	BRN/WHT	6	YEL/BLK	10	BLK
3	BLU/BLK	7	GRN	11	BLK
4	PPL	8	RED	12	RED/ORN

ENGINE HARNESS CONNECTOR

NOTE: Refer to Item Number 20 on Electrical Box, from preceding page.

Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code
A	YEL/RED	H	TAN	R	YEL/WHT
B	RED	J	LT BLU	S	ORN
C	TAN/BLK	K	BLU/TAN	T	BRN/WHT
D	BLK	L	BLK/YEL	U	(NOT USED)
E	GRN/RED	M	YEL	V	(NOT USED)
F	TAN/WHT	N	PPL/YEL	X	RED/YEL
G	PPL	P	GRY	W	BRN

DIAGNOSTIC CONNECTOR

NOTE: Refer to Item Number 19 on Electrical Box, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PPL/YEL	2	BLK	3	PPL (+)

This diagram illustrates the electrical wiring for a vehicle, showing the connection between a fuse block, battery, and various components. The components are numbered 1 through 9:

- 1:** A multi-pin connector at the top left, with wires labeled with colors like BLU/BLK, BRN/BLK, RED, BRN/WHT, WHT/RED, BLK, and GRN/RED.
- 2:** A large fuse block in the center, with numerous fuses labeled with numbers (e.g., 1, 2, 3, 4, 5, 7, 8, 11, 12, 14, 15, 21, 23, 24, 26, 28, 29, 32, 33, 38, 40, 41, 42, 45, 46, 49, 50, 51, 52, 53, 55, 57, 61, 63, 64, 65, 68) and wire colors.
- 3:** A component on the right side, possibly a relay or solenoid, with wires labeled BLU, BRN, WHT, and BLK.
- 4:** A component in the lower center, possibly a solenoid or relay, with wires labeled YEL/PNK, ORN/WHT, BLK, and BLU/WHT.
- 5:** A component on the left side, possibly a solenoid or relay, with wires labeled BRN/PPL, WHT/BRN, and YEL.
- 6:** A large component on the left, possibly an alternator or generator, with wires labeled GRN/WHT, GRN/RED, BLK/PUR, and BLU/RED.
- 7:** A component on the left side, possibly a solenoid or relay, with wires labeled YEL and YEL/PNK.
- 8:** A component in the center, possibly a solenoid or relay, with wires labeled WHT, BRN, BLU/WHT, GRN/BLK, and WHT/YEL.
- 9:** A component on the left side, possibly a solenoid or relay, with wires labeled YEL and YEL/PNK.

The diagram also shows the battery connection at the bottom right, with a positive terminal connected to a BLK wire and a negative terminal connected to a BLK wire. Various other wires are labeled with colors like BLU, BRN, WHT, BLK, YEL, GRN, and PUR.

76438

All D2.8L D-Tronic and D4.2L D-Tronic Models

ECM and Fuel System Wiring - Page 2 of 2

- 1** - ECM (Electronic Control Module) / Fuel System Connector
- 2** - ECM
- 3** - Engine-Speed Sensor
- 4** - Throttle Position Sensor
- 5** - Engine Coolant Temperature Sensor (ECT to ECM)
- 6** - Electronic Distributor Injection Pump
- 7** - Electronic Shut-Off Solenoid (ELAB)
- 8** - Manifold Absolute Pressure Sensor (MAP)
- 9** - Number 1 Cylinder Fuel Injector with Needle Motion Sensor (NBF)

ECM / FUEL SYSTEM HARNESS CONNECTOR

NOTE: Refer to Item Number 1, connected on Electrical Box, from preceding page.


Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	PNK	5	BRN/BLK	9	RED
2	BRN/WHT	6	BLK/YEL	10	BLK
3	BLU/BLK	7	WHT RED	11	BLK
4	GRN/RED	8	RED	12	RED/ORN

ECM CONNECTOR

NOTE: Refer to Item Number 2 connected on ECM, from preceding page.

Terminal Number	Wire Color Code	Terminal Number	Wire Color Code	Terminal Number	Wire Color Code
1	BLK	23	RED	50	BLU/BLK
2	BRN/BLK	24	BLK	51	BLU
3	YEL/BLK	26	BRN/WHT	52	BLU/YEL
4	GRN/WHT	29	GRN	53	YEL
5	GRN/WHT	33	BLK	55	BLU/WHT
7	ORN	38	PNK	57	YEL/PNK
8	WHT	40	WHT/YEL	61	GRN/RED
11	BRN	41	GRN	63	BLU/RED
12	WHT	42	WHT/RED	64	GRN/BLK
14	WHT/BLK	45	RED	65	BRN/RED
15	ORN/WHT	46	BLK	68	RED
21	BRN	49	GRN/WHT	37	RED/ORN

Quicksilver Primary Instrumentation Wiring - Page 1 of 4



Early Model D2.8L D-Tronic and D4.2L D-Tronic With Standard Connector

Quicksilver Primary Instrumentation Wiring - Page 2 of 4


- 1** - Oil Pressure Gauge
- 2** - Tachometer Gauge
- 3** - Wires Not Used On This Model
- 4** - Engine Coolant Temperature Gauge
- 5** - Voltmeter Gauge
- 6** - Cruise Log (Engine Hour Meter)
- 7** - Engine System Monitor Panel
- a** - Preheat Indicator Lamp
- b** - Charge Indicator Lamp
- c** - Oil Pressure Warning Lamp / Low Gear Lube Monitor Level Lamp
- d** - Coolant High Temperature Lamp
- e** - Malfunction Indicator Lamp
- 8** - Panel Lights/Audio Warning Test Switch
- 9** - Key Switch
- 10** - 20 Amp Fuse
- 11** - Audio Warning Horns - Oil Pressure and Engine Coolant Temperature
- 12** - Neutral Start Safety Circuit - Refer To Transmission Neutral Start Safety Switch Circuit On Inboard Models
- 13** - Instrument Harness Connector (Standard)

 **1.** Keep wires separated. Not used on this model. Tape each wire separately with at least two layers of electrical tape.

The following circuits on some very early instrumentation harnesses may have alternate color codes as follows.

- Ignition (+) - PINK
- Positive(+) - PINK
- Key Switch "B" Terminal - ORANGE
- Key Switch "I" Terminal - PINK
- Key Switch "S" Terminal - YELLOW
- Sender Coolant Temperature - BLUE or GRAY
- Tachometer Signal - BROWN/BLACK

Quicksilver Primary Instrumentation Wiring - Page 3 of 4



76908

Later Model D2.8L D-Tronic and D4.2L D-Tronic With 21-Pin Deutsch™ Connector

Quicksilver Primary Instrumentation Wiring - Page 4 Of 4

Later Model D2.8L D-Tronic and D4.2L D-Tronic Harness - Deutsch Connector

- 1** - Voltmeter Gauge
- 2** - Tachometer Gauge
- 3** - Water Temperature Gauge
- 4** - Oil Pressure Gauge
- 5** - Wires Not Used On This Model
- 6** - Engine System Monitor Panel
- 7** - Malfunction Indicator Lamp (Check Engine)
- 8** - Coolant High Temperature
- 9** - Oil Pressure Warning Lamp / Low Gear Lube Monitor Level Lamp
- 10** - Charge Indicator Lamp
- 11** - Preheat Indicator Lamp
- 12** - Panel Lights/Audio Warning Test Switch
- 13** - Key Switch
- 14** - Neutral Start Safety Circuit - Refer To Transmission Neutral Start Safety Switch Circuit On Inboard Models
- 15** - Spare Wires (Optional Hour Meter Gauge)
- 16** - Audio Warning Horn - Oil
- 17** - Audio Warning Horn - Temperature
- 18** - Instrument Harness Connector (21-Pin Deutsch™)
- 19** - Fuel Gauge (Optional)
- 20** - Connector With Relay (If Second Station Equipped)
- 21** - Connector Jumper (If Single Station Only)
- 22** - 20 Amp Fuse
- 23** - Audio Warning Delay Relay (During Pre-Heat)
- 24** - Diode Pack

 **1.** Keep wires separated. Not used on this model. Tape each wire separately with at least two layers of electrical tape.

 **2.** Spare wire.

INSTRUMENT HARNESS CONNECTOR

NOTE: Refer to Item Number 18 from preceding page.

Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code
A	YEL/RED	H	TAN	R	YEL/WHT
B	RED	J	LT BLU	S	ORN
C	TAN/BLK	K	BLU/TAN	T	BRN/WHT
D	BLK	L	BLK/YEL	U	(NOT USED)
E	GRN/RED	M	YEL	V	(NOT USED)
F	TAN/BLK	N	PPL/ORN	X	RED/YEL
G	PPL	P	GRY	W	BRN

Quicksilver Second Station Instrumentation Wiring


Models With Early Connectors

STERNDRIVE (MCM) - SECOND STATION INSTRUMENTATION

- 1 - Oil Pressure
- 2 - Tachometer
- 3 - Trim Gauge
- 4 - Coolant Temperature
- 5 - Voltmeter
- 6 - Cruise Log (Engine Hour Meter)
- 7 - Engine System Monitor -
 - a. - Glow Plug Indicator, b. - Alternator, c. - Oil Pressure, d. - Coolant Temp. e. - Malfunction Indicator Lamp
- 8 - Instrument Lights and Audio Test Switch
- 9 - Start Switch
- 10 - Stop Switch
- 11 - 20-Amp Fuse and Holder
- 12 - Audio Warning Buzzers
- 13 - Remote Control - (Neutral Safety Circuit)
- 14 - Extension Harness
- 15 - Relay



Bullet connectors shown. Alternately, if equipped, connect wires together with ring terminals using screws and hex nuts. Apply Liquid Neoprene to connections and slide rubber sleeves over connections.




76057

INBOARD (MIE) - SECOND STATION INSTRUMENTATION

- 1 - Oil Pressure
- 2 - Tachometer
- 3 - Wires Not Used on MIE (See NOTE 1.)
- 4 - Coolant Temperature
- 5 - Voltmeter
- 6 - Cruise Log (Engine Hour Meter)
- 7 - Engine System Monitor -
 - a. - Glow Plug Indicator, b. - Alternator, c. - Oil Pressure,
 - d. - Coolant Temp. e. - Malfunction Indicator Lamp
- 8 - Instrument Lights and Audio Test Switch
- 9 - Start Switch
- 10 - Stop Switch
- 11 - 20-Amp Fuse and Holder
- 12 - Audio Warning Buzzers
- 13 - Relay
- 14 - Extension Harness


1. Keep wires separated. Not used on this model. Tape each wire separately with at least two layers of electrical tape.



76058

Models With 21-Pin Deutsch™ Connector

STERNDRIVE (MCM) - SECOND STATION INSTRUMENTATION



76907

STERNDRIIVE (MCM) - SECOND STATION INSTRUMENTATION - PAGE 2 OF 2

- 1** - Voltmeter Gauge
- 2** - Tachometer Gauge
- 3** - Water Temperature Gauge
- 4** - Oil Pressure Gauge
- 5** - Trim Position Gauge
- 6** - Engine System Monitor Panel
- 7** - Malfunction Indicator Lamp (Check Engine)
- 8** - Coolant High Temperature
- 9** - Oil Pressure Warning Lamp / Low Gear Lube Monitor Level Lamp
- 10** - Charge Indicator Lamp
- 11** - Preheat Indicator Lamp
- 12** - Panel Lights/Audio Warning Test Switch
- 13** - Stop Switch
- 14** - Start Switch
- 15** - Spare Wires (Optional Hour Meter Gauge)
- 16** - Audio Warning Horn - Oil
- 17** - Audio Warning Horn - Temperature
- 18** - Instrument Harness Connector (Deutsch™)
- 19** - Fuel Gauge Wires Not Used
- 20** - Connector Without Relay
- 21** - Connector Jumper
- 22** - 20 Amp Fuse
- 23** - Audio Warning Delay Relay (During Pre-Heat)
- 24** - Diode Pack
- 25** - Neutral Start Safety Circuit - Sterndrive (MCM) Remote Control

1. Bullet connectors shown. Alternately, if equipped, connect wires together with ring terminals using screws and hex nuts. Apply Liquid Neoprene to connections and slide rubber sleeves over connections.

2. Keep wires separated. Not used on this model. Tape each wire separately with at least two layers of electrical tape.


3. Spare wire.

INSTRUMENT / EXTENSION HARNESS CONNECTOR

NOTE: Refer to Item Number 18 from preceding page.

Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code
A	YEL/RED	H	TAN	R	YEL/WHT
B	RED	J	LT BLU	S	ORN
C	TAN/BLK	K	BLU/TAN	T	BRN/WHT
D	BLK	L	BLK/YEL	U	(NOT USED)
E	GRN/RED	M	YEL	V	(NOT USED)
F	TAN/BLK	N	PPL/ORN	X	RED/YEL
G	PPL	P	GRY	W	BRN

INBOARD (MIE) - SECOND STATION INSTRUMENTATION



76907

INBOARD (MIE) - SECOND STATION INSTRUMENTATION - PAGE 2 OF 2

- 1** - Voltmeter Gauge
- 2** - Tachometer Gauge
- 3** - Water Temperature Gauge
- 4** - Oil Pressure Gauge
- 5** - Wires Not Used On This Model.
- 6** - Engine System Monitor Panel
- 7** - Malfunction Indicator Lamp (Check Engine)
- 8** - Coolant High Temperature
- 9** - Oil Pressure Warning Lamp / Low Gear Lube Monitor Level Lamp
- 10** - Charge Indicator Lamp
- 11** - Preheat Indicator Lamp
- 12** - Panel Lights/Audio Warning Test Switch
- 13** - Stop Switch
- 14** - Start Switch
- 15** - Spare Wires (Optional Hour Meter Gauge)
- 16** - Audio Warning Horn - Oil
- 17** - Audio Warning Horn - Temperature
- 18** - Instrument Harness Connector (Deutsch™)
- 19** - Fuel Gauge Wires Not Used
- 20** - Connector Without Relay
- 21** - Connector Jumper
- 22** - 20 Amp Fuse
- 23** - Audio Warning Delay Relay (During Pre-Heat)
- 24** - Diode Pack
- 25** - Neutral Start Safety Circuit - Refer To Transmission Neutral Start Safety Switch Circuit On Inboard Models

1. Keep wires separated. Not used on this model. Tape each wire separately with at least two layers of electrical tape.

2. Spare wire.

INSTRUMENT / EXTENSION HARNESS CONNECTOR

NOTE: Refer to Item Number 18 from preceding page.

Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code	Terminal Letter	Wire Color Code
A	YEL/RED	H	TAN	R	YEL/WHT
B	RED	J	LT BLU	S	ORN
C	TAN/BLK	K	BLU/TAN	T	BRN/WHT
D	BLK	L	BLK/YEL	U	(NOT USED)
E	GRN/RED	M	YEL	V	(NOT USED)
F	TAN/BLK	N	PPL/ORN	X	RED/YEL
G	PPL	P	GRY	W	BRN

THIS PAGE IS INTENTIONALLY BLANK

FUEL SYSTEM

Section 5A - Description

Table of Contents

Introduction	5A-3	Analog Signals	5A-9
Precautions	5A-4	Analog Value Conditioning	5A-11
Testing Procedure	5A-5	Digital Signals	5A-13
General Information	5A-6	Engine Control Module (ECM)	5A-15
Basic Knowledge and Tools Required ..	5A-6	Speed Density System	5A-17
Visual/Physical Inspection	5A-6	ECM Input and Sensor Descriptions ..	5A-18
Electrostatic Discharge Damage	5A-6	Fuel Management	5A-26
Diagnostic Information	5A-7	Control	5A-26
Terminology	5A-7	Modes Of Operation	5A-27
Electronic Control Module (ECM)		Diagnosis and Testing	5A-30
and Sensors	5A-9	ECM Reactions During Operation	5A-30
General Description	5A-9	ECM Self-Diagnostics	5A-30
Computers and Voltage Signals	5A-9		

THIS PAGE IS INTENTIONALLY BLANK

Introduction

The following information has been prepared for effective service and diagnosis of the Mercury MerCruiser Electronic Diesel Injection (EDI) system.

All information, illustrations and specifications contained herein are based on the latest product information available at the time of publication approval. The right is reserved to make changes at any time without notice.

An understanding of the material contained in this manual and in subsequent publications issued when necessary, will assist service personnel in properly maintaining the quality to which Mercury MerCruiser engine control systems are built.

Precautions

CAUTION


To reduce the chance of personal injury and/or property damage, the following instructions must be carefully observed: proper service and repair are important to the safety of the service technician and the safe, reliable operation of all Mercury MerCruiser Electronic Diesel Injection (EDI) equipped engines. If part replacement is necessary, the part must be replaced with one of the same part number or with an equivalent part. Do NOT use a replacement part of lesser quality. The service procedures recommended and described in this service manual are effective methods of performing service and repair. Some of these procedures require the use of tools specially designed for the purpose. Accordingly, anyone who intends to use a replacement part, service procedure or tool, which is not recommended by the system manufacturer, must first determine that neither his safety nor the safe operation of the engine will be jeopardized by the replacement part, service procedure or tool selected. It is important to note that this manual contains various "Cautions" and "Notes" that must be carefully observed in order to reduce the risk of personal injury during service or repair, or the possibility that improper service or repair may damage the engine or render it unsafe. It is also important to understand that these "Cautions" and "Notes" are not exhaustive, because it is impossible to warn of all the possible hazardous consequences that might result from failure to follow these instructions.

The following requirements must be observed when working on EDI equipped engines:

- Before removing any ECM (Engine Control Module) system component, disconnect the negative battery cable.
- Never start the engine without the battery cable terminal ends being solidly connected.
- Never separate the battery from the on-board electrical system while the engine is operating.
- Never separate the battery feed wire from the charging system while the engine is operating.
- When charging the battery, disconnect it from the boat's electrical system.
- Ensure that all cable harnesses are connected solidly and that battery connections are thoroughly clean.
- Never connect or disconnect the wiring harness at the ECM when the ignition is switched ON.
- Before attempting any electric arc welding, disconnect the battery leads and the ECM connector.
- When steam cleaning engines, Do NOT direct the steam cleaning nozzle at ECM system components. If this happens, corrosion of the terminals or damage of components can take place.
- Use only the test equipment specified since other test equipment may either give incorrect results or damage good components.
- All voltage measurements using a voltmeter require a digital voltmeter with a rating of 10 megohms input impedance.

Testing Procedure

5. When a test light is specified, a low-power test light must be used. DO NOT use a high-wattage test light. While a particular brand of test light is not suggested, a simple test, as shown below, on any test light will ensure it to be safe for system circuit testing:
 - a. Connect an accurate ammeter (such as the high impedance digital multimeter) in series with the test light being tested, and power the test light/ammeter circuit with the battery.
 - b. If the ammeter indicates LESS than 3/10 amp current flow (.3 A or 300 mA), the test light is SAFE to use.
 - c. If the ammeter indicates MORE than 3/10 amp current flow (.3 A or 300 mA), the test light is NOT SAFE to use.



f - Amp Meter
g - Test Light
h - 12 Volt Battery

NOTE: Using a test light with 100 mA or less rating may show a faint glow when test actually states no light.

6. When using a DVOM to perform voltage measurements, turn the ignition OFF when connecting the DVOM to the circuitry to be tested.

General Information

Basic Knowledge and Tools Required

To use the information in this manual most effectively, a general understanding of basic electrical circuits and circuit testing tools is required. You should be familiar with wiring diagrams; the meaning of volts, ohms and amperes; the basic theories of electricity and understand what happens in an open or shorted wire. To perform system diagnosis, several special tools and equipment are required. Please become acquainted with the tools and their use before attempting to diagnose the system. Special tools, which are required for system service, are listed in the particular sections.

Visual/Physical Inspection

IMPORTANT: A careful visual and physical inspection must be performed as part of any diagnostic procedure. This can often lead to fixing a problem without further steps.

Inspect all lines and hoses for correct routing, pinches, cuts or disconnects. Inspect components that are difficult to see. Inspect all the wires in the engine compartment for proper connections, burned or chafed spots, pinched wires or contact with sharp edges or hot exhaust manifolds. This visual/physical inspection is very important. It must be done carefully and thoroughly.

Electrostatic Discharge Damage

Electronic components used in control systems are often designed to carry very low voltage, and are very susceptible to damage caused by electrostatic discharge. It is possible for less than 100 volts of static electricity to cause damage to some electronic components. By comparison, it takes as much as 4,000 volts for a person to even feel the effect of a static discharge.

There are several ways for a person to become statically charged. The most common methods of charging are by friction and by induction. An example of charging by friction is a person sliding across a seat, in which a charge of as much as 25,000 volts can build up. Charging by induction occurs when a person with well-insulated shoes stands near a highly charged object and momentarily touches ground. Charges of the same polarity are drained off, leaving the person highly charged with the opposite polarity. Static charges of either type can cause damage; therefore, it is important to use care when handling and testing electronic components.

Diagnostic Information

The diagnostic information and functional checks contained in SECTION 5E of this manual are designed to locate a faulty circuit or component through logic based on the process of elimination. The information was prepared with the requirement that the system functioned correctly at the time of assembly and that there are no multiple failures.

Terminology

ABBREVIATIONS

ADF	MAP (Manifold Atmospheric Pressure) Sensor
BARO	Barometric Pressure
BAT	Battery Positive Terminal, Battery or System Voltage
B+	Battery Positive
CKT	Circuit
CONN	Connector
CYL	Cylinder
DEG	Degrees
DIAG	Diagnostic
DLC	Data Link Connector
DTC	Diagnostic Trouble Code
DVOM	Digital Volt Ohmmeter
ECM	Engine Control Module
ECT	Engine Coolant Temperature
EEPROM	Electronic Erasable Programmable Read Only Memory
EMI	Electromagnetic Interference
ENG	Engine
GND	Ground
GPH	Gallons Per Hour
IAT	Intake Air Temperature
in. hg	Inches Of Mercury
INJ	Injection
IGN	Ignition

ABBREVIATIONS (CONTINUED)

kPa	Kilopascal
KV	Kilovolts
LDF	MAP or Boost Pressure Sensor
LGS	Low Idle Switch
MAP	Manifold Absolute Pressure
MIL	Malfunction Indicator Lamp
msec	Millisecond
mV	Millivolt
NBF	Instrumented Injector
N/C	Normally Closed
N/O	Normally Open
PID	Packet of Informational Data
PROM	Programmable Read Only Memory
RAM	Random Access Memory
REF HI	Reference High
REF LO	Reference Low
ROM	Read Only Memory
SRC	Signal Range Check
SW	Switch
TACH	Tachometer
TERM	Terminal
TP	Throttle Position Sensor
V	Volts
VAC	Vacuum
WOT	Wide Open Throttle

Electronic Control Module (ECM) and Sensors

General Description

The Mercury MerCruiser Electronic Diesel Injection (EDI) system is equipped with a computer that provides the operator with state-of-the-art control of fuel delivery. Computers use voltage to send and receive information.

Computers and Voltage Signals

Voltage is electrical pressure. Voltage does not flow in circuits. Instead, voltage causes current. Current does the real work in electrical circuits. It is current, the flow of electrically charged particles, that energizes solenoids, closes relays and lights lamps.

Besides causing currents in circuits, voltage can be used as a signal. Voltage signals can send information by changing levels, changing waveform (shape) or changing the speed at which the signal switches from one level to another. Computers use voltage signals to communicate with one another. The different sections inside computers also use voltage signals to communicate with each other.


There are two kinds of voltage signals, analog and digital. Both of these are used in computer systems. It's important to understand the difference between them and the different ways they are used.

Analog Signals


An analog signal is continuously variable. This means that the signal can be any voltage within a certain range. An analog signal usually gives information about a condition that changes continuously over a certain range. For example, in a marine engine, information about temperature is usually provided by an analog signal. There are two general types of sensors that produce analog signals: the 3-wire and the 2-wire sensor.

SENSORS WITH MORE THAN TWO WIRES (MAP / IAT AND TP)

As an example, the following figure shows a schematic representation of a 3-wire sensor. All 3-wire sensors have a reference voltage, a ground and a variable wiper. The lead coming off of the wiper will be the signal to the Engine Control Module (ECM). As this wiper position changes, the signal voltage returned to the computer also changes.

**3-Wire Sensor****TWO-WIRE SENSORS (ECT)**

The following figure is the schematic of a 2-wire type sensor. This sensor is basically a variable resistor in series with a fixed-known resistor within the computer. By knowing the values of the input voltage and the voltage drop across the known resistor, the value of the variable resistor can be determined. The variable resistors that are commonly used are called thermistors. A thermistor's resistance varies inversely with temperature.

**2-Wire Sensor**

Analog Value Conditioning

The analog value conditioning is subdivided into two parts: sampling the analog signals and scaling and checking the raw values.

The following analog values are made available as messages by the analog value conditioning circuits of the ECM:

- Water temperature
- Air temperature
- Fuel temperature
- Intake manifold pressure (boost pressure)
- Atmospheric pressure
- Throttle Position (TP)
- Instrumented Injector Needle movement
- TP current
- Reference voltage
- Battery voltage

ANALOG VALUE SAMPLING

Sampling saves the results of the periodic analog/digital conversion as raw values. The stored values are evaluated at a later time.

In addition to periodic signal sampling there is also an active speed-synchronous sampling. Upon starts, the speed-synchronous sampling conversion that may be running is stopped. In the next signal sampling period, the discontinued conversion is again started.

ANALOG VALUE EVALUATION

To process the raw values there are three different loop frames: speed-synchronous (speed interrupt-synchronous up to a max of 6 ms), fast time-synchronous (20 ms) and slow time-synchronous (100 ms).

To evaluate the analog signals, the raw values are checked and converted. Checking consists of a signal range check (SRC). Upon exceeding the valid signal range, a default value is used for the raw values. As an example, an engine coolant temperature (ECT) sensor malfunction would set an internal switch, causing a default value to replace the signal from the defective ECT sensor.

The data set parameter is selected so that the default value is accepted over a ramp (time) function or directly. If the raw value is again in a valid range after a SRC error, the new value is brought to the current value.

The raw value is scaled by means of a curve. There are additional special routines for evaluating the TP sensor and MAP sensor. These signals have a supply voltage through which the raw value is scaled.

In case of TP sensor failure, such as a SRC defect on supply voltage, a default value for fuel quantity calculation would be substituted by the ECM. The engine would only be capable of a default set speed of 800 rpm.

The ECM is programmed to respond appropriately to variations from other devices, also. For example:

- The instrumented injector needle movement sensor is only evaluated and checked when the battery voltage is greater than 9 volt.
- If the battery voltage is below a given amount for a specified time the ECM determines that the needle movement sensor cannot be evaluated.
- If certain preset SRC value thresholds are exceeded or exceeded for specified lengths of time, errors may be reported. At this point devices involved in the variation may be checked for plausibility.

NOTE: "Checked for plausibility" means that the ECM will try to establish which component or input from a component is at fault. That is, it will compare data and attempt to "reason" through what might be the most probable faulty component based on information it has received.

Digital Signals

GENERAL

The computer uses digital signals in a code that contains only ones and zeros. The high voltage of the digital signal represents a one (1), and no voltage represents a zero (0). Each zero and each one is called a bit of information, or just a bit. Eight bits together are called a word. A word, therefore, contains some combination of eight binary code bits: eight ones, eight zeros, five ones and three zeros, and so on.

Binary code is used inside a computer and between a computer and any electronic device that understands the code. By stringing together thousands of bits, computers can communicate and store an infinite variety of information. To a computer that understands binary, 11001011 might mean that it should reset engine rpm at a lower level. Although the computer uses 8-bit digital codes internally and when talking to another computer, each bit can have a meaning.

PROCESSING THE DIGITAL INPUTS

The digital inputs are centrally read, processed and distributed throughout the system. The first input message indicates the raw electrical conditions; a special internal message indicates the logical, validity-checked conditions of the inputs.

Digital input signals that are processed:

1. Glow time feedback
2. Low-idle switch
3. Terminal 15 (battery voltage, key ON)
4. Terminal 15, not validity-checked
5. Logical conditions, validity-checked
6. Electrical conditions, not validity-checked

Inputs that are not used are masked out. Each input signal is checked for validity (correctness). Every input is converted into its assigned logical level dependant on four data set parameters.

The four parameters for every input:

- a. Maximum
- b. Off-Limit
- c. On-Limit
- d. Minimum

For Terminal 15 input, the unchecked (not validity checked) status is also made available.

SWITCH TYPES

Switched inputs (also known as discretes) to the computer can cause one bit to change, resulting in information being communicated to the computer. Switched inputs can come in two types: they are pull-up and pull-down types. Both types will be discussed.

With a pull-up type switch, the ECM will sense a voltage when the switch is CLOSED. With the pull-down switch, the ECM recognizes the voltage when the switch is OPEN.

Discretes can also be used to inform a computer of FREQUENCY information.

PULSE COUNTERS


For the computer to determine frequency information from a switched input, the computer must measure the time between voltage pulses. As a number of pulses are recorded in a set amount of time, the computer can calculate the frequency. The meaning of the frequency number can have any number of meanings to the computer.

An example of a pulse counter type of input is the Engine rpm Speed sensor reference pulse input. The computer can count a train of pulses, a given number of pulses per engine revolution, and determine the rpm of the engine.

Engine Control Module (ECM)

The Engine Control Module (ECM) is the control center of the fuel injection system. It constantly monitors information from various sensors, and controls the systems that affect engine performance.

The ECM also performs a diagnostic function check of the system. It can recognize operational problems and store a code or codes, which identify the problem areas to aid the technician in making repairs.




75301

D2.8L D-Tronic and D4.2L D-Tronic Engine Control Module (ECM)

The ECM is supplied voltage from the key switch through a 5 ampere fuse and holder located in the electrical box on the port side of the engine. If the fuse is defective (blown) certain systems will not function properly.

As an example the engine may crank but not start, since the ECM would not have a 12 volt signal. Also, when the 5 ampere fuse is defective the scan tool will indicate "No Communication" at the Diagnostic Connector.



75298

- a** - Electrical Box
- b** - 5 Amp. Fuse In Holder

ECM FUNCTION

The ECM supplies 4.9 volts (generally rounded to 5 volts, in conversation) or 12 volts to power various sensors or switches. This is done through resistances in the ECM which are so high in value that a test light will not light when connected to the circuit. In some cases, even an ordinary shop voltmeter will not give an accurate reading because its resistance is too low. Therefore, the use of a **10 megohm input impedance digital voltmeter** is required to assure accurate voltage readings.

MEMORY

There are three types of memory storage within the ECM: ROM, RAM and EEPROM.

ROM

Read Only Memory (ROM) is a permanent memory that is physically soldered to the circuit boards within the ECM. The ROM contains the overall control programs. Once the ROM is programmed, it cannot be changed. The ROM memory is non-erasable, and does not need power to be retained.

RAM

Random Access Memory (RAM) is the microprocessor scratch pad. The processor can write into, or read from, this memory as needed. This memory is erasable and needs a constant supply of voltage to be retained.

EEPROM

Electronic Erasable Programmable Read Only Memory (EEPROM) is the portion of the ECM that contains the different engine calibration information that is specific to each marine application.

Speed Density System

The Electronic Diesel Injection (EDI) system is a speed and air density system. The system is based on speed/density fuel management.

Three specific data sensors provide the ECM with the basic information for the fuel management portion of its operation. That is, three specific signals to the ECM establish the engine speed and air density factors: the Engine rpm Sensor, Intake Air Sensor and the Manifold Absolute Pressure Sensor.

SPEED

The Engine rpm Speed sensor signal comes from a three-wire magnetic pickup mounted on the port side of the flywheel housing. The ECM uses this information to determine the speed or rpm factor for fuel quantity and injection timing management.

DENSITY

The Intake Air Temperature (IAT) and the Manifold Absolute Pressure (MAP) sensors are joined into one sensor assembly. These two sensors contribute to determining the air density factor.

The IAT sensor circuit measures the temperature of the air entering the intake manifold. The IAT sensor is a thermistor that changes its resistance depending on the air temperature. When the temperature is low, the resistance is high, and when the temperature is high, the resistance is low.

The Manifold Absolute Pressure (MAP) sensor circuit is a sensor that monitors the changes in intake manifold pressure which results from changes in engine loads. These pressure changes are supplied to the ECM in the form of electrical signals.

As intake manifold pressure increases or vacuum decreases, the air density in the intake manifold also increases, and additional fuel is required.


The MAP sensor sends this pressure information to the ECM, and the ECM increases the amount of fuel injected by applying voltage to the Fuel Quantity Actuator (rotary actuator). As manifold pressure decreases or vacuum increases, the amount of fuel is decreased. When no voltage is applied to the actuator, its return springs reduce the injected fuel quantity to zero (none injected).

These three inputs MAP, IAT and rpm are the major determinants of the air/fuel mixture, delivered by the fuel injection system.

The remaining sensors and switches provide electrical inputs to the ECM which are used for modification of the air/fuel mixture, as well as for other ECM control functions.


ECM Input and Sensor Descriptions

The following shows the sensors, switches, and other inputs used by the ECM to output control the various systems. Although we will not cover them all in great detail, there will be a brief description of each.



INSTRUMENTED INJECTOR [NEEDLE MOVEMENT SENSOR (NBF)]

The injector timing reference is supplied to the ECM by way of the Instrumented Injector (Needle Movement Sensor) in the cylinder number 1 injector. This position variable type input creates the timing signal for the ECM. This signal is used for a number of control and testing functions within the ECM.



75339


Instrumented Injector

- a** - Instrumented Injector
- b** - Electrical Harness Connector
- c** - Locking Tab

A failure in the Instrumented Injector circuit should set Code P1201 or P1725. Display of these codes indicates a failure in the sensor circuit, so proper diagnosis will lead to either repairing a wiring problem or replacing the sensor.

ENGINE COOLANT TEMPERATURE (ECT) SENSOR

The Engine Coolant Temperature (ECT) Sensor is a thermistor (a resistor which changes value based on temperature) immersed in the engine coolant stream. Low coolant temperature produces a high resistance, while high temperature causes low resistance.



75341


- a** - ECT Sensor
- b** - Harness Connector
- c** - Locking Tab

The ECM supplies a fixed current to the ECT through a resistor in the ECM and measures the voltage. The voltage will be high when the engine is cold, and low when the engine is hot. By measuring the voltage, the ECM knows the engine coolant temperature. Engine coolant temperature affects most systems the ECM controls.

A failure in the ECT circuit should set Code P0115. Remember, this code indicates a failure in the coolant temperature sensor circuit, so proper use of the chart will lead to either repairing a wiring problem or replacing the sensor.

INTAKE AIR TEMPERATURE AND MANIFOLD PRESSURE SENSOR ASSEMBLY**Intake Air Temperature (IAT) Sensor**

The Intake Air Temperature (IAT) sensor and MAP sensor form an assembly. The IAT portion of the assembly is a thermistor (a resistor which changes value based on temperature). Low temperature produces a high resistance, while high temperature causes a low resistance.



75340


- a** - IAT Sensor
- b** - Harness Connector
- c** - Locking Tab

The ECM supplies a fixed current to the sensor through a resistor in the ECM and measures the voltage. The ECM voltage will be high when the intake air is cold, and low when the intake manifold air is hot.

A failure in the IAT sensor circuit should set a Code P1110.

Manifold Absolute Pressure (MAP) Sensor

The Manifold Absolute Pressure (MAP) sensor is a pressure transducer that measures the changes in the intake manifold pressure. The pressure changes as a result of engine load and speed change, and the MAP sensor converts this to a voltage output.



- a** - Sensor
- b** - Pressure Sensor
- c** - Temperature Sensor
- d** - Electrical Connector Attachment
- e** - Locking Tab


The ECM sends a 5 volt reference signal to the MAP sensor. As the manifold pressure changes, the electrical resistance of the MAP sensor also changes. By monitoring the sensor output voltage, the ECM knows the manifold pressure. A higher pressure, low vacuum (high voltage) requires more fuel, while a lower pressure, higher vacuum (low voltage) requires less fuel. The ECM uses the MAP sensor to control fuel delivery and injection timing.

A closed throttle position on engine coast-down would produce a relatively low MAP output voltage, while a wide open throttle would produce a high MAP output voltage. This higher output voltage is produced because the pressure inside the manifold is increasing. When manifold pressure is high, vacuum is low.

A failure in the MAP sensor circuit should set a Code P0105.

FUEL QUANTITY ACTUATOR AND SENSOR

Inside the electronic diesel pump the solenoid actuator (rotary actuator) for injected fuel quantity control engages with the control collar through a shaft. Similar to the mechanically governed fuel injection pump, the cutoff ports are opened or closed depending upon the control collar's position. The injected fuel quantity can be infinitely varied between zero and maximum (e.g., for cold starting). Using an angle sensor (potentiometer) called the Fuel Quantity Sensor the rotary actuator's angle of rotation, and thus the position of the control collar, are reported back to the ECM and used to determine the injected fuel quantity as a function of engine speed. When no voltage is applied to the actuator, its return springs reduce the injection quantity to zero.



75407

- a** - EDI Injection Pump
- b** - Fuel Quantity (Control-Collar Position) Sensor
- c** - Control Collar
- d** - Fuel Quantity Actuator

A failure of the Fuel Quantity Actuator circuit should set a Code P1220. A failure of the Fuel Quantity Sensor should set a Code P1225.

FUEL TEMPERATURE SENSOR


The Fuel Temperature Sensor is a thermistor (a resistor which changes value based on temperature) immersed in the fuel inside the upper chamber of the fuel pump. It is not a serviceable item. Low fuel temperature produces a high resistance, while high temperature causes low resistance.

The ECM supplies a fixed current to the pump through a resistor in the ECM and measures the voltage. The voltage will be high when the fuel is cold, and low when the fuel is hot. By measuring the voltage, the ECM knows the fuel temperature.

A failure in the fuel temperature circuit should set Code P0180. Remember, this code indicates a failure in the fuel temperature sensor circuit, so proper use of the chart will lead to either repairing a wiring problem or determining the failure is the fuel pump. However, it is not suggested that the pump be replaced for this failure unless the customer complains of related driveability problems.

ENGINE RPM SPEED SENSOR

The Engine rpm Speed sensor is an induction-type pulse generator which scans the leading edge of the flywheel. Four notches (drillings) serve to sense the engine speed. The resulting change in magnetic flux induces an AC voltage signal which is evaluated by the ECM. The ECM processes the signal to establish TDC and the crankshaft position relative to TDC.




75311

- a** - RPM Sensor
- b** - Electrical Connector

A failure in the Engine RPM Speed sensor circuit should set a Code P0725.

THROTTLE POSITION (TP) SENSOR

The Throttle Position (TP) Sensor is a potentiometer connected to the throttle cable. The TP has one end connected to 5 volts from the ECM and the other to ECM ground. A third wire is connected to the ECM to measure the voltage from the TP. As the throttle cable is operated, the angle of the wiper inside the TP body is changed: the voltage output of the TP also changes. At a closed throttle position, the voltage output of the TP is low (approximately .4 volt). As the throttle position changes the output increases, so that at wide open throttle (WOT), the output voltage should be near 4.5 volts. By monitoring the output voltage from the TP sensor, the ECM can determine fuel delivery based on the throttle position (operator demand).



75336

- a** - TP Sensor
- b** - Electrical Connector

Failures that might occur with the TP sensor, are:

- TP sensor out of range (SRC High or Low).
- Low idle switch defective.
- TP sensor supply voltage incorrect.
- Plausibility (possibility of error) between TP sensor and low idle switch signal to the ECM.

If the TP circuit is open, the ECM will set a Code P1515. If the TP circuit is shorted, the ECM will think the vessel is at WOT, and a trouble Code P1515 will be set. A problem in any of the TP circuits will set a Code P1515. Once a trouble code is set, the ECM will use a default value resulting in an engine speed of 800 rpm.

Fuel Management

Control


As stated previously, the Electronic Diesel Injection (EDI) is controlled by an Engine Control Module (ECM). This module is the nerve/decision center of the system. It uses all the information it gathers to manage and deliver increased fuel economy and maximum engine performance.

The EDI system has been designed so that the ECM controls the injected quantity and timing by the ECM. This electronic control allows the ECM to maintain optimum engine performance and the lowest exhaust emissions possible.

Recall that the EDI system uses inputs from sensors to make decisions on the quantity of fuel and amount of pump timing advance or retard allowed.

In order for the ECM to properly calculate advance, it must always know the engine speed.

The ECM also performs a diagnostic function check of the system. It can recognize operational problems and store a code or codes, which identify the problem areas to aid the technician in making repairs.



75343

Engine Control Module (ECM)

Modes Of Operation

PREHEATING THE GLOW PLUGS (IF EQUIPPED)

The operation of the glow plugs and the glow plug preheating on-time is controlled by the ECM. The time period during which the glow plugs are ON (supplied 12 volts) depends directly on the temperature of the engine coolant (coolant temperature sensor) and the altitude of the engine. The altitude is determined by the BARO Barometric Absolute pressure sensor located inside the ECM. The ignition OFF time in which the engine can be restarted without the preheat cycle is about 20 seconds.

The ECM also uses a post heat strategy, in which power to the glow plugs (12 v) is maintained after engine start-up. This time period is calculated by the ECM and is based on engine ECT sensor signal equivalent to approximately 60° C (140° F) and engine speed up to 1500 rpm. By using coolant temperature and engine rpm references it is possible to reduce cold engine noise as well as emissions after starting.

ENGINE STARTING

During engine starting the ECM does not look at the throttle position information. The throttle position has no influence on the starting procedure. Additionally, the ECM ignores the input signal from the instrumented first injector. While starting, the fuel flow rate is determined exclusively on the basis of the engine speed and the engine coolant temperature input information. The ECM sets the fuel injection timing based on the signal from the coolant temperature sensor.

ENGINE OPERATION

During engine operation, the ECM calculates the fuel flow rate based on signals from the throttle position sensor and Engine rpm Speed sensor. This information is then sent to the injection pump, which regulates the rate of the fuel flowing into the cylinders of the engines. The injection pump uses a rotating electromagnetic actuator to move the delivery plunger which controls the pumps working stroke and the amount of fuel flow. The quantity of fuel to be injected is also corrected based on the following parameters:

- Fuel temperature. The ECM uses this information to calculate the exact weight of the fuel injected. The pump actually controls the volume of fuel, but the calculation of the air/fuel ratio by the ECM requires knowledge of the weight of the fuel injected. The weight of the fuel is determined by fuel temperature.
- Air intake temperature and absolute barometric pressure. These inputs are needed by the ECM to optimize the ideal air/fuel ratio for the prevailing engine operating conditions.

The maximum flow rate of the fuel entering the engine is limited according to the torque curve based on the engine speed. The actual position of the fuel quantity actuator, which is necessary to send the correct amount of fuel to the injectors, is detected by the Fuel Quantity Sensor (an inductive control-collar position sensor or potentiometer) located on the actuator. By comparing the real data and the calculated data, the ECM constantly changes the position of the actuator.

ENGINE SPEED CHANGES

The ECM adjusts the engine operating strategy during acceleration and deceleration in order to avoid unstable operating conditions such as jerkiness and roughness.

FUEL FLOW PROPORTIONING

The ECM uses information from the Throttle Position sensor and the Engine rpm Speed sensor along with the strategies in its memory to determine the proper fuel quantity to be injected into the engine. After comparing the nominal position on the control collar with the actual position of the control collar, a fuel quantity adjustment is made based on the fuel temperature detected by the sensor on the pump. The adjustment will be made until the actual position of the control collar coincides with its nominal position.

In this way the quantity of fuel appropriate for the selected operating conditions is delivered. The maximum flow rate of the fuel is determined by engine rpm. The flow rate adjustment also takes into account the input information detected by the ECM from the engine coolant temperature sensor and the air intake temperature sensor. The ECM also handles an engine operation control function, particularly during acceleration and deceleration.

ELECTRONIC INJECTION PUMP

The electronic injection pump with its upper chambers (high pressure) and lower chamber (low pressure) pump and actuators are the same as the mechanically controlled injector pump.

The pump interior pressure is dependent upon pump speed. Similar to the mechanical timing device, this pressure is applied to the timing-device piston. This pressure on the timing-device pressure side is modulated by the Timing Solenoid Valve (a clocked solenoid valve).

With this solenoid valve permanently opened (pressure reduction), start of injection is retarded. With it fully closed (pressure increase), start of injection is advanced. In the intermediate range, the ON/OFF ratio (the ratio of solenoid valve open to solenoid valve closed) can be infinitely varied by the ECM.

SENSORS

The position of the throttle and the control collar in the injection pump are registered by the angle sensors. These use either contacting or non-contacting methods. Engine speed and TDC are registered by inductive sensors. Sensors with high measuring accuracy and long-term stability are used for pressure and temperature measurements. The start of injection is registered by a sensor that is directly integrated in the nozzle holder and which detects the start of injection by sensing the needle movement.

INJECTOR TIMING REGULATION

Determining the proper fuel injection point (timing) depends on the quantity of fuel, engine rpm and coolant temperature. The ECM controls the timing using the signal from the number one instrumented injector and corrects the timing to the nominal timing rate. Timing is changed by modulating the pressure in the upper (high pressure) chamber communicating with the pump body through the Timing Solenoid Valve.

During operation, the fuel pressure in the pump upper chamber exerts pressure on the injection timing actuator piston. The piston has a spring on the lower side which, along with the pressure chamber, allows the piston to maintain a regulated pressure in the upper chamber that the ECM can monitor and adjust.

The Timing Solenoid Valve is operated by the ECM. The ECM will adjust the pressure in the upper chamber to the level that provides the required timing and discharges the excess pressure into the lower chamber. From the lower chamber, the excess fuel is returned to the tank. The position of the Timing Solenoid Valve piston is actually determined by the difference in the pressure acting on the face of the piston. The position of the injection timing adjustment piston also determines the position of the piston in its valve seat. Rotating the bearing ring changes the piston valve seat phasing compared to the position of the rotating cam disk. This advances the intake phase. With the valve open, the injection is delayed. Reducing the inlet orifice by closing the valve, advances the timing based on the resulting pressure drop. The solenoid is closed if power (12 v) is removed.

NOTE: *The electronic injection pump is not serviceable. If a pump needs service, consult your Mercury MerCruiser Dealer or the nearest Bosch Dealer Service Network office.*

ENGINE SHUT OFF

The principle of auto-ignition as applied to the diesel engine means that the engine can only be switched off by interrupting its supply of fuel.

When equipped with Electronic Diesel Injection control, the engine is switched OFF by the Fuel Quantity Actuator (an input signal from the ECM: injected fuel quantity = zero). The Fuel Shut Off Valve, a separate electrical engine shut off device on the fuel pump, serves as a standby shut off in case the actuator should fail.

Diagnosis and Testing

NOTICE

For more information on diagnosis and testing refer to SECTION 5E.
--

ECM Reactions During Operation

The ECM is capable of performing diagnostic checks within the electronic diesel fuel injection system. When the ECM senses a problem in the system it will identify the problem(s) by storing fault code number(s) in its memory. The fault code number(s) can be retrieved from the ECM memory and can be used to identify the improperly operating circuit or component.

There are two recommended methods of retrieving fault codes from the ECM:

1. Scan Tool
2. Blink Code Tool

ECM Self-Diagnostics

The ECM performs a continual self-diagnosis on certain control functions. This diagnostic capability is complemented by the diagnostic procedures contained in this manual. The ECM's language for communicating the source of a malfunction is a system of diagnostic codes. The codes are four digit numbers preceded by the letter P. The prefix letter P is the abbreviation for Powertrain, an internationally standardize reference. When a malfunction is detected by the ECM, a code is set and the Malfunction Indicator Lamp (MIL) is illuminated in most instances.

NOTE: On factory instrumentation the MIL is a lamp with a check mark (✓) on the colored lens.

MALFUNCTION INDICATOR LAMP

The Engine System Monitor Panel provided in the factory instrumentation package is equipped with a Malfunction Indicator Lamp (MIL). The MIL is a lamp with a check mark (✓) on the colored lens.

- It informs the operator and service technician that a problem has occurred and that the vessel is in need of service as soon as reasonably possible.
- It displays Codes stored by the ECM which help the technician diagnose system problems.

As a bulb and system check, the lamp will come ON with the key on and the engine not operating. When the engine is started, the light will turn OFF. If the lamp remains ON, the self-diagnostic system has detected a problem. If the problem is corrected, the light will go out in most cases after ten seconds, but a code will remain stored in the ECM.

When the lamp remains ON while the engine is operating, or when a malfunction is suspected due to a driveability problem, an EDI Diagnostic Circuit Check must be performed. These checks will expose malfunctions which may not be detected if other diagnostics are performed prematurely.

The ECM has been programmed to illuminate the MIL during or due to the errors associated with the following devices:

- Engine Coolant Temperature (ECT) sensor
- Intake Air Temperature (IAT) sensor
- Manifold Absolute Pressure (MAP) sensor
- Throttle Position (TP) and Low Idle Switch (LGS) sensor
- Instrumented injector (NBF)
- Timing Solenoid Valve
- Timing advance regulation
- Fuel Shut Off Valve
- Battery + (12 Volts)
- Fuel Quantity Actuator
- Fuel Quantity Sensor
- Engine RPM Speed Sensor
- EEPROM in ECM

INTERMITTENT PROBLEMS AND MALFUNCTION INDICATOR LAMP

In the case of an intermittent problem, the Malfunction Indicator Lamp will light for ten seconds and then will go out. However, the corresponding code will be stored in the memory of the ECM. When unexpected codes appear during the code reading process, one can assume that these codes were set by an intermittent malfunction and could be helpful in diagnosing the system.

An intermittent code may or may not reset. IF IT IS AN INTERMITTENT FAILURE, A DIAGNOSTIC CODE CHART IS NOT USED. Consult the Diagnostic Help section following the Circuit Description information. Troubleshooting also covers the topic of Intermittents. A physical inspection of the applicable sub-system most often will resolve the problem.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

FUEL SYSTEMS


Section 5B - Fuel Delivery Pump and Fuel Filter

Table of Contents

Identification	5B-3	Testing	5B-8
Specifications	5B-3	Removal	5B-10
Torque	5B-3	Installation	5B-11
Tools	5B-3	Water Separating Fuel Filter	5B-13
Lubricants / Sealants / Adhesives	5B-3	Removal	5B-13
Precautions	5B-4	Installation	5B-13
Exploded View	5B-6	Water Drain Valve Operation	5B-15
Fuel Delivery Pump, Fuel Filter and Related Components	5B-6	Purging Air From The Fuel System	5B-16

THIS PAGE IS INTENTIONALLY BLANK

Identification



70163

D2.8L D-Tronic and D4.2L D-Tronic Fuel Delivery Pump

Specifications

Description		D2.8L D-Tronic And D4.2L D-Tronic
Fuel Flow per Minute	Measured at 2500 rpm; no load.	80 Liters (85 U. S. Qts.) at 2500 rpm
Delivery Pressure		14 - 34 kPa (2-5 psi)
Supply Restriction		20.261 kPa (6 in. Hg)
Return Pressure		13.78 kPa (2 psi)

Torque

Description	Nm	lb-in.	lb-ft
Filter Header To Bracket Nut	32		24
Pump To Block Nut	24		18
Fuel Filter	Hand tighten only		

Tools

DESCRIPTION	PART NUMBER
Fuel Pressure Gauge [0-103.35 kPa (0-15 psi)]	Obtain Locally

Lubricants / Sealants / Adhesives

Description	Part Number
SAE 30W Engine Oil	Obtain Locally

Precautions

WARNING

ALWAYS disconnect battery cables from battery **BEFORE** working on fuel system to prevent fire. This eliminates the engine wiring as a potential source of ignition.

WARNING

FIRE HAZARD: Be careful when changing fuel system components; diesel fuel is flammable. Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death. Ensure that ignition key is **OFF**. Do **NOT** smoke or allow sources of open flame in the area while changing fuel system components. Do **NOT** allow fuel to come into contact with any hot surface which may cause it to ignite.

WARNING

FIRE HAZARD: Wipe up any spilled fuel immediately. Dispose of rags appropriately. Dispose of fuel soaked rags, paper, etc. in an appropriate air tight, fire retardant container. Fuel soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

WARNING

Avoid diesel fuel fire or explosion. Improper installation of brass fittings or plugs into fuel filter base can crack casting and/or cause a fuel leak.

- Apply #565 Loctite Pipe Sealant with Teflon to threads of brass fitting or plug. Do **NOT** USE TEFLON TAPE.
- Thread brass fitting or plug into fuel pump or fuel filter base until finger-tight.
- Tighten fitting or plug an additional 1-3/4 to 2-1/4 turns using a wrench. Do **NOT** overtighten.
- Install fuel line. To prevent overtightening, hold brass fitting with suitable wrench and tighten fuel line connectors securely.
- Check for fuel leaks.

⚠ WARNING

FIRE HAZARD: Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death. Careful periodic inspection of entire fuel system is mandatory, particularly after storage. All fuel components including fuel tanks, whether plastic, metal or fiberglass, fuel lines, primers, fittings and fuel filters should be inspected for leakage, softening, hardening, swelling or corrosion. Any sign of leakage or deterioration requires replacement before further engine operation.

⚠ WARNING

Make sure that no fuel leaks exist, before closing engine hatch.

⚠ CAUTION


Do NOT operate engine without cooling water being supplied to seawater pickup pump or pump impeller will be damaged, and subsequent overheating damage may result.

⚠ WARNING

Boating industry standards (NMMA, ABYC, etc.) federal standards and Coast Guard regulations must be adhered to when installing fuel delivery system.

Exploded View

Fuel Delivery Pump, Fuel Filter and Related Components



- 1** - Fuel Pump
- 2** - Screw
- 3** - Lockwasher
- 4** - Filter Bracket
- 5** - Fuel Filter
- 6** - O-ring
- 7** - Drain Cap
- 8** - Pipe, Pump-To-Filter Header
- 9** - Hollow Bolt (3)
- 10** - Sealing Washer
- 11** - Pipe, Filter Header-To-Injection Pump
- 12** - Nut
- 13** - Fuel Pump Cover
- 14** - Diaphragm
- 15** - Diaphragm Spring
- 16** - O-ring
- 17** - Stud (2)
- 18** - Lockwasher (2)
- 19** - Nut (2)
- 20** - Fuel Inlet Fitting
- 21** - Elbow Fittings
- 22** - Bracket


Description		Part Number
A	30W Engine Oil	Obtain Locally

Testing

IMPORTANT: Avoid a decrease in engine performance. Restrictions of either fuel supply or fuel return circuits will adversely affect engine performance.

TESTING FUEL DELIVERY PUMP PRESSURE

3. Remove the bleeder valve from the filter header.
4. Install a suitable barbed , tapered fitting with a short section of fuel hose connected.
5. Attach a suitable 0-100 kPa (0-15 PSI) pressure gauge to this hose.




Testing Delivery Pressure

- c** - Bleeder Valve
- d** - Suitable Barbed Fitting
- e** - Pressure Gauge

6. If the measured value is not within specifications, repair as needed.

TESTING FUEL SYSTEM RESTRICTION TO DELIVERY PUMP


1. Install a suitable vacuum gauge to the inlet side of fuel delivery pump.
2. If measured value is greater than specified, repair as needed.

**Testing Restriction**

- a** - Inlet Fitting
- b** - Suitable Vacuum Gauge
- c** - Fuel Supply From Fuel Tank

Removal

1. Disconnect battery cables from battery.
2. Remove fuel supply hose. Plug hose to prevent fuel from leaking into boat.




75298

Typical

d - Fuel Delivery Pump

e - Fuel Supply Hose

3. Remove the hollow bolt from the fuel outlet pipe. Discard sealing washers.
4. Remove the fuel pump. Discard the O-ring seal.



75298

Typical

a - Hollow Bolt

b - Sealing Washer


c - Lockwasher

d - Mounting Nut

e - O-ring

Installation


1. Using 2 new sealing washers on hollow bolt, attach fuel inlet fitting to fuel pump as shown.
2. Tighten hollow bolt securely.



75298

- a** - Hollow Bolt
- b** - Sealing Washer
- c** - Fuel Inlet Fitting


3. Using a new O-ring, install the fuel pump on the engine block. Temporarily hand tighten the mounting nuts.



75298

- a** - O-ring
- b** - Lockwasher
- c** - Nut

4. Using 2 new sealing washers on hollow bolt, attach fuel outlet pipe to fuel pump.
5. Torque fuel pump mounting nuts securely.
6. Tighten fuel outlet pipe hollow bolt securely.
7. Connect fuel supply hose. Tighten hose clamp securely.



75298

- a** - Hollow Bolt
- b** - Sealing Washer
- c** - Fuel Outlet Pipe
- d** - Mounting Nut
- e** - Clamp
- f** - Fuel Supply Hose

Water Separating Fuel Filter

Removal


1. Disconnect battery cables from battery.

NOTE: Use a suitable container to catch excess fuel.

2. Twist locking ring by hand. Remove water separating fuel filter and sealing ring from mounting bracket. Do NOT use a filter wrench.

IMPORTANT: Element cannot be cleaned and reused. It must be replaced.

3. Remove the drain cap and O-ring from bottom of the existing filter. Note position of O-ring seal. Inspect and replace damaged components.




- a** - Locking Ring
- b** - Filter Element
- c** - Drain Cap
- d** - O-ring

4. Discard filter and sealing ring.


Installation

1. Install O-ring and drain cap on new filter.



- a** - O-ring Seal
- b** - Drain Cap

2. Lubricate fuel filter seal with clean 30W engine oil. Align filter to bracket. Twist locking ring by hand to secure filter to bracket. Do NOT use a filter wrench.




74731

- a** - Filter Header
- b** - Locking Ring
- c** - Sealing Ring (Lubricate)
- d** - Water Separating Fuel Filter

NOTE: Place a suitable container under fuel filter to catch excess fuel.

3. Loosen bleed screw on fuel filter bracket.
4. Move plunger on hand pump/primer up and down repeatedly, until an air free stream of fuel flows from bleed screw. Filter is full when this occurs.
5. Tighten bleed screw.



74726

- a** - Pump/Primer Knob
- b** - Bleed Screw


6. Connect battery cables.
7. Start engine, check for fuel leaks. If leaks exist stop engine immediately. Recheck filter installation.

Water Drain Valve Operation

The fuel filter can be drained of water and small dirt particles without removal of filter.

NOTE: To ensure complete draining, in warm weather open the water bleed valve before starting daily operations. In cold weather, where there is a possibility that the condensed water will freeze, drain the filter shortly after the end of daily operations.

1. Using a suitable container to catch contaminated fuel and/or water, open drain cap at bottom of filter by turning the drain counterclockwise (as viewed from the bottom of the filter).
2. Drain until fuel is clear in appearance.



- a** - Fuel Filter
- b** - Drain Cap
- c** - Expelled Fuel

74726

3. Close the drain. Tighten securely.
4. Fill the fuel filter.

Purging Air From The Fuel System

⚠ CAUTION


Absolute cleanliness is required for work on the fuel system, since the injection pump and fuel injectors have very close tolerances. Even minute particles of dirt or small amounts of water can impair the function of the fuel injection system.

The practice of draining and replacing the water separating fuel filter, including purging a new filter of air, is generally the only time for purging air from the system. In most cases the design of the EDI System will prevent needing to purge the fuel injection pump itself.

However, should it become necessary to purge air from the fuel injection pump proceed as follows.

NOTE: Place suitable container under the fuel filter and injection pump to catch excess fuel.

1. Bleed air from the water separating fuel filter.
2. Loosen the bleed screw on injection pump.
3. Move plunger on hand pump/primer up and down repeatedly, until an air free stream of fuel flows from bleed screw.



71371

a - Bleed Screw
b - Expelled Fuel

4. Close the bleed screw on the injection pump. Tighten securely.
5. Connect the battery cables.
6. Start the engine. Check for leaks. If leaks exist stop the engine immediately. Recheck the filter installation.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

FUEL SYSTEM

Section 5C - Fuel Injectors


Table of Contents

Identification	5C-3	Exploded View	5C-8
Specifications	5C-3	Injector Test (Engine Misfiring)	5C-9
Torque	5C-3	Removal	5C-10
Tools	5C-4	Inspection	5C-12
Bosch	5C-4	Testing	5C-12
Lubricants / Sealants / Adhesives	5C-4	Installation	5C-13
Precautions	5C-5	Purging Air From Fuel Injectors	
Description	5C-6	(Bleeding)	5C-16
Fuel Injector (Cutaway View)	5C-7		

THIS PAGE IS INTENTIONALLY BLANK

Identification

The Bosch injector for Direct Injected D-Tronic engines can be identified as shown.



75339

Instrumented Injector Shown (Non-Instrumented Injector Similar)

Specifications


Description		Specification
Manufacturer		Robert Bosch Corporation
Injector Type	D2.8L D-Tronic	Multi-Orifice, Hole-Type Nozzle
	D4.2L D-Tronic	
Opening Pressure (New Injector)		27,000 kPa (3915 psi)
Spray Angle		157 Degrees
Spray Hole Diameter		0.25 mm (.001 in.)

Torque

Description	Nm	lb-in.	lb-ft
Injector Clamp Nut	24		18
Injection Pipe Sleeve Nut	17	156	
Injection Pipe Clamp Screws	12.7	112	

Tools

Bosch

EFEP60H Nozzle Tester	0 681 200 502
Description: Robert Bosch Corporation 2800 South 25th Avenue Broadview, IL 60153 Mailing Address: P.O. Box 4601 North Suburban, IL 60197 Phone: (312) 865-5200	 74442

Lubricants / Sealants / Adhesives

Description	Part Number
30W Engine Oil	Obtain Locally

Precautions

WARNING

ALWAYS disconnect battery cables from battery BEFORE working on fuel system to prevent fire. This eliminates the engine wiring as a potential source of ignition.

WARNING

FIRE HAZARD: Be careful when changing fuel system components; diesel fuel is flammable. Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death. Ensure that ignition key is OFF. Do NOT smoke or allow sources of open flame in the area while changing fuel system components. Do NOT allow fuel to come into contact with any hot surface which may cause it to ignite.

WARNING

FIRE HAZARD: Wipe up any spilled fuel immediately. Dispose of rags appropriately. Dispose of fuel soaked rags, paper, etc. in an appropriate airtight, fire-retardant container. Fuel soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

WARNING

FIRE HAZARD: Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death. Careful periodic inspection of entire fuel system is mandatory, particularly after storage. All fuel components including fuel tanks, whether plastic, metal or fiberglass, fuel lines, primers, fittings, and fuel filters should be inspected for leakage, softening, hardening, swelling or corrosion. Any sign of leakage or deterioration requires replacement before further engine operation.

WARNING

Safety glasses should be worn while working on fuel injection system. The fuel injection pump will generate pressures in excess of 13790 kPa (2000 psi). Use caution when removing injectors, injector lines, or bleeding air from injection system.

CAUTION

Keep injectors and injection pump fittings clean. Do NOT allow dirt to enter fittings when removing or installing lines. Dirt will cause injectors or injection pump to malfunction.

IMPORTANT: Mercury MerCruiser does not recommend fuel injectors be disassembled for service. If an injector tester is not available, substitute a new injector for any injectors thought to be faulty.

IMPORTANT: Always wash hands and use clean tools when working on fuel injection system.

Description

In the EDI fuel injection system, the injectors (with their nozzles in the particular nozzle holders) are an important connection between the electronically controlled injection pump and the engine.


The injectors job includes the following:

- Meter the injected fuel.
- Manage and prepare the fuel spray in the cylinder.
- Set the rate of fuel discharge.
- Close-off the injection system from the combustion process taking place inside each cylinder.

The EDI diesel engines use a hole type injector nozzle and holder. In contrast to the previous throttling pintle nozzles, the hole type nozzle must be installed in a given position. The spray holes are at different angles in the nozzle body and must be correctly aligned with regard to the combustion chamber. The nozzle has a specially shaped end, or nozzle cone, into which the needle of the injector seats. Two precisely sized and matched pressure springs hold the needle seated.

The springs are calibrated to allow the needle to unseat at about 27,000 kPa (3,915 psi). The shape of the needle, the holes and spring pressures restricts the amount of fuel injected when the needle first starts to open. Not until the needle is completely open is the full amount of fuel injected. Because it promotes a gradual pressure rise, this action gives soft combustion and therefore a smooth operating engine.

Fuel Injector (Cutaway View)




75439

Instrumented Injector (Needle Motion Sensor) Shown (Non-Instrumented Similar)

- 1 - Holder Body
- 2 - Adjusting Spindle
- 3 - Contact Lug
- 4 - Sensor Coil
- 5 - Pressure Adjustment Shim
- 6 - Pressure Spring
- 7 - Pressure Spindle
- 8 - Guide
- 9 - Spring Support
- 10 - Stop Sleeve
- 11 - Intermediate Disc
- 12 - Nozzle Retaining Nut

Exploded View



73911


- | | |
|---|--|
| 1 - Injector / Instrumented Injector
(Cylinder Number 1 Only) | 13 - Clamp |
| 2 - Nozzle Gasket | 14 - Clamp |
| 3 - O-ring | 15 - Clamp |
| 4 - Nut (M8) | 16 - Hollow Bolt |
| 5 - Washer (If Equipped) | 17 - Sealing Washer |
| 6 - Injector Clamp | 18 - Hollow Bolt (M14 x 1.5) |
| 7 - Injection Pipe (Cylinder #1) | 19 - Sealing Washer |
| 8 - Injection Pipe (Cylinder #2) | 20 - Fuel Return Fitting |
| 9 - Injection Pipe (Cylinder #3) | 21 - Return Fuel Connector |
| 10 - Injection Pipe (Cylinder #4) | 22 - Hollow Bolt (M8 x 1) |
| 11 - Injection Pipe (Cylinder #5 - D4.2L
D-Tronic Only) | 23 - Washer |
| 12 - Injection Pipe (Cylinder #6 - D4.2L
D-Tronic Only) | 24 - Return Pipe |
| | 25 - Injector / Pressure Pipe Adaptor |
| | 26 - Sealing Washer |

NOTICE

Read Precautions at front of this SECTION before proceeding.

Injector Test (Engine Misfiring)

7. Supply cooling water to seawater inlet holes.
8. Put on safety glasses.
9. With the engine operating at idle, carefully loosen injector pipe sleeve nut at injectors, one cylinder at a time.
 - a. If idle rpm changes, injector is operating.
 - b. If idle rpm does not change, injector may be faulty.



70148

Typical

a - Sleeve Nut At Injector


10. Check all injectors, one at a time.
11. Stop engine. Replace injector or injectors as necessary.
12. If engine continues to misfire, check for mechanical problems (faulty injection pump, burned valves).

Removal

1. Remove engine cover.
2. Clean dirt from around fuel injector fittings and pipes.

IMPORTANT: Ensure that each pipe adapter is counterheld with a second wrench when removing the return pipe hollow bolts.

3. Counterhold fuel return pipe adapter and remove the fuel return pipe hollow bolts. Discard sealing washers.
4. Remove fuel return pipe.




73911

Typical


- a** - Return Pipe Adapter
- b** - Fuel Return Pipe
- c** - Hollow Bolts
- d** - Sealing Washers
- e** - Return Fuel Connector On Injection Pump

5. Loosen fuel injection pipe clamps.
6. Loosen fuel injection pipe sleeve nuts.



73911

- a** - Injection Pipe Clamp
- b** - Fuel Injection Pipe
- c** - Sleeve Nut




75583

⚠ CAUTION

Do NOT bend fuel injection pipes. Bending may cause metal to flake off inside pipes, causing injectors or injection pump to malfunction.

7. Remove fuel injection pipes from injection pump and injectors.
8. Remove flanged hex nut and washer (some engines may not have washers installed).
9. Remove injector clamp. Retain all components.



75584


- a** - Flanged Hex Nut (or Hex Nut and Washer, If Equipped)
b - Clamp

⚠ CAUTION

To prevent injector nozzle from rusting, wet parts with diesel fuel before handling.

NOTE: To assist in removal, rotate the injector slightly clockwise and counter-clockwise to break any seal formed by paint or corrosion. Repeat for each injector if required.

10. Withdraw the fuel injector from the bore together with mounting hardware. Discard copper sealing washer and O-ring.



73911

- a** - Fuel Injector
b - Fuel Return Pipe Adaptor
c - O-ring
d - Copper Sealing Washer

Inspection

1. Remove any injector seals that may have stayed in the head. Do NOT gouge or nick seat.
2. Ensure that cylinder head injector bores are clean.


Testing

⚠ WARNING

Test fluid from the injection nozzle tester will spray out under great pressure. It can easily puncture a person's skin. Keep your hands away from the injection nozzle tester at all times.

Mercury MerCruiser recommends using the EFEP60H nozzle tester from the Robert Bosch Corporation. Follow instructions with injector tester for checking nozzle opening pressure and spray pattern.

IMPORTANT: Mercury Marine does not recommend fuel injectors be disassembled for service. If an injector tester is not available, substitute a new injector for any injectors thought to be faulty.




74442

EFEP60H Nozzle Tester

1. Put on safety glasses.
2. Use a nozzle tester to check the injection nozzle opening pressure and the spray condition.

Description	Specifications
Opening Pressure	27,000 kPa (3915 psi)

3. If the opening pressure is above or below the specified value, the injector must be replaced or reconditioned.
4. If the spray condition is bad, the injector must be replaced or reconditioned.




77719

- a** - Correct
b - Incorrect (Restrictions In Orifices)
c - Incorrect (Dripping)

Installation

1. Place new copper sealing washer on injector seat as shown.

IMPORTANT: Make certain the sealing washer is centered in the bore, and fully seated on the head.




70146


Typical

a - Copper Sealing Washer

2. Install new O-ring seal on injector. Lubricate seal with a light coat of 30W engine oil.
3. Point fuel return pipe adaptor away from valve cover and install injector. Ensure seal is not damaged during installation.
4. Install injector clamp nut. Torque nut to 24 Nm (18 lb-ft).




73911



75584

- a** - Fuel Injector
- b** - Fuel Return Pipe Adaptor
- c** - O-ring
- d** - Clamp
- e** - Flanged Hex Nut (Or Hex Nut And Washer, If Equipped)

5. Install fuel injection pipes . Tighten sleeve nuts to 17 Nm (156 lb-in.).





75583

- a** - High Pressure Fuel Line
b - Sleeve Nut

6. Using 2 new sealing washers for each hollow bolt, install fuel return pipe on injector adapters.

IMPORTANT: Ensure that each pipe adapter is counterheld with a second wrench when installing the return pipe hollow bolts.

7. Counterhold fuel return pipe adapter and tighten hollow bolts securely.




73911

75583

Typical

- a** - Fuel Return Pipe
b - Hollow Bolts
c - Sealing Washers (Two Per Hollow Bolt and Fitting)
d - Adapter

8. Using 2 new sealing washers for the hollow bolt, install fuel return pipe line on injection pump connector. Tighten hollow bolt securely.



73911

75583

Typical

- a** - Fuel Return Pipe
 - b** - Hollow Bolts
 - c** - Sealing Washers (Two Per Hollow Bolt and Fitting)
9. Refer to Purging Air From Fuel Injectors (Bleeding) to operate the engine and check for fuel leaks. Repair as needed.
 10. Install the engine cover.

Purging Air From Fuel Injectors (Bleeding)

In most cases the design of the EDI System will prevent needing to purge air from the fuel lines and injectors. Draining and replacing the water separating fuel filter should include purging air from the new filter, but not usually from the fuel lines, injectors or system.

⚠ CAUTION

Overheating from insufficient cooling water will cause engine and drive system damage. Ensure that there is sufficient water always available at water inlet holes during operation.

1. Supply cooling water to water inlet.


⚠ CAUTION

To prevent damage to starter motor, Do NOT use for more than 15 seconds at one time. Allow at least 2 minutes for starter motor to cool before reusing.

2. Put on safety glasses.
3. Slightly loosen each injection pipe sleeve nut.
4. Crank the engine with the starter motor.

NOTE: Engine may attempt to start when fuel appears at sleeve nuts.

5. When an air free stream of fuel appears at sleeve nut, tighten nut. Continue until all injectors are purged and sleeve nuts are tightened.



70148

Typical

a - Sleeve Nut

6. Torque sleeve nuts to 17 Nm (156 lb-in.).

 WARNING

Avoid injury. Fuel pressure is high enough to penetrate the skin. Do NOT use your fingers to feel for fuel leaks at fittings.

7. Start the engine.
 8. Check for fuel leaks while waiting for engine to reach normal operating temperature. Immediately stop the engine if leaks exist.
 9. Recheck the installation.
 10. Start the engine.
 11. Allow the engine to reach normal operating temperature. Check for fuel leaks at injection pump and injectors by placing a piece of paper near the sleeve nuts or pipes to be checked. The paper should show fuel spray if leaks are present. **Do NOT** use your fingers to feel for leaks! Watch for fuel spray on paper.
 12. Repair as needed.
- NOTE:** *It is sometimes helpful to use compressed air to dry area near fittings when checking for fuel leaks. Be certain to observe precautions about the use of safety glasses!*
13. Test until certain no leaks are present.

THIS PAGE IS INTENTIONALLY BLANK

FUEL SYSTEM

Section 5D - Injection Pump

Table of Contents


Identification	5D-2	Repair and Service	5D-8
Pump Code and Identification		General Information	5D-8
Number Location	5D-2	Service Information	5D-8
Specifications	5D-2	Testing Information	5D-9
Injection Pump	5D-2	Exploded View	5D-10
Timing	5D-3	Fuel Injection Pump Removal	5D-11
Torque Specifications	5D-3	Fuel Injection Pump Installation	5D-16
Special Tools	5D-3	Installation With Engine Assembled ..	5D-16
Tools	5D-4	Installation During Engine	
Special EDI Tools	5D-4	Reassembly	5D-19
Kent-Moore Tools	5D-4	Fuel Injection Pump Timing	5D-23
Lubricants / Sealants / Adhesives	5D-4	Checking	5D-23
Precautions	5D-5	Setting	5D-23
Description	5D-6	Starting Engine - After Fuel Injection	
Fuel Ratings	5D-7	Pump Installation and Timing	5D-28
Diesel Fuel in Cold Weather	5D-7		

NOTICE

Refer to SECTION 5A and 5E for additional information on the EDI Fuel System and the Fuel Injection Pump.

Identification

Pump Code and Identification Number Location



75409

a - Identification Plate

Engine - MCM and MIE	Pump Code and Identification Number
D2.8L D-Tronic	Code:VE 4/12 E 1900 LV1857 L718 Bosch Part Number: 0 460 424 ____ (Quicksilver Part Number: 854213)
D4.2L D-Tronic	Code:VE 4/12 E 1900 LV1848 L719 Bosch Part Number: 0 460 424 ____ (Quicksilver Part Number: 854134)

Specifications

Injection Pump

Description	
Manufacturer	Robert Bosch Corporation
Type of Injection Pump	Distributor Type VE
Ejection Pressure at Fuel Injectors	27,000 kPa (3915 psi)
Delivery Begins	Electronically Controlled
Governor Type	Electronically Controlled

Timing

IMPORTANT: The following conditions must be met before injection pump timing is changed or set:

- Dial Gauge mounted and set on pump.
- Notch on crankshaft damper, or power steering pulley, aligns with timing mark on gear housing cover (0 Degrees - TDC).
- Number 1 Piston at TDC.

Model	Setting
D2.8L D-Tronic - MCM and MIE	0.60 - 0.65 mm (0.023 - 0.025 in.)
D4.2L D-Tronic - MCM and MIE	1.74 - 1.76 mm (0.068 - 0.069 in.)

Torque Specifications

NOTE: Securely tighten all fasteners not listed below.

Description	Nm	lb-in.	lb-ft
Pump Mounting Nuts	30		22
Pump Gear	88		64
Fuel Line Sleeve Nut (High Pressure)	18	156	

Special Tools

Description	Part Number
Graduated Disc ¹	91-801333500
Injection Pump Gear Puller	91-818372
Crankshaft Tool	91-814827
Injection Pump Adaptor Tools	91-854220
DMT 2000A Tachometer / Multi-Meter Kit	91-854009A3

¹ : Some modification may be required for use on some models.

Tools

Special EDI Tools

Tool Name	Description	Part Number
EFI / EDI Scan Tool (Rinda Technologies ¹)	Displays problem codes stored in the ECM. It also allows monitoring of various circuits and components in the fuel injection system. Allows for test firing injectors.	94050M (English) 94055M (Multi-Language)
Quicksilver Diagnostic Blink Code Tool	Flashes light to display problem codes.	91-854221

¹: **Rinda Technologies**, 4563 N. Elston Ave., Chicago, IL 60630, Phone: 312-736-6633

Kent-Moore Tools

Kent-Moore Tools, Inc. 29784 Little Mack Roseville, MI 48066 Phone: (313) 774-9500		
Description		Part Number
High Impedance Multimeter (DVM) ¹	Minimum 10 megohm input impedance required on all voltage ranges. As ammeter, accurately measures low value current flow. As ohmmeter, reads 0-200 ohms, 2/20/200 kΩ, 2/20 mΩ	J-34029-A or Equivalent
Unpowered Test Light ²	Used to check circuit wiring, short to ground, or voltage.	J-34142-B

¹ The High Impedance Multimeter that comes with the existing Outboard EFI Tester (91-11001A1) meets the requirements listed above.

² Using a test light with 100 mA or less rating may show a faint glow when test actually states no light.

Lubricants / Sealants / Adhesives

Description	Part Number
Liquid Neoprene	92-25711-3

Precautions

WARNING

Electrical system components on this engine are not external ignition protected. Do NOT STORE OR UTILIZE GASOLINE ON BOATS EQUIPPED WITH THESE ENGINES, UNLESS PROVISIONS HAVE BEEN MADE TO EXCLUDE GASOLINE VAPORS FROM ENGINE COMPARTMENT (ref: 33 CFR). Failure to comply could result in fire, explosion and/or severe personal injury.

WARNING

Always disconnect battery cables from battery BEFORE working on fuel system to prevent fire. This eliminates the engine wiring as a potential source of ignition.

CAUTION

It is good practice to ventilate the engine compartment prior to servicing any engine components to remove any fuel vapors which may cause difficulty breathing or be an irritant.

WARNING

FIRE HAZARD: Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death. Careful periodic inspection of entire fuel system is mandatory, particularly after storage. All fuel components including fuel tanks, whether plastic, metal or fiberglass, fuel lines, primers, fittings, and fuel filters should be inspected for leakage, softening, hardening, swelling or corrosion. Any sign of leakage or deterioration requires replacement before further engine operation.

WARNING

Be careful when changing fuel system components; diesel fuel is flammable. Ensure that ignition key is OFF. Do NOT smoke or allow sources of open flame in the area while changing fuel system components. Wipe up any spilled fuel immediately. Dispose of rags appropriately. Do NOT allow fuel to come into contact with any hot surface which may cause it to ignite.

WARNING

Dispose of fuel soaked rags, paper, etc. in an appropriate air tight, fire retardant container. Fuel soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

WARNING

Safety glasses should be worn while working on fuel injection system. The fuel injection pump generates very high pressure. Use caution when removing injection pump, injectors, injector lines or bleeding air from the system.

Description

Mercury MerCruiser EDI Diesel Engines use the Bosch, Type VE, Distributor Fuel Injection Pump with an electronic governor and integral timing device.

The pump is mounted on the port side of the engine and is driven by the camshaft gear. The pump is formed basically by an electrical (upper) part and a mechanical (lower) part. The mechanical (lower) part is mainly the same as the previous mechanically controlled VE-style pump, with the exception of the electric Timing Solenoid Valve that is controlling pressure between the upper and lower chambers (parts) of the pump.

When the ECM (Engine Control Module) signals the Timing Solenoid Valve it is electro-mechanically held open (pressure reduction) and the start of injection is retarded. When the valve is fully closed (pressure increase) the start of injection is advanced. In the intermediate range, the ON/OFF ratio (duty cycle) can be infinitely varied by the ECM allowing for a wide range of control over the injected fuel quantity. This is especially so when simultaneously the ECM is controlling the upper electrical portion of the pump.

The upper electrical part consists of these main components:

- Fuel Quantity Actuator
- Fuel Quantity Sensor
- Fuel Temperature Sensor
- Fuel Shut Off Valve

The ECM uses inputs from various sensors to make decisions on the quantity of fuel and amount of pump timing advance or retard allowed. During engine operation, the ECM calculates the fuel flow rate based on signals from the Throttle Position sensor and Engine rpm speed sensor. This information is then sent to the injection pump, which regulates the rate of the fuel flowing into the cylinders of the engine. The injection pump uses a rotational electromagnetic actuator, called the Fuel Quantity Actuator (or control collar actuator), to move the delivery plunger which controls the pumps working stroke and the amount of fuel flow.

Fuel quantity adjustments are made based on internally stored information after a comparison is made between the nominal position on the fuel pump's control collar with the actual position of the control collar. Further adjustment of the fuel quantity actuator can be made based on such inputs as fuel temperature detected by the Fuel Temperature Sensor in the pump. These adjustments will be made until the actual position of the fuel quantity actuator (control collar) coincides with its nominal position. The adjusted fuel quantity is then electronically timed to deliver the correct pressurized amount of fuel to the fuel injectors. Injection pump pressure, at the fuel injectors, exceeds 27000 kPa (3900 psi).

Diesel engines are stopped by shutting off the fuel supply. This is accomplished by the Fuel Quantity Actuator delivering no (zero) fuel or by an ECM controlled redundant electric Fuel Shut Off Valve on the pump.

Fuel Ratings

WARNING

Under no circumstances should gasoline be mixed with diesel fuel for any reason. This mixture of gasoline and diesel fuel is highly flammable and produces a significant risk to the user.

IMPORTANT: Use of improper or water contaminated diesel fuel can damage the engine seriously. Use of improper fuel is considered misuse of engine, and damage caused thereby will not be covered by warranty.

Grade 2-D diesel fuel is required, meeting ASTM Standards D975 (or fuel rated Diesel DIN 51601), and having a minimum cetane rating of 45.

The Cetane number is a measure of the ignition quality of diesel fuel. Increasing the cetane number will not improve overall engine performance, but it may be necessary to raise the cetane rating for low temperature, or high altitude use.

Sulphur content of the above fuel is rated at 0.50% by weight, maximum (ASTM). Limits may vary in countries outside of the United States.

On intermittent use engines, high sulphur content diesel fuel will greatly increase:

- Corrosion of metal parts.
- Deterioration of elastomer and plastic parts.
- Corrosion and extensive damage, and excessive wear of internal engine parts, particularly bearings.
- Starting and operating difficulties.

Diesel Fuel in Cold Weather

WARNING

Under no circumstances should gasoline be mixed with diesel fuel for any reason. This mixture of gasoline and diesel fuel is highly flammable and produces a significant risk to the user.

Unaltered diesel fuels thicken and gel in cold temperatures, unless treated. Virtually all diesel fuels are climatized to allow their use in the particular region for that time of the year. If it becomes necessary to further treat diesel fuel, it is the owner/operator's responsibility to add a commercial standard brand anti-gel diesel fuel additive, following that product's directions.

Repair and Service

General Information

The Robert Bosch Corporation has a network of authorized Bosch Service Dealers throughout the world to service their products.

The electronically controlled EDI pump and injectors must be sent to an authorized Bosch Service Center.

When shipping an injection pump to a service center for adjustments or repairs, the fuel return line hollow bolt must accompany the unit. The hollow bolt incorporates a sized orifice (is calibrated) for proper pressure which is matched to the pump. The pump cannot be properly adjusted without the matched orifice.

Contact the Bosch distributor nearest you for the location of an authorized Bosch Service Center.


Service Information

It is required that you observe the following procedural information when working on EDI equipped engines:

- Before removing any ECM system component, disconnect the negative battery cable.
- Never start the engine without the battery cable terminal ends being solidly connected.
- Never separate the battery from the on-board electrical system while the engine is operating.
- Never separate the battery feed wire from the charging system while the engine is operating.
- When charging the battery, disconnect it from the boat's electrical system.
- Ensure that all cable harnesses are connected solidly and that battery connections are thoroughly clean.
- Never connect or disconnect the wiring harness at the ECM when the ignition is switched ON.
- Before attempting any electric arc welding, disconnect the battery leads and the ECM connectors.
- When steam cleaning engines, Do NOT direct the steam cleaning nozzle at ECM system components. If this happens, corrosion of the terminals or damage of components can take place.
- Use only the test equipment specified in the diagnostic charts, since other test equipment may either give incorrect results or damage good components.
- All voltage measurements using a voltmeter require a digital voltmeter with a rating of 10 megohms input impedance.

Testing Information

14. When a test light is specified, a low-power test light must be used. Do NOT use a high-wattage test light. While a particular brand of test light is not suggested, a simple test, as shown below, on any test light will ensure it to be safe for system circuit testing:
- Connect an accurate ammeter (such as the high impedance digital multimeter) in series with the test light being tested, and power the test light/ammeter circuit with the battery.
 - If the ammeter indicates LESS than 3/10 amp current flow (0.3 amp or 300 mA), the test light is SAFE to use.
 - If the ammeter indicates MORE than 3/10 amp current flow (0.3 amp or 300 mA), the test light is NOT SAFE to use.




- a** - Amp Meter
b - Test Light
c - 12 Volt Battery

NOTE: Using a test light with 100 mA or less rating may show a faint glow when test actually states no light.

15. When using a DVOM to perform voltage measurements, turn the ignition OFF when connecting the DVOM to the circuitry to be tested.

Exploded View



- 27 - Injection Pump
- 28 - Gasket
- 29 - Stud (M8 x 30)
- 30 - Washer
- 31 - Nut
- 32 - Key
- 33 - Lockwasher
- 34 - Nut
- 35 - Electric Fuel Shut-Off Device
- 36 - Washer
- 37 - Nut
- 38 - Sealing Washer
- 39 - Banjo bolt (M14 x 1.5)
- 40 - Return Fuel Connector
- 41 - Keyway Orientation During Install
(All Settings At TDC Cylinder 1)


Description		Part Number
A	Perfect Seal	92-25711-3

Fuel Injection Pump Removal

⚠ WARNING

Safety glasses should be worn while working on fuel injection system. The fuel injection pump will generate pressures in excess of 27000 kPa (3900 psi). Use caution when removing injectors, injector lines or bleeding air from injection system.

1. Remove the hex-head plug in cylinder number 1 glow plug hole, or remove cylinder number 1 cylinder glow plug, if equipped.



75585

Typical

- a** - Hex Head Plug (or Glow Plug, If Equipped)
- b** - Port Side Of Cylinder Head

2. Attach Remote Starter Switch 91-52024A1, or similar, to the starter solenoid in accordance with manufacturer's instructions.

⚠ CAUTION

Avoid breathing difficulties or injury. Diesel fuel and diesel fuel vapors may be expelled from cylinder openings causing breathing difficulty or injury. Do NOT crank the engine using the ignition key switch when establishing Top Dead Center (TDC) of a cylinder because the engine could start unexpectedly. Use a suitable remote starter switch. As an added safety measure remove the key from the ignition switch to prevent start up.


3. Position a piece of thin paper, or similar, near the glow plug hole opening of the cylinder number 1.

NOTE: When cylinder number 1 begins compression stroke, combustion air will be expelled from the cylinder through the glow plug hole opening. Watch for movement of the paper. Stop cranking on compression stroke.

4. Using the remote starter switch, crank the engine to locate compression stroke. Stop cranking on cylinder number 1 compression stroke.
5. Slowly rotate the engine to Top Dead Center (TDC) using a suitable hand tool.

NOTE: Attach and use Crankshaft Tool 91-814827, if necessary.


6. The TDC notch is on the pulley aft edge of the larger drive pulleys. Align notch to timing marks on gear cover for TDC number 1 cylinder.



Typical


- a** - TDC Notch On Pulley
b - Timing Cover Mark

7. Disconnect battery cables.
 8. Using a suitable device remove threaded, round injection pump gear cover by turning cover COUNTERCLOCKWISE.



- a** - Cover (Pin-Type or Hex-Head)


9. Remove injection pump gear nut and lockwasher. Do NOT allow crankshaft to rotate.



- a** - Gear
b - Nut and Lockwasher

10. With central bolt of gear puller tool backed out, install tool into timing cover. Puller will hold gear against timing cover while pump is removed.

NOTE: Gear puller tool screws into timing cover.



70770

- a** - Timing Cover
b - Gear Puller Tool
c - Central Bolt


11. Remove the throttle cable and throttle cable bracket.
12. Disconnect the ECM 68 pin connector and TP sensor connector. The ECM has a slide-to-lock catch on it and the TP sensor connector is a twist-to-lock.
13. Remove three allen head screws retaining the port engine lifting eye and heat exchanger bracket to the timing cover.
14. Remove the two ECM bracket lower isolator flanged nuts.
15. Lift the ECM, ECM bracket and engine lifting eye from the engine.

IMPORTANT: Hollow bolts, used to hold fuel inlet and return lines to injection pump, are calibrated and **MUST** remain with pump in their original location.

⚠ CAUTION

Do NOT bend fuel injector lines. Bending may cause metal to flake off inside lines, causing injectors or injection pump to malfunction.

16. Remove the fuel supply line between the pump and filter flange.
17. Remove the fuel return hose from connector. Plug the hose after removal to prevent a fuel leak.
18. Remove the injector fuel return pipe from pump. Discard old sealing washers.




- a** - Supply Line (Filter to Pump)
- b** - Return Hose
- c** - Connector
- d** - Return Pipe (Injectors to Pump)

19. Unclamp injection pipes.

⚠ CAUTION

Keep injectors and injection pump fittings clean. Do NOT allow dirt to enter fittings when removing lines. Dirt will cause injectors or injection pump to malfunction.

20. Loosen injection pipe sleeve nuts.
21. Remove high pressure fuel injection pipes from the injection pump and fuel injectors.



- a** - Clamps
- b** - Injector Sleeve Nuts
- c** - Pump Sleeve Nuts

NOTE: If necessary, refer to SECTION 5E for description and location of electrical items.

22. Disconnect the Fuel Shut Off Solenoid wire.
23. Disconnect the Fuel Quantity Actuator/Sensor connector.
24. Disconnect the Fuel Timing Solenoid Valve connector.
25. Remove the three injection pump mounting nuts and washers.
26. Slowly turn central bolt of gear puller tool CLOCKWISE until pump and gear separate.

IMPORTANT: The injection pump shaft and gear use a key to stay in alignment. Be careful not to drop the key into the engine when removing pump.

27. Paying special attention to the key, to avoid dropping it into the engine, carefully remove the pump and place it aside.

IMPORTANT: Put suitable protective covers (shipping plugs or similar) over the injection pump fuel ports to avoid contamination.

28. Back the central bolt out of the puller tool, but leave the tool installed.

IMPORTANT: Do NOT turn crankshaft after injection pump is removed. Battery cables should remain disconnected and a notice attached to ignition switch to alert others that the engine should not be disturbed.


Fuel Injection Pump Installation

Installation With Engine Assembled

IMPORTANT: If engine has been disturbed, or must be rotated before installing injection pump take care not to wedge pump gear in gear housing while turning crankshaft.

1. Ensure cylinder number 1 piston is at top dead center (TDC) of its compression stroke and timing marks are aligned.
1. Ensure pump gear is held in the same position as when pump was removed. This should be cylinder number 1 TDC.
2. Rotate shaft to align keyway with cylinder number 1 injector port.

NOTE: To rotate shaft, temporarily install original shaft nut and a suitable jam nut. Do NOT damage pump shaft threads with improper nuts or overtightening.




70420

Typical

a - Shaft Keyway

3. Remove any pump backlash by rotating shaft COUNTERCLOCKWISE (when facing the pump) until resistance is felt.




70767

Typical

a - Shaft - Rotate COUNTERCLOCKWISE
b - Keyway at 11 O'clock

4. Being careful not to disturb shaft alignment, remove nuts temporarily installed to rotate shaft.
5. Apply Perfect Seal sealant to a new injection pump gasket.
6. Install new gasket on pump mounting studs.
7. Ensure pump gear upper keyway is positioned approximately as shown.



70768


- a** - Gasket
- b** - Pump Mounting Studs
- c** - Pump Gear Upper Keyway

8. Install injection pump key in pump shaft keyway. Apply heavy grease to hold key in position.
9. Ensure the key is positioned properly.

IMPORTANT: Do NOT drop key into engine. If key is dropped into engine the key must be removed before operation of the engine.

10. Insert pump shaft into gear, being careful not to dislodge key. Do NOT turn pump shaft from 11 o'clock position. Rotate pump body in slotted holes to align key with gear slot.
11. Install pump to cylinder block hex nuts with flat washers and lockwashers. Temporarily only finger-tighten the nuts.
12. Remove gear puller tool. Make certain key is in position.
13. Using a new lockwasher, secure gear to shaft with hex nut. Torque nut to 88 Nm (64 lb-ft).
14. Using new O-ring in groove, install and securely tighten injection pump gear cover on timing cover.

15. Rotate pump to end of adjustment slot travel in direction shown.



70422

Typical

a - Direction To Rotate

16. Timing of the injection pump **MUST BE** accomplished. Refer to Fuel Injection Pump Timing for instructions.

Installation During Engine Reassembly

1. Temporarily install crankshaft pulley, if removed previously.
2. Attach Crankshaft Tool 91-814827 if necessary.


⚠ CAUTION

To avoid severe engine damage the engine **MUST BE** set on cylinder number 1 COMPRESSION STROKE at Top Dead Center (TDC) before proceeding.

IMPORTANT: If crankshaft position was disturbed after assembly (rotated), it may be necessary to slowly rotate the crankshaft, in the direction of rotation, numerous revolutions to align the crankshaft gear, idler gear, and camshaft gear alignment marks. Refer to SECTION 3A - Camshaft, and verify alignment to establish cylinder number 1 Top Dead Center on compression stroke in the following steps.

3. Ensure cylinder number 1 piston is at TDC of its compression stroke and timing marks are aligned.
4. Attach the graduated disc 91-801333500 to crankshaft with zero positioned as shown.


NOTE: Use the graduated disc adapter plate if crankshaft vibration damper is installed.



Typical Engine


- a** - Adaptor Plate (To Damper, If Installed)
- b** - Bolts (3)
- c** - Graduated Disc
- d** - Crankshaft Tool

5. Using a suitable gauge of wire, make a wire pointer. Attach the pointer to a suitable location on the block. Do NOT damage the mating surfaces
6. Align wire pointer to zero degrees (0) as shown.



- a** - Wire Pointer
b - Zero (0) Degree Mark


7. Using a heavy grease to hold key in place, install injection pump key in pump slot.
8. Temporarily install gear on injection pump shaft. Do NOT secure gear at this time.
9. Rotate shaft to align keyway with cylinder number 1 injector port.
10. Remove any pump backlash by rotating gear COUNTERCLOCKWISE (when facing pump) until resistance is felt.
11. Ensure keyway is at approximately the 11 o'clock position, as shown.



Typical

- a** - Shaft - Rotate COUNTERCLOCKWISE
b - Keyway at 11 O'clock


12. Being careful not to disturb shaft alignment, remove gear. Ensure injection pump key is properly positioned.
13. Apply Perfect Seal sealant to a new injection pump gasket.
14. Install new gasket on pump mounting studs.



70768

- a** - Gasket
b - Pump Mounting Studs

15. Install pump to cylinder block.
16. Install hex nuts with flat washers and lockwashers. Temporarily only finger-tighten the nuts.
17. Rotate pump to end of adjustment slot travel in direction shown.



70422

Typical


- a** - Hex Nuts With Flat Washers And Lockwashers (3 Total)
b - Direction to Rotate

18. Ensure injection pump key is properly positioned.

IMPORTANT: Do NOT force gear on shaft.

19. Install gear on injection pump shaft, using whichever key slot on gear that allows gear to be installed the easiest.

20. Using a new lockwasher, install gear on shaft with hex nut. Torque to 88 Nm (64 lb-ft).



22217

- a** - Gear
- b** - New Lockwasher
- c** - Hex Nut

21. Timing of the injection pump **MUST BE** accomplished. Refer to Fuel Injection Pump Timing in this section for instructions.

Fuel Injection Pump Timing


Checking

On completely assembled and/or installed engines, and for the purpose of checking fuel injection pump timing refer to instructions previously outlined and accomplish steps, in that section, dealing with installation of crankshaft tool, graduated disc, positioning of crankshaft and removal of parts to gain access to rear of fuel injection pump and vent screw.

Setting

1. Establish that the engine is on TDC of the Number One Cylinder.
2. Remove vent screw and sealing washer from rear of injection pump.

NOTE: Pump shown removed for visual clarity.




75409

- a** - Injection Pump
b - Vent Screw With Sealing Washer

3. Install adaptor tool and dial gauge as shown. *Pre-load* the dial indicator with at least 2.54 mm (0.10 in.).


NOTE: Adaptor tool 854220 is designed to use on EDI engines.



70430

- a** - Suitable Adaptor Tool
- b** - Dial Gauge - Preloaded


4. Watch dial indicator needle and SLOWLY rotate the crankshaft COUNTERCLOCKWISE (viewed from water pump end looking toward flywheel) until dial indicator *STOPS* moving.
5. Set the dial indicator to zero (0) as shown.



70431

- a** - Dial Indicator

6. SLOWLY rotate crankshaft CLOCKWISE (viewed from water pump end looking toward flywheel) until 0 Degrees (engine Top Dead Center) is indicated on graduated disc as shown (or until notch on crankshaft damper, or power steering pulley, aligns with timing mark on gear housing cover).




70432


NOTE: The dial indicator follows this rotational movement of crankshaft and **STOPS** when the cylinder number 1 piston is at TDC, when the crankshaft is not turned further.

7. AT THIS MOMENT, the dial indicator should show the specified timing setting. If not, loosen the injection pump mounting nuts and rotate the pump slightly in the appropriate direction to obtain the setting.

Model	Setting
D2.8L D-Tronic - MCM and MIE	0.60-0.65 mm (0.0236 - 0.0256 in.)
D4.2L D-Tronic - MCM and MIE	1.74-1.76 mm (0.0685 - 0.0692 in.)



70433



70422

Typical

- a** - Direction to Rotate
b - Dial Gauge Indication

⚠ CAUTION

Dial gauge indication **MUST NOT** be allowed to change when mounting nuts are tightened. Failure to maintain setting will result in engine damage.

8. Torque the three injection pump mounting nuts to 27.5 Nm (20 lb-ft).
9. Remove dial gauge and adaptor. Reinstall fuel injection pump vent screw using new sealing washer. Tighten securely.



⚠ CAUTION

Keep injectors and injection pump pipes and fittings clean. Do **NOT** allow dirt to enter fittings when installing. Dirt will cause injectors or injection pump to malfunction.

⚠ CAUTION

Do **NOT** bend fuel injector pipes. Bending may cause metal to flake off inside causing injectors or injection pump to malfunction.

10. **During Engine Reassembly:** Continue engine reassembly. Refer to following instructions after all other necessary engine reassembly steps are complete.
11. **With Engine Assembled or After Checking Timing:** Install fuel injection pipes on injection pump and injectors. Tighten all sleeve nuts evenly by hand. Then, torque each sleeve nut to 18 Nm (156 lb-in.).




- a** - Sleeve Nut At Injection Pump
b - Sleeve Nut At Injector

IMPORTANT: Hollow bolts used to hold fuel inlet and return pipes to injection pump are calibrated and **MUST** remain with pump in their original location.

IMPORTANT: Use new sealing washers on hollow bolts to prevent leaks.

12. Install the fuel supply pipe between the pump and filter flange.
13. Unplug and install the fuel return hose to the connector.
14. Install the injector fuel return pipe to the pump.



75579

- a** - Supply Pipe (Filter to Pump)
- b** - Return Hose
- c** - Connector
- d** - Return Pipe (Injectors to Pump)

NOTE: Refer to the Exploded Views in SECTION 5C and to those in this section in the following.

15. Position the ECM, ECM bracket and engine lifting eye on the engine.
16. Install the ECM bracket lower isolator flanged nuts. Tighten nuts securely.
17. Install three allen head screws retaining the port engine lifting eye and heat exchanger bracket to the timing cover. Torque screws to 50 Nm (37 lb-ft).
18. If you previously removed the upper ECM isolator nut, you will need to adjust the ECM and isolator height before tightening the nut. Tighten nut securely.
19. Attach the ECM 68 pin connector to the ECM. Slide the lock to hold it on the ECM.
20. Attach the TP sensor connector halves together. Twist collar to hold halves together.

21. Install throttle cables. Refer to SECTION 2A - Throttle Cable Installation and Adjustment.

IMPORTANT: When installing throttle cables, ensure that cables are routed in such a way as to avoid sharp bends and/or contact with moving parts. Do NOT fasten any items to throttle cables.

22. Remove graduated disc and adaptor ring, crankshaft tool and wire pointer from front of engine. Install the three balancer screws previously removed. Torque screws to 50 Nm (37 lb-ft).
23. Refer to Section 4B - MAINTENANCE, and install alternator belt, power steering belt, if equipped, and optional belts, if equipped.


Starting Engine - After Fuel Injection Pump Installation and Timing

Generally purging air from the system is only needed after draining and replacing the water separating fuel filter or purging a new filter of air. In most cases the design of the EDI System will prevent needing to purge the Fuel Injection Pump itself.

After installing the fuel injection pump, checking or setting pump timing, it will be necessary to fill the fuel injection system.

NOTE: Place a suitable container under fuel filter to catch excess fuel.

1. Loosen bleed screw on fuel filter bracket.
2. Move plunger on hand pump/primer up and down repeatedly, until an air free stream of fuel flows from bleed screw. Filter is full when this occurs.
3. Tighten bleed screw.



74726


a - Plunger
b - Bleed Screw

4. Continue moving the plunger on hand pump/primer up and down repeatedly until resistance is felt. This should have filled the fuel injection pump.

However, should the engine not start and it becomes necessary to purge air from the fuel injection pump, proceed as follows.

NOTE: Place suitable container under fuel filter and injection pump to catch excess fuel.

5. Bleed air from Water Separating Fuel Filter.
6. Loosen bleed screw on injection pump.
7. Move plunger on hand pump/primer up and down repeatedly, until an air free stream of fuel flows from bleed screw.



71371

- a** - Injection Pump
- b** - Bleed Screw
- c** - Expelled Fuel

8. Close bleed screw on injection pump. Tighten securely.

9. Install a fully charged battery.

⚠ CAUTION

To prevent damage to starter motor, Do NOT operate starter for more than 15 seconds at one time. Allow at least 2 minutes for starter motor to cool before reusing.

10. Attempt to start the engine.


⚠ WARNING

Safety glasses should be worn while working on fuel injection system. The fuel injection pump will generate pressures in excess of 13790 kPa (2000 psi). Use caution when removing injectors, injector lines, or bleeding air from injection system.

⚠ WARNING

Do NOT use your fingers to feel for fuel leaks at fittings. Fuel pressure is high enough to penetrate the skin.

11. **IF THE ENGINE STARTS:** Operate engine at idle. Check all fuel connections for fuel leaks. If leaks exist, stop engine and refer to following Step 13. and correct as needed.
12. **IF THE ENGINE WILL NOT START:** Air will have to be bled from injector lines. Follow these instructions:
- Wear safety glasses when bleeding air from injection pipes. Slightly loosen each injection pipe sleeve nut. Turn ignition key switch to the START position while observing injectors.



75590

a - Injection Pipe Sleeve Nut

- Tighten each injection pipe sleeve nut when fuel appears at nut, until all fittings are tightened.

NOTE: Engine may start during this operation.

- When engine starts, injectors may still be bled by loosening injection pipe sleeve nuts at individual injectors if required. Tighten each after bleeding.
- After bleeding injectors, torque all injection pipe sleeve nuts at injectors to 18 Nm (156 lb-in.).

13. Check for fuel leaks at injection pump and injectors using a piece of paper placed near the suspect fitting or sleeve nut to be checked. The paper should show leaks if present. **Do NOT** use your fingers to feel for leaks! Watch for fuel spray on paper. Repair as needed.

14. Retest until certain no leaks are present.

NOTE: Be certain to observe precautions about the use of safety glasses! It is sometimes helpful to use compressed air to dry the area near fitting and sleeve nuts when checking for fuel leaks.

15. Allow engine to reach operating temperature. Once again check for leaks as previously outlined and correct as needed.

⚠ WARNING


Dispose of fuel soaked rags, paper, etc. in an appropriate air tight, fire retardant container. Fuel soaked items may spontaneously ignite and result in a fire hazard which could cause serious bodily injury or death.

⚠ WARNING

Make sure no fuel leaks exist, before closing engine hatch.

TESTING FUEL RETURN PRESSURE

1. Install a suitable 0-100 kPa (0-15 PSI) pressure gauge in the fuel return hose.
2. If measured value is greater than specified, repair as needed.



71967

75579

Testing Return Pressure

- a** - Suitable Pressure Gauge
- b** - Fuel Return Hose
- c** - Fuel Return To Fuel Tank

THIS PAGE IS INTENTIONALLY BLANK

FUEL SYSTEMS

Section 5E - EDI Diagnosis

Table of Contents

General Information	5E-2	Main Relay	5E-46
Introduction	5E-2	Timing Actuator	
Basic Knowledge and Tools Required ..	5E-2	(Timing Solenoid Valve)	5E-48
Visual/Physical Inspection	5E-3	Glow Plug Main Relay	
Electrostatic Discharge Damage	5E-3	(Glow Plug Relay Actuator),	
Special Tools	5E-4	If Equipped	5E-50
Special EDI Tools	5E-4	Glow Plug Auxiliary Relay, If Equipped	5E-52
Kent-Moore Tools	5E-4	Glow Plug Lamp (Glow Plug Display) ..	5E-54
Service Precautions	5E-5	Glow Plug Lamp (Glow Plug Display) ..	5E-56
Diagnostic Information	5E-7	MIL [Malfunction Indicator Lamp	
Abbreviations	5E-7	(Diagnostic Lamp)]	5E-58
ECM Self-Diagnosis	5E-8	MIL [Malfunction Indicator Lamp	
Malfunction Indicator Lamp	5E-9	(Diagnostic Lamp)]	5E-60
Intermittent Problems and		Fuel Shut Off Valve [EAB	
Malfunction Indicator Lamp	5E-10	(Electrical Shut Off)]	5E-62
Reading Codes	5E-10	EEPROM Fault (EEPROM and	
Clearing Codes	5E-13	Configuration)	5E-64
Diagnosis of Driveability Concerns ...	5E-14	RPM Signal From Injector	
ECM Input and Sensor Diagram	5E-15	(Secondary Engine Speed Sensor) ..	5E-66
ECM Connector Pin Layout	5E-16	Troubleshooting For EDI Systems	5E-68
Connector Chart	5E-17	Trouble Codes	5E-68
MAP (Manifold Air Pressure) Sensor ..	5E-20	Display Terminology	5E-69
ECT (Engine Coolant Temperature)		Troubleshooting Charts	5E-74
Sensor	5E-22	Repair Procedures	5E-93
Fuel Temperature Sensor	5E-24	Service Precautions	5E-93
RPM (Engine Speed) Sensor	5E-26	Replacement Parts Warning	5E-94
BARO (Atmospheric Pressure)		Torque Specifications	5E-95
Sensor	5E-28	Lubricants / Sealants / Adhesives	5E-95
IAT (Intake Air Temperature) Sensor ..	5E-30	System Components	5E-96
Instrumented Injector		Fuel Injection Pump Repair	5E-98
(Needle Movement Sensor)	5E-32	Wiring Harness Service	5E-99
Fuel Quantity Actuator		Relay, Module and Sensor Servicing	
(Pump Actuator)	5E-34	(On-Board Service)	5E-102
Fuel Quantity Sensor		Precautions	5E-102
(Control Sleeve Position Sensor)	5E-36	Main Relay	5E-102
Timing Fault		ECM (Electronic Control Module) ...	5E-104
(Timing Advance Regulation)	5E-38	ECT (Engine Coolant Temperature)	
TP (Throttle Position)		Sensor	5E-106
Sensor / Low Idle Switch	5E-40	MAP (Manifold Absolute Pressure) /	
Battery Voltage	5E-42	IAT (Intake Air Temperature) Sensor	5E-108
Battery (Switched K15)	5E-43	Throttle Position (TP) Sensor	5E-110
Microcontroller Fault	5E-44	Instrumented Injector	5E-112
ECM Reference Voltage		Engine RPM Speed Sensor	5E-112
(u_ref - 2.5v)	5E-45	Idle Speed Setting Circuit	5E-113

General Information

CAUTION

To reduce the chance of personal injury and/or property damage, the following instructions must be carefully observed: proper service and repair are important to the safety of the service technician and the safe, reliable operation of all Mercury MerCruiser Electronic Diesel Injection (EDI) equipped engines. If part replacement is necessary, the part must be replaced with one of the same part number or with an equivalent part. Do NOT use a replacement part of lesser quality. The service procedures recommended and described in this service manual are effective methods of performing service and repair. Some of these procedures require the use of tools specially designed for the purpose. Accordingly, anyone who intends to use a replacement part, service procedure or tool, which is not recommended by the system manufacturer, must first determine that neither his safety nor the safe operation of the engine will be jeopardized by the replacement part, service procedure or tool selected. It is important to note that this manual contains various "Cautions" and "Notes" that must be carefully observed in order to reduce the risk of personal injury during service or repair, or the possibility that improper service or repair may damage the engine or render it unsafe. It is also important to understand that these "Cautions" and "Notes" are not exhaustive, because it is impossible to warn of all the possible hazardous consequences that might result from failure to follow these instructions.

Introduction

The following pages been prepared for effective diagnosis of the Mercury MerCruiser Electronic Diesel Injection (EDI) system.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication approval. The right is reserved to make changes at any time without notice.

An understanding of the material contained herein and in subsequent publications issued when necessary, will assist service personnel in properly maintaining the quality to which Mercury MerCruiser engine control systems are built.

Basic Knowledge and Tools Required

To use this manual most effectively, a general understanding of basic electrical circuits and circuit testing tools is required. You should be familiar with wiring diagrams; the meaning of volts, ohms and amperes; the basic theories of electricity; and understand what happens in an open or shorted wire. To perform system diagnosis, several special tools and equipment are required. Please become acquainted with the tools and their use before attempting to diagnose the system. Special tools, which are required for system service, are listed later in this section. Refer to the Table of Contents.

Visual/Physical Inspection

A careful visual and physical inspection must be performed as part of any diagnostic procedure. This can often lead to fixing a problem without further steps. Inspect all hoses for correct routing, pinches, cuts, or disconnects. Inspect hoses that are difficult to see. Inspect all the wires in the engine compartment for proper connections, burned or chafed spots, pinched wires, or contact with sharp edges or hot exhaust manifolds. This visual/physical inspection is very important. It must be done carefully and thoroughly.

Electrostatic Discharge Damage

Electronic components used in control systems are often designed to carry very low voltage, and are very susceptible to damage caused by electrostatic discharge. It is possible for less than 100 volts of static electricity to cause damage to some electronic components. By comparison, it takes as much as 4,000 volts for a person to even feel the effect of a static discharge.

There are several ways for a person to become statically charged. The most common methods of charging are by friction and by induction. An example of charging by friction is a person sliding across a seat, in which a charge of as much as 25,000 volts can build up. Charging by induction occurs when a person with well-insulated shoes stands near a highly charged object and momentarily touches ground. Charges of the same polarity are drained off, leaving the person highly charged with the opposite polarity. Static charges of either type can cause damage; therefore, it is important to use care when handling and testing electronic components.

Special Tools

Tool Name	Description	Part Number
DMT 2000A	Tachometer / Multi-Meter Kit - High Impedance Multimeter	91-854009A3

Special EDI Tools

Tool Name	Description	Part Number
EFI / EDI Scan Tool (Rinda Technologies ¹)	Displays problem codes stored in the ECM. It also allows monitoring of various circuits and components in the fuel injection system. Allows for test firing injectors.	94050M (English) 94055M (Multi-Language)
Quicksilver Diagnostic Blink Code Tool	Flashes light to display problem codes.	91-854221

¹: **Rinda Technologies**, 4563 N. Elston Ave., Chicago, IL 60630, Phone: 312-736-6633

Kent-Moore Tools

Kent-Moore Tools, Inc. 29784 Little Mack Roseville, MI 48066 Phone: (313) 774-9500		
Description		Part Number
High Impedance Multimeter (DVM) ¹	Minimum 10 megohm input impedance required on all voltage ranges. As ammeter, accurately measures low value current flow. As ohmmeter, reads 0-200 ohms, 2/20/200 kΩ, 2/20 mΩ	J-34029-A or Equivalent
Unpowered Test Light ²	Used to check circuit wiring, short to ground, or voltage.	J-34142-B

¹ The High Impedance Multimeter that comes with the existing Outboard EFI Tester (91-11001A1) meets the requirements listed above.


² Using a test light with 100 mA or less rating may show a faint glow when test actually states no light.

Service Precautions

Observe the following when working on EDI equipped engines:

- Before removing any ECM system component, disconnect the negative battery cable.
- Never start the engine without the battery cable terminal ends being solidly connected.
- Never separate the battery from the on-board electrical system while the engine is operating.
- Never separate the battery feed wire from the charging system while the engine is operating.
- When charging the battery, disconnect it from the boat's electrical system.
- Ensure that all cable harnesses are connected solidly and that battery connections are thoroughly clean.
- Never connect or disconnect the wiring harness at the ECM when the ignition is switched ON.
- Before attempting any electric arc welding, disconnect the battery leads and the ECM connectors.
- When steam cleaning engines, Do NOT direct the steam cleaning nozzle at ECM system components. If this happens, corrosion of the terminals or damage of components can take place.
- Use only the test equipment specified in the diagnostic charts, since other test equipment may either give incorrect results or damage good components.
- All voltage measurements using a voltmeter require a digital voltmeter with a rating of 10 megohms input impedance.

3. When a test light is specified, a low-power test light must be used. Do NOT use a high-wattage test light. While a particular brand of test light is not suggested, a simple test, as shown below, on any test light will ensure it to be safe for system circuit testing:
 - a. Connect an accurate ammeter (such as the high impedance digital multimeter) in series with the test light being tested, and power the test light/ammeter circuit with the battery.
 - b. If the ammeter indicates LESS than 3/10 amp current flow (.3 A or 300 mA), the test light is SAFE to use.
 - c. If the ammeter indicates MORE than 3/10 amp current flow (.3 A or 300 mA), the test light is NOT SAFE to use.



- d** - Amp meter
e - Test Light
f - 12 Volt Battery

NOTE: Using a test light with 100 mA or less rating may show a faint glow when test actually states no light.

4. When using a DVOM to perform voltage measurements, turn the ignition OFF when connecting the DVOM to the circuitry to be tested.

Diagnostic Information

The diagnostic information and functional checks in this manual are designed to locate a faulty circuit or component through logic based on the process of elimination. The information was prepared with the requirement that the system functioned correctly at the time of assembly and that there are no multiple failures.

Abbreviations

ADF	Atmospheric Pressure Sensor (See BARO)
BARO	Barometric Pressure
BAT	Battery Positive Terminal, Battery or System Voltage
B+	Battery Positive
CKT	Circuit
CONN	Connector
CYL	Cylinder
DEG	Degrees
DIAG	Diagnostic
DLC	Data Link Connector
DTC	Diagnostic Trouble Code
DVOM	Digital Volt Ohmmeter
ECM	Engine Control Module
ECT	Engine Coolant Temperature
EEPROM	Electronic Erasable Programmable Read Only Memory
EMI	Electromagnetic Interference
ENG	Engine
GND	Ground
GPH	Gallons Per Hour
IAT	Intake Air Temperature
in. hg	Inches Of Mercury
INJ	Injection
IGN	Ignition
kPa	Kilopascal

Abbreviations (continued)

KV	Kilovolts
LDF	Boost Pressure Sensor (See MAP)
LGS	Low Idle Switch
MAP	Manifold Absolute Pressure
MIL	Malfunction Indicator Lamp
msec	Millisecond
NBF	Instrumented Injector
N/C	Normally Closed
N/O	Normally Open
PID	Packet of Informational Data
PROM	Programmable Read Only Memory
PWG	Throttle Position Sensor
RAM	Random Access Memory
REF HI	Reference High
REF LO	Reference Low
ROM	Read Only Memory
SRC	Signal Range Check
SW	Switch
TACH	Tachometer
TERM	Terminal
TP	Throttle Position Sensor
V	Volts
VAC	Vacuum
WOT	Wide Open Throttle

ECM Self-Diagnosis

The ECM performs a continual self-diagnosis on certain control functions. This diagnostic capability is complemented by the diagnostic procedures contained in this manual. The ECM's language for communicating the source of a malfunction is a system of diagnostic codes. The codes are four digit numbers preceded by the letter "P." The prefix letter "P" is the abbreviation for "Powertrain," an internationally standard reference. When a malfunction is detected by the ECM, a code is set and the Malfunction Indicator Lamp (MIL) is illuminated.

NOTE: On factory instrumentation the MIL is a lamp with a check mark (✓) on the colored lens.

Malfunction Indicator Lamp

The Engine System Monitor Panel provided in the factory instrumentation package is equipped with a Malfunction Indicator Lamp (MIL). The MIL is a lamp with a check mark (✓) on the colored lens.

- It informs the operator and service technician that a problem has occurred and that the vessel is in need of service as soon as reasonably possible.
- It displays Codes stored by the ECM which help the technician diagnose system problems.

As a bulb and system check, the lamp will come ON with the key on and the engine not operating. When the engine is started, the light will turn OFF. If the lamp remains ON, the self-diagnostic system has detected a problem. If the problem goes away, the light will go out in most cases after ten seconds, but a code will remain stored in the ECM.

When the lamp remains ON while the engine is operating, or when a malfunction is suspected due to a driveability problem, an EDI Diagnostic Circuit Check must be performed. These checks will expose malfunctions which may not be detected if other diagnostics are performed prematurely.

The ECM has been programmed to illuminate the MIL during or due to the errors associated with the following devices:

- Engine Coolant Temperature (ECT) sensor
- Intake Air Temperature (IAT) sensor
- Manifold Absolute Pressure (MAP) sensor
- Throttle Position (TP) sensor and Low Idle Switch (LGS) sensor
- Instrumented Injector (NBF)
- Timing Advance Actuator
- Timing Solenoid Valve
- Fuel Shut Off Valve
- Battery + (12 Volts)
- Fuel Quantity Actuator
- Fuel Quantity Sensor
- RPM Sensor
- EEPROM in ECM

Intermittent Problems and Malfunction Indicator Lamp


In the case of an intermittent problem, the Malfunction Indicator Lamp will light for ten seconds and then will go out. However, the corresponding code will be stored in the memory of the ECM. When unexpected codes appear during the code reading process, one can assume that these codes were set by an intermittent malfunction and could be helpful in diagnosing the system.

An intermittent code may or may not reset. IF IT IS AN INTERMITTENT FAILURE, A DIAGNOSTIC CODE CHART IS NOT USED. Consult the Diagnostic Aids information on the same topic as the diagnostic code discussion. Troubleshooting The EDI System also covers the topic of Intermittents. A physical inspection of the applicable sub-system most often will resolve the problem.

Reading Codes

The provision for communicating with the ECM is the Data Link Connector (DLC) connector. It is part of the EDI engine wiring harness and is a 4-pin connector, of which only 3 pins are currently being used. The connector is mounted on the Electrical Box and is electrically connected to the ECM. It is used in the assembly plant to receive information that the engine is operating properly before it leaves the plant.

The code(s) stored in the ECM's memory can be read by counting the number of flashes of the light on a Blink Code Tool when connected or by using a scan tool, a diagnostic scanner that plugs into the DLC connector.



75395

DLC Connector

- a** - Electrical Box
- b** - DLC Connector

BLINK CODE TOOL

1. Install diagnostic Blink Code Tool (BCT) connector into the cavity of the DLC connector.
2. Switch the key ON. Keep the key ON for all diagnostic work.
3. Press the button on the BCT for 2.5 - 5.0 seconds.
4. When the button is released the BCT lamp will start to flash an output sequence which begins with a long blink followed by four groups of shorter blinks.
5. If there are no fault codes stored, the code 4 4 4 4 will be blinked out. This will appear as:

- pause for 2.5 seconds
- flash for 2.5 seconds (diagnosis accepted)
- pause for 2.5 seconds
- 4 flashes of 0.5 seconds at 0.5 second intervals (representing the first blink code number)
- pause for 2.5 seconds
- 4 flashes of 0.5 seconds at 0.5 second intervals (representing the second blink code number)
- pause for 2.5 seconds
- 4 flashes of 0.5 seconds at 0.5 second intervals (representing the third blink code number)
- pause for 2.5 seconds
- 4 flashes of 0.5 seconds at 0.5 second intervals (representing the forth blink code number)
- pause for 2.5 seconds
- flash for 2.5 seconds (indicating end of the code)

NOTE: The Malfunction Indicator Lamp (MIL) on the engine monitor panel (dash) should flash the same sequence as the BCT.

6. If a fault code is stored, the code will be blinked out in the same way. Then, the cycle will repeat itself.
7. Press the button on the BCT for 2.5 - 5.0 seconds to blink out the next code.
8. Repeat Step 7, until the code 0 0 0 0 is observed. This appears as a continuous series of long blinks, such as:
 - pause for 2.5 seconds
 - flash for 2.5 seconds
 - pause for 2.5 seconds
 - flash for 2.5 seconds
 - pause for 2.5 seconds
- The sequence will continue until a new request for diagnosis is initiated, by pressing the BCT button for between 2.5 - 5 seconds.

SCAN CODE TOOL

IMPORTANT: If a scan tool is used to read the codes, follow the manufacturer's instructions.

The ECM can communicate a variety of information through the DLC connector. This data is transmitted at a high frequency which requires a scan tool for interpretation.

With an understanding of the data which the tool displays, and knowledge of the circuits involved, the tool can be very useful in obtaining information which would be more difficult or impossible to obtain with other equipment.

Scan tools Do NOT make the use of diagnostic charts unnecessary, nor can they indicate exactly where a problem is in a particular circuit.

The scan tool allows manipulation of wiring harnesses or components with the engine not operating, while observing the scan tool readout.

The scan tool can be plugged in and observed while operating the vessel under the condition when the Malfunction Indicator Lamp illuminates momentarily or when the engine driveability is momentarily poor. If the problem seems to be related to certain parameters that can be checked on the scan tool, they should be checked while operating the vessel. If there does not seem to be any correlation between the problem and any specific circuit, the scan tool can be checked on each position, watching for a period of time to see if there is any change in the readings that indicates intermittent operation.

The scan tool is also an easy way to compare the operating parameters of a poorly operating engine with those of a known good one. For example, a sensor may shift in value but not set a trouble code. Comparing the sensor's readings with those of the EDI / Scan Tool Normal Specifications readings may uncover the problem.

The scan tool has the ability to save time in diagnosis and prevent the replacement of good parts. The key to using the scan tool successfully for diagnosis is the technician's ability to understand the system as well as an understanding of the scan tool operation and limitations. The technician should read the tool manufacturer's operating manual to become familiar with the tool's operation.

Clearing Codes

IMPORTANT: To avoid improper tool functions, Ensure the battery is fully charged.

BLINK CODE TOOL

1. Connect BCT (Blink Code Tool), if not already connected.
2. Make certain the ignition key is in the OFF position.
3. Press the button on the Diagnostic Code Tool, and hold it depressed.
4. Switch the key to ON while continuing to press the Tool button for between 2.5 and 5 seconds.
5. When the button on the Tool is released the 0000 Code should be seen.

NOTE: The 0000 Code is displayed when all Trouble Codes have been read or cleared. The Code 0000 (meaning end of diagnosis is displayed as follows: A pause in the MIL for 2.5 seconds, a flash for 2.5 seconds, pause for 2.5 seconds, flash for 2.5 seconds.) This code sequence will repeat until a new request for diagnosis interrupts the communication between the Tool and the ECM.

6. Press the button for longer than 2.5 seconds to interrupt the diagnostic procedure.
7. Press the button again for longer than 2.5 seconds to start the ECM checking for codes.
8. See that the 4444 Code (meaning no trouble codes present) is displayed.
9. If codes are still present refer to appropriate Troubleshooting and/or Diagnostic information.
10. Each time the Blink Code Tool (BCT) is employed, the following procedure should be used:
 - a. Interrogate the ECM to check for memory errors.
 - b. Cancel memory errors.
 - c. Use the engine at least 10 minutes to ensure that any errors have been re-recorded.
 - d. Re-interrogate the ECM to find out which errors are really present and which of the previous errors were casual.
11. Refer to appropriate Diagnostic Circuit Check or Troubleshooting section.

SCAN TOOL


1. Connect scan tool.
2. Turn Key On.
3. Select clear codes function.
4. Clear codes.
5. Turn key OFF.
6. Turn key ON and read codes. If codes are still present, there is a real system fault. Refer to appropriate Troubleshooting and/or Diagnostic information.

Diagnosis of Driveability Concerns

If a driveability concern still exists after following the diagnostic circuit checks and reviewing Troubleshooting, an out-of-range sensor may be suspected. Because of the unique design of the EDI system, fail-safes have been incorporated into the ECM to replace a sensed value with a default value in the case of a sensor malfunction or sensor wiring concern. By allowing this to occur, limited engine performance is restored until the vessel is repaired. A basic understanding of sensor operation is necessary in order to diagnose an out-of-range sensor.


ECM Input and Sensor Diagram

The following shows the sensors, switches, other inputs and outputs used by the ECM to control its various systems. Although we will not cover them all in great detail, there will be a brief description of each.



ECM Connector Pin Layout

All related wiring attaches to the ECM with one 68 pin wiring harness connector. This connector is represented by the following diagram. The numbered squares represent a pin and its relative location in the cavity of the ECM. Those numbered squares which appear *shaded* represent pins not utilized in the Marine application. The *white* squares indicate pins that are currently used and have corresponding wires connected when the harness is attached to the ECM. Refer to Connector Chart for additional information.



- a** - ECM Wiring Harness Connector
- b** - Number And Location Of Individual Pin (68 Total)

Connector Chart

The following chart will aid in identification and diagnosis of wiring circuits that are attached to the ECM through the 68 pin connector.

⚠ CAUTION

AVOID loss of engine operation or wiring damage. Serious electrical damage could result from improper probing of wires and connectors. Do NOT damage wires, connectors or electrical system.

NOTE: Clear each code after disconnecting and reconnecting each sensor. Failure to do so may result in an incorrect diagnosis of the problem.

ECM Pin	Circuit Designation	Wire Color Abbreviation	Diagnostic Trouble Codes ScanTool
1	Battery Minus	BLK	P1600
2	Engine Speed sensor signal output	BRN/BLK	P1735
3	Glowplug Indicator Lamp	BLK/YEL	P1645
4	Fuel Quantity Actuator	GRN/WHT (twisted pair)	P1220
5	Fuel Quantity Actuator	GRN/WHT (twisted pair)	P1220
6	Unused	-	-
7	Fuel Quantity Control Sleeve Position Sensor (Middle Tap)	ORN	P1225
8	Engine Speed Sensor Signal (shield wire)	WHT	P0725
9	Unused	-	-
10	Unused	-	-
11	Instrumented Injector Ground	BRN	P1201
12	Instrumented Injector Signal	WHT	P1725
13	Unused	-	-
14	Engine Coolant Temperature (ECT) Sensor	WHT/BRN	P0115
15	Throttle Position Sensor (signal)	ORN/WHT	P1515
16	Unused	-	-
17	Unused	-	-

Connector Chart (continued)

ECM Pin	Circuit Designation	Wire Color Abbreviation	Diagnostic Trouble Codes DTC(s) ScanTool
18	Unused	-	-
19	Unused	-	-
20	Unused	-	-
21	Engine Speed Sensor (Digital)	BRN/RED	P0725
22	Unused	-	-
23	Battery Feed	RED	P1600
24	Battery Minus	BLK	P1600
25	Unused	-	-
26	Malfunction Indicator Lamp (MIL)	BRN/WHT	P1650
27	Unused	-	-
28	Unused	-	-
29	Control Sleeve Position Sensor	GRN	P1225
30	Unused	-	-
31	Unused	-	-
32	Unused	-	-
33	Analog Ground (ECT / Injection Pump)	BRN/PUR	P0115
34	Unused	-	-
35	Unused	-	-
36	Unused	-	-
37 ¹	Idle rpm Increase Signal	RED/ORN	-
38	Switched battery (15 - Ignition)	PNK	P1605
39	Unused	-	-
40	MAP Sensor Signal	WHT/YEL	P0105
41	5 Volt Output	GRN	
42	Main Relay	WHT/RED	P1625
43	Unused	-	-


¹: Unused on early model engines with 11 Pin ECM harness connector at electrical box.

Connector Chart (continued)

ECM Pin	Circuit Designation	Wire Color Abbreviation	Diagnostic Trouble Codes DTC(s) ScanTool
44	Unused	-	-
45	Battery Feed	RED	P1600
46	Battery Minus	BLK	P1600
47	Unused	-	-
48	Unused	-	-
49	Fuel Quantity Actuator	GRN/WHT	P1220
50	Glow Plug Relay (control side)	BLU/BLK	P1635
51	Solenoid Valve for Timing	BLU	P1630
52	Fuel Quantity Sensor (Measure Coil)	BLU/YEL	P1225
53	Electric Shut Off Device	YEL	P1660
54	Unused	-	-
55	a. Throttle Position Sensor Ground	a. BLU/WHT	a. P1515
	b. MAP / IAT Sensor Ground	b. BLU/WHT	b. P1110
56	Unused	-	-
57	TP Sensor - 5 Volt	PNK/YEL	P1515
58	Unused	-	-
59	Unused	-	-
60	Unused	-	-
61	K-Line	GRN/RED	
62	Unused	-	-
63	Fuel Temperature Sender	BLU/RED	P0180
64	Air Intake temperature Sensor Signal	GRN/BLK	P1110
65	Low Idle Position Switch	BRN/RED	P1515
66	Unused	-	-
67	Unused	-	-
68	Battery Feed	RED	P1600

MAP (Manifold Air Pressure) Sensor

Scan Code:	P0105
Blink Code:	2222
Malfunction Indicator Lamp:	ON



- a** - MAP / IAT Sensor Assembly
- b** - IAT Signal
- c** - 5 Volt Reference Signal
- d** - MAP Signal
- e** - Sensor Ground
- f** - To Throttle Position Sensor

CIRCUIT DESCRIPTION:

The MAP (Manifold Air Pressure) sensor and IAT (Intake Air Temperature) sensor form an assembly. The MAP sensor portion of this assembly is a pressure transducer that measures the changes in the intake manifold pressure. The pressure changes as a result of engine load and speed change, and the MAP sensor converts this to a voltage output signal from the assembly.

NOTE: Sometimes this component may be referred to as a boost pressure sensor due to the presence of a turbocharger.

The ECM sends a 5 volt reference signal to the MAP sensor. As the manifold pressure changes, the electrical resistance of the MAP sensor also changes. By monitoring the sensor output voltage, the ECM knows the manifold pressure. A higher pressure, low vacuum (high voltage) requires more fuel, while a lower pressure, higher vacuum (low voltage) requires less fuel. The ECM uses the MAP sensor to control fuel delivery and injection timing.

A failure in the MAP sensor circuit should set a Scan Code P0105.

CKT PIN	NAME
40	MAP Signal
41	5 Volt Reference Signal
55	Sensor Ground (-)

TEST DESCRIPTION:

Verify continuity between the following pins:

ECM 68 PIN CONNECTOR	4 TERMINAL CONNECTOR AT ECT
40	4
41	3
55	1

DIAGNOSTIC HELP:

Verify the following:

- Open or short in the CKT Pin 40, CKT Pin 41 or CKT Pin 55 will cause low amount of smoke.
- Assembly loose on manifold or a damaged O-ring seal, causing improper signal. Will cause high amount of smoke.
- Bent terminal or pin at the MAP connection or ECM.
- Defective MAP or ECM.

MAP failure influences engine performance as follows:


- FUEL QUANTITY ACTUATION: Maximum engine rpm is 70% of the normal operating range (45% of fuel quantity reduction).

NOTE: Failure of the MAP and IAT sensor at the same time will limit engine performance to 60% maximum of the normal operating range (50% fuel quantity reduction).

IMPORTANT: Replace the O-ring seal whenever removing the MAP/IAT sensor. Torque the sensor to specification when replacing.

ECT (Engine Coolant Temperature) Sensor

Scan Code:	P0115
Blink Code:	1113
Malfunction Indicator Lamp:	ON



75341

- a** - ECT Sensor
- b** - ECT Connector
- c** - ECT Signal
- d** - 5 Volt Reference Signal
- e** - Sensor Ground
- f** - To Injection Pump

CIRCUIT DESCRIPTION:

The ECT (Engine Coolant Temperature) Sensor is a thermistor (a resistor which changes value based on temperature) immersed in the engine coolant stream. Low coolant temperature produces a high resistance, while high temperature causes low resistance.

The ECM supplies a 5 volt signal to the ECT through a resistor in the ECM and measures the voltage. The voltage will be high when the engine is cold, and low when the engine is hot. By measuring the voltage, the ECM knows the engine coolant temperature. Engine coolant temperature affects most systems the ECM controls. The voltage received at the ECM will determine operation of the fuel timing solenoid and glow plug relays.

A failure in the ECT circuit should set Scan Code P0115. Remember, this code indicates a failure in the coolant temperature sensor circuit, so proper use of the test description information will lead to either repairing a wiring problem or replacing the sensor.

CKT PIN	NAME
14	Engine Coolant Temperature Sensor Signal
33	Sensor Ground (-)

TEST DESCRIPTION:

Verify continuity between the following pins:

ECM 68 PIN CONNECTOR	2 TERMINAL CONNECTOR AT ECT
14	1
33	2

Verify the sensor resistance between the two ECT sensor terminals as a function of temperatures:

NOTE: Stabilization time before each measurement should be at least 10 minutes in water.

TEMPERATURE °C (°F)	RESISTANCE (kOhm)	MAXIMUM MEASURE- MENT Current (mA)
-30 (-22)	22.2 - 31.8	0.2
-10 (13)	8.29 - 10.61	0.4
20 (67)	2.28 - 2.72	1.0
50 (122)	0.751 - 0.901	1.5
80 (175)	0.291 - 0.353	2.0
120 (247)	0.104 - 0.120	3.0

DIAGNOSTIC HELP:

Verify the following:

- Open or short in the CKT Pin 14 or CKT Pin 33.
- Bent terminal or pin at the ECT or ECM.
- Defective ECT or ECM.


ECT failure influences engine performance as follows:

- FUEL QUANTITY ACTUATION: Maximum engine rpm is 80% of the normal operating range (35% of fuel quantity reduction).
- LOW IDLE SETPOINT VALUE: The engine operates at 850 rpm for the first 300 seconds after engine start up and then goes to 700 rpm (normal idle).
- TIMING ADVANCE: The system adds 3 to 4 degrees of timing throughout the engine operating range (engine is noisier).
- GLOW PLUG LAMP: Even if the engine is not equipped with glow plugs, the glow plug lamp flashes at each start up for 12 seconds.

IMPORTANT: Torque the ECT sensor to specification when replacing.

Fuel Temperature Sensor

Scan Code:	P0180
Blink Code:	3333
Malfunction Indicator Lamp:	OFF



75565

75409

- a - Fuel Temperature Sensor (Inside Fuel Injection Pump)
- b - 5 Volt Reference Signal
- c - Fuel Temperature Sensor Signal
- d - Sensor Ground

CIRCUIT DESCRIPTION:

The Fuel Temperature Sensor is a thermistor (a resistor which changes value based on temperature). Low temperature produces a high resistance, while high temperature causes a low resistance.

The ECM supplies a 5 volt signal to the sensor through a resistor in the ECM and measures the voltage. The ECM voltage will be high when the fuel temperature is cold, and low when the fuel temperature is hot.

A failure in the Fuel Temperature Sensor circuit should set a Scan Code P0180.

CKT PIN	NAME
33	Sensor Ground (Analog -)
63	Fuel Temperature Sensor Signal

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	7 TERMINAL CONNECTOR AT FUEL INJECTION PUMP
33	5
63	6

Verify the sensor resistance between terminals 5 and 6 of the injection pump connector as a function of temperatures:

TEMPERATURE °C° (F)	RESISTANCE (kOhm)
-10 (13)	8.29 - 10.61
20 (67)	2.28 - 2.72
50 (122)	0.751 - 0.901
80 (175)	0.291 - 0.353

DIAGNOSTIC HELP:

Verify the following:


- Open or short in the CKT Pin 33 or CKT Pin 63.
- Bent terminal or pin at the fuel pump connector or ECM.
- Defective fuel injection pump (temperature sensor circuit) or ECM.

Fuel Temperature Sensor failure influences engine performance as follows:

- FUEL QUANTITY ACTUATION: No fuel quantity correction can occur as a function of fuel temperature. When sensor is functioning the engine has the same performance for all fuel temperatures. With this sensor failure the engine has better performance with a cold fuel condition than when the fuel is warm.
- Unless there is a complaint about performance, it is not necessary to change the injection pump for this failure.

RPM (Engine Speed) Sensor

Scan Code:	P0725
Blink Code:	1131
Malfunction Indicator Lamp:	ON



75311

- a** - RPM (Engine Speed) Sensor
- b** - Harness Connector
- c** - Sensor ECM Input Signal
- d** - Sensor Ground (–)
- e** - Symbol for Shield Cable

CIRCUIT DESCRIPTION:

The rpm (Engine Speed) Sensor is an induction-type pulse generator which mounts close the leading edge of the flywheel. Four notches (drilling) serve to sense the engine speed. The resulting change in magnetic flux induces an AC voltage signal which is evaluated by the ECM. The ECM processes the signal to establish TDC and the crankshaft position relative to TDC.

A failure in the rpm sensor circuit should set a Scan Code P0725.

CKT PIN	NAME
8	ECM Input Signal from rpm (Engine Speed) Sensor
21	Sensor Ground, (Digital –)

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	3 TERMINAL CONNECTOR
8	2
21	1 and 3 (3 is shield wire)
21	3 (shield wire)

Verify the resistance between terminals 1 and 2 of the sensor:

RESISTANCE (Ohm)	MAXIMUM MEASUREMENT
1000	1000 ohm

DIAGNOSTIC HELP:

Verify the following:


- Open or short in the CKT Pin 8 or CKT Pin 21.
- Bent pin at the 3 terminal connector or ECM.
- Sensor mounting is improper.
- Defective rpm sensor or ECM.

RPM Sensor failure influences engine performance as follows:

- The engine will not start If the engine speed sensor fails during starting procedures. The MIL (Malfunction Indicator Lamp) IS NOT illuminated.
- The engine immediately shuts OFF if the engine speed sensor fails with the engine operating. The MIL IS illuminated.

BARO (Atmospheric Pressure) Sensor

Scan Code:	P1105
Blink Code:	1121
Malfunction Indicator Lamp:	OFF



75336

a - ECM

b - BARO (Atmospheric Pressure) Sensor

CIRCUIT DESCRIPTION:

The BARO (Atmospheric Pressure) Sensor is inside the ECM. It is not serviceable or replaceable individually. The complete ECM must be replaced to repair a faulty BARO sensor.

A failure in the BARO sensor circuit should set a Code P1105.

CKT PIN	NAME
Not Applicable	BARO (Atmospheric Pressure) Sensor

TEST DESCRIPTION

Verify failure using either the Blink Code Tool and/or Scan Tool. There are no individual circuits to be tested. All BARO sensor circuits are inside the ECM and are not serviceable.


DIAGNOSTIC HELP:

BARO Sensor failure influences engine performance as follows:

- The engine behavior does not change noticeably when the engine is operated at or near sea level. It is acceptable to operate the engine with this failure, unless there is a complaint.
- If the engine is most frequently operated at high altitude [elevation higher than 4900 ft (1500 m)] it is suggested that the ECM be replaced.

IAT (Intake Air Temperature) Sensor

Scan Code:	P1110
Blink Code:	1112
Malfunction Indicator Lamp:	ON



- a** - IAT / MAP Sensor Assembly
- b** - IAT Signal
- c** - 5 Volt Reference Signal
- d** - MAP Signal
- e** - Sensor Ground
- f** - To Throttle Position Sensor

CIRCUIT DESCRIPTION:

The IAT sensor and MAP (Manifold Absolute Pressure) sensor form an assembly. The IAT portion of the assembly is a thermistor (a resistor which changes value based on temperature). Low temperature produces a high resistance, while high temperature causes a low resistance.

The ECM supplies a 5 volt signal to the sensor through a resistor in the ECM and measures the voltage. The ECM voltage will be high when the intake air is cold, and low when the intake manifold air is hot.

A failure in the IAT sensor circuit should set a Scan Code P1110.

CKT PIN	NAME
55	Sensor Ground
64	IAT Signal

TEST DESCRIPTION:

Verify continuity between the following pins:

ECM 68 PIN CONNECTOR	4 TERMINAL CONNECTOR AT MAP
55	1
64	2

Verify the sensor resistance between the two IAT sensor terminals as a function of temperature:

NOTE: Stabilization time before each measurement should be at least 10 minutes in test medium.

TEMPERATURE °F (°C)	MINIMUM RESIS- TANCE (kOhm)	TYPICAL RESIS- TANCE (kOhm)	MAXIMUM RESIS- TANCE (kOhm)
-40 (-40) ± 1	39.18	48.55	57.92
-30 (-23) ± 1	22.22	27.00	31.78
-20 (-5) ± 1	13.24	15.67	18.10
-10 (14) ± 1	8.160	9.45	10.74
0 (32) ± 1	5.180	5.89	6.60
10 (50) ± 1	3.390	3.79	4.190
20 (67) ± 1	2.270	2.500	2.730
30 (85) ± 1	1.528	1.692	1.856
40 (104) ± 1	1.059	1.170	1.281
50 (122) ± 1	0.748	0.826	0.904
60 (140) ± 1	0.538	0.594	0.650
80 (175) ± 1	0.2902	0.3224	0.3546
100 (212) ± 1	0.1641	0.1852	0.2063
120 (247) ± 1	0.0970	0.1116	0.1262

DIAGNOSTIC HELP:

Verify the following:

- Open or short in the CKT Pin 55 or CKT Pin 64.
- Bent pin at the ECT or ECM.
- Defective ECT or ECM.

IAT failure influences engine performance as follows:


- FUEL QUANTITY ACTUATION: Maximum engine rpm is 90% of the normal operating range (15% of fuel quantity reduction).

NOTE: Failure of the IAT and MAP sensor at the same time will limit engine performance to 60% maximum of the normal operating range (50% fuel quantity reduction).

IMPORTANT: Replace the O-ring seal whenever removing the IAT/MAP sensor. Torque the sensor to specification when replacing.

Instrumented Injector (Needle Movement Sensor)

Scan Code:	P1201
Blink Code:	1132
Malfunction Indicator Lamp:	ON



75339

- a** - Instrumented Injector (Needle Movement Sensor)
- b** - Harness Connector
- c** - Sensor ECM Signal
- d** - Sensor Ground (-)
- e** - Symbol for Shield Cable

CIRCUIT DESCRIPTION:

The injector timing reference is supplied to the ECM by way of the Instrumented Injector (Needle Movement Sensor, or referred to sometimes as NBF) installed in the Number 1 Cylinder injector. This position variable type input device creates the timing signal for the ECM. This signal is used for a number of control and testing functions within the ECM.

A failure in the Instrumented Injector circuit should set Scan Code P1201. Display of this code indicates a failure in the sensor circuit, so proper diagnosis will lead to either repairing a wiring problem or replacing the sensor.

CKT PIN	NAME
11	Sensor Ground (-)
12	Instrumented Injector Sensor Signal

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	2 TERMINAL CONNECTOR
11	2 (is shield wire, also)
12	1

Verify the sensor resistance between terminals 1 and 2 of the sensor:

RESISTANCE (Ohm)	MINIMUM / MAXIMUM MEASUREMENT
100	90 - 110

DIAGNOSTIC HELP:

Verify the following:

- Open or short in the CKT Pin 11 or CKT Pin 12.
- Defective sensor.
- Defective ECM.


Instrumented Injector failure influences engine performance as follows:

- FUEL QUANTITY ACTUATION: Maximum engine rpm is 80% of the normal operating range (35% of fuel quantity reduction).
- LOW IDLE SETPOINT VALUE: The engine operates at 850 rpm for the first 72 seconds after engine start up and then goes to 700 rpm (normal idle).
- TIMING ADVANCE: Timing actuation is in open loop which means the engine may be slightly noisier.

IMPORTANT: Torque the Instrumented Injector to specification when replacing.

Fuel Quantity Actuator (Pump Actuator)

Scan Code:	P1220
Blink Code:	1223
Malfunction Indicator Lamp:	ON



- a - Fuel Quantity Actuator (Inside Injection Pump)
- b - Harness Connector
- c - Battery Supply Voltage To Sensor From ECM
- d - Sensor Ground (-)
- e - Twisted Wire Pair

CIRCUIT DESCRIPTION:

Inside the electronic diesel pump the Fuel Quantity Actuator (a rotary solenoid actuator) for injected fuel quantity control engages with the control collar through a shaft. Similar to the mechanically governed fuel injection pump, the cutoff ports are opened or closed depending upon the control collar’s position. The injected fuel quantity can be infinitely varied between zero and maximum (e.g., for cold starting). When no voltage is applied to the actuator, its return springs reduce the injection quantity to zero.

A failure of the Fuel Quantity Actuator circuit should set a Scan Code P1220.

CKT PIN	NAME
4	Fuel Quantity Actuator (1 of 3 total, one of a twisted pair)
5	Fuel Quantity Actuator (2 of 3 total, second of a twisted pair)
49	Fuel Quantity Actuator (3 of 3 total)
23	Battery Supply Voltage (1 of 3)
45	Battery Supply Voltage (2 of 3)
68	Battery Supply Voltage (3 of 3)

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	7 TERMINAL CONNECTOR
4 / 5 / 49	4
23 / 45 / 68	7

Verify the actuators resistance between terminals 4 and 7 of the injection pump connector:

RESISTANCE (Ohm)	MINIMUM / MAXIMUM MEASUREMENT
1	± 0.3

Verify supply voltage to injection pump with the 7 terminal connector unplugged and key ON. Measure between terminals 5 and 7 of the harness side connector:

CURRENT (VOLTS)	MINIMUM / MAXIMUM MEASUREMENT
12	Battery Voltage

DIAGNOSTIC HELP:

Verify the following:


- Open or short in the CKT Pins 4 / 5 / 49, or CKT Pins 23 / 45 / 68.
- Improper terminals or pins at the 7 terminal connector or ECM.
- Defective fuel injection pump.
- Defective ECM.

Failure of the Fuel Quantity Actuator influences engine performance as follows:

- If the Fuel Quantity Actuator fails with the engine operating, the engine immediately shuts off. If it failed at start up, the engine does not start. In both cases the MIL is illuminated.

Fuel Quantity Sensor (Control Sleeve Position Sensor)

Scan Code:	P1225
Blink Code:	1222
Malfunction Indicator Lamp:	ON



75565

- a** - Fuel Quantity Sensor (Control Sleeve Position Sensor)
- b** - Fuel Quantity Sensor Connector
- c** - Control Sleeve Position Sensor
- d** - Fuel Quantity Sensor (Measure Coil)
- e** - Control Sleeve Position Sensor Signal
- f** - Analog Ground (–)

CIRCUIT DESCRIPTION:

Inside the electronic diesel pump the Fuel Quantity Actuator (a rotary solenoid actuator for controlling injected fuel quantity) engages with the control collar through a shaft. Similar to the mechanically governed fuel injection pump, the cutoff ports are opened or closed depending upon the control collar's position. The injected fuel quantity can be infinitely varied between zero and maximum (e.g., for cold starting). Using this Fuel Quantity Sensor (an angle sensor or potentiometer) the fuel quantity actuator's angle of rotation, and thus the position of the control collar, are reported back to the ECU. This information is used by the ECM to determine the injected fuel quantity as a function of engine speed.

A failure of the Fuel Quantity Sensor circuit should set a Scan Code P1225.

CKT PIN	NAME
7	Control Sleeve Position Sensor (Middle Tap)
33	Analog Ground (–)
29	Control Sleeve Position Sensor
52	Fuel Quantity Sensor Input to ECM (Measure Coil)

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	7 TERMINAL CONNECTOR
29	1
52	2
7	3
33	5

Verify the actuators resistance between terminals 1 and 2 of the injection pump connector:

RESISTANCE (Ohm)	MINIMUM / MAXIMUM MEASUREMENT
11.3	± 0.3

Verify supply voltage to injection pump with the 7 terminal connector unplugged and key ON. Measure between terminals 3 and 5 of the harness side connector:

CURRENT (VOLTS)	MINIMUM / MAXIMUM MEASUREMENT
5	± 0.0

DIAGNOSTIC HELP:

Verify the following:


- Open or short in the CKT Pin 5, CKT Pin 7 or CKT Pin 52.
- Improper terminals or pins at the 7 terminal connector or ECM.
- Defective fuel injection pump.
- Defective ECM.

Failure of the Fuel Quantity Sensor influences engine performance as follows:

- If the Fuel Quantity Sensor fails with the engine operating, the engine immediately shuts off. If it failed at start up, the engine does not start. In both cases the MIL is illuminated.

Timing Fault (Timing Advance Regulation)

Scan Code:	P1230
Blink Code:	1321
Malfunction Indicator Lamp:	OFF



75409

- a - Fuel Injection Pump
- b - Timing Solenoid Valve
- c - Harness Connector
- d - Sensor Ground (-)
- e - Battery Supply Voltage (1 of 3)

CIRCUIT DESCRIPTION:

Determining the proper fuel injection point (timing) depends on the quantity of fuel, engine rpm and coolant temperature. The ECM controls the timing using the signal from the number one instrumented injector and corrects the timing to the nominal timing rate. Adjustment of pressure is carried out by an electric Timing Solenoid Valve which the ECM operates. When the actuated timing advance (timing governing) is different from the setpoint (ECM stored information) advance by more or less than 5°, this error will be set.

A failure in the Timing Fault circuit should set a Scan Code P1230.

CKT PIN	NAME
51	Solenoid
68	Battery Supply Voltage
45	Battery Supply Voltage
23	Battery Supply Voltage

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	2 TERMINAL CONNECTOR
23 / 45 / 68	1
51	2

Verify the solenoid valves resistance between terminals 1 and 2 of the connector:

RESISTANCE (Ohm)	MINIMUM / MAXIMUM MEASUREMENT
15	± 0.0

Verify supply voltage to solenoid valve terminal connector with the connector unplugged and key ON. Measure between terminal1 and engine ground (–):

CURRENT (VOLTS)	MINIMUM / MAXIMUM MEASUREMENT
12	Battery Voltage

DIAGNOSTIC HELP:

Verify the following:


- Open or short in the CKT Pins 23 / 45 / 68 or CKT Pin 51.
- Improper terminals or pins at the 2 terminal connector or ECM.
- Defective fuel injection pump.
- Defective ECM.

Failure of the timing governing solenoid valve influences engine performance as follows:

- FUEL QUANTITY ACTUATION: Maximum engine rpm is 80% of the normal operating range (35% of fuel quantity reduction).
- The engine becomes noisy.

TP (Throttle Position) Sensor / Low Idle Switch

Scan Code:	P1515
Blink Code:	1144
Malfunction Indicator Lamp:	ON



75565

- a - TP Sensor
- b - Harness Connector
- c - TP Sensor Signal
- d - 5 Volt Reference Signal
- e - Sensor Ground (–)
- f - Battery Supply Voltage
- g - To MAP/IAT Sensor

CIRCUIT DESCRIPTION:

The TP (Throttle Position) sensor translates throttle position into a voltage signal. The TP sensor is basically a linear potentiometer. The ECM supplies 5 volts to the sensor and processes a returning voltage signal for operation of the fuel timing solenoid valve. The TP output voltage will vary through the range from idle to WOT. Also at closed throttle the Low Idle Switch (sometimes referred to as LGS) is activated. This confirms to the ECM that the TP is at the closed throttle position. As the throttle position changes the output increases, so that at WOT, the output voltage should be near 4.5 volts. By monitoring the output voltage from the TP sensor, the ECM can determine fuel delivery based on the throttle position (operator demand).

If the TP circuit is open, the ECM will set a Scan Code P1515. If the TP circuit is shorted, the ECM will think the vessel is at WOT, and this code will be set. A problem in any of the TP circuits (e. g. Low Idle Switch) will set this same code. Once this trouble code is set, the ECM will use a default value for TP signal.

CKT PIN	NAME
15	TP Sensor Signal
57	5 Volt Reference Signal
55	Sensor Ground (–)
65	Low Idle Switch (LGS)
1	ECM / Battery Ground (–)

TEST DESCRIPTION

NOTE: Constant voltage may be observed at the very first part and the very last part of the TP's rotation.

Verify continuity between the following:

ECM 68 PIN CONNECTOR	7 TERMINAL CONNECTOR
15	1
57	2
55	4
65	5
1	6

Verify supply voltage to TP sensor with the 7 terminal connector unplugged and key ON. Measure between terminals 2 and 4 of the harness side connector:

CURRENT (VOLTS)	MINIMUM / MAXIMUM MEASUREMENT
5	

Verify the TP sensor potentiometer current flow between terminals 4 and 5 of the sensor with the 7 terminal connector plugged in and key ON:

CURRENT (VOLTS)	MINIMUM / MAXIMUM MEASUREMENT
5	

With the key OFF and the 7 terminal connector unplugged, verify the TP sensor potentiometer resistance between terminals 1 and 4 of the sensor connector:

CONDITION	RESISTANCE (Ohm)	MINIMUM / MAXIMUM MEASUREMENT
TP at Idle Position	1050	± 100
TP at WOT Position	1650	± 100

DIAGNOSTIC HELP:

Verify the following:



- Open or short in the CKT Pin 2, CKT Pin 5 or CKT Pins 1.
- Improper terminals or pins at the 7 terminal connector or ECM.
- Defective TP sensor.
- Defective ECM.

Failure of the TP sensor influences engine performance as follows:

- Any failure of the TP sensor or circuits (e. g. plausibility between TP sensor and low idle switch, TP out of operating range, LGS defective, TP voltage supply defective) will cause the engine to operate at 800 rpm *maximum*.

Battery Voltage

Scan Code:	P1600
Blink Code:	1233
Malfunction Indicator Lamp:	OFF



72965

CIRCUIT DESCRIPTION:

If battery voltage drops below 9 volts the Instrumented Injector (needle movement sensor) stops working. If the battery voltage drops below 6 - 9 volts the fuel quantity actuator begins to work improperly. The ECM stops working when the battery voltage drops below 6 volts. However, the diagnostic system will not recognize a low voltage problem. The only error recognized by the ECM is if the battery voltage is too high (above 20 volts).


DIAGNOSTIC HELP:

Verify the following:

- Alternator drive belt or belt tension improper.
- Open in the battery supply (+) or ground (-) circuits.
- Defective alternator.

Battery (Switched K15)

Scan Code:	P1605
Blink Code:	1232
Malfunction Indicator Lamp:	ON/OFF



75343

CIRCUIT DESCRIPTION:

Battery voltage is supplied to the ECM through several circuits. The ignition switch terminal 15 (sometimes called K15) is energized when the key is switched to the ON / RUN position. However, the ignition switch is not monitored by the ECM. Instead, evaluation of the unverified terminal 15 is carried out by the ECM. If the ECM detects 0 volt at CKT Pin 38 it sets the trouble code.

DIAGNOSTIC HELP:

Verify the following:


- Open in CKT Pin 38 from ignition switch.
- Improper terminals or pins at the electrical box terminal connectors or ECM.
- Defective ignition switch.
- Internal ECM system failure. Defective ECM.

Recognition by the ECM of a defective battery switched terminal 15 influences engine performance as follows:

- No loss of power.

Microcontroller Fault

Scan Code:	P1615
Blink Code:	1311
Malfunction Indicator Lamp:	OFF



75343

CIRCUIT DESCRIPTION:

As part of self-diagnosis the ECM is capable of determining if failures have occurred to circuits within the ECM. If defects exists the ECM sets this code.

DIAGNOSTIC HELP:

Verify the following:


- Replace the ECM.

Recognition by the ECM of Microprocessor Fault influences engine performance as follows:

- No loss of power.

ECM Reference Voltage (u_ref - 2.5v)

Scan Code:	P161A
Blink Code:	1234
Malfunction Indicator Lamp:	OFF



75343

CIRCUIT DESCRIPTION:

As part of self-diagnosis the ECM is capable of determining if failures have occurred to the reference voltage circuits within the ECM. If defects exists the ECM sets a Scan Code 161A.

DIAGNOSTIC HELP:

Verify the following:


- Replace the ECM.

Recognition by the ECM of a Reference Voltage fault influences engine performance as follows:

- No loss of power.

Main Relay

Scan Code:	P1625
Blink Code:	1231
Malfunction Indicator Lamp:	OFF



75342

- a** - Electrical box
- b** - Battery 12 Volt To Circuit Breaker
- c** - Circuit Breaker
- d** - Main Relay
- e** - 11 Terminal ECM Harness Connector on Electrical Box
- f** - 11 Terminal Connector
- g** - Ground (–) CKT Pin 42 for Relay
- h** - 12 Volt Power Supply to ECM

CIRCUIT DESCRIPTION:

The Main Relay test monitors whether the power supply was shut off too early or too late and the condition of the Fuel Shut Off Valve function.

If a signal change from Battery (Switched K15) occurs and the main relay was shut off before the ECM had given the shut off command (After-Run not completely finished), then there has been a control unit defect. Over the defect validity check. The defect "main relay switched-off too early" is reported during the next control unit initialization.

If a signal change from Battery (Switched K15) occurs and the functions for after-run test has ended with a complete error storage then the main relay is shut off and monitored for a specified length of time. If the main relay is shut off before the programmed time elapses then the main relay is functioning correctly. If not, then the defect "main relay turned off too late" is reported after the ECM does a defect validity check. This test may only be carried out if no system error exists.

DIAGNOSTIC HELP:

Verify the following:

- Replace the ECM.


Recognition by the ECM of a Main Relay fault influences engine performance as follows:

- No loss of power.

THIS PAGE IS INTENTIONALLY BLANK

Timing Actuator (Timing Solenoid Valve)

Scan Code:	P1630
Blink Code:	1214
Malfunction Indicator Lamp:	OFF



75409

- a - Fuel Injection Pump
- b - Timing Solenoid Valve
- c - Harness Connector
- d - Sensor Ground (-)
- e - Battery Supply Voltage (1 of 3)

CIRCUIT DESCRIPTION:

Determining the proper fuel injection point (timing) depends on the quantity of fuel, engine rpm and coolant temperature. The ECM controls the timing using the signal from the number one instrumented injector and corrects the timing to the nominal timing rate. Timing is changed by modulating (adjusting) the pressure in the upper (high pressure) chamber to injector opening pressure at the correct instant (timing). Adjustment of pressure is carried out by an electric Timing Solenoid Valve which the ECM operates. The solenoid valve is *closed* if power (12 volts) is removed. With the valve fully closed (no voltage - pressure increases) start of injection is advanced. With the solenoid valve permanently opened (voltage present - pressure reduction) start of injection is retarded. In the intermediate range, the on/off ratio (the ratio of solenoid valve open to solenoid valve closed - sometimes referred to as duty cycle) can be infinitely varied by the ECM. Excess pressure is discharged into the lower chamber.

A failure in the Timing Fault circuit should set a Scan Code P1630.

CKT PIN	NAME
51	Solenoid
68	Battery Supply Voltage
45	Battery Supply Voltage
23	Battery Supply Voltage

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	2 TERMINAL CONNECTOR
23 / 45 / 68	1
51	2

Verify the solenoid valves resistance between terminals 1 and 2 of the connector:

RESISTANCE (Ohm)	MINIMUM / MAXIMUM MEASUREMENT
15	± 0.0

Verify supply voltage to solenoid valve terminal connector with the connector unplugged and key ON. Measure between terminal1 and engine ground (–):

CURRENT (VOLTS)	MINIMUM / MAXIMUM MEASUREMENT
12	Battery Voltage

DIAGNOSTIC HELP:

Verify the following:


- Open or short in the CKT Pins 23 / 45 / 68 or CKT Pin 51.
- Improper terminals or pins at the 2 terminal connector or ECM.
- Defective fuel injection pump.
- Defective ECM.

Failure of the timing governing solenoid valve influences engine performance as follows:

- FUEL QUANTITY ACTUATION: Maximum engine rpm is 80% of the normal operating range (35% of fuel quantity reduction).
- The engine becomes noisy.

Glow Plug Main Relay (Glow Plug Relay Actuator), If Equipped

Scan Code:	1635
Blink Code:	No recognition by ECM.
Malfunction Indicator Lamp:	OFF



75476

- a** - Engine Main Relay
- b** - Circuit Breakers
- c** - Glow Plug Main Relay
- d** - Glow Plug Auxiliary Relay
- e** - Engine Harness Connector
- f** - To Glow Plugs

CIRCUIT DESCRIPTION:

The Glow Plug Main Relay (or Actuator) and the Glow Plug Auxiliary Relay are inside the electrical box of the engine. The ECM determines if, when and for how long a period the glow plug relays should be activated based on coolant temperature information from the ECT. This processing by the ECM is done before, during and after the engine is started. It is the relay that controls the large amount of amperes needed by the glow plugs. Concurrent with supplying power to half of the engines glow plugs this relay actuates the Glow Plug Auxiliary Relay which handles current to the remaining glow plugs.

A failure in the Glow Plug Main Relay circuit should set a Scan Code P1635.

CKT PIN	NAME
50	ECM controlled Glow Plug Relay Ground (–)
3	ECM controlled Ground (–) for dash panel Glow Plug Lamp

TEST DESCRIPTION

NOTE: The relay terminal numbers can be found on the bottom of the relay.

Verify continuity between the following:

ECM 68 PIN CONNECTOR	GLOW PLUG RELAY CONNECTOR / TERMINAL NUMBER
50	85

Verify continuity between the following:

ECM 68 PIN CONNECTOR	INSTRUMENT PANEL TERMINAL
3	BLK/YEL Wire at glow plug indicator lamp on the Engine Monitor Panel

Verify supply voltage from circuit breakers to relays with relay connector unplugged and key ON. Measure:

CURRENT (VOLTS)	GLOW PLUG RELAY CONNECTOR NUMBER
12	30
12	86

DIAGNOSTIC HELP:

Verify the following:


- Open or short in the CKT Pin 50, or CKT Pins 1.
- Improper terminals or pins at the electrical box, relay connector or ECM.
- Defective circuit breaker.
- Defective Relay.
- Defective ECM.

Failure of a Glow Plug Relay influences engine performance as follows:

- Difficult or no starting.
- May have white smoke on start up.

Glow Plug Auxiliary Relay, If Equipped

Scan Code:	P1640
Blink Code:	No recognition by ECM.
Malfunction Indicator Lamp:	OFF



- a - Engine Main Relay
- b - Circuit Breaker
- c - Glow Plug Main Relay
- d - Glow Plug Auxiliary Relay
- e - Engine Harness Connector
- f - 16 Terminal Instrument Harness Connector
- g - To Glow Plug Lamp

CIRCUIT DESCRIPTION:

The Glow Plug Main Relay (or Actuator) and the Glow Plug Auxiliary Relay are inside the electrical box of the engine. The ECM determines if, when and for how long a period the glow plugs (relays) should be activated based on coolant temperature information from the ECT. This processing by the ECM is done before, during and after the engine is started. It is the relay that controls the large amount of amperes needed by the glow plugs. Concurrent with supplying power to half of the glow plugs the Glow Plug Relay Actuator relay activates the Glow Plug Auxiliary Relay. The Auxiliary Relay's coil is energized closing a switch which thereby supplies current to the remaining glow plugs.

The ECM closes a ground path circuit for the Glow Plug Lamp whenever the system is operating.

A failure in the Glow Plug Auxiliary Relay circuit should set a Scan Code P1640.

CKT PIN	NAME
50	ECM controlled Glow Plug Relay Ground (-)
3	ECM controlled Ground (-) for dash panel Glow Plug Lamp

TEST DESCRIPTION

NOTE: The relay terminal numbers can be found on the bottom of the relay.

Verify continuity between the following with relay connectors unplugged and key OFF. Measure:

GLOW PLUG RELAY CONNECTOR / TERMINAL NUMBER	GLOW PLUG AUXILIARY RELAY CON- NECTOR / TERMINAL NUMBER
87	86

Verify supply voltage from circuit breaker to Glow Plug Auxiliary Relay with relay connector unplugged and key ON. Measure:

CURRENT (VOLTS)	GLOW PLUG AUXILIARY RELAY CON- NECTOR NUMBER
12	30

Verify supply voltage from Glow Plug Relay Actuator with relay connector unplugged and key ON. Measure:

CURRENT (VOLTS)	GLOW PLUG AUXILIARY RELAY CON- NECTOR NUMBER
12	86

DIAGNOSTIC HELP:

Verify the following:

- Open or short in wiring between glow plug relays.
- Improper terminals or pins at the electrical box, relay connectors or ECM.
- Defective circuit breaker.
- Defective Glow Plug Relay Actuator and/or Glow Plug Auxiliary Relay.
- Defective ECM.

Failure of the Glow Plug Auxiliary Relay influences engine performance as follows:


- Difficult or no starting.
- May have white smoke on start up.

Glow Plug Lamp (Glow Plug Display)

MODELS WITH EARLY (16 PIN) CONNECTOR

NOTE: Functional only if the engine is equipped with a Glow Plug System.

Scan Code:	P1645
Blink Code:	1411
Malfunction Indicator Lamp:	OFF



- a** - Electrical Box
- b** - Pin 6 of Instrumentation Harness 16 Pin Connector
- c** - Pin 6 of ECM 11 Pin Harness Connector
- d** - Glow Plug Lamp
- e** - Instrument Panel
- f** - ECM Supplied Ground Circuit

CIRCUIT DESCRIPTION:

The Glow Plug Lamp (wait-to-start) is controlled by the ECM. The lamp is supplied 12 volts with the key in the ON/RUN position. A ground (–) path is closed when the ECM is operating the relays for the glow plugs and the lamp is illuminated.

CKT PIN	NAME
3	ECM controlled Ground (–) for dash panel Glow Plug Lamp

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	GLOW PLUG BULB SOCKET WIRE AT DASH PANEL
3	BLK/YEL

Verify supply voltage from key switch terminal 15 with key ON. Measure:

CURRENT (VOLTS)	GLOW PLUG BULB SOCKET WIRE AT DASH PANEL
12	PNK

DIAGNOSTIC HELP:

Verify the following:

- Open or short in wiring between instrument panel and ECM.
- Improper terminals or pins at the electrical box harness connectors or ECM.
- Defective bulb.
- Defective bulb socket.
- Defective ECM.


Failure of the Glow Plug Lamp circuit does not influence engine performance.

Glow Plug Lamp (Glow Plug Display)

MODELS WITH LATE (21 PIN) CONNECTOR

NOTE: Functional only if the engine is equipped with a Glow Plug System.

Scan Code:	P1645
Blink Code:	1411
Malfunction Indicator Lamp:	OFF



- a - Electrical Box
- b - Pin K of Instrumentation Harness 21 Pin Connector
- c - Pin 6 of ECM 12 Pin Harness Connector
- d - Glow Plug Lamp
- e - Instrument Panel
- f - ECM Supplied Ground Circuit

CIRCUIT DESCRIPTION:

The Glow Plug Lamp is controlled by the ECM. The lamp is supplied 12 volts with the key in the ON/RUN position. A ground (–) path is closed when the ECM is operating the relays for the glow plugs and the lamp is illuminated.

CKT PIN	NAME
3	ECM controlled Ground (–) for dash panel Glow Plug Lamp

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	GLOW PLUG BULB SOCKET WIRE AT DASH PANEL
3	BLU/TAN

Verify supply voltage from key switch terminal 15 with key ON. Measure:

CURRENT (VOLTS)	GLOW PLUG BULB SOCKET WIRE AT DASH PANEL
12	PUR

DIAGNOSTIC HELP:

Verify the following:


- Open or short in wiring between instrument panel and ECM.
- Improper terminals or pins at the electrical box harness connectors or ECM.
- Defective bulb.
- Defective bulb socket.
- Defective ECM.

Failure of the Glow Plug Lamp circuit does not influence engine performance.

MIL [Malfunction Indicator Lamp (Diagnostic Lamp)]

MODELS WITH EARLY (16 PIN) CONNECTOR

Scan Code:	P1650
Blink Code:	1242
Malfunction Indicator Lamp:	OFF



- a - Electrical Box
- b - Pin 2 of Instrumentation Harness 16 Pin Connector
- c - Pin 2 of ECM 11 Pin Harness Connector
- d - MIL
- e - Instrument Panel
- f - ECM Supplied Ground Circuit

CIRCUIT DESCRIPTION:

The MIL (Malfunction Indicator Lamp) is controlled by the ECM. The lamp is supplied 12 volts with the key in the ON/RUN position. A ground (–) path is closed when the ECM determines that a malfunction (trouble code) has occurred. The lamp is illuminated.

CKT PIN	NAME
26	ECM controlled Ground (–) for dash panel MIL

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	GLOW PLUG BULB SOCKET WIRE AT DASH PANEL
26	BRN/WHT

Verify supply voltage from key switch terminal 15 with key ON. Measure:

CURRENT (VOLTS)	GLOW PLUG BULB SOCKET WIRE AT DASH PANEL
12	PNK

DIAGNOSTIC HELP:

Verify the following:


- Open or short in wiring between instrument panel and ECM.
- Improper terminals or pins at the electrical box harness connectors or ECM.
- Defective bulb.
- Defective bulb socket.
- Defective ECM.

Failure of the MIL circuit does not influence engine performance.

MIL [Malfunction Indicator Lamp (Diagnostic Lamp)]

MODELS WITH LATE (21 PIN) CONNECTOR

Scan Code:	P1650
Blink Code:	1242
Malfunction Indicator Lamp:	OFF



- a - Electrical Box
- b - Pin M of Instrumentation Harness 21 Pin Connector
- c - Pin 2 of ECM 12 Pin Harness Connector
- d - MIL
- e - Instrument Panel
- f - ECM Supplied Ground Circuit

CIRCUIT DESCRIPTION:

The MIL (Malfunction Indicator Lamp) is controlled by the ECM. The lamp is supplied 12 volts with the key in the ON/RUN position. A ground (–) path is closed when the ECM determines that a malfunction (trouble code) has occurred. The lamp is illuminated.

CKT PIN	NAME
26	ECM controlled Ground (–) for dash panel MIL

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	GLOW PLUG BULB SOCKET WIRE AT DASH PANEL
26	BRN/WHT

Verify supply voltage from key switch terminal 15 with key ON. Measure:

CURRENT (VOLTS)	GLOW PLUG BULB SOCKET WIRE AT DASH PANEL
12	PUR

DIAGNOSTIC HELP:


Verify the following:

- Open or short in wiring between instrument panel and ECM.
- Improper terminals or pins at the electrical box harness connectors or ECM.
- Defective bulb.
- Defective bulb socket.
- Defective ECM.

Failure of the MIL circuit does not influence engine performance.

Fuel Shut Off Valve [EAB (Electrical Shut Off)]

Scan Code:	P1660
Blink Code:	1221
Malfunction Indicator Lamp:	ON



- a - Fuel Injection Pump
- b - Fuel Shut Off Valve
- c - ECM Controlled12 Volt Power Supply

CIRCUIT DESCRIPTION:

As a safety feature the engine is equipped with a Fuel Shut Off Valve (Electrical Shut Off). This valve is a redundant method of stopping the engine. In case of a defect in a part or parts of the EDI system, which would prevent the engine from stopping, the ECM can energize this valve to positively stop the flow of fuel. This valve is similar as on the previous Indirect Injection systems but is controlled by the ECM. A 12 volt current is supplied to CKT Pin 53 which energizes the valve and stops the flow of fuel to the injectors when required.

A failure in the Fuel Shut Off Valve circuit should set a Scan Code P1660.

CKT PIN	NAME
53	Fuel Shut Off Valve

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	DEVICE TERMINAL
53	Electrical Fuel Shut Off

Verify supply voltage to fuel shut off valve terminal with the wire disconnected and key ON. Measure between the wire and the engine ground (–). Current should be present for the first 25 seconds only, and then cease, unless there is a failure.

CURRENT (VOLTS)	MINIMUM / MAXIMUM MEASUREMENT
12	Battery Voltage

Verify the resistance between the terminal on the valve and ground (–):

RESISTANCE (Ohm)	MINIMUM / MAXIMUM MEASUREMENT
7.5	± 0.5

DIAGNOSTIC HELP:

Verify the following:


- Open or short in the CKT Pin 53.
- Improper terminals or pins at the device connection or ECM.
- Defective fuel shut off valve.
- Defective ECM.

Failure of the fuel shut off valve or circuit influences engine performance as follows:

- If the valve failed previously the engine will not start.
- If there is a plausibility error, the engine may start but the ECM controls FUEL QUANTITY ACTUATION: Maximum engine rpm is 80% of the normal operating range.
- If there was a previous failure in the Fuel Shut Off Valve circuit but it is no longer defective, or the defect memory has not been erased (error still in memory), the maximum engine rpm will be 80% of the normal operating range. Erase the defect from memory and retest.

EEPROM Fault (EEPROM and Configuration)

Scan Code:	P1680
Blink Code:	1313
Malfunction Indicator Lamp:	OFF



75336

a - ECM (Engine Control Module)

CIRCUIT DESCRIPTION

The EEPROM Fault code may appear as a result of a calibration failure in the ECM. At startup the defect memory is read out from the EEPROM and interpreted. Thus a determination is made concerning how many entries are filed in the defect memory. Failures may include detected checksum errors, internal ECM communication errors, and even incorrect numbers stored in the EEPROM.

A failure in the EEPROM circuits should set a Scan Code P1680.

DIAGNOSTIC AIDS:

An intermittent Code P1680 may be caused by a bad cell in the EEPROM that is sensitive to temperature changes. If the EEPROM failed more than once, but is intermittent, replace ECM.


An intermittent problem may be caused by a poor or corroded connection, rubbed through wire connection, a wire that is broken inside the insulation, or a corroded wire.

Any circuitry that is suspected as causing the intermittent complaint should be thoroughly checked for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wiring connections, corroded terminals and/or wiring, or physical damage to the wiring harness. After repairs, clear codes following "Clearing Codes" in "ECM Self-Diagnostics." Failure to do so may result in codes not properly being cleared.

THIS PAGE IS INTENTIONALLY BLANK

RPM Signal From Injector (Secondary Engine Speed Sensor)

Scan Code:	P1725
Blink Code:	3332
Malfunction Indicator Lamp:	ON



- a** - Instrumented Injector (Needle Movement Sensor)
- b** - Harness Connector
- c** - Sensor ECM Signal
- d** - Sensor Ground (-)
- e** - Symbol for Shield Cable

CIRCUIT DESCRIPTION:

A secondary engine speed sensor signal called rpm Signal From Injector, is supplied to the ECM by way of the Instrumented Injector in the Number 1 Cylinder.

When functioning for the ECM circuitry as the Secondary Speed Sensor, a failure in this circuit will set a Scan Code P1725. Display of this code indicates a failure in the sensor circuit, so proper diagnosis will lead to either repairing a wiring problem or replacing the sensor.

CKT PIN	NAME
11	Sensor Ground (-)
12	Instrumented Injector Sensor Signal

TEST DESCRIPTION

Verify continuity between the following:

ECM 68 PIN CONNECTOR	2 TERMINAL CONNECTOR
11	2 (is shield wire, also)
12	1

Verify the sensor resistance between terminals 1 and 2 of the sensor:

RESISTANCE (Ohm)	MINIMUM - MAXIMUM MEASUREMENT
100	90 - 110

DIAGNOSTIC HELP:

Verify the following:

- Open or short in the CKT Pin 11 or CKT Pin 12.
- Defective sensor.
- Defective ECM.
- It is possible to have this failure when the two terminals in the Instrumented Injector connector are reversed.

Failure of the rpm Signal From Injector influences engine performance as follows:

- FUEL QUANTITY ACTUATION: Maximum engine rpm is 80% of the normal operating range (35% of fuel quantity reduction).
- TIMING ADVANCE: Timing actuation is in open loop which means the engine may be slightly noisier.

IMPORTANT: Torque the Instrumented Injector to specification when replacing.

Troubleshooting For EDI Systems

Trouble Codes

Code Number		Code Description
Scan Code Number	Blink Code Number	
P0105	2222	MAP Sensor
P0115	1113	ECT Sensor
P0180	3333	Fuel Temp. Sensor
P0725	1131	RPM Sensor
P1105	1121	BARO Sensor
P1110	1112	IAT Sensor
P1201	1132	Instrumented Injector
P1220	1223	Fuel Quantity Actuator
P1225	1222	Fuel Quantity Sensor
P1230	1321	Timing Fault
P1515	1144	TP Sensor / Low Idle Switch
P1600	1233	Battery Voltage
P1605	1232	Battery (Switched K15)
P1615	1311	Microcontroller Fault
P161A	1234	ECM Reference Voltage
P1625	1231	Main Relay
P1635	None	Glow Plug Main Relay, If Equipped
P1640	None	Glow Plug Auxiliary Relay, If Equipped
P1645	None	Glow Plug Lamp
P1650	1242	MIL (Malfunction Indicator Lamp)
P1660	1221	Fuel Shut Off Valve
P1680	1313	EEPROM Fault
P1725	3332	RPM Signal From Injector

Display Terminology

In addition to displaying trouble codes and their description, the Scan Tool is capable of supplying Extended Information. This information is designed to assist the technician in more readily resolving the cause of a listed Trouble Code. Refer to "Diagnostic Circuit Check" information and procedures. Although not all displayed information needs further explanation (e.g., short circuit or open circuit) other less obvious terms used in the Extended Information display are explained as follows:

Related to Scan Tool Code	Displayed Extended Information As Shown On Scan Tool	Explanation / Possible Cause
P0105, P1515	PICK-UP SRC LOW EXCEEDED	Check for open circuit in signal from ECM.
P0105, P1515	PICK-UP SRC HIGH EXCEEDED	Check for short circuit in signal from ECM.
P0105, P1515	SUPPLY SRC LOW EXCEEDED	Check for open circuit.
P0105, P1515	SUPPLY SRC HIGH EXCEEDED	Check for short circuit.
P0105, P1515	PLAUSIBILITY WITH LDF/ADF	The difference between the MAP and BARO sensor signals has exceeded a programmed amount. Check MAP and BARO circuits.
P0115	OPERATING TEMPERATURE NOT ATTAINED	The engine did not reach operating temperature within a prescribed period of time. Check thermostats, or check the ECT sensor and circuit.
P0725, P1725	OVERSPEED RECOGNITION	The rpm sensor or instrumented injector has detected engine revolutions in excess of a predetermined amount given all conditions. Unlikely to occur in a Marine application, unless related to propeller or drive failure.

Display Terminology (Continued)

Related to Scan Tool Code	Displayed Extended Information As Shown On Scan Tool	Explanation / Possible Cause
P0725	PLAUSIBILITY WITH LDF	Problem most likely to be found in MAP circuit. Example: boost pressure equals atmospheric pressure but rpms are high.) Check wiring.
P0725, P1725	DYNAMIC PLAUSIBILITY	The rpm sensor or instrumented injector have indicated a fault while the engine was operating (that is, over a period of time).
P0725, P1725	STATIC PLAUSIBILITY	This fault occurs when the instrumented injector signal (speed) is more than a specified amount but the rpm sensor is less than a specific amount. Check both circuits.
P1220	PERSISTENT NEGATIVE GOVERNOR DEVIATION (WARM)	When the engine is warm and the monitored fuel quantity is greater at a preset engine speed than the real position of the fuel quantity actuator. Check wiring first. If connections are OK, the pump itself should be replaced.
P1220	PERSISTENT POSITIVE GOVERNOR DEVIATION (WARM)	When the engine is warm and the monitored fuel quantity is less at a preset engine speed than the real position of the fuel quantity actuator. Check wiring first. If connections are OK, the pump itself should be replaced.

Display Terminology (Continued)

Related to Scan Tool Code	Displayed Extended Information As Shown On Scan Tool	Explanation / Possible Cause
P1220	PERSISTENT NEGATIVE GOVERNOR DEVIATION (COLD)	When the engine is cold and the monitored fuel quantity is greater at a preset engine speed than the real position of the fuel quantity actuator. Check wiring first. If connections are OK, the pump itself should be replaced.
P1220	PERSISTENT POSITIVE GOVERNOR DEVIATION (COLD)	When the engine is cold and the monitored fuel quantity is less at a preset engine speed than the real position of the fuel quantity actuator. Check wiring first. If connections are OK, the pump itself should be replaced.
P1225	START POSITION NOT ATTAINED	The fuel quantity sensor has indicated to the ECM that the fuel quantity actuator was not at the set point value during an ECM controlled start position test. Check wiring first. If connections are OK, the pump itself should be replaced.
P1225	STOP POSITION NOT ATTAINED	The fuel quantity sensor has indicated to the ECM that the fuel quantity actuator was not at the set point value during an ECM controlled stop position test. Check wiring first. If connections are OK, the pump itself should be replaced.

Display Terminology (Continued)

Related to Scan Tool Code	Displayed Extended Information As Shown On Scan Tool	Explanation / Possible Cause
P1230	POSITIVE GOVERNOR DEVIATION	Control of injection timing is occurring at a greater frequency than the programmed control values. Check the instrumented injector circuit and injection pump.
P1230	NEGATIVE GOVERNOR DEVIATION	Control of injection timing is occurring at a lesser frequency than the programmed control values. Check the instrumented injector circuit and injection pump.
P1515	PWG PLAUSIBILITY WITH LGS	A fault has been indicated in the TP sensor, most likely in the low idle switch circuit. Check these circuits.
P1515	PWG PLAUSIBILITY WITH POTENTIOMETER	A fault has been indicated in the TP sensor, most likely in the TP sensor circuit. Check these circuits.
P1515	PWG PLAUSIBILITY WITH BRE	Not applicable to marine EDI. Should not appear during testing.
P1515	PWG PLAUSIBILITY GENERAL	A fault has been indicated between the TP sensor and/or low idle switch signals. Check these circuits.
P1605	PLAUSIBILITY AFTER START-UP	A fault has been indicated in the key switched 12 volt power supply (terminal 15). Check battery connections, key switch and/or wiring to and from the switch.

Display Terminology (Continued)

Related to Scan Tool Code	Displayed Extended Information As Shown On Scan Tool	Explanation / Possible Cause
P1615	RECOVERY HAS OCCURRED	Clear the code(s) and start the engine. If the same fault occurs at each start, replace the ECM.
P1615	PREPARE ACTUATOR FOR GATE ARRAY FUEL QUANTITY STOP	
P1615	REDUNDANT OVERRUN MONITORING	
P1615	GATE ARRAY FUEL QUANTITY STOP	
P1615	GATE ARRAY MONITORING	
P1615	GATE ARRAY REPROGRAMMING	
P1625	SHUTS OFF TOO EARLY	The main relay shut off BEFORE the ECM gave the shut off command. Replace the ECM.
P1625	SHUTS OFF TOO LATE	The main relay shut off AFTER the ECM gave the shut off command. Replace the ECM.
P1635	GENERAL PLAUSIBILITY ERROR	Not recognized by Marine ECM application.
P1660	POWER STAGE DEFECT	An error was saved at ignition OFF when the shut off valve circuit was tested. Check the circuit and valve.
P1660	PLAUSIBILITY IN AFTER-RUN	
P1680	CHECKSUM ERROR IN CC212 VALUE	A problem in the ECM converting fuel quantity sensor signal. An internal ECM problem. Replace the ECM.
P1680	CHECKSUM ERROR	An internal ECM problem. Replace the ECM.
P1680	COMMUNICATION ERROR	An internal ECM problem. Replace the ECM.
P1680	WRONG EPROM NUMBER	An internal ECM problem. Replace the ECM.
P1680	WRONG CODE NUMBER	An internal ECM problem. Replace the ECM.

Troubleshooting Charts

IMPORTANT PRELIMINARY CHECKS

BEFORE USING THIS SECTION

Before using this section you should have determined that:

1. The ECM is operating correctly.
2. There are no diagnostic trouble codes (DTC) stored.

SYMPTOM

Verify the customer complaint, and locate the correct symptom. Check the items indicated under that symptom.

VISUAL/PHYSICAL CHECK

Several of the symptom procedures call for a careful visual/physical check. The importance of this step cannot be stressed too strongly. It can lead to correcting a problem without further checks and can save valuable time. These checks should include:

1. ECM grounds and sensors for being clean, tight and in their proper locations.
2. Fuel lines or hoses for splits, kinks, and proper connections. Check thoroughly for any type of leak or restriction.
3. Air leaks at intake manifold sealing surfaces.
4. Wiring for proper connections, pinches and cuts.
5. Salt corrosion on electrical connections.
6. Ensure engine is in good mechanical condition.

Troubleshooting Charts (Continued)

INTERMITTENTS

Definition: Problem occurs randomly. May or may not store a Diagnostic Trouble Code (DTC).

Do NOT use the diagnostic trouble code charts for intermittent problems, unless instructed to do so. If a fault is intermittent, incorrect use of diagnostic trouble code charts may result in replacement of good parts.

Most intermittent problems are caused by faulty electrical connections or wiring. Perform careful check of suspected circuits for:

1. Poor mating of the connector halves or terminals not fully seated in the connector body (loose).
2. Improperly formed or damaged terminals and or connectors. All connector terminals and connectors in problem circuit should be carefully reformed or replaced to insure proper contact tension.
3. Poor terminal to wire connection (crimping).

An intermittent may be caused by:

1. Electrical system interference caused by a sharp electrical surge. Normally, the problem will occur when the faulty component is operated.
2. Improper installation of electrical options, such as lights, ship to shore radios, sonar, etc.
3. Improperly routed wires. Wires should be routed **AWAY** from charging system components.
4. Arching at part of internal circuitry shorted to ground such as in starters, relays and alternators.

If a visual/physical check does not find the cause of the problem, the EDI system can be tested with a voltmeter or a scan tool connected while observing the suspected circuit. An abnormal reading, when the problem occurs, indicates the problem may be in that circuit.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
ENGINE WILL NOT CRANK OR CRANKS SLOWLY	1. Starting motor operating, but not cranking the engine. 2. Crankshaft rotation restricted. 3. Starting circuit connections loose or corroded. 4. Neutral safety switch or starter relay inoperative. 5. Battery charge low. 6. No voltage to starter solenoid. 7. Solenoid or starter motor inoperative.	1. Remove the starter motor. Check for broken flywheel teeth or a broken starting motor spring. 2. Rotate the engine to check for rotational resistance. 3. Clean and tighten connections. Reapply Liquid Neoprene, when required. 4. Check starter relay supply voltage and proper operation of neutral safety switch (if equipped). Replace defective parts. 5. Check battery voltage. Replace battery if a charge cannot be held. 6. Check voltage to solenoid. If necessary, replace the solenoid. 7. Replace starter motor.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
ENGINE CRANKS BUT WILL NOT START NO SMOKE	1. No fuel in supply tank. 2. Fuel Shut Off Valve not operating. 3. Air intake or exhaust plugged. 4. Fuel filter plugged. 5. Excessive fuel inlet restriction. 6. Injection pump not getting fuel or fuel is aerated. 7. One or more injectors worn or not operating properly. 8. Worn or inoperative injection pump. 9. Camshaft out of time.	1. kit fuel supply. 2. Check for loose wires and verify that the fuel shutdown solenoid and fuel shutdown solenoid relay is functioning. 3. Remove the obstruction. 4. Drain fuel/water separator and replace fuel filter. 5. Check fuel inlet restriction. Correct cause. 6. Check fuel flow/bleed fuel system. 7. Check/replace bad or improperly operating injectors. 8. Visually check delivery with externally connected injector to one of the pump outlets. Repair or replace as needed after testing, if fuel is not being delivered. 9. Check/correct gear train timing alignment.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
ENGINE HARD TO START, OR WILL NOT START, SMOKE FROM EXHAUST.	1. Incorrect starting procedure. 2. Cranking speed too slow. 3. Glow Plug Actuating Relay or Auxiliary Relay defective. 4. One or more glow plugs defective. 5. Insufficient intake air. 6. Air in fuel system or the fuel supply is inadequate. 7. TP Sensor and/or Throttle cable loose or damaged.	1. The fuel shutoff solenoid control must be in the run position. Ensure proper procedure is being used. 2. (A) Verify that the drive / transmission is not engaged. (B) Check the battery, starting motor and look for loose or corroded wiring connections. 3. Scan / Verify system is working. Repair / replace inoperative parts. 4. Verify glow plugs / system is working. Repair/replace inoperative parts. 5. Inspect or replace filter and check for obstruction to the air supply. 6. Check the flow through the filter and bleed the system. Locate and eliminate the air source. 7. Scan / Visually inspect the TP Sensor, throttle cable and mounting. Adjust/replace.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
ENGINE HARD TO START, OR WILL NOT START, SMOKE FROM EXHAUST.	1. Contaminated fuel. 2. Fuel screen plugged. 3. One or more injectors worn or not operating properly. 4. Malfunctioning, worn or inoperative injection pump. 5. Injection pump out of time or Timing Fault. 6. Engine compression low.	1. Verify by operating the engine with clean fuel from a temporary tank. Check for presence of gasoline. Drain and flush fuel supply tank. Replace fuel/water separator filter. 2. Check fuel screen. 3. Check/replace improperly operating injectors. 4. Scan / Repair / Replace components as needed. 5. Scan/Check/Time the pump. 6. Check compression to identify the problem.
ROUGH IDLE (IRREGULARLY FIRING OR ENGINE SHAKING)	1. If engine is cold, glow plug relay on glow plug(s) defective. 2. Idle speed / fuel quantity too low for the accessories. 3. Engine mounts damaged or lose. 4. High pressure fuel leaks. 5. Air in the fuel system. 6. Sticking needle valve in an injector.	1. Refer to troubleshooting for cylinder head heater plugs (see Group, Fuel System). 2. Adjust idle speed. 3. Repair or replace mounts. 4. Correct leaks in the high pressure lines, fittings or delivery valves. 5. Bleed the fuel system and eliminate the source of the air. 6. Check and replace the injector with the sticking needle valve.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
ENGINE OPERATES ROUGH	1. Fuel injection lines leaking. 2. Air in the fuel or the fuel supply is inadequate. 3. Contaminated fuel. 4. Incorrect valve operation. 5. Injection pump timing incorrect. 6. Improperly operating injectors. 7. Defective injection pump (fuel quantity or solenoid valve). 8. Camshaft out of time. 9. Damaged camshaft or tappets. 10. Automatic timing advance not operating.	1. Correct leaks in the high pressure lines, fittings, injectors sealing washers or delivery valves. 2. Check the flow through the filter and bleed the system. Locate and eliminate the air source. 3. Verify by operating the engine with clean fuel from a temporary supply tank. Check for presence of gasoline. Replace fuel/water separator filter. 4. Check for a bent push rod or damaged roller lifter. Replace parts if necessary. 5. Check/time pump (refer to Grouped Fuel System). 6. Replace inoperative injectors. 7. Scan, repair or replace injection pump. 8. Check/correct gear train timing alignment. 9. Inspect camshaft valve lift. Replace camshaft and tappets. 10. Check injection pump and instrumented injector at number 1 cylinder.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
ENGINE STARTS, BUT WILL NOT KEEP OPERATING	1. Glow plug relay(s) defective. 2. One or more glow plugs defective. 3. Idle speed / fuel quantity too low for the accessories. 4. Intake air or exhaust system restricted. 5. Air in the fuel system, or the fuel supply is inadequate. 6. Fuel waxing due to extremely cold weather. 7. Contaminated fuel.	1. Verify system is working. Repair/replace inoperative parts. 2. Verify system is working. Repair/replace inoperative parts. 3. Adjust the idle speed. 4. Visually check for exhaust restriction and inspect the air intake. Repair/replace restricting parts. 5. Check flow through the filter and bleed the system. Locate and eliminate the source. 6. Verify by inspecting the fuel filter. Clean the system and use climatized fuel. Replace fuel/water separator filter. Check fuel heater for properly operate if equipped. 7. Verify by operating the engine with clean fuel from a temporary supply to check for presence of gasoline. Replace fuel/water separator filter.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
SURGING (SPEED CHANGE)	1. If the condition occurs at idle, the idle speed is set too low for the accessories. 2. High pressure fuel leak. 3. One or more injectors worn or not operating properly. 4. Improperly operating injection - pumps	1. Adjust the idle speed. 2. Inspect/correct leaks in the high pressure lines. Fittings and delivery valve sealing washers. 3. Check/replace the inoperative injector 4. Replace the injector pump.
ENGINE RPM WILL NOT REACH RATED SPEED	1. Engine overload. 2. Improperly operating tachometer. 3. Throttle linkage worn or incorrectly adjusted. 4. Inadequate fuel supply. 5. Air/fuel controls leak. 6. Improperly operating injection pump. 7. Incorrect ECM part number	1. Verify high idle speed without load. Investigate operation to ensure correct gear is being used. 2. Verify engine speed with hand tachometer, correct as required. 3. Adjust linkage for stop to stop fuel control lever travel. Replace linkage if necessary. 4. Check the fuel flow through the system to locate the reason for inadequate fuel supply, correct as required. 5. Check and repair leak. Check AFC tubing for obstruction. 6. Repair or replace injection pump. 7. Ensure ECM part number is correct for your model; some derated ECMs are for dual installations in emission regulated countries

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
LOW POWER	1. Throttle cable not moving to full throttle. 2. High oil level. 3. Engine overloaded. 4. Slow throttle response caused by leaking or obstructed air control tube or improperly operating injection pump. 5. Inadequate intake air flow. 6. Inadequate fuel supply. Air in the fuel. 7. Excessive exhaust restriction. 8. High fuel temperature. 9. Poor quality fuel or fuel contaminated with gasoline.	1. Check/correct for stop-to-stop travel. 2. Check/correct oil level. 3. Check for added loading from accessories or driven units, brakes dragging and other changes in vehicle loading. Repair/replace as needed. 4. Check for leaks and obstructions. Tighten the fittings. Repair or replace the pump, if Scan/Check determines pump is not functioning. 5. Inspect/replace air cleaner element. Look for other restrictions. 6. Check the flow through the filter to locate the source of the restriction. Check fuel pressure and inlet restriction. 7. Check/correct the restriction in the exhaust system. 8. Verify that fuel heater, if equipped is off when engine is warm. Check for restricted fuel return lines. Repair/replace as needed. 9. Verify by operating from a temporary tank with good fuel. Check for presence of gasoline. Replace fuel/water separator filter.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
LOW POWER (continued)	1. Air leak between the turbocharger and the intercooler. 2. Exhaust leak at the manifold or turbocharger. 3. Improperly operating turbocharger. 4. Wastegate operation. 5. Valve not operating 6. Worn or improperly operating injectors. 7. Incorrect injection pump timing. 8. Improperly operating injection pump.	1. Check/correct leaks in hoses, gaskets, intercooler and around mounting capscrews or through holes in the cooler end covers. 2. Check/correct leaks in the manifold or turbocharger gaskets. If manifold is cracked, replace manifold. 3. Inspect/replace turbocharger. 4. Check wastegate operation. 5. Check for bent push rod, faulty hydraulic lifter, replace if necessary. 6. Check/replace injectors. 7. Scan/Verify injection pump timing. 8. Repair or replace injection pump.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
EXCESSIVE EXHAUST SMOKE	1. Engine operating too cold (white smoke). 2. Improper starting procedure (white smoke). 3. Fuel supply inadequate. 4. Injection pump timing. 5. inadequate intake air. 6. Air leak between turbocharger and intake manifold. 7. Exhaust leak at the manifold or turbocharger. 8. Improperly operating turbocharger. 9. Improperly operating injectors. 10. Improperly operating or over fueled injector pump. 11. Piston rings not sealing (blue smoke).	1. Refer to troubleshooting for coolant temperature below normal (refer to Cooling System). Inspect glow plugs for proper operation. 2. Use proper starting procedures. 3. Check fuel supply pressure and inlet restriction. 4. Scan/Check pump timing. 5. Inspect/change air filter. Look for other restriction. Check charge air cooler for obstructions. 6. Check/correct leaks in the air crossover tube. hoses, gaskets, mounting capscrews or through holes in the manifold cover. 7. Check/correct leaks in the manifold or turbocharger gaskets. If cracked replace manifold. 8. Inspect/replace turbocharger. 9. Check and replace inoperative injectors. 10. Repair or replace injection pump. 11. Perform compression / blow-by check. Correct as required.

Troubleshooting Charts (Continued)

WARNING

In case of engine runaway due to flammable fumes from gasoline spills or turbocharger oil leaks being sucked into the engine, shut off engine ignition switch first then use a CO₂ fire extinguisher and direct the spray near the engine air inlet to remove oxygen supply. The engine air inlet is on the port side on the flywheel end of the engine. The fire extinguisher must be directed at this location for emergency shutdown conditions.

CONDITION	POSSIBLE CAUSES	CORRECTION
ENGINE WILL NOT SHUT OFF	1. Fuel shutoff solenoid inoperative. 2. Engine operating on fumes drawn into the air intake. 3. Fuel injection pump and/or Fuel Shut Off Valve malfunction	1. Check/replace fuel shutoff solenoid. 2. Check the air intake ducts for the source of fumes. 3. Repair or replace fuel injection pump.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
COOLANT TEMPERATURE ABOVE NORMAL	- Low coolant level. - Incorrect/improperly operating pressure cap. - Loose drive belt on water pump. - Improperly operating temperature sensor / gauge - Obstructed or restricted seawater pump inlet. - Improperly operating. incorrect or no thermostat. - Air in the cooling system. - Inoperative water pump. - Incorrect injection pump timing. - Over fueled injection pump. - Plugged cooling passages in coolers/heat exchanger, head, head gasket or block. - Engine overloaded.	- Check coolant level. Add coolant, if necessary. Locate and correct the source Off the coolant loss, (refer to Group, Cooling). - Replace cap with the correct rating for the system. - Check/replace belt or belt tensioner. - Verify that the gauge and temperature sensor are accurate. Replace gauge/sensor, if bad. - Remove obstruction / restriction. - Check and replace the thermostat. (A) Make sure the fill rate is not being exceeded and the correct vented thermostat is installed. (B) Check for loose hose Cams. Tighten if loose. (C) If aeration continued, check for a compression leak through the head gasket. - Check and replace the water pump. - Verify pump timing marks are aligned. Check/time the injector pump (refer to Group, Fuel System). - Repair or replace the injection pump. - Flush the system and fill with clean coolant. - Verify that the engine load rating is not being exceeded.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
COOLANT TEMPERATURE BELOW NORMAL	1. Incorrect thermostat or Contamination in thermostat. 2. Temperature sensor or gauge inoperative. 3. Coolant not flowing by temperature sensor.	1. Check and replace thermostat. 2. Verify that the gauge and sensor are accurate. If not, replace gauge/sensor. 3. Check and clean coolant passages.
LUBRICATING OIL PRESSURE LOW	1. Low oil level. 2. Oil viscosity thin, diluted or wrong specification. 3. Improperly operating pressure switch/gauge. 4. Relief valve stuck open. 5. Plugged oil filter. 6. If cooler was replaced, snipping plugs remain in cooler. 7. Worn oil pump. 8. Suction tube loose or seal leaking. 9. Loose main bearing cap. 10. Worn bearings or wrong bearings installed. 11. Oil jet under piston bad fit into main carrier.	1. (A) Check and fill with clean engine oil. (B) Check for a severe external oil leak that could reduce the pressure. 2. Verify the correct oil is being used. Check for oil dilution. Refer to Contaminated Lube Oil (Engine Diagnosis Mechanical). 3. Verify the pressure switch is functioning correctly. If not, replace switch/gauge. 4. Check/replace valve. 5. Change oil filter. Oil filter change interval may need to be revised. 6. Check/remove shipping plugs. 7. Check and replace oil pump. 8. Check and replace seal. 9. Check and install new bearing and tighten cap to proper torque. 10. Inspect and replace connecting rod or main bearings. Check and replace piston cooling nozzles. 11. Check oil jet position.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
LUBRICATING OIL PRESSURE TOO HIGH	1. Pressure switch/gauge not operating properly. 2. Engine operating too cold. 3. Oil viscosity too thick. 4. Oil pressure relief valve stuck closed or binding.	1. Verify the pressure switch is functioning correctly. If not, replace switch/gauge. 2. Refer to "Coolant Temperature Below Normal." 3. Make sure the Correct oil being used, (Refer to Group, Lubrication and Maintenance). 4. Check and replace valve.
LUBRICATING OIL LOSS	1. External leaks. 2. Crankcase being overfilled. 3. Incorrect oil specification or viscosity. 4. Oil Cooler leak. 5. High blow-by forcing oil out the breather. 6. Turbocharger leaking oil to the air intake. 7. Piston rings not sealing (oil being consumed by the engine).	1. Visually inspect for oil leaks. Repair as required. 2. Verify that the correct dipstick and/or correctly marked dipstick is being used. 3. (A) Make sure the correct oil is being used. (B) Look for reduced viscosity from dilution with fuel. (C) Review/reduce the oil change intervals. 4. Check and replace the oil cooler. 5. Check the breather tube area for signs of oil loss. Perform the required repairs. 6. Inspect intercooler for evidence of oil transfer. Repair as required. 7. Perform compression check. Repair as required.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
COMPRESSION KNOCKS	1. Air in the fuel system. 2. Poor quality fuel or water/gasoline contaminated fuel. 3. Engine overloaded. 4. Incorrect injection pump timing. 5. Improperly operating injectors.	1. Bleed the fuel system. 2. Verify by operating from a temporary tank with good fuel. Clean and flush the fuel supply tanks. Replace fuel/water separator. 3. Verify the engine load rating is not being exceeded. 4. Scan / check injection pump timing. 5. Check and replace inoperative Injector.
EXCESSIVE VIBRATION	1. Loose or broken engine mounts. 2. Damaged or improperly operating accessories. 3. Improperly operating vibration damper. 4. Worn or damaged alternator bearing. 5. Flywheel housing misaligned. 6. Loose or broken power component. 7. Worn or unbalanced drive line components.	1. Replace engine mounts. 2. Check and replace the vibrating components. 3. Inspect / replace the vibration damper. 4. Check/replace the alternator. 5. Check/correct flywheel alignment. 6. Inspect the crankshaft and rods for damage that causes an unbalance. repair/replace as required. 7. Check/repair drive line components.

Troubleshooting Charts (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
EXCESSIVE ENGINE NOISES	1. Drive belt squeal, insufficient tension or abnormally high loading. 2. Intake air or exhaust leaks. 3. Excessive valve lash. 4. Turbocharger noise. 5. Gear train noise. 6. Power function knock.	1. Inspect the drive belt. Check drive belt tension. 2. Refer to Excessive Exhaust smoke (Engine Diagnosis Performance). 3. Make sure the push rods are not bent and rocker levers are not severely worn. Replace Bent or severely worn pads. 4. Check turbocharger impeller and turbine wheel for housing contact. Repair/replace as required. 5. Visually inspect and measure gear backlash. Replace gears as required. 6. Check/replace rod and main bearings.
ALTERNATOR NOT CHARGING OR INSUFFICIENT CHARGING	1. Loose or corroded battery. 2. Alternator belt slipping. 3. Alternator pulley loose on shaft. 4. Improperly operating alternator.	1. Clean/tighten battery connection. 2. Check/replace and adjust belt. 3. Tighten pulley. 4. Check/replace alternator.

THIS PAGE IS INTENTIONALLY BLANK

Repair Procedures

Service Precautions

WARNING

Electrical system components on this engine are not external ignition protected. Do NOT STORE OR UTILIZE GASOLINE ON BOATS EQUIPPED WITH THESE ENGINES, UNLESS PROVISIONS HAVE BEEN MADE TO EXCLUDE GASOLINE VAPORS FROM ENGINE COMPARTMENT (ref: 33 CFR). Failure to comply could result in fire, explosion and/or severe personal injury.

WARNING

Always disconnect battery cables from battery BEFORE working on fuel system to prevent fire. This eliminates the engine wiring as a potential source of ignition.

WARNING

FIRE HAZARD: Fuel leakage from any part of the fuel system can be a fire hazard which can cause serious bodily injury or death. Careful periodic inspection of entire fuel system is mandatory, particularly after storage. All fuel components including fuel tanks, whether plastic, metal or fiberglass, fuel lines, primers, fittings, and fuel filters should be inspected for leakage, softening, hardening, swelling or corrosion. Any sign of leakage or deterioration requires replacement before further engine operation.

WARNING

Be careful when changing fuel system components; diesel fuel is flammable. Ensure that ignition key is OFF. Do NOT smoke or allow sources of open flame in the area while changing fuel system components. Wipe up any spilled fuel immediately. Dispose of rags appropriately. Do NOT allow fuel to come into contact with any hot surface which may cause it to ignite.

WARNING

Dispose of fuel soaked rags, paper, etc. in an appropriate airtight, fire-retardant container. Fuel soaked items may spontaneously ignite and result in a fire hazard, which could cause serious bodily injury or death.

⚠ WARNING

Make sure no fuel leaks exist, before closing engine hatch.

⚠ CAUTION

It is good practice to ventilate the engine compartment prior to servicing any engine components to remove any fuel vapors which may cause difficulty breathing or be an irritant.

⚠ CAUTION

Fuel pressure **MUST BE** relieved before servicing high pressure components in the fuel system.

⚠ CAUTION

Do **NOT** operate engine without cooling water being supplied to water pickup holes in gear housing, or water pump impeller will be damaged and subsequent overheating damage to engine may result.

IMPORTANT: The following information **MUST BE** adhered to when working on the fuel system:

- Always keep a dry chemical fire extinguisher at the work area.
- Do **NOT** replace fuel pipe with fuel hose.
- Do **NOT** attempt any repair to the fuel system until instructions and illustrations relating to that repair are thoroughly understood.
- Observe all Precautions and Notes.

Replacement Parts Warning

⚠ WARNING

Electrical and fuel system components on your Mercury MerCruiser are designed and manufactured to comply with U.S. Coast Guard Rules and Regulations to minimize risks of fire and explosion. Use of replacement electrical, ignition or fuel system components, which Do **NOT** comply with these rules and regulations, could result in a fire or explosion hazard and should be avoided.

Torque Specifications


NOTE: Securely tighten all fasteners not listed below.

Description	Nm	lb-in.	lb-ft
MAP / IAT Sensor	3.5	31	
ECT Sensor Reducer Fitting To Cylinder Head	24.3		18
TP Sensor	6.7	60	
ECM Bracket To Isolator Mounts	19	168	
ECM To Bracket	8	72	
RPM Sensor	6.7	60	
ECT Sensor To Reducer Fitting	Tapered Threads, Tighten Securely		

Lubricants / Sealants / Adhesives

Description	Part Number
Liquid Neoprene	92-25711-3
Loctite 567 PST Pipe Sealant	92-809822
Loctite 242 Thread Locker	92-809821

System Components



System Component List

- 42** - Instrumented Injector (#1 Cylinder)
- 43** - MAP/IAT Sensor
- 44** - ECT Sensor
- 45** - Engine Speed Sensor
- 46** - Electrical Box
- 47** - Data Link Connector (DLC)
- 48** - Instrument Harness Connector
- 49** - Engine Harness Connector
- 50** - Main Relay
- 51** - Start Relay
- 52** - Circuit Breakers
- 53** - Glow Plug Relays (If Equipped)
- 54** - Electric Shut Off Solenoid
- 55** - Injection Pump
- 56** - ECM (Standard Calibration, Or Bodensee Compliant Calibration Available)
- 57** - TP Sensor

Fuel Injection Pump Repair

The Robert Bosch Corporation has a network of authorized Bosch Service Dealers throughout the world to service their products.

The pump and injectors must be sent to an authorized Bosch Service Center.

When shipping an injection pump to a service center for adjustments or repairs, the fuel *return line* hollow bolt must accompany the unit. The hollow bolt incorporates a sized orifice (is calibrated) for proper pressure which is matched to the pump. The pump cannot be properly adjusted without the matched orifice.

Contact the Bosch distributor nearest you for the location of an authorized Bosch Service Center.

Wiring Harness Service

GENERAL INFORMATION

Marine engine control circuits contain many special design features not found in standard land vehicle wiring. Environmental protection is used extensively to protect electrical contacts. Proper splicing methods must be used when making repairs.

The proper operation of low amperage input/output circuits depends upon good continuity between circuit connectors. It is important before component replacement and/or during normal troubleshooting procedures that a visual inspection of any questionable mating connector is performed. Mating surfaces should be properly formed, clean and likely to make proper contact. Some typical causes of connector problems are listed below.

- Improperly formed contacts and/or connector housing.
- Damaged contacts or housing due to improper engagement.
- Corrosion, sealer or other contaminants on the contact mating surfaces.
- Incomplete mating of the connector halves during assembly or during subsequent troubleshooting procedures.
- Tendency for connectors to come apart due to vibration and/or temperature cycling.
- Terminals not fully seated in the connector body.
- Inadequate terminal crimps to the wire.


Wire harnesses should be replaced with proper part number harnesses. When signal wires are spliced into a harness, use the same gauge wire with high temperature insulation only.

With the low current and voltage levels found in the system, it is important that the best possible bond be made at all wire splices by soldering the splices, as shown in Wire Repair. Use care when probing a connector or replacing connector terminals. It is possible to short between opposite terminals. If this happens, certain components can be damaged. Always use jumper wires with the corresponding mating terminals between connectors for circuit checking. **NEVER** probe through connector seals, wire insulation, boots, nipples or covers.

Microscopic damage or holes may result in eventual water intrusion, corrosion and/or component or circuit failure.


WIRE REPAIR

1. Locate damaged wire.
2. Remove insulation as required.



73048

3. Splice two wires together using a splice clip. Solder with rosin core solder.



73048

4. Cover splice with heat shrink sleeve to insulate from other wires.



73048

CONNECTOR SERVICE


Most connectors in the engine compartment are protected against moisture and dirt which could create oxidation and deposits on the terminals. This protection is important because of the very low voltage and current levels found in the electronic system. The connectors have a lock which secures the male and female terminals together. A secondary lock holds the seal and terminal into the connector.

When diagnosing, open circuits are often difficult to locate by sight because oxidation or terminal misalignment are hidden by the connectors. Merely wiggling a connector on a sensor or in the wiring harness may locate the open circuit condition. This should always be considered when an open circuit or failed sensor is indicated. Intermittent problems may also be caused by oxidized or loose connections.

Before making a connector repair, be certain of the type of connector. Some connectors look similar but are serviced differently. Replacement connectors and terminals are listed in the Parts Catalog.

NOTE: Replacement connectors for Mercury MerCruiser EDI engines may come with the wires already attached to the connector.


HARNESS VIEWS



75300

Instrument Harness And Connector

- a** - Early model 16 Pin Standard Connector
- b** - Late Model 21 Pin Deutsch™ Connector



75395

Engine Harness And Electrical Box

Relay, Module and Sensor Servicing (On-Board Service)

Precautions

⚠ WARNING


BEFORE attempting to disconnect and remove any module or sensor, check to make sure that the engine ignition system is OFF. Then disconnect the negative (-) battery cable from the terminal. Do NOT reconnect the negative (-) battery cable until the module or sensor removed has been re-installed with secure connections.

IMPORTANT: Modules and sensors are electrical devices easily damaged by contact with liquid cleaners or solvents. Clean with a dry cloth unless specifically directed to do otherwise.

Main Relay

REMOVAL

1. Remove electrical box cover.
2. Detach main relay from inside of electrical box.



75395

- a** - Electrical Box
- b** - Main Relay
- c** - Main Relay Connector

3. Disconnect electrical connector and remove relay.

CLEANING

IMPORTANT: The main relay is an electrical component. Do NOT soak in any liquid cleaner or solvent; damage may result.

1. Clean exterior with a dry cloth.
2. Clean terminals with a suitable cleaner.

INSPECTION

1. Look for evidence of any physical damage to base or connector surfaces of relay.
2. Visually inspect electrical pins of ECT for straightness and no corrosion.
3. Visually inspect connectors on the wiring harness for corrosion and for terminals that may have backed out of the harness.

TESTING

NOTE: The relay numbers can be found on the bottom of the relay.

1. The following information applies to operations/tests of this relay:
 - Terminal 30 is connected to battery voltage through a circuit breaker.
 - Terminal 87 is connected (a circuit is formed) to terminal 30 in the energized (ON) position. Terminal 87 then supplies battery voltage to two ECM pins.
 - Terminal 86 is connected to terminal 30.
 - Terminal 85 is grounded by the ECM, causing the relay to be energized.

INSTALLATION

1. Insert electrical connector onto main relay.
2. Attach relay to electrical box.

ECM (Electronic Control Module)

NOTICE

Refer to Service Precautions, in Repair Procedures, BEFORE proceeding.


IMPORTANT: The ECM is a sensitive electrical device, subject to electrostatic damage. Therefore, take care not to touch connector pins when removing, cleaning or installing the module.

IMPORTANT: An ECM with derated calibration is used for the D4.2L D-tronic in order to meet Bodensee emission requirements in twin-installations. Ensure any replacement ECM is the correct part.

REMOVAL

1. Slide the locking top of the connector aside and disconnect the 68 pin electrical connector from the engine control module (ECM).
2. Remove ECM from electrical bracket. Retain hardware.

NOTE: A taller ECM bracket is used on D-Tronic engines with V-Drive Transmissions.



Typical

- a** - Electrical Bracket
- b** - ECM
- c** - 68 Pin Electrical Connector

CLEANING

1. Clean the exterior of the ECM with a dry cloth being careful to avoid contact with connector pins.
2. Clean ECM mounting bracket to assure ground (–) contact.


INSPECTION

NOTE: The ECM is a sealed electrical component. If a Scan check has shown it to be defective, replace the unit with another ECM having the same part number and service number as the original.

1. Inspect outer surfaces for any obvious damage
2. Visually inspect electrical pins of ECM for straightness and no corrosion.
3. Visually inspect connectors on the wiring harness for corrosion and terminals that may have backed off the harness.

INSTALLATION

1. Mount new ECM to electrical bracket. Torque bolts and flanged nuts to specifications.
2. Connect and lock the 68 pin electrical connector to the ECM.



- a** - Electrical Bracket
b - ECM
c - 68 Pin Electrical Connector

75298

TESTING

Refer to Diagnostic Circuit Checks for information and procedures.

ECT (Engine Coolant Temperature) Sensor

NOTICE
Refer to Service Precautions in Repair Procedures, BEFORE proceeding.


REMOVAL

NOTE: Handle the ECT carefully as any damage to it will affect operation of the EDI system.

1. Refer to SECTION 6B and drain coolant.
2. Disconnect electrical connector from ECT (Engine Coolant Temperature) sensor.

NOTE: The ECT is mounted in a reducer fitting that is installed in the head.

3. Stabilize the reducer fitting with a separate tool and remove the ECT.



75579

Typical

- a** - Reducer Fitting
- b** - ECT Sensor
- c** - Connector

CLEANING


1. Clean sensor with a dry cloth.
2. Remove sealing washer and clean the seating area.
3. Clean harness connector.

INSPECTION

1. Look for evidence of any physical damage to base or connector surfaces of the ECT.
2. Visually inspect electrical pins of ECT for straightness and no corrosion.
3. Visually inspect connectors on the wiring harness for corrosion and terminals that may have backed of the harness.

INSTALLATION

1. Install reducer fitting, if removed previously. Replace the sealing washer. Torque the reducer to specifications.
2. Apply Loctite 567 PST Pipe Sealant to the threads of ECT. Install the ECT and tighten securely.
3. Connect electrical connector to ECT.



Typical

- a** - Reducer Fitting
- b** - ECT Sensor
- c** - Connector
- d** - Sealing Washer

4. Refer to SECTION 6B and fill with coolant.

TESTING

Refer to Diagnostic Circuit Checks for information and procedures.


MAP (Manifold Absolute Pressure) / IAT (Intake Air Temperature) Sensor

NOTICE

Refer to Service Precautions, in Repair Procedures, BEFORE proceeding.

REMOVAL

1. Disconnect electrical connector from the MAP / IAT sensor.
2. Remove screws from sensor and J-clip retaining coolant pipe.
3. Remove sensor from intercooler housing.



- a** - MAP/IAT Sensor
- b** - Electrical Connector
- c** - Intercooler
- d** - J-clip

CLEANING


1. Clean sensor with a dry cloth.
2. Clean harness connector.

INSPECTION

1. Look for evidence of any physical damage to base or connector surfaces of the sensor.
2. Visually inspect electrical pins of sensor for straightness and no corrosion.
3. Visually inspect connectors on the wiring harness for corrosion and terminals that may have backed out of the harness.
4. Inspect O-ring seal for damage.

INSTALLATION


1. Install new O-ring on MAP/IAT sensor.



75408

- a** - O-ring
- b** - MAP/IAT Sensor

2. Install MAP/IAT sensor to plenum using screws. Insert upper screw through J-clip for coolant pipe and then through the sensor to the intercooler. Torque screws to specifications.
3. Attach and lock the engine harness electrical connector to the MAP/IAT sensor.



- a** - MAP/IAT Sensor
- b** - Electrical Connector
- c** - Lock
- d** - Screw
- e** - J-clip

TESTING


Refer to Diagnostic Circuit Checks for information and procedures.

Throttle Position (TP) Sensor

NOTICE
Refer to Service Precautions in Repair Procedures, BEFORE proceeding.

REMOVAL

1. Disconnect throttle cable.
2. Disconnect TP electrical connector from engine harness.
3. Remove TP from ECM bracket.



75332

- a** - ECM Bracket
- b** - TP Sensor
- c** - Allen Head Screw and Flanged Nut (2 Required)

CLEANING


1. Clean sensor with a dry cloth.
2. Clean harness connector.

INSPECTION

1. Look for evidence of any physical damage to base or connector surfaces of the ECT.
2. Visually inspect electrical pins of ECT for straightness and no corrosion.
3. Visually inspect connectors on the wiring harness for corrosion and terminals that may have backed out of the harness.

INSTALLATION

1. Install TP sensor to ECM bracket using allen head screws with flanged nuts. Torque screws to specifications.
2. Connect sensor to engine harness.
3. Install throttle cable. Refer to SECTION 2.
4. Tighten throttle cable locknuts until they bottom and loosen 1/2 turn.



- a** - Throttle Cable End Guide
- b** - Cable Barrel
- c** - Anchor Stud
- d** - Flat Washer And Locknut
- e** - Spacer (If Required)

5. Connect the battery cables. Start the engine and check the TP sensor output voltage. It should be 0.4-0.8 V at idle and 4.5 V at WOT Refer to Testing Diagnostic Circuit Check.

75332


Instrumented Injector

Refer to SECTION 5C for information and procedures.

Engine RPM Speed Sensor

REMOVAL

1. Disconnect rpm Sensor from harness.
2. Remove screw retaining sensor to flywheel housing or adapter piece if equipped.
3. Withdraw sensor from housing.



75377

- a** - Engine RPM Speed Sensor
- b** - Allen Head Screw
- c** - Adapter (If Equipped)
- d** - Flywheel Housing

CLEANING

1. Clean sensor and connector with a dry cloth.
2. Clean harness connector.


INSPECTION

1. Look for evidence of any physical damage to sensor surfaces and tip of sensor.
2. Visually inspect connectors for corrosion and terminals that may have backed out of the harness.
3. Inspect O-ring seal for damage.

INSTALLATION

1. Install new O-ring on Engine rpm Speed sensor.
2. Install sensor to adapter piece using screw. Torque screw to specifications.
3. Attach and lock the engine harness electrical connector to the sensor.

Idle Speed Setting Circuit



77611

An electrical circuit, using two RED/ORANGE wires inside the electrical box, has been added to allow for a 100 rpm increase in the base idle speed signal from the ECM. This is called the Idle Speed Setting Circuit.

Locate the RED/ORANGE wire male and female bullet connector ends. One wire end is from terminal 12 of the ECM / Fuel System Harness connector and the other is from terminal 87 of the Main Relay. When the wires are connected the engine idle speed should be 700 rpm. If the wires are disconnected the idle speed should be 600 rpm.

Determine the best idle speed for the power package and application. Set the idle speed circuit accordingly.

INSPECTION

1. Visually inspect connectors for corrosion, if wires are connected.
2. Visually inspect for terminals that may have backed out of the harnesses.

CLEANING

1. Clean connectors with a suitable tool or solvent, if wires are connected.

INSTALLATION

1. Connect the RED/ORANGE wire male and female bullet connector ends and the engine idle speed should be 700 rpm.

NOTE: If the RED/ORANGE wire bullet connectors are disconnected the idle speed should be 600 rpm.

THIS PAGE IS INTENTIONALLY BLANK

COOLING SYSTEM

Section 6A - Seawater Cooling System

Table of Contents

Torque Specifications	6A-3	Inspection	6A-18
Lubricants / Sealants / Adhesives	6A-3	Assembly	6A-19
Tools	6A-3	Installation	6A-25
Seawater (Raw Water) System		Seawater Strainer	6A-27
Specifications	6A-4	Exploded View	6A-27
Seawater Pump Delivery Rates	6A-4	Removal	6A-28
Seawater Pickup Connections	6A-4	Installation	6A-30
Precautions	6A-5	Oil / Power Steering / Transmission	
Seawater Pickup Connection	6A-5	Fluid Coolers	6A-31
Seacock	6A-6	General Information	6A-31
Seawater Strainer	6A-6	Exploded View	6A-32
Exploded View - Seawater Pumps	6A-7	Location of Coolers	6A-33
D2.8L D-Tronic	6A-7	Inspection Before Removal	6A-34
D4.2L D-Tronic	6A-8	Cleaning Without Removal	6A-34
Seawater Flow Diagram	6A-10	Engine Oil Cooler	6A-35
Seawater Pump	6A-12	Power Steering	6A-40
Removal	6A-12	Transmission Fluid Cooler	6A-42
Disassembly	6A-13	Installation	6A-43
Cleaning	6A-17		

THIS PAGE IS INTENTIONALLY BLANK

NOTICE

For instructions on Cleaning Seawater Strainer, Flushing Seawater Cooling System or Draining Seawater Section refer to SECTION 1B.

Torque Specifications

Description		Nm	lb-in.	lb-ft
Heat Exchanger End Covers				
	Upper	14-15	120-132	
	Lower	11	108-120	
Port Heat Exchanger Bracket		30		22
J-clamp to Exhaust Manifold		32		24

Lubricants / Sealants / Adhesives

Description	Part Number
Loctite Master Gasket	92-12564--1
U-joint and Gimbal Bearing Grease	92-802870A1
Petroleum Jelly	Obtain Locally
Loctite Pipe Sealant With Teflon	

Tools

Schaefer Brush Manufacturing Company 117 West Walker Street Milwaukee, WI 53204 U.S.A.	
Description	Part Number
Heat Exchanger Cleaning Brush	01299

Seawater (Raw Water) System Specifications

Seawater Pump Delivery Rates

Description	Engine rpm	Liters (U.S. Gallons) Per Minute
D2.8L D-Tronic	2000	60 (16)
	3000	87 (23)
	3800	109 (29)
D4.2L D-Tronic	2000	71 (19)
	3000	98 (26)
	3800	114-1/2 (30-1/2)

Seawater Pickup Connections

SEAWATER PICKUP HOSE

Description	D2.8L D-Tronic D4.2L D-Tronic
Seawater Pickup Hose Diameter	38 mm (1-1/2 in.) Minimum

SEACOCK (WATER INLET VALVE)

Description	D2.8L D-Tronic D4.2L D-Tronic
Seacock Size (Internal Cross Sectional Area)	38 mm (1-1/2 in.) Minimum

SEAWATER STRAINER

Description	D2.8L D-Tronic D4.2L D-Tronic
Seawater Strainer Flow Requirement	150 liter (40 U.S. Gallons) Minimum Per Minute

THROUGH THE HULL SEAWATER PICKUP

Description	D2.8L D-Tronic D4.2L D-Tronic
Seawater Pickup Flow Requirement	150 liter (40 U.S. Gallons) Minimum Per Minute

Precautions

IMPORTANT: If the possibility of freezing exists, seawater section, and associated heat exchangers, **MUST BE** drained to prevent freeze damage to cooling system and engine. Seawater section also should be drained if boat is to be stored for an extended period of time, to prevent corrosion damage.

CAUTION

Seawater cooling system **MUST BE** completely drained for storage, or trapped water may cause freeze and/or corrosion damage to engine and/or components.

CAUTION

If boat is in the water, seacock (if equipped) **MUST** remain closed until engine is to be restarted, to prevent water from flowing back into the cooling system. If boat is not fitted with a seacock, water inlet hose must remain disconnected and plugged to prevent water from flowing into cooling system and/or boat. As a precautionary measure, attach a tag to the ignition switch or steering wheel with the **WARNING** that the seacock must be opened or the water inlet hose reconnected prior to starting the engine.

IMPORTANT: A wire should be repeatedly inserted into drain holes to ensure that foreign material is not obstructing the drain holes.

IMPORTANT: To prevent threads from rusting out during storage, reinstall plugs using Perfect Seal on threads. **NEVER** leave drain plugs out after cleaning or during storage.

Seawater Pickup Connection

Water pickup must be large enough to permit sufficient water flow to engine seawater pickup pump for adequate engine cooling.

IMPORTANT: Do **NOT** install water pickup directly in line with propeller, as pickup may create turbulence and allow air to flow into the propeller slipstream. This will cause propeller ventilation and will adversely affect boat performance.

Pickup also must supply a positive head while underway. Water pickup should be located as close to seawater pickup pump inlet as possible and in an area where an uninterrupted, solid stream of water will flow past when boat is underway.

Use only inner diameter wire reinforced hose of adequate wall thickness to prevent it from collapsing from pump suction. Secure hose connections with double hose clamps.


Refer to Specifications.

Seacock

If a seacock is being used, it must be installed between water pickup and seawater pickup pump (or seawater strainer), to allow operator to shut off the seawater in case of a leak or when boat is not in use. This will also allow the operator to flush or drain the engine, or clean the sea strainer while boat is in the water. Install seacock in an area where it will be easily accessible and support adequately to prevent hose fatigue.

To prevent restricting water flow seacock used must have an internal cross-sectional area equal to or greater than hose.

Refer to Specifications.



70355

Through The Hull Components Shown - All Similar

- a** - Wire Reinforced Hose
- b** - Seacock
- c** - Seawater Pickup


Seawater Strainer

The strainer, if equipped, must be of sufficient size to ensure that an adequate supply of water will be maintained for cooling engine. A minimum flow rate is required.

Refer to Specifications.

Exploded View - Seawater Pumps


D2.8L D-Tronic



- 58** - Pump Housing
- 59** - Screw
- 60** - Housing Pin
- 61** - Ball Bearing
- 62** - Bearing Spacer
- 63** - Snap Ring
- 64** - Shaft
- 65** - Thrust Washer
- 66** - Lip Seal
- 67** - Slinger
- 68** - Spacer
- 69** - Primary Lip Seal
- 70** - Cam
- 71** - Impeller
- 72** - Spline Plug
- 73** - Gasket
- 74** - Cover
- 75** - Screw
- 76** - O-Ring
- 77** - Nut With Washer (4) (Washers Not Shown)

Description	Part Number
A Loctite Master Gasket	92-12564-2

D4.2L D-Tronic




73946

- 1** - Pump Housing
- 2** - Screw
- 3** - Cover
- 4** - Gasket
- 5** - Impeller and Spline Plug
- 6** - Cam (Apply Sealer Indicated to Back-Side)
- 7** - Thrust Washer (Align Notch with Housing Pin)
- 8** - Retaining Ring
- 9** - Spacer
- 10** - Seal
- 11** - Oil Seal
- 12** - Screw
- 13** - Sealed Ball Bearing
- 14** - Shaft
- 15** - O-ring
- 16** - Lockwasher (4)
- 17** - Nut (4)

Description		Part Number
A	Loctite Master Gasket	92-12564-2

THIS PAGE IS INTENTIONALLY BLANK

Seawater Flow Diagram



Typical - All Engines

Seawater Cooling Circuit (Raw Water)

- 1** - Seawater Inlet -
Through Drive - Sterndrive
Through Hull - Inboard
- 2** - Seacock (If Equipped)
- 3** - Seawater Strainer
- 4** - Seawater Pump
- 5** - Intercooler
- 6** - Engine Oil Cooler
- 7** - Heat Exchanger
- 8** - Fluid Cooler -
Power Steering Fluid - Sterndrive
Transmission Fluid - Inboard
- 9** - Exhaust Pipe Water Jacket
- 10** - Seawater Outlet (Exhaust)

Engine Components

- a** - Thermostat Housing and Thermostats
- b** - Circulating Pump - Closed Coolant
- c** - Engine Block - Upper Section of Liners
- d** - Cylinder Heads
- e** - Water Manifold
- f** - Turbocharger
- g** - Exhaust Manifold


Seawater Pump

Removal

⚠ CAUTION

If boat is in water while working on seawater pump, when removing seawater inlet hose, close seacock, if equipped. If boat is not equipped with a seacock, remove and plug seawater inlet hose to prevent a siphoning action that may occur, allowing seawater to enter boat.

1. Close seacock if equipped, or remove and plug seawater pump inlet hose.
2. Loosen the 6 seawater pump cover screws to drain water into a suitable container. Remove outlet hose.




75299

Typical

- a - Inlet Hose
- b - Connector Fitting
- c - Cover Screws (6)
- d - Outlet Hose

3. Remove the 4 hex nuts with lockwashers or flange nuts. Remove the pump.




70423

- a - Location of Hex Nuts
- b - Pump

Disassembly

1. Clamp the pump in a vise.
2. Remove the 6 cover screws.




70625

Typical


a - Cover Screws

3. Using 2 screwdrivers, carefully remove the impeller.



70626

4. **On D2.8L D-Tronic pumps:** Remove internal snap ring from pump body.




70628

a - Snap Ring

5. On D4.2L D-Tronic pumps:


- a. Remove external retaining ring from pump shaft.



70694

a - External Retaining Ring


- b. Remove spacer from shaft.



70695

a - Spacer

6. Using a soft faced hammer, tap shaft and bearing assembly out of pump housing.




70638

Typical

- a** - Shaft and Bearing Assembly
b - Pump Housing

IMPORTANT: Take note of factory markings on bearings (if visible), or suitably mark each bearing, to ensure installation in original position if reused.


7. **On D2.8L D-Tronic pumps:** Using an arbor press and suitable hardware, remove one bearing at a time from pump shaft to avoid damaging spacer. Press off toward splines of shaft and on inner race of bearings only.



70635

- a** - Bearing(s)
- b** - Spacer
- c** - Pump Shaft


8. **On D4.2L D-Tronic pumps:** Using an arbor press and suitable hardware, remove one bearing at a time from pump shaft (spacer is machined as part of shaft). Press one bearing off toward splines of shaft and the other opposite. Press on inner race of bearings only.



70696

- a** - Bearing(s)
- b** - Spacer (Is machined as part of shaft)
- c** - Pump Shaft

9. Remove screw from between inlet and outlet to allow cam removal.




70632

Typical Pump and Cam

- a** - Screw
b - Cam

10. Remove thrust washer from its position on locating pin in pump housing.




70631

Typical Pump and Thrust Washer

- a** - Thrust Washer

11. **On D2.8L D-Tronic pumps:** Using a suitable tool, remove two lipseals, one spacer, and one slinger ring from pump housing. Notice positioning.




70637

- a** - Primary Lipseal
b - Spacer
c - Slinger Ring
d - Lipseal

12. On D4.2L D-Tronic pumps:

- a. Being careful not to gouge or nick pump housing, remove rear seal by inserting a screwdriver through holes in pump housing and carefully pry (push).




70697

- a** - Screwdriver
- b** - Rear Seal
- c** - Pump Housing

- b. Using a suitable tool, press front seal assembly out front of pump housing from rear.

NOTE: Although different in appearance the front seal will press out like a normal seal.



- a** - Front Seal
- b** - Pump Housing
- c** - Rear Seal

Cleaning

⚠ WARNING

Always wear safety glasses when using compressed air.

1. Clean metal parts in solvent and dry with compressed air.
2. After cleaning, apply a coat of light engine oil to shaft and bearings to prevent rusting.
3. Clean all gasket material and sealer from sealing surfaces.

Inspection


1. Inspect bearing housing. Examine surfaces (where bearings contact housing) for evidence of bearing outer races turning in housing.
2. Inspect bearings for worn or defective condition. Examine sealed bearings for evidence of loss of factory grease, or evidence of internal contamination by engine oil.
3. Inspect seals from bearing housing.
4. Inspect pump shaft for grooves in surface where seals contact shaft.
5. Inspect drive key on shaft.
6. Inspect surface, where bearings contact shaft for evidence of inner races turning on shaft.
7. Inspect impeller splines and shaft splines.
8. Inspect pump body.
9. Inspect cam for scratches or gouging.
10. Inspect pump impeller for wear on sides and tips of blades.
11. Inspect blades for cracks in area where blades flex.
12. Replace impeller, if blades have taken a set (remain in curved position).
13. Replace all parts that Do NOT conform to standards.

Assembly

1. On D2.8L D-Tronic pumps:

IMPORTANT: In the following steps press on inner races of bearings **ONLY**. Do **NOT** crush spacer.

- Using an arbor press, install first bearing against shoulder of pump shaft beginning from splined end.
- Install plastic spacer and press second bearing on shaft, in positions shown.




70634

- a** - First Bearing
- b** - Spacer (Plastic)
- c** - Second Bearing

2. On D4.2L D-Tronic pumps:

IMPORTANT: In the following steps press on inner races of bearings **ONLY**.


- Using an arbor press, install rear bearing against shoulder of spacer. Press from rear of shaft.
- Press front bearing against shoulder of spacer. Press from splined end.



70443

- a** - Rear Bearing
- b** - Spacer (Machined As Part of Shaft)
- c** - Front Bearing


3. **On D2.8L D-Tronic pumps:** Install spacer into impeller side of housing. Using a suitable tool, install impeller primary lipseal (lip facing out - back of seal visible).



70629

- a** - Rubber Washer (Installed First, Not Shown In This View)
b - Impeller Primary Seal


4. **On D4.2L D-Tronic pumps:** Install impeller primary seal assembly using a suitable tool. Plastic collar around lip **MUST** face impeller.



70630

- a** - Impeller Primary Seal
b - Plastic Collar Around Lip


5. **On D2.8L D-Tronic pumps:** Install slinger ring into bearing side of housing. Using a suitable tool, install rear seal (lip facing front of pump - back of seal visible).



70629

a - O-ring
b - Rear Seal


6. **On D4.2L D-Tronic pumps:** Using a suitable tool, install rear seal (lip facing out - back of seal visible).



70444

a - Rear Seal

7. Install thrust washer into pump housing. Align washer notch with pin in housing.




70630

Typical Pump and Thrust Washer

a - Thrust Washer
b - Washer Notch
c - Housing Pin


8. Coat backside of cam with Loctite Master Gasket sealant.
9. Install cam in housing as shown. Tighten screw securely. Remove excess sealant and allow to dry before continuing assembly.



Typical Pump and Cam

- a** - Sealant
- b** - Cam
- c** - Screw


10. Coat lips of seals in pump housing with U-Joint and Gimbal Bearing Grease.
11. Install shaft and bearing assembly into housing as shown.
12. Tap lightly with soft faced hammer if needed to seat assembly.



70638

Typical Pump and Shaft With Bearings

13. On D2.8L D-Tronic pumps: Install internal snap ring into pump body groove.




70628

a - Snap Ring

14. On D4.2L D-Tronic pumps:


- Install spacer (washer) on shaft next to front seal assembly.
- Install external retaining ring into groove of shaft.



70694

a - Front Seal Assembly
b - Spacer (Washer)
c - External Retaining Ring


15. Hold pump housing in soft-jaw vise. Install impeller into housing by turning clockwise while simultaneously pushing inward as shown.



70624

Typical Pump and Impeller

16. Push rubber button seal into end of impeller.




70627

a - Rubber Button Seal

b - Impeller

17. Install gasket (wide surface on cam side) and cover. Tighten screws evenly in a diagonal pattern. Tighten securely.



70625

Typical Pump and Cover

a - Cover


b - Gasket (Wide Surface On Cam Side)

c - Screws (6)

70625

Installation

1. Install O-ring on pump housing shoulder.




70628

Typical Pump

a - O-ring

2. Turn pump shaft in direction shown to align pump keyway with camshaft key.




Typical Pump and Camshaft End

a - Pump Keyway

b - Camshaft Key


3. Install pump on timing gear cover studs. Tighten hex nuts with washers securely.



Typical Pump Installation

- a** - Studs
- b** - Hex Nuts With Washers

4. Install seawater inlet and outlet hoses. Tighten hose clamps securely.




Typical Pump and Hoses

- a** - Inlet Hose
- b** - Outlet Hose
- c** - Hose Clamps

5. Open seacock, if equipped, or remove plug from seawater inlet hose and reconnect hose. Tighten hose clamps securely.
6. Start engine.
7. Check for leaks.

Seawater Strainer

Exploded View



78157

Typical

- 1 - Drain Plug and Gasket
- 2 - Filter Housing
- 3 - Filter Element
- 4 - O-ring Seal
- 5 - Clear Lens
- 6 - Lens Cover
- 7 - Nozzle (2)
- 8 - Cover Screw with Washer

Removal


⚠ CAUTION

If boat is in water while working on seawater strainer, close seacock, if equipped. If boat is not equipped with a seacock, remove and plug seawater inlet hose to prevent a siphoning action that may occur, allowing seawater to flow from the drain holes or removed hoses and enter the boat.

IMPORTANT: Be certain engine is OFF and cooling system is cold.

1. Models Equipped With A Seacock:


- a. Close seacock (seawater inlet valve), if equipped.



70355

a - Seacock (Seawater inlet valve)

- (1.) Disconnect seawater inlet hose from seawater strainer.




50226

a - Seawater Inlet Hose

b - Seawater Strainer

2. Models Without A Seacock:


- a. If not equipped with seacock, disconnect seawater inlet hose, from seawater strainer inlet.
- b. Quickly plug seawater inlet hose.



70062

- a** - Inlet Hose
- b** - Strainer
- c** - Strainer Inlet
- d** - Suitable Plug

3. Remove seawater outlet hose. Drain into a suitable container.



70062


- a** - Outlet Hose
- b** - Strainer

4. Remove mounting bolts.
5. Remove strainer.

Installation

IMPORTANT: Mount seawater strainer in a vibration-free location. Never mount it on the engine or transmission. Hoses must not be kinked or allowed to come in contact with hot or moving engine or transmission parts.


1. Mount seawater strainer. Ensure the following:
 - Arrow (flow direction) must point towards seawater pump.
 - Tighten mounting bolts securely.



50226

- a** - Strainer
- b** - Arrow
- c** - Mounting Bolt Hole


2. Install seawater inlet and outlet hoses. Use 2 hose clamps on each hose connection. Tighten clamps securely.



50226

- a** - Inlet Hose
- b** - Strainer
- c** - Hose Clamps (2 Each)

3. Check drain plug and lens cover bolts. Tighten securely. Do NOT overtighten cover bolts or cover may warp and leak water into boat.



50226

- a** - Drain Plug
- b** - Lens Cover Bolt

Oil / Power Steering / Transmission Fluid Coolers


General Information

Cooling efficiency of an engine and components is greatly dependent upon heat transfer through the tubes within the coolers (heat exchanger or exchangers, if equipped with more than one). During engine operation, contaminants within the seawater (such as salt, silt or lime) collect on the inside of the tubes, thus reducing heat transfer and greatly decreasing cooler (heat exchanger) efficiency.

It is therefore, recommended that the seawater coolers be cleaned periodically according to Maintenance Schedules chart in SECTION 1B, or whenever decreased cooling efficiency is suspected.

Additionally, inspect cooler hoses and clamps according to Maintenance Schedules chart in SECTION 1B.

Exploded View




78386

- 1** - D4.2L Inboard (MIE) Early Design
- 2** - D2.8L D-Tronic And D4.2L D-Tronic Sterndrive (MCM) Design
- 3** - D2.8L D-Tronic And D4.2L D-Tronic Inboard (MIE) Later Design

Location of Coolers



Refer to the following for location of oil, power steering and transmission fluid coolers.



75297

Typical Sterndrive (MCM) Model

- a** - Fluid Cooler (D4.2L)
- b** - Engine Oil Cooler
- c** - Fluid Cooler (D2.8L)



Typical Inboard (MIE) Model

- a** - Fluid Cooler
- b** - Engine Oil Cooler

Inspection Before Removal

NOTICE
Refer to Cold Weather or Extended Storage, Draining Instructions in SECTION 1B and Precautions in this section, BEFORE proceeding.

1. Drain the seawater system.
2. Remove hose clamp or end cover from INLET end of the appropriate coolers. Refer to Seawater Flow Diagrams.
3. Inspect the passages. Clean if needed.
4. Refit hose or end cover. Torque end cover to specification or securely tighten hose clamp.

Cleaning Without Removal

NOTICE
Refer to Cold Weather or Extended Storage, Draining Instructions in SECTION 1B and Precautions in this section, BEFORE proceeding.

1. Drain the seawater system.
2. **On coolers:**
 - a. Remove hoses from both ends of cooler to be cleaned.
 - b. Temporarily attach a suitable hose to inlet end of cooler and place end of hose in a suitable container to catch water in the following.
 - c. Attach a suitable adaptor to the outlet end of cooler to which a tap water hose may be connected.
 - d. Open tap water faucet and backflush cooler until discharge water is clean.
 - e. Remove temporary hose and adaptor.
3. **On heat exchangers:**
 - a. Remove end covers from section to be cleaned.
 - b. Open tap water faucet and backflush exchanger until discharge water is clean.
 - c. Discontinue backflushing.


Engine Oil Cooler

REMOVAL

NOTICE
Refer to Cold Weather or Extended Storage, Draining Instructions in SECTION 1B and Precautions in this section, BEFORE proceeding.

1. Drain the seawater system.
2. Drain the closed cooling system.
3. Obtain clean, suitable devices and plug hoses in following instructions to avoid loss of engine oil.
4. Mark port and starboard oil hoses to aid in reassembly.
5. Disconnect oil lines from oil cooler fittings (near each end of oil cooler) on heat exchanger. Quickly plug the lines.


NOTE: Components shown removed for visual clarity.



- a** - Engine Oil Cooler / Heat Exchanger
- b** - Starboard Oil Line and Fitting
- c** - Port Oil Line and Fitting

6. Disconnect seawater and closed cooling hoses as required to allow removal of heat exchanger and engine oil cooler.
7. Disconnect turbocharger coolant vent hose from fitting on upper-port side of heat exchanger expansion tank.
8. Remove the two large screw clamps retaining the heat exchanger to the port and starboard brackets.
9. Remove the heat exchanger and engine oil cooler.

NOTE: If the oil cooler is to be replaced, it will be necessary to replace the complete heat exchanger assembly.




74484

Engine Oil Cooler / Heat Exchanger and Related Components

- a** - Hoses
- b** - Clamps
- c** - Coolant Vent Hose Fitting

INSTALLATION


1. Apply a small amount of petroleum jelly on the heat exchanger brackets and hose ends to ease installation.
1. Install the heat exchanger and engine oil cooler.
2. Make all necessary seawater and closed cooling hose connections. Tighten hose clamps securely.



74484

Engine Oil Cooler / Heat Exchanger and Related Components**a** - Hoses**b** - Clamps

3. Unplug and install port and starboard oil lines, as marked upon disassembly, to fittings near each end of oil cooler.
4. Reconnect coolant recovery bottle hose.
5. Install the two large screw clamps retaining the heat exchanger to the port and starboard brackets.
6. Reconnect turbocharger coolant vent hose.



Engine Oil Cooler / Heat Exchanger and Related

- a** - Heat Exchanger / Oil Cooler
- b** - Starboard Oil Line And Fitting
- c** - Port Oil Line And Fitting
- d** - Turbocharger Coolant Vent Hose
- e** - Coolant Recovery Bottle Hose
- f** - Large Screw Clamps

7. Inspect cooler / exchanger passages.

- **If passages are clear:** Reconnect seawater hoses and tighten hose clamps securely.

IMPORTANT: Mercury MerCruiser does not recommend the immersion of oil/power steering/ transmission fluid coolers in cleaning solutions. If backflushing and/or wire brushing of the problem cooler does not satisfactorily clear the passages replacement of the cooler is recommended.

- **If passages are still obstructed:**
 - a. Clean tubes in heat exchanger and coolers by operating a suitable wire brush of the proper size through each tube.



71724

a - Wire Brush, Sized to Fit Passages

- b. Rinse out heat exchanger and cooler tubes with tap water from a hose to remove loosened particles.
- c. Replace unit if it cannot be satisfactorily cleaned. Refer to the following section.

Power Steering

REMOVAL


NOTICE

Refer to Cold Weather or Extended Storage, Draining Instructions in SECTION 1B-Maintenance and Precautions in this section, BEFORE proceeding.

1. Drain the seawater system.
2. Disconnect seawater hoses from fluid cooler.
3. Mark fore and aft fluid hoses to aid in reassembly.

NOTE: Obtain two clean, suitable devices and plug hoses in following instructions to avoid loss of fluid.

4. Using a suitable container to catch excess fluid, disconnect fluid hoses. Plug hoses quickly.
5. Remove fasteners from clamps retaining cooler.
6. Remove cooler with J-clamp.




75594

Typical Power Steering Cooler Installation

- a** - D4.2L D-Tronic Cooler
- b** - Forward Fluid Hose (From Reservoir)
- c** - Aft Fluid Hose (To Pump)
- d** - Seawater Hoses
- e** - J-clamp And Nut
- f** - D2.8L D-Tronic Cooler

INSTALLATION

1. Install J-clamp and cooler onto exhaust manifold stud. Torque to 24 lb-ft (32 Nm).
2. Install connecting seawater hoses. Position fittings as shown and tighten seawater hose clamps.
3. Remove plugs from power steering fluid hoses and connect to fittings as marked on disassembly. Tighten fluid hose clamps securely.

**Typical Power Steering Cooler Installation**

- a** - D4.2L D-Tronic Cooler
- b** - Forward Fluid Hose (From Reservoir)
- c** - Aft Fluid Hose (To Pump)
- d** - Seawater Hose From Heat Exchanger
- e** - Seawater Hose To Exhaust Elbow Or Riser
- f** - J-clamp And Nut
- g** - D2.8L D-Tronic Cooler

4. Refer to SECTION 1B and refill power steering reservoir.
5. Open seacock, or unplug seawater inlet hose and reconnect. Tighten hose clamps securely.
6. Operate the engine briefly to fill the cooler. Check for leaks.
7. Stop the engine.
8. Refill power steering reservoir.

Transmission Fluid Cooler

REMOVAL

NOTICE


Refer to Cold Weather or Extended Storage, Draining Instructions in SECTION 1B and Precautions in this section, BEFORE proceeding.

1. Drain the seawater system.
2. Disconnect seawater hoses from fluid cooler.
3. Mark fore and aft fluid hoses to aid in reassembly.

NOTE: Obtain clean, suitable devices and plug hoses in following instructions to avoid loss of fluid.

4. Using a suitable container to catch excess fluid, disconnect fluid hoses. Plug hoses quickly.
5. Remove fasteners from clamps retaining cooler.
6. Remove transmission fluid cooler.
7. If cooler is to be replaced, note position of transmission fluid hose connectors. Remove and retain the connectors.

NOTE: Some early model fluid hose connectors are 90 degree elbow connectors. Later models have straight connectors.




Typical Transmission Fluid Cooler

- a** - Fluid Cooler
- b** - Seawater Hoses
- c** - Fluid Hoses
- d** - Retaining Clamps
- e** - Fasteners
- f** - Connectors (90 Degree Elbow Shown, Straight Not Shown)

Installation


1. Coat threads of fluid hose connectors with Loctite Pipe Sealant with Teflon and install on cooler in positions noted on disassembly.



Typical Transmission Fluid Cooler Shown

- a** - Transmission Fluid Cooler
- b** - Connectors

2. Install transmission fluid cooler on intake/exhaust manifold or bracket. Secure with clamps and fasteners. Torque manifold nuts to 32 Nm (24 lb-ft).
3. Connect transmission fluid hoses to cooler in positions noted on disassembly. Tighten hose clamps securely.



73522

Typical Transmission Fluid Cooler Installation Shown

- a** - Fluid Cooler
- b** - Seawater Hoses
- c** - Fluid Hoses
- d** - Retaining Clamps
- e** - Hex Nut and Washer
- f** - Connectors

4. Open seacock if equipped, or unplug seawater inlet hose and reconnect. Tighten hose clamps securely.
5. Start engine. Operate briefly to fill cooler.
6. Check for leaks.
7. Stop engine.

IMPORTANT: Use only ATF (Automatic Transmission Fluid), such as Dexron III.

8. Quickly check transmission fluid level. Fluid should be between MIN and MAX marks on dipstick.
9. Fill transmission to proper level.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

COOLING SYSTEMS

Section 6B - Closed Cooling System

Table of Contents

Specifications	6B-4	Draining Closed Cooling System	6B-17
Capacity	6B-4	Cleaning Closed Cooling System	6B-19
Thermostats	6B-4	Using A Cleaner	6B-19
Pressure Cap	6B-4	Heat Exchanger and Cooler Cleaning	6B-19
Coolant	6B-4	Flushing The Closed Cooling System	6B-20
Torque Specifications	6B-5	Filling The Closed Cooling System	6B-21
Lubricants / Sealants / Adhesives	6B-5	Thermostats	6B-22
Tools	6B-5	Removal	6B-22
Special Tools	6B-5	Testing	6B-23
Tools	6B-5	Installation	6B-25
Diagrams and Exploded Views	6B-6	Heat Exchanger	6B-26
Coolant Flow Diagram	6B-6	Testing	6B-26
Heat Exchanger / Coolant Tank		Repair	6B-26
and Related Components	6B-8	Removal	6B-27
Engine Water Circulating Pump	6B-10	Cleaning and Inspection	6B-28
Checking Coolant Level	6B-11	Installation	6B-29
Testing Closed Cooling System	6B-12	Water Circulating Pump	6B-31
Testing Coolant for Alkalinity	6B-12	Removal	6B-31
Pressure Testing System	6B-12	Cleaning and Inspection	6B-31
Testing for Cylinder Head		Installation	6B-32
Gasket Leak	6B-14	Coolant Manifold	6B-33
Testing Pressure Cap	6B-15	Corrosion Protection	6B-33
Coolant Change Interval	6B-17	Auxiliary Hot Water Heater Connections	6B-33
Coolant Requirement	6B-17		

THIS PAGE IS INTENTIONALLY BLANK

NOTICE

For instructions on Cleaning Seawater Strainer, Flushing Seawater Cooling System or Draining Seawater Section refer to SECTION 1B - Maintenance.

NOTICE

For information on other heat exchangers cooled by seawater refer to SECTION 6A - Seawater Cooling System, Oil / Power Steering / Transmission Fluid Coolers.

NOTICE

For information on Oil Filter Head and Oil Thermostat refer to SECTION 3A - Engine Mechanical, Oil Thermostat.

Specifications

Capacity

Description	Liters (U.S. Quarts) Approximate
D2.8L D-Tronic	11 (11-2/3)
D4.2L D-Tronic	13 (13-3/4)

Thermostats

Description	Operating Temperature
D2.8L D-Tronic	1 at 70 Degrees C (160 Degrees F), and 1 at 82 Degrees C (180 Degrees F)
D4.2L D-Tronic	

IMPORTANT: It is not necessary to position either thermostat in a certain location within the thermostat housing. Ensure however, that one of each specified operating temperature is present.

Pressure Cap

Description	Operating Pressure
D2.8L D-Tronic	97 kPa (14 psi) ¹
D4.2L D-Tronic	

¹ Must hold rated pressure for 30 seconds without going below 76 kPa (11 psi).

Coolant

IMPORTANT: Use only Mercury MerCruiser specified coolant. Use of other coolant may cause fouling of the heat exchangers, and overheating of the engine.

These specified, premixed formulas **require no mixing with water** or other additives. The low silicate **ethylene glycol, special additives, and purified water** formulas prevent silicate gelling which can restrict engine cooling passages. They provide protection down to -38 degrees C (-33 degrees F).

Description	Part Number
Premixed Marine Engine Coolant	92-813054A2
Fleetguard Compleat (Product 91-50663 with DCA4 additive)	Obtain Locally

Torque Specifications

Description	Nm	lb-in.	lb-ft
Engine Water Circulating Pump Screw	30		22
Thermostat Housing Cover	16	132	
Heat Exchanger Bracket / Thermostat Housing	30		22
Water Pump Pulley Screw	8.5	72	
Water Manifold	10	84	
Upper Heat Exchanger End Cover Bolt	14-15	120 - 132	
Lower Heat Exchanger End Cover Bolt	12-14	108 - 120	

Lubricants / Sealants / Adhesives

Description	Part Number
2-4-C Marine Lubricant With Teflon	92-802859A1
Special Lubricant 101	92-802865A1
Perfect Seal	92-34227--1
Loctite Master Gasket	92-12564--2
Loctite Pipe Sealant with Teflon	Obtain Locally

Tools

Special Tools


Description	Part Number
Cooling System Cleaner	91-814825
Fleetguard Restore - CC2610	Obtain Locally

Tools

Description	Part Number
Pink Litmus Paper	Obtain Locally
Thermostat Tester	Obtain Locally
Heat Exchanger Cleaning Brush	Obtain Locally
Cooling System Pressure Tester	Obtain Locally

Diagrams and Exploded Views

Coolant Flow Diagram




75351

Closed Cooling Circuit (Fresh Water / Coolant)

Coolant Flow Diagram (continued)

- g** - Circulating Pump - Closed Coolant
- h** - Engine Block - Upper Section Of Liners
- i** - Cylinder Heads
- j** - Water Manifold
- k** - Turbocharger
- l** - Exhaust Manifold
- m** - Thermostat Housing And Thermostats
- n** - Heat Exchanger

Heat Exchanger / Coolant Tank and Related Components



78273


78387

Heat Exchanger / Coolant Tank and Related Components (continued)

- 1** - Screw, M6x78 mm (5)
- 2** - Lockwasher (6)
- 3** - Hose Clamp
- 4** - Thermostat Housing To Heat Exchanger Hose
- 5** - Engine Lifting Eye
- 6** - Screw, M10 x 35 mm (1-3/8 in.) Long (3)
- 7** - Lockwasher (3)
- 8** - Port Side Heat Exchanger Bracket
- 9** - Water Circulating Pump Bypass Hose
- 10** - Thermostat Housing And Starboard Heat Exchanger Bracket
- 11** - Hose Clamp
- 12** - Gasket
- 13** - Thermostats - 2 Different Temperatures
- 14** - Thermostat Housing Cover
- 15** - Stud, M6 x 75 mm (3 in.) Long (1)
- 16** - Lockwasher
- 17** - Engine Cover Mount Threaded Spacer/ Nut (1)
- 18** - Thermostat Housing To Heat Exchanger Hose
- 19** - Screw with Lockwasher, M8 x 100 mm (3-15/16 in.) Long (2)
- 20** - Screw with Lockwasher, M8 x 60 mm x (2-23/64 in.) Long (2)
- 21** - Pressure Cap
- 22** - Heat Exchanger / Coolant Tank
- 23** - Hose Clamp (2)
- 24** - Circulating Pump-to-Heat Exchanger Hose
- 25** - Drain Screw and Sealing Washer
- 26** - Engine Model Decal
- 27** - Heat Exchanger To Bracket Clamps (2)
- 28** - Engine Water Circulating Pump

Description		Nm	lb-in.	lb-ft
A	Heat Exchanger Bracket / Thermostat Housing Bolt	30		22
B	Thermostat Housing Cover Bolt	16	132	
C	Heat Exchanger End Cover Bolt	Upper	14-15	120 - 132
D	Heat Exchanger End Cover Bolt	Lower	12-14	108 - 120

Engine Water Circulating Pump



73948

- 1 - Water Circulating Pump
- 2 - Screws With Washers
- 3 - Gasket
- 4 - Pulley
- 5 - Screws With Washers

Description		Nm	lb-in.	lb-ft
A	Engine Water Circulating Pump Screw	30		22
B	Water Pump Pulley Screw	8.5	72	

Checking Coolant Level

CAUTION

Alcohol or methanol base antifreeze or plain water are not recommended for use in cooling system at any time.

Before starting engine each day, check to ensure that coolant is visible in coolant recovery bottle.

WARNING

Do NOT remove coolant pressure cap when the engine is hot - coolant may discharge violently, causing severe burns. Let the engine cool before removing the pressure cap.

CAUTION

If the coolant should get extremely low and the engine very hot, let the engine cool for approximately 15 minutes before adding coolant; then, with the engine operating, add coolant slowly. Adding cold coolant to a hot engine may crack the cylinder head or crankcase. Never use only water in the closed coolant section.

If coolant is not visible, check coolant (fresh water) section of cooling system, including coolant recovery system, for leaks and repair as necessary. Refill coolant section with required coolant solution.

If coolant is visible, start engine and operate until it reaches normal operating temperature, then recheck coolant level in coolant recovery bottle. Coolant level MUST BE between the Add and Full marks (on front of bottle). If level is low, remove fill cap from coolant recovery bottle and add needed amount of required coolant. If frequent additions of coolant are required, check closed cooling section for leaks.

Occasionally, check to ensure that coolant recovery system is functioning properly by removing pressure cap from heat exchanger and checking the coolant level. **After engine has cooled down, turn pressure cap 1/4 turn to allow any pressure to escape slowly, then push down and turn cap all-the-way off.** Coolant level should be up to bottom of heat exchanger filler neck. If low, inspect entire closed cooling coolant (fresh water) section (especially coolant recovery system) for leaks and repair, as necessary.

IMPORTANT: When reinstalling pressure cap, tighten it until it contacts locking tabs on filler neck.

Testing Closed Cooling System

Testing Coolant for Alkalinity

WARNING

Allow engine to cool before removing pressure cap as sudden loss of pressure could cause hot coolant to boil and discharge violently. After engine has cooled, turn cap 1/4 turn to allow any pressure to escape slowly, then push down and turn cap all the way off.

Coolant in closed cooling (fresh water) section should be changed every two years. Checked for alkalinity at least once between change intervals. To check coolant for alkalinity, proceed as follows:

1. Obtain pink litmus paper from a local supplier (drug store, pet shop, etc.).
2. Remove pressure cap from heat exchanger and insert one end of litmus paper into coolant.
 - a. **If pink litmus paper turns blue**, coolant is alkaline and need not be replaced.
 - b. **If pink litmus paper remains pink**, coolant is not alkaline and **MUST BE REPLACED**. Refer to Changing Coolant.

Pressure Testing System

WARNING

Allow engine to cool before removing pressure cap. Sudden loss of pressure could cause hot coolant to boil and discharge violently. After engine has cooled, turn cap 1/4 turn to allow any pressure to escape slowly, then push down and turn cap all the way off.

If coolant section of closed cooled system is suspected of leaking or not holding sufficient pressure, and no visible signs of leakage can be found, perform the following test:

1. Remove pressure cap from heat exchanger or reservoir.
2. Clean and inspect pressure cap to ensure that cap is maintaining proper pressure in system. Refer to Testing Pressure Cap.
3. Clean and inspect fill neck:
 - a. Clean inside of filler neck to remove any deposits or debris.
 - b. Examine lower inside sealing surface for nicks or other damage. Surface must be perfectly smooth to achieve a good seal between it and rubber seal on cap.
 - c. Check locking cams on sides of filler neck to ensure that they are not bent or damaged. If locking cams are bent or damaged, pressure cap will not hold the proper pressure.
4. Adjust coolant level in fresh water section to 25 mm (1 in.) below filler neck.

5. Attach an automotive-type cooling system pressure tester to filler neck and pressurize closed cooling system to amount specified in following chart, based on pressure cap rating for your engine.

Pressure Cap Rating	Amount of Pressure Applied to Closed Cooling System
97 kPa (14 psi)	137 kPa (20 psi)

6. Observe gauge reading for approximately two minutes; pressure should not drop during this time. If pressure drops, proceed with the following steps until leakage is found.
7. While maintaining specified pressure on closed cooling system, visually inspect external portion of cooling system (hoses, gaskets, drain plugs, core plugs, circulating pump seal, etc.) for leakage. Also listen closely for bubbling or hissing, as they usually are a sure indication of a leak.
8. Refer to Testing Heat Exchanger in this section and test as outlined.
9. If no leakage could be found in above steps, engine is leaking internally, and it probably is due to one or more of the following:
- Loose cylinder head bolts or damaged gasket
 - Loose turbocharger bolts or damaged gasket
 - Loose exhaust elbow or damaged gasket
 - Cracked or porous cylinder head or block
 - Cracked or porous exhaust manifold
10. Proceed as follows until location of internal leak is found:
- a. Start engine. Pressurize system to previously specified amount and observe pressure gauge on tester. If needle in gauge vibrates, compression or combustion is leaking into closed cooled section from a leak in the combustion chamber. Stop engine.
 - b. Remove glow plugs (one at a time) from cylinders and examine for presence of coolant. A glow plug that is perfectly clean or milky appearing is a sure indication of a leak.
 - c. Drain oil from engine and examine for presence of coolant. Oil usually will be milky if coolant is present.
 - d. If coolant is present, remove engine from boat and remove the oil pan. With engine in the upright position, pressurize closed cooled section to previously specified amount and examine internal surfaces of engine to locate leak.
 - e. If no leaks can be found in above steps, entire engine must be disassembled and inspected for leaks.

Testing for Cylinder Head Gasket Leak

A leaking head gasket will cause combustion gas to be forced into the cooling system. The mixture of coolant and tiny air bubbles is a poor heat conductor and will overheat an engine quickly. Compression tests or cooling system pressure check normally will not detect the leak because the test pressure is far below the combustion pressures which cause the leak. An effective test follows.

IMPORTANT: Operate boat in lake for this test. It is best to operate the engine at or above cruising speed during this test. Usually a failed head gasket will not cause the engine to overheat below cruising speed.

1. Install a clear plastic hose between the reservoir and coolant recovery bottle. Use a 61-91 cm (2-3 ft) long hose for this test.
2. Route this hose so a U is formed.
3. Put enough coolant into hose to fill the center 10-13 cm (4 or 5 in.) of the U.
4. Start the engine and observe the U while the engine is operating.
 - a. **During Idle and Warm-Up:** Some coolant and/or air will leave the reservoir.
 - b. **During Cruising Speed (2800 - 3200 rpm):** Coolant and/or air leaving the reservoir should stop after approximately five minutes of operation at a steady rpm. A leaking head gasket will produce air bubbling through the U, going to the coolant recovery bottle. The frequency and size of the bubbles will depend on the size of the leak.
 - c. **At Higher Speeds (3200 - 3600 rpm):** Normal operation is the same as described in b. above. A failed head gasket will cause the bubbles to come faster and may be accompanied by violent, intermittent bursts of coolant.

It is important not to confuse normal warm-up expansion with a failed head gasket. Normal warm-up produces an intermittent flow of coolant which will stop within approximately five minutes at a steady rpm. A head gasket leak will not stop because the one thing that marks a failed head gasket is the continued passage of air. This may be accompanied by violent, intermittent bursts of coolant leaving the reservoir. If coolant continues to flow (not in violent, intermittent bursts) from the reservoir at cruising speed, something other than the head gasket is causing the engine to overheat.


Testing Pressure Cap

Pressure cap is designed to maintain a pressure of approximately its rated capacity (refer to Specifications) in closed cooled section once engine has attained operating temperature. Cap should be cleaned, inspected and pressure-tested at regular tune-up intervals or whenever cap is suspected of maintaining improper pressure.

⚠ WARNING

Allow engine to cool before removing pressure cap. Sudden loss of pressure could cause hot coolant to boil and discharge violently. After engine has cooled, turn cap 1/4 turn to allow any pressure to escape slowly, then push down and turn cap all the way off.

1. Carefully remove pressure cap from reservoir or heat exchanger.
2. Wash cap with clean water to remove any deposits or debris from sealing surfaces.
3. Inspect gasket (if used) and rubber seal on cap for tears, cuts, cracks or other signs of deterioration.
4. Replace gasket, if damaged, or entire cap if rubber seal is damaged.




72714

- a** - Rubber Seal
- b** - Gasket
- c** - Locking Tabs (1 Not Shown)

5. Ensure that locking tabs on cap are not bent or damaged.


6. Examine lower inside sealing surface in filler neck to ensure that it is perfectly smooth and free of debris. Also, inspect cam lock flanges on sides of filler neck to ensure that they are not bent.



72715

- a** - Filler Neck
b - Cam Lock Flange

7. Using a cooling system pressure tester similar to one shown, test cap to ensure that it releases at proper pressure and does not leak. Refer to instructions which accompany tester for correct test procedure. Cap must relieve pressure at 97 kPa (14 psi), and must hold rated pressure for 30 seconds without going below 76 kPa (11 psi). Replace cap if measured values are less than specified.



72716

Typical Pressure Cap Tester

8. Reinstall cap on heat exchanger.

Coolant Change Interval

Refer to SECTION 1B.

Coolant Requirement

Refer to SECTION 1B.

Draining Closed Cooling System


IMPORTANT: Observe the following:

- Insert a wire into drain holes to ensure that foreign material is not obstructing the drain holes.
- Ensure that the engine is as level as possible to promote complete draining of cooling system.
- If engine will be exposed to freezing temperatures, make sure closed cooling section is filled with an ethylene glycol antifreeze and water solution properly mixed to protect engine to lowest temperature to which it will be exposed.
- Closed cooling section must be kept filled year round with required coolant. Do NOT use Propylene Glycol antifreeze in the closed cooling section of the engine.

⚠ WARNING

Allow engine to cool before removing pressure cap. Sudden loss of pressure could cause hot coolant to boil and discharge violently causing severe injury.

1. Allow engine to cool. After engine has cooled, turn pressure cap 1/4 turn to allow any pressure to escape slowly, then push down and turn cap all the way off of heat exchanger/coolant tank.
2. Drain coolant from intake/exhaust manifold by opening the drain valve.
3. Drain coolant from the engine block by opening the drain valve.
4. After coolant has drained completely, securely close drain valves.
5. Empty coolant recovery bottle.
6. If required, clean system. Refer to Cleaning Closed Cooling System.
7. Fill system with required coolant.



Typical Sterndrive (MCM) Shown, Inboard (MIE) Similar

- a** - Pressure Cap
- b** - Intake/Exhaust Manifold Drain Valve
- c** - Engine Block Drain Valve
- d** - Coolant Recovery Bottle

Cleaning Closed Cooling System

The closed cooling section of the cooling system should be cleaned according to the Maintenance Schedules in SECTION 1B, or whenever decreased cooling efficiency is experienced.

A good grade automotive cooling system cleaning solution may be used to remove rust, scale or other foreign material. Always follow manufacturer's instructions for the cleaner.

If closed cooling system is extremely dirty, a pressure flushing device may be used to flush out remaining deposits. Flushing should be done in direction opposite normal coolant flow to allow water to get behind deposits and force them out. Refer to instructions which accompany flushing device for proper hookup and flushing procedure.

Using A Cleaner

1. Drain closed cooling system.

NOTE: Properly dispose of old coolant.

2. Add one liter of Cooling System Cleaner (92-814825) or add Fleetguard Restore CC2610 to cooling system following the manufacturer's instructions.
3. Fill the cooling system with tap water to within 13 - 19 mm (1/2 - 3/4 in.) of bottom of filler neck.
4. Install pressure cap.

NOTE: During system cleaning leave auxiliary heater, if equipped, connected to engine. Otherwise, the engine will be contaminated when the heater is reconnected.

5. Operate the engine in open water at wide open throttle at normal operating temperature for a minimum of thirty minutes to circulate cleaner.
6. Stop the engine and after cool down, drain cleaner from closed cooling system.
7. Flush the closed cooling system. Refer to Flushing The Closed Cooling System.

NOTE: Properly dispose of contaminated cleaner.

Heat Exchanger and Cooler Cleaning

1. Clean tubes in heat exchanger and coolers by running a suitable wire brush through each tube.



71724


a - Wire Brush, Sized to Fit Passages

2. Rinse out heat exchanger and cooler tubes with tap water from a hose to remove loosened particles.
3. Replace unit if it cannot be satisfactorily cleaned.

Flushing The Closed Cooling System

1. Remove thermostat housing cover.
2. Remove the thermostats and temporarily install housing cover. Torque housing cover screws to 16 Nm (132 lb-in.).
3. Remove large hex plug from exhaust manifold rear cover. Then, install an adapter to this opening, suitable for connecting a tap water hose.

NOTE: On engines equipped with auxiliary hot water heater, remove heater hose from fitting (in place of hex plug).



70192

Hex Plug Drain (Similar With Hot Water Connection)

4. Attach hose from water source to adapter.
5. **On engines with Auxiliary Hot Water Heater:** Proceed to step 7.
6. **On engines without Auxiliary Hot Water Heater:** Open cylinder block drain valves.
7. Run tap water through system until discharge water is clean.

NOTE: Catch expelled water in a suitable container and dispose of properly.

8. Shut off water tap.
9. Remove tap water hose and adapter.
10. Install large hex plug, with new sealing washer, on intercooler, or reconnect heater hose.
11. Close cylinder block drain valves if previously opened.
12. Install thermostats in housing.
13. Position a new thermostat housing gasket on housing. Torque housing cover screws to 16 Nm (132 lb-in.).
14. Fill system with required coolant.

NOTICE
For instructions on Flushing Seawater Section refer to SECTION 1B - Maintenance.

Filling The Closed Cooling System

1. Remove pressure cap from heat exchanger and fill section with specified coolant until coolant level is 25 mm (1 in.) below filler neck.

CAUTION

Avoid seawater pickup pump impeller damage and subsequent overheating damage to sterndrive unit. DO NOT operate engine without water being supplied to seawater pickup pump.

2. With pressure cap off, start engine and operate at fast idle (1500-1800 rpm). Add recommended coolant solution to heat exchanger, as required, to maintain coolant level 25 mm (1 in.) below filler neck.
3. After engine has reached normal operating temperature (thermostats are fully open), and coolant level remains constant, fill heat exchanger to bottom of filler neck.
4. Observe engine temperature gauge to make sure that engine operating temperature is normal.

IMPORTANT: If gauge indicates excessive temperature, stop engine immediately and examine for cause.


5. Install pressure cap on heat exchanger.
6. Remove cap from coolant recovery reservoir. Fill to FULL mark with recommended coolant solution. Reinstall cap.
7. With engine still operating, check hose connections, fittings and gaskets for leaks. Repeat Step 4.

Thermostats

Removal

1. Refer to Draining Instructions as previously outlined, and drain coolant.
2. Remove closed cooling system hose between thermostat housing and heat exchanger.
3. Remove thermostat housing cover screws and washers, including the cover spacer.

NOTE: Components shown removed for visual clarity only. It is not necessary to remove the housing itself.



73973


- a** - Hose and Clamps
- b** - Thermostat Housing Cover
- c** - Screws and Washers (5)
- d** - Stud
- e** - Washer
- f** - Spacer (For Engine Cover)

4. Remove housing cover.

IMPORTANT: Do NOT allow old gasket material or debris inside, which might foul cooling system passages.

5. Remove old gasket.

6. Remove thermostats.




73973

- a** - Thermostat Housing Cover
- b** - Thermostat(s)
- c** - Gasket

Testing


1. Clean thermostats in soap and water to remove any deposits or debris.
2. Inspect thermostats for corrosion or other visible damage.
3. If thermostats are suspected of producing insufficient engine temperature, check thermostats for leaks by holding them up to lighted background. Light leaking around the thermostat valve indicates that thermostat is not closing completely and should be replaced. A few light leaks at one or two points around the valve perimeter is acceptable.



72717

- a** - Perimeter of Valve

4. Following the manufacturers recommendations for usage, check opening and closing temperature. The thermostat opens when it drops off of thread using a tester. Thermostat must open at specified temperature stamped on thermostat.



72675

Typical Thermostat Tester In Use

- a** - Thermometer
- b** - Nylon String
- c** - Thermostat

IMPORTANT: Refer to specifications and note that the two thermostats have different opening temperatures.

5. Continue to heat water until a temperature 14 degrees C (25 degrees F) above opening temperature is obtained. Thermostat valve must be completely OPEN at this temperature.
6. Unplug tester and allow water to cool to a temperature 5 degrees C (10 degrees F) below specified opening temperature. The thermostat must be completely CLOSED at this temperature.
7. Always replace a thermostat that fails to meet all of the preceding tests with one of the same temperature specification.


Installation

NOTE: Always install the thermostats before the gasket. Regardless of position, ensure that 1 thermostat is a 70 degrees C (160 degrees F) thermostat and 1 is an 82 degrees C (180 degrees F) thermostat.

1. Install thermostats.

NOTE: Always use a new thermostat housing gasket.

2. Apply Perfect Seal to both sides of the new thermostat housing gasket.
3. Install the new gasket.
4. Install thermostat housing cover.
5. Torque the housing cover screws and nut evenly to 16 Nm (132 lb-in.), in a diagonal pattern.



- a** - Housing Cover
- b** - Thermostat (2 Different Temperatures)
- c** - Gasket
- d** - Screw With Washer (5)
- e** - Engine Cover Mount Threaded Spacer/ Nut (1)

6. Connect hoses.
7. Fill the closed cooling system.
8. Open seacock if equipped, or unplug and reconnect seawater inlet hose.
9. Start and operate the engine.
10. Check for leaks.
11. Check for normal engine operating temperatures.

78274

Heat Exchanger

NOTICE
Refer to Cold Weather or Extended Storage, Draining Instructions in SECTION 1B and Precautions in this section, BEFORE proceeding.

Testing

INTERNAL LEAK

An internal leak will cause coolant to go into the seawater system when pressure is put on the closed cooling circuit.

1. Remove top seawater (inlet) hose from the exchanger. Do NOT drain the exchanger.
2. Pressurize the closed cooling circuit to 137 kPa (20 psi) with a radiator tester.
3. If seawater begins to flow from the fitting there is a leak.

BLOCKAGE

IMPORTANT: Seawater flows THROUGH the tubes in the exchanger. Closed cooling coolant flows AROUND the tubes.

1. Remove end caps and inspect for any blockage in the seawater circuit (weeds, etc.).
2. Remove closed cooling circuit hoses and inspect the tubes just inside the fittings. Because the complete heat exchanger cannot be inspected, the heat exchanger should be replaced if blockage is suspected.

Repair

IMPORTANT: Braze with BCUP 2 rod or silver solder. Care must be taken not to melt other joints during repair.

1. Internal leaks can be repaired by brazing shut the ends of the leaking tube. This is only a temporary fix because usually another tube will start leaking after a short period of time and this also causes a reduction in cooling capacity. Do NOT close more than three tubes.
2. Fittings and drains that have been broken off the heat exchanger can be reattached by brazing.

Removal

NOTICE


Refer to Cold Weather or Extended Storage, Draining Instructions in SECTION 1B and Precautions in this section, BEFORE proceeding.

1. Drain the seawater system.
2. Drain the closed cooling system.

NOTE: In the following instructions, obtain clean, suitable devices and plug hoses to avoid loss of engine oil.

3. Disconnect oil lines from oil cooler fittings near each end of oil cooler on heat exchanger. Quickly plug lines.

NOTE: Components shown removed for visual clarity.




75301

- a - Heat Exchanger With Oil Cooler
- b - Starboard Oil Line And Fitting
- c - Port Oil Line And Fitting

4. Disconnect seawater and closed cooling hoses as required to allow removal of heat exchanger.
5. Disconnect turbocharger coolant vent hose from fitting on upper-port side of the heat exchanger.
6. Remove the two large screw clamps retaining the heat exchanger to the port and starboard brackets.

7. Remove combination heat exchanger and engine oil cooler.



74484

Heat Exchanger / Engine Oil Cooler and Related Components

- a** - Hoses
- b** - Clamps
- c** - Coolant Vent Hose Fitting


8. If either the closed cooling section or oil cooler portion of the heat exchanger are defective, it will be necessary to replace the complete assembly.

Cleaning and Inspection

1. Clean water passages in heat exchanger by inserting a suitable sized wire brush on a proper length rod into each passage.
2. Put on safety glasses.
3. Blow loose particles out of, and from between, water passages using compressed air.
4. Provided the passages for seawater are acceptably clean and free of debris, clean the exterior of the heat exchanger with soap and water. Scrub gently with a brush as required.
5. Visually inspect all exterior surfaces and water passages for cracks or damage. Repair or replace as required.

Installation

1. Apply a small amount of petroleum jelly on the brackets and hose ends to ease installation.
2. Install the combination heat exchanger and engine oil cooler.
3. Make all necessary seawater and closed cooling hose connections.




74484


Engine Oil Cooler / Heat Exchanger and Related Components

- a** - Hoses
- b** - Clamps

4. Unplug and install port and starboard oil lines to fittings near each end of oil cooler.




- a** - Engine Oil Cooler
- b** - Starboard Oil Line And Fitting
- c** - Port Oil Line And Fitting



5. Install the two large screw clamps retaining the heat exchanger to the port and starboard brackets.

NOTE: There is a new style clamp to be used on the D2.8L D-Tronics that uses an automatic spring tensioner. This clamp will replace the earlier clamps.

6. Reconnect coolant recovery bottle hose.
7. Reconnect turbocharger coolant vent hose.



74487

- a** - Heat Exchanger / Oil Cooler
- b** - Large Screw Clamps, Or Automatic Tension Clamps (Not Shown)
- c** - Coolant Recovery Bottle Hose
- d** - Turbocharger Coolant Vent Hose

8. Fill the closed cooling system.
9. Open seacock if equipped, or unplug and reconnect seawater inlet hose.
10. Pre-lube the turbocharger and engine.
11. Start the engine. Operate briefly to fill oil cooler
12. Check for leaks.
13. Stop the engine.
14. Check engine oil level. Fill to proper level with specified oil.


Water Circulating Pump

NOTICE
Refer to Cold Weather or Extended Storage, Draining Instructions in SECTION 1B and Precautions in this section, BEFORE proceeding.

IMPORTANT: Water circulating pump on D4.2L engines is a larger volume pump and does NOT interchange with circulating pumps on D2.8L engines.

Removal

1. Drain the seawater system.
2. Drain the closed cooling system.
3. Remove the heat exchanger.
4. Remove alternator drive belts.
5. Disconnect water circulating pump hoses.
6. Remove the pump.
7. Discard gasket.



78273

Typical


- a** - Water Circulating Pump
- b** - Gasket
- c** - Nuts

Cleaning and Inspection

1. Remove all traces of old gasket material from water circulating pump body.
2. Remove all traces of old gasket material from engine block do NOT allow debris inside, which might foul cooling system passages.
3. Inspect pump for blockage, cracks, sand holes, corrosion or other damage. Inspect pump impeller for cracks and erosion. Replace complete pump, if any damage exists.
4. Check impeller shaft and bearings for excessive side play. If play can be felt, replace complete pump.
5. Inspect pump pulley for bends, cracks, corrosion, or other damage. Inspect pulley for runout. Replace complete pump, if pulley is damaged or untrue.

Installation

1. Apply Loctite Master Gasket to both sides of new gasket and position on engine block.
2. Install water circulating pump.
3. Connect water circulating pump hoses.
4. Torque nuts evenly to 30 Nm (22 lb-ft), in a diagonal pattern.



Typical

- a** - Water Circulating Pump
- b** - Gasket
- c** - Nuts

5. Install the heat exchanger.
6. Install and tension drive belts.

NOTE: On all models, check belt tension by depressing upper strand of belt at center point between pulleys. Belt must not deflect more than 5 mm (3/16 in.).

7. Fill the closed cooling system.
8. Unplug and connect seawater inlet hose or open the seacock.
9. Ensure seawater pickup pump is supplied cooling water.
10. Start the engine.
11. Test the engine operation - observe temperature gauge and check for leaks.
12. Stop the engine.

IMPORTANT: Use only specified coolant.

13. Check engine coolant level. Fill to proper level.


Coolant Manifold

Refer to SECTION 3A.

Corrosion Protection

Refer to SECTION 1B.

Auxiliary Hot Water Heater Connections



Auxiliary Hot Water Heater Adaptor Kit On A Typical Engine

- a** - Allen Head Plug, Rear Cover
- b** - Sealing Washer
- c** - Hose Coupler Fitting
- d** - Sealing Washer
- e** - Plug, On Closed Coolant Tank/Heat Exchanger
- f** - Sealing Washer
- g** - Hose Coupler Fitting
- h** - Sealing Washer
- i** - Supply Hose
- j** - Return Hose
- k** - Heater

THIS PAGE IS INTENTIONALLY BLANK

INTAKE AND EXHAUST SYSTEM

Section 7A - Intercooler

Table of Contents

Torque Specifications	7A-3	Removal	7A-8
Lubricants / Sealants / Adhesives	7A-3	Disassembly	7A-11
Exploded Views	7A-4	Cleaning and Inspection	7A-13
D2.8L Intercooler	7A-4	Assembly	7A-14
D4.2L Intercooler	7A-6	Installation	7A-17
Intercooler	7A-8		

THIS PAGE IS INTENTIONALLY BLANK


Torque Specifications

Description		Nm	lb-in.	lb-ft
Intake Duct Screw				
	Rear - (All Models)	10	84	
	Side (D21.8L D-Tronic Only)	10	84	
End Cover Screw		40		30
Anode Plug		13	120	
Intercooler Housing Nut		32		24

Lubricants / Sealants / Adhesives

Description	Part Number
Loctite 514	92-75505-1
Perfect Seal	92-34227--1

D2.8L Intercooler



75619


D2.8L Intercooler (continued)

- 1** - Radiator Insert (Heat Exchanger Core)
- 2** - Intercooler Housing
- 3** - Side Intake Duct
- 4** - Rear Intake Duct
- 5** - Front Cover
- 6** - Rear Cover
- 7** - O-ring (4 On Engines Equipped With Plate, 3 On Others)
- 8** - Plate (If Equipped)
- 9** - Anode
- 10** - Anode Plug With Sealing Washer
- 11** - Drain Plug With Sealing Washer
- 12** - Rear Intake Duct Screw and Washer
- 13** - Gasket
- 14** - Intake Duct Screw
- 15** - End Cover Screw
- 16** - Nut and Washer

Description	Part Number
A Loctite 514	Obtain Locally

Description	Nm	lb-in.	lb-ft
A	Intake Duct Screw		
	Rear - (All Models)	10	84
	Side (D21.8L D-Tronic Only)	10	84
B	End Cover Screw	40	30
C	Anode Plug	13	120
D	Intercooler Housing Nut	32	24

D4.2L Intercooler



70904

D4.2L Intercooler (continued)

- 1** - Radiator Insert (Heat Exchanger Core)
- 2** - Intercooler Housing
- 3** - Intake Duct
- 4** - Gasket (6)
- 5** - Front Cover
- 6** - Rear Cover
- 7** - O-ring (4 On Engines Equipped With Plate, 3 On Others)
- 8** - Plate (If Equipped)
- 9** - Anode
- 10** - Anode Plug With Sealing Washer
- 11** - Drain Plug With Sealing Washer (Not Shown In This View)
- 12** - Intake Duct Screw (4)
- 13** - Cover Screws
- 14** - Stud (2 Lengths)
- 15** - Engine Cover Spacer
- 16** - Intercooler Housing Nut

LUBRICANT / SEALANTS / ADHESIVES

Description	Part Number
A Loctite 514	Obtain Locally


TORQUE

Description	Nm	lb-in.	lb-ft
A	Intake Duct Screw		
	Rear - (All Models)	10	84
	Side (D21.8L D-Tronic Only)	10	84
B	End Cover Screw	40	30
C	Anode Plug	13	120
D	Intercooler Housing Nut	32	24

Intercooler

Removal

14. Remove engine cover.
15. Drain the seawater system.
16. Disconnect MAP/IAT sensor. Remove J-clamp for coolant vent hose.




75582

- a** - MAP/IAT Sensor Connector
b - J-clamp

17. On Sterndrive Engines:

- a. Remove sterndrive shift bracket.
- b. Remove engine lifting eye bracket from intercooler end cover.




75300

Sterndrive (MCM) Engine

- a** - Shift Bracket
b - Engine Lifting Eye Bracket

18. Remove drain plug and sealing washer from rear cover of intercooler.




75621

Sterndrive Shown (Inboard Similar)

- a** - Intercooler
- b** - Rear Cover
- c** - Drain Plug With Sealing Washer

19. Remove hollow bolt and sealing washers from wastegate valve pressure line.




70916

Sterndrive Shown (Inboard Similar)

- a** - Wastegate Valve Pressure Line
- b** - Hollow Bolt With Sealing Washers


20. Loosen hose clamps and disconnect seawater hoses from intercooler-to-heat exchanger and from seawater pump-to-intercooler.



75298

- a** - Seawater Pump To Intercooler Hose
b - Intercooler To Heat Exchanger Hose

21. Loosen hose clamp at turbocharger as shown.




70918


Typical

- a** - Hose
b - Hose Clamp
c - Turbocharger

22. Remove hex nuts retaining intercooler housing flanges to exhaust / intake manifold studs.



70916



70921

Typical

- a** - Intercooler/Intercooler Housing
- b** - Exhaust/Intake Manifold
- c** - Hex Nuts

CAUTION

Remove **ALL** washers from studs **BEFORE** lifting off intercooler and intercooler housing. Do **NOT** drop anything into intake ports or severe engine damage could occur.


23. Using a magnet to remove all lockwashers from studs where hex nuts were removed.
24. Remove intercooler and housing.

Disassembly

CAUTION

Whenever intercooler is disassembled or radiator insert removed from intercooler **ALL** O-ring seals must be replaced to prevent seawater from leaking into intake air duct and manifold which could result in severe engine damage.

1. Remove intake duct from rear of intercooler.




70931

D4.2L Shown (D2.8L Similar)

- a** - Intercooler Housing (Side Intake Duct on D2.8L)
- b** - Intake Duct

2. Remove rear cover. Note position of O-ring, and if equipped, plate and second O-ring position.




70906

Typical

- a** - Intercooler Housing
- b** - Rear Cover
- c** - O-ring (Two - If Equipped)
- d** - Plate


3. Remove front cover and O-ring.



70907

- a** - Intercooler Housing
- b** - Front Cover
- c** - O-ring

4. Slide radiator insert out front of intercooler housing. Note position of O-ring.




70905

- a** - Radiator Insert
- b** - O-Ring

Cleaning and Inspection

1. Clean old gasket material and sealant from flanges. Do NOT nick or gouge the surfaces which would cause intake or water leaks.
2. **On D2.8L Engines:** Depending on service requirement and/or to allow for a complete cleaning and inspection, separate (remove) side intake duct from intercooler housing. Clean old gasket material and sealant from flanges. Do NOT nick or gouge the surfaces which would cause intake or water leaks.



75619

D2.8L Engine Intercooler Housing and Intake Duct

- a** - Side Intake Duct
- b** - Intercooler Housing

3. Use a 4.4 mm (11/64 in.) diameter by 610 mm (24 in.) long rod to clean out radiator insert tubes, or take to a radiator shop for cleaning.
4. Inspect each part for cracks or other damage which would render it unserviceable.
5. Refer to SECTION 1B - and check anodes.
6. Clean and paint exterior surfaces as required to prevent corrosion.


IMPORTANT: Be careful not to drop anything into intake ports.

7. Clean old gasket material from manifold.

Assembly

IMPORTANT: Do NOT roll or twist O-ring(s) when installing.

1. Install O-ring on radiator insert against front flange.




70925


Typical Radiator Insert Shown

- a** - Radiator Insert (Front Flange)
- b** - O-ring

2. Install radiator insert into intercooler housing. Align insert passages as shown.





D4.2L D-Tronic



D2.8L D-Tronic

- a** - Housing
- b** - Radiator Insert
- c** - Alignment Reference Mark

3. Place O-ring into groove of front cover. Fasten to housing using 4 allen-head screws and wave washers. Torque to 40 Nm (30 lb-ft).




70908

Typical

- a** - Front Cover
- b** - O-ring
- c** - Allen-Head Screws And Wave Washers

IMPORTANT: Do NOT roll or twist O-ring(s) when installing.

4. Install O-ring on rear of intercooler housing.




70927

Typical

- a** - O-ring
- b** - Rear of Intercooler Housing

5. **On intercoolers WITHOUT plate and second O-ring:** Proceed to next step.
6. **On intercoolers WITH plate and second O-ring:**
 - a. Install plate on rear of intercooler.
 - b. Install second O-ring around radiator insert and against plate.




70928

Typical

- a** - Plate
- b** - O-ring (Second One Required)

7. Using the 4 allen-head screws and wave washers, install rear cover. Torque to 40 Nm (30 lb-ft). Install drain plug with new sealing washer.




70912

Typical

- a** - Rear Cover
- b** - Drain Plug
- c** - Allen-Head Screws And Wave Washers

8. Apply Loctite 514 sealer on intake duct-to-intercooler housing mating surface. On D2.8L D-Tronic engines apply sealer to side intake duct mating surface.
9. Using 4 allen-head screws and wave washers, install intake duct. Torque to 40 Nm (30 lb-ft).




70929

D4.2L D-Tronic Shown (D2.8L D-Tronic Similar)

- a** - Intercooler Housing (Side Intake Duct On D2.8L Engines)
- b** - Intake Duct (Rear Intake Duct On D2.8L Engines)
- c** - Allen-Head Screws and Wave Washers

10. On D2.8L D-Tronic Engines:

- a. If the side intake duct of the intercooler housing was removed for cleaning and inspection, apply Loctite 514 sealer on mating surfaces.
- b. Assemble using screws with washers. Torque screws to 10 Nm (84 lb-in.).




75619

D2.8L D-Tronic Engine Intercooler Housing and Intake Duct

- a** - Intake Duct
- b** - Intercooler Housing
- c** - Mating Surface
- d** - Allen-Head Screws With Wave Washers

Installation

1. Install new intake port gaskets.




70881


Typical

- a** - Manifold
- b** - Intake Ports
- c** - Intake Port Gaskets

2. Install intercooler housing.
3. Install hex nuts with lockwashers and torque to 32 Nm (24 lb-ft).



70916




70921

Typical

- a** - Intercooler/Intercooler Housing
- b** - Exhaust/Intake Manifold
- c** - Hex Nuts

4. Securely tighten hose clamp at turbocharger-to-intake duct hose as shown.




70918

Typical

- a** - Hose
- b** - Hose Clamp
- c** - Turbocharger
- d** - Intake Duct

5. Connect wastegate valve pressure line using the hollow bolt with two new sealing washers as shown. Tighten securely.




70916

Sterndrive Shown (Inboard Similar)

- a** - Wastegate Valve Pressure Line
- b** - Hollow Bolt With Sealing Washers

6. Install seawater hoses from seawater pump-to-intercooler and from intercooler-to-heat exchanger. Tighten Hose clamps securely.




75298

- a** - Seawater Pump-to-Intercooler Hose
- b** - Intercooler-to-Heat Exchanger Hose

7. On Sterndrive (MCM) Engines:

- a. Install sterndrive shift bracket onto side of intercooler. Tighten screws securely.
- b. Install engine lifting eye bracket onto intercooler end cover. Tighten screws securely.



75300

- a** - Shift Bracket
- b** - Engine Lifting Eye Bracket

8. Install engine cover.

⚠ CAUTION

Do NOT operate an engine without water flowing through seawater pickup pump, as pump impeller may be damaged and subsequent overheating damage to engine, transmission or sterndrive unit may result.

⚠ CAUTION

Watch temperature gauge on dash to ensure that engine does not overheat.

9. Upon first operating engine, after repair or service of intake system and/or intercooler, observe temperature gauge for normal engine operating temperatures, and be certain to check for leaks. Stop engine IMMEDIATELY in the event of leaking or overheating, and repair as needed.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

INTAKE AND EXHAUST SYSTEM

Section 7B - Manifolds, Elbows And Risers

Table of Contents

Torque	7B-3	Locating And Installing The Inboard (MIE)	
Lubricants / Sealants / Adhesives	7B-3	Exhaust System	7B-9
Description	7B-3	Exhaust Pipe - Sterndrive (MCM)	7B-11
Exploded Views	7B-4	Removal	7B-11
Typical Intake / Exhaust Manifold	7B-4	Cleaning	7B-11
Sterndrive (MCM) Exhaust Systems ...	7B-5	Installation	7B-12
Inboard (MIE) Exhaust Systems	7B-6	Intake / Exhaust Manifold	7B-13
Representative View of Complete		Removal	7B-13
Inboard Exhaust System	7B-7	Cleaning and Inspection	7B-14
Locating and Installing The Sterndrive		Installation	7B-15
(MCM) Exhaust System	7B-8		

THIS PAGE IS INTENTIONALLY BLANK

Torque

Description	Nm	lb-in.	lb-ft
Intake / Exhaust Manifold Nuts	32		24
Rear Cover Bolts	40		30
Water Temperature Switch/Sender	13	120	
Exhaust Pipe Bolts (MCM)	30		23
Exhaust Elbow Clamp Nut			

Lubricants / Sealants / Adhesives

Description	Part Number
Loctite 592 Pipe Sealant With Teflon	Obtain Locally

Description


All diesel engines covered in this manual use an exhaust manifold which incorporates air passages for both intake and exhaust in a single unit. Fresh water from the closed cooling system is pumped by the engine water circulating pump through the combined intake and exhaust manifold when the engine is operating.

When reference is made to the exhaust manifold, keep in mind that it includes the intake air passages (or intake manifold).

Additionally, the engines exhaust manifold includes a flange for mounting a turbocharger wastegate and valve assembly.

Exploded Views


Typical Intake / Exhaust Manifold



28085

- 1** - Intake / Exhaust Manifold, With Wastegate Flange
- 2** - Stud
- 3** - Welch Plug
- 4** - Gasket(s)
- 5** - Drain Valve
- 6** - Plug With Washer
- 7** - Cover
- 8** - Plug With Washer, If Equipped
- 9** - Cover Screw With Lock Washer
- 10** - Nut
- 11** - Flange Nut
- 12** - Gasket
- 13** - Turbocharger Flange Nut


Sterndrive (MCM) Exhaust Systems



Typical

- 1 - Exhaust Riser
- 2 - Clamp
- 3 - Gasket
- 4 - Hose Clamps
- 5 - Exhaust Hose
- 6 - Round Exhaust Pipe For Exhaust Riser Equipped Engines (No Water Shutter Assembly)
- 7 - Screw And Lockwasher (4)
- 8 - Wastegate Exhaust Pipe And Gaskets
- 9 - Heat Shield Blanket


Inboard (MIE) Exhaust Systems



- 1** - Exhaust Elbow (Design 1)
- 2** - Connector
- 3** - Plug
- 4** - Clamp
- 5** - Gasket
- 6** - Hose Clamps
- 7** - Short Exhaust Hose (If Equipped)
- 8** - Exhaust Pipe Oval-To-Round Adapter (If Equipped)
- 9** - Wastegate Exhaust Pipe, Gaskets And Hardware
- 10** - Exhaust Elbow (Design 2)
- 11** - Wastegate Exhaust Pipe, Gaskets And Hardware
- 12** - Heat Shield Blanket
- 13** - Exhaust Probe Hole
- 14** - Round To Round Adapter, If Equipped

Representative View of Complete Inboard Exhaust System

NOTE: (Use diagrams for parts identification only.)



73942

Typical

- a** - Exhaust Elbow With Gasket And Clamp
- b** - Hose
- c** - Outlet With Water Shutter And Flapper
- d** - Water Lift Muffler
- e** - Oval-To-Round Adapter (If Equipped)


Locating and Installing The Sterndrive (MCM) Exhaust System

IMPORTANT: It is the responsibility of the boat manufacturer, or installing dealer, to properly locate the engine and install the exhaust system. Improper installation may allow water to enter the exhaust manifolds and combustion chambers and severely damage the engine. Damage caused by water in the engine will not be covered by Mercury MerCruiser Warranty, unless this damage is the result of defective parts.

Determine if an exhaust riser kit or a water lift muffler kit is required, by taking measurements “a” and “b”, with boat at rest in the water and maximum load aboard. Subtract “b” from “a” to find “c”. If “c” is less than specified in chart, an exhaust riser kit must be installed.

The Sterndrive (MCM) engine is equipped with a factory installed exhaust riser. Verify that the riser provides the required dimension “c”, or a distance greater than “c”, as indicated.

Model	“c” = “a” Minus “b”
All Models	“c” Must Be 11 in. (279 mm) or More



74298

Typical Sterndrive (MCM) Engine


- a - From Waterline To Top Of Transom
- b - From Highest Point On Exhaust Elbow To Top Of Transom
- c - From “a” Minus “b”
- d - Waterline At Rest

Locating And Installing The Inboard (MIE) Exhaust System

IMPORTANT: It is the responsibility of the boat manufacturer, or installing dealer, to properly locate the engine and install the exhaust system. Improper installation may allow water to enter the exhaust manifolds and combustion chambers and severely damage the engine. Damage caused by water in the engine will not be covered by Mercury MerCruiser Warranty, unless this damage is the result of defective part(s).

Determine if an exhaust riser kit or a water lift muffler kit is required, by taking measurements "a" and "b", with boat at rest in the water and maximum load aboard. Subtract "b" from "a" to find "c". If "c" is less than specified in chart, an exhaust riser kit or a water lift muffler kit must be installed.

Model	"c" = "a" Minus "b"
All Models	"c" Must Be 279 mm (11 in.) or More



73592


Typical Inboard (MIE) Engine

- a** - From Waterline To Top Of Transom
- b** - From Highest Point On Exhaust Elbow To Top Of Transom
- c** - From "a" minus "b"
- d** - Waterline At Rest

Additional information:

1. If an exhaust riser or a water lift muffler kit is **NOT** required:
 - The exhaust outlet (for routing exhaust to outside of boat) must be located so that a minimum of 13 mm (1/2 in.) per 305 mm (12 in.) downward pitch (drop) exists in the exhaust hose or pipe from the engine exhaust elbow to the outlet.
 - A minimum drop of 100 mm (4 in.) overall is required. (This is an American Boat and Yacht Council recommendation.) The drop must be constant so that a low spot does not exist at any point in the exhaust hose or pipe.
2. Exhaust outlet must be slightly above the water line with boat at rest in the water and a full load aboard.
3. Exhaust outlet should be equipped with an internal shutter to prevent seawater from running back into exhaust system.
4. The use of an exhaust flapper on each outlet also is recommended.


5. System must not cause excessive back pressure when measured at exhaust elbow outlets. Back pressure MUST NOT exceed a 1000 mm (39-1/2 in.) water column, or 76 mm (3 in.) of mercury when measured with a mercury manometer [approximately 10.3 kPa (1-1/2 psi)]. Minimum exhaust hose size is 102 mm (4 in.).



71774

Typical Continuously Sloping Exhaust Line

- a** - Exhaust Elbow
- b** - Measurement - 379 mm (11 in.) Minimum
- c** - Exhaust Hose Or Pipe (Slope to Specifications)
- d** - Muffler
- e** - Exhaust Outlet Internal Shutter
- f** - Exhaust Flapper Valve
- g** - Waterline



71775

Typical Waterlift Muffler Exhaust System

- a** - Exhaust Elbow
- b** - Vent Line [6 mm (1/4 in.)]
- c** - Water Lift Muffler
- d** - Exhaust Hose
- e** - Drain Cock
- f** - Transom
- g** - Waterline


6. An oval-to-round exhaust adaptor (818184T) and tube (32-815529) is available to assist in exhaust connection from the oval turbocharger exhaust elbow to 102 mm (4 in.) round exhaust outlet pipes.

Exhaust Pipe - Sterndrive (MCM)

Removal

IMPORTANT: Engine must be removed to gain access to exhaust pipe. Refer to SECTION 2A for engine removal and installation.

1. Remove the 4 bolts and thick lockwashers retaining the exhaust pipe to the gimbal housing.
2. Remove the exhaust pipe.
3. Remove the O-ring seal and discard.



24841

- a** - Bolts And Thick Lockwashers (4)
b - Exhaust Pipe


Cleaning

IMPORTANT: Exhaust pipe and gimbal housing assembly mating surfaces must be clean and free of nicks and scratches. O-ring must be properly seated in groove, or water and exhaust may leak into boat.

1. Clean the mating surfaces of the exhaust pipe.
2. Clean the mating surfaces of the gimbal housing.

Installation


1. Install new O-ring. Be certain it is seated properly in groove of gimbal housing.



22030

- a** - Mating Surface (Gimbal Housing, Exhaust Pipe Similar)
- b** - O-ring

2. Hold exhaust pipe in position. Install the four thick washers and bolts. Torque evenly in a diagonal pattern to 30 Nm (23 lb-ft).
3. Lubricate the inside of large end of exhaust hose with a soap and water solution. Slide hose over exhaust pipe and install two hose clamps. Tighten hose clamps securely.



24841

- a** - Exhaust Pipe
- b** - Bolts And Thick Lockwashers (4)
- c** - Hose
- d** - Hose Clamps (2)



Intake / Exhaust Manifold

Removal

NOTICE

Refer to Cold Weather or Extended Storage, Draining Instructions in SECTION 1B and Precautions in this section, BEFORE proceeding.


1. Drain seawater cooling system.
2. Drain closed cooling system.
3. Remove heat exchanger assembly.
4. Remove intercooler housing.
5. Remove wastegate and valve.
6. Remove turbocharger.
7. Remove shift bracket, fluid cooler and hoses, if equipped.
8. Loosen hose clamp on rear cover to rear of water manifold strip hose.



Typical

- a** - Exhaust Manifold
- b** - Rear Cover
- c** - Hose Clamp
- d** - Hose, Rear Cover To Rear Of Water Manifold Strip

9. Remove remaining intake / exhaust manifold flange nuts or nuts and lockwashers.



70881

Typical

a - Flange Nuts Or Nuts And Lockwashers

Cleaning and Inspection


1. Clean gasket material from all surfaces and wash parts in solvent.
2. Inspect all parts carefully. Machined surfaces must be clean and free of all marks and deep scratches, or water and exhaust leaks may result.
3. Check water passages for foreign material. Passages must be clean for efficient cooling.
4. If more thorough inspection is desired, pipe plugs may be removed from exhaust manifold and exhaust elbow.

IMPORTANT: If plugs are removed, coat threads with Perfect Seal before reinstalling.

5. Check for cracks.
6. Ensure mating surfaces of cylinder heads are clean and free of all old gasket material.
7. To test manifold body for leaks, block off plates, plugs, or short hoses with plugged ends must be used. One block off plate must have a threaded hole for attaching compressed air hose. Use new gaskets when installing block off plate(s). Apply 276 kPa (40 psi) of air pressure and submerge manifold in water. Air bubbles will indicate a leak.

Installation

1. Install new intake / exhaust manifold gaskets.




70883

Typical

- a** - Manifold Studs
- b** - Gaskets

2. Install intake / exhaust manifold on studs.
3. Position shift bracket, clamps and fluid cooler with hoses, where removed previously.
4. Install intake / exhaust manifold flange nuts or lockwashers and nuts. Torque nuts evenly in a diagonal pattern to 32 Nm (24 lb-ft).
5. Install hose clamp on rear cover-to-rear of manifold strip elbow hose. Tighten securely.



70882

70881

Typical

- a** - Exhaust Manifold
- b** - Rear Cover
- c** - Hose Clamp
- d** - Hose, Rear Cover-To-Rear Manifold Strip
- e** - Manifold Strip
- f** - Flange Nuts or Nuts and Lockwashers

6. Install turbocharger
7. Install wastegate and valve.
8. Install intercooler housing
9. Install heat exchanger assembly.
10. Fill closed cooling system.
11. Start engine. Check for leaks.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

INTAKE / EXHAUST SYSTEM


Section 7C - Turbocharger

Table of Contents

Identification	7C-3	Testing Turbocharger Boost Pressure	7C-9
Turbocharger Specifications	7C-3	Checking Turbine Bearings	
Torque Specifications	7C-4	(Assembled)	7C-10
Lubricants / Sealants / Adhesives	7C-4	Removal	7C-11
Description	7C-5	Disassembly	7C-15
Turbocharger	7C-5	Cleaning	7C-17
Wastegate	7C-5	Inspection	7C-18
Exploded Views	7C-6	Assembly	7C-19
Turbocharger And Related		Installation	7C-21
Components	7C-6	Boost Pressure Control	7C-28
Boost Pressure Control (Wastegate)		Exhaust Pipe	7C-28
Components	7C-8	Valve	7C-31
Turbocharger	7C-9	Wastegate	7C-33

THIS PAGE IS INTENTIONALLY BLANK

Identification



70076

a - Identification Number Location

Turbocharger Specifications

Model		D2.8L D-Tronic	D4.2L D-Tronic
Manufacturer		KKK - Kuhnle, Kopp and Kaush	
Part Number	KKK	K24-2467GxA6.71	K26-2967MxA8.72
	Quicksilver	854212	854128
Maximum turbine shaft axial (end) play		0.15 mm (0.0059 in.)	
Maximum turbine shaft radial (side) play		0.42 mm (0.0165 in.)	
Maximum Boost		100 - 124 kPa (14.5 - 18 psi)	
Engine rpm when boost starts		1600 - 1800	1500 - 1800
Wastegate		Equipped	Equipped

Torque Specifications

Description	lb-ft	Nm
Turbocharger Mounting Nuts	18	24
Clamping Plate Nuts or Screws	22	30
Wastegate-to-Exhaust Manifold Mounting Nuts	18	24
Valve-to-Wastegate Screws	Tighten Securely (Equally, in a diagonal pattern.)	

Lubricants / Sealants / Adhesives

Description	P/N
Loctite 514	92-75505-1
Gasket Sealer	92-72592-1

Description

Turbocharger

All diesel engines covered in this manual are equipped with a turbocharger to boost intake pressure resulting in increased horsepower. In one casing on the turbocharger housing exhaust gases are used to spin the turbine up to 100,000 rpm. The compressor, which is installed on the same shaft but in a separate casing, draws in filtered air, compresses it, and delivers it to the engine through an intake duct and intercooler.

The turbo bearings are lubricated by engine oil.

Coolant from the engine's closed cooling system cools the turbocharger housing, while the exhaust elbow (or exhaust riser) is cooled by seawater flowing through it from the seawater system.

Turbocharger pressure is limited by a boost pressure control valve (commonly called a wastegate) is mounted on the combined exhaust / intake manifold.

Wastegate

When used in combination with the turbocharger a higher torque output even at low engine speeds is obtained and allows the engine a wider operating speed range.


The function of the wastegate is to limit the boost pressure generated by the turbocharger within a controlled tolerance band.

When factory set boost pressure is exceeded, the valve opens and bypasses a part of the exhaust gas flow around the turbine. The resulting reduced mass-flow produces a lower power output. The compressor output is reduced in proportion and the boost pressure falls to the predetermined level. This control process is repeated for each change in engine load.

This allows the use of a smaller turbocharger turbine which provides better acceleration and torque, as boost comes on more rapidly and turbo lag is reduced.

Exploded Views

Turbocharger And Related Components




73941

Turbocharger And Related Components (continued)

- 15** - Turbocharger
- 16** - Gasket
- 17** - Stud (4 x M10x30 mm)
- 18** - Clamp
- 19** - Gasket
- 20** - Sterndrive (MCM) Exhaust Riser (If Equipped)
- 21** - Pipe Plug, 1/4 in. x 18
- 22** - Oil Drain Pipe
- 23** - Hollow Bolt with Sealing Washer
- 24** - Coolant Vent Pipe and Hose
- 25** - Fitting At Water Manifold
- 26** - Seawater Hose Fitting (Cast Into MCM Riser)
- 27** - Turbocharger-to-Intake Duct Hose
- 28** - Hose Clamps
- 29** - Oil Feed Pipe
- 30** - Gasket
- 31** - Spacer
- 32** - O-ring
- 33** - Connector
- 34** - Sealing Washer
- 35** - Turbocharger Support Bracket and Fasteners
- 36** - Plug
- 37** - Inboard (MIE) Exhaust Elbow (Design 1)
- 38** - Inboard (MIE) Exhaust Elbow (Design 2)

Boost Pressure Control (Wastegate) Components



73940

- 1** - Wastegate
- 2** - Wastegate-to-Exhaust Manifold Gasket
- 3** - Typical Inboard Wastegate Exhaust Pipe
- 4** - Gasket (2)
- 5** - Hex Nut and Lockwasher (4)
- 6** - Heat Shield Blanket (For Exhaust Pipe)
- 7** - Boost Pressure Valve
- 8** - Boost Pressure Line
- 9** - Hollow Bolt and Sealing Washers (at Exhaust Manifold)
- 10** - Hollow Bolt and Sealing Washers (at Valve)
- 11** - Typical Sterndrive Wastegate Exhaust Pipe
- 12** - Stud, M8 x 20 mm

Turbocharger

IMPORTANT: Before suspecting the turbocharger for engine operating problems, the fuel injection system and engine mechanicals (valves, camshaft, etc.) must be in good working order.


Testing Turbocharger Boost Pressure

⚠ CAUTION

Safety glasses, gloves and protective clothing should be worn while testing turbocharger boost pressure, to protect against pressurized air being released by a leak or rupture of a hose which could cause injury.

The following should be observed prior to testing:

- Engine should be at normal operating temperature.
 - Engine air cleaner should be clean (or replaced if not clean).
1. Remove plug (screw with sealing washer) from intercooler housing as shown.



Typical


- a** - Plug (Screw With Sealing Washer)
- b** - Intercooler Housing

2. Install a 0-172.4 kPa (0-25 psi) pressure gauge into intercooler where plug was removed in Step 1.
 3. Start engine and watch pressure gauge.
- **On All Engines:** Maximum boost should be between 100 - 124 kPa (14.5 - 18 psi) at 3800 rpm.

Readings LOWER than specified above indicate possible turbocharger problems or boost pressure control system problems, IF no engine problem exists, such as incorrect valve clearance or a blockage in the exhaust system. Refer to appropriate sections in this manual, including Troubleshooting. NO boost pressure would indicate a faulty turbocharger requiring replacement.

Checking Turbine Bearings (Assembled)

1. Refer to the following pages for Turbocharger - Removal and remove exhaust elbow as outlined for your engine.
2. Rotate the turbine impeller by hand to see that it turns smoothly. If not, turbine bearings or impeller problems exist.
3. Using a feeler gauge as shown, check clearance between turbine blades and housing at two locations opposite one another. The difference in the two readings is the radial play. Maximum radial play is 0.42 mm (0.0165 in.).



70984

Checking Turbine Blade Clearance

4. Check if turbine blades are rubbing on housing, replace turbocharger as necessary.


Removal

⚠ WARNING

Always disconnect battery cables from battery before working around electrical system components to prevent injury to yourself or damage to electrical system.

REMOVING EXHAUST ELBOW

1. Disconnect battery cables from battery terminals.
2. Loosen hose clamp and disconnect seawater hose at turbocharger exhaust elbow or riser. Drain seawater into a suitable container.




50665

Typical

- a** - Hose Clamp
- b** - Seawater Hose

3. Loosen exhaust elbow hose clamps as shown.




74298

Sterndrive D4.2L With Riser Shown (All Similar)

- a** - Hose Clamps
- b** - Exhaust Elbow Or Riser
- c** - Exhaust Hose

4. Loosen spring retaining heat-shield blanket around wastegate exhaust pipe.
5. Remove fasteners and lockwashers retaining wastegate exhaust pipe to exhaust elbow.




70986

Typical

- a** - Spring (Blanket Retainer)
- b** - Heat-Shield Blanket
- c** - Hex Nuts With Lockwashers
- d** - Wastegate Exhaust Pipe

6. Make matching marks on exhaust elbow or riser and turbocharger housing, for alignment during reassembly.
7. Loosen exhaust elbow, or riser, clamp. Remove elbow gasket and clamp.




70987

Typical Exhaust Elbow (Similar With Riser)

- a** - Matching Marks
- b** - Clamp
- c** - Exhaust Elbow
- d** - Exhaust Gasket

REMOVING TURBOCHARGER UNIT

1. Drain the closed cooling system.
2. Remove exhaust elbow or riser as previously outlined.
3. Remove lifting eye bracket.




70988

Typical

- a** - Bracket, Lifting Eye
- b** - Screws

4. Remove oil feed pipe and hollow bolt from coolant vent pipe at turbocharger as shown. Loosen air filter and turbocharger-to-intake duct hose clamps.




70989

Typical

- a** - Intake Duct Hose Clamp
- b** - Oil Feed Pipe
- c** - Hollow Bolt, With Sealing Washers
- d** - Air Filter Clamp

5. Remove oil drain pipe on bottom of turbocharger as shown.




70990

- a** - Oil Drain Pipe
b - Hex Nuts With Lockwashers

6. Follow instructions a. or b.:
- a. **On D2.8L D-Tronic Engines:** Remove intake duct from side of intercooler housing. (Refer to SECTION 7A - Intercooler, for instructions on removal.)
 - b. **On D4.2L D-Tronic Engines:** To gain access to turbocharger mounting nuts, remove intake duct from rear of intercooler housing. (Refer to SECTION 7A - Intercooler.)

IMPORTANT: In the event that turbocharger mounting nuts are corroded, or otherwise resist loosening in the following, it may become necessary to completely remove the intercooler housing to gain a more suitable access to mounting nuts. Refer to SECTION 7A - Intercooler, for instructions on removal and installation of the intercooler housing.


7. Remove four mounting nuts retaining turbocharger to exhaust manifold.



70991

- a** - Mounting Nuts (4 Total, Two Not Shown)

8. Remove the two support bracket mounting screws as shown. Remove turbocharger unit.




70992

- a** - Support Bracket
b - Screw With Washer (2)

Disassembly

1. Make matching marks on the exhaust housing and bearing housing to aid alignment in reassembly.
2. Remove 6 hex nuts or hex screws and the 3 clamping plates shown.




70993

- a** - Matching Marks
b - Hex Nuts or Hex Screws (6 Total - 2 Not Shown In This View)
c - Clamping Plates (3 Total - One Not Shown In This View)
d - Exhaust Housing
e - Bearing Housing

NOTE: If the exhaust housing cannot easily be removed by hand, tap on it carefully all around using a plastic hammer and carefully remove it in the following.

IMPORTANT: Be careful not to damage the turbine impeller when removing exhaust housing.


3. Remove exhaust housing as shown.



70994

- a** - Exhaust Housing
- b** - Bearing Housing
- c** - Turbine Impeller

4. Inspect turbine blades. If blades are rubbing against housing, the bearings are worn. Replace turbocharger.



70994

- a** - Turbine
- b** - Inspect (Edges of Blades)

Cleaning

IMPORTANT: Never use a caustic cleaning solution, as it may attack aluminum. Also, never use a wire brush which could damage impeller or mating surfaces.

1. BEFORE cleaning, inspect the disassembled parts for burning, abrasion, carbon deposits, gas and oil leakage.

CAUTION

Always wear safety glasses when using compressed air to protect from hose rupturing or flying debris.

WARNING

When using compressed air to dry components, Do NOT spin turbine, or allow turbine to spin, since no oil is being provided to the bearings and could result in damage to the bearings.


2. Thoroughly clean all the parts with clean diesel fuel, using a soft brush. Dry with compressed air.

Inspection

IMPORTANT: If turbine shaft bearing axial or radial play is excessive, replace turbocharger.

AXIAL (END) PLAY - MEASURING

1. With turbocharger held in vise, attach dial indicator as shown following.
2. Move turbine shaft in direction shown. Maximum axial play (end play) is 0.15 mm (0.0059 in.).
3. If measured value is greater than specified, replace the turbocharger.




70995

a. Measuring Axial (End) Play

RADIAL (SIDE) PLAY - MEASURING

1. With turbocharger held in vise, attach dial indicator as shown in following.
2. Move turbine shaft in direction shown. Maximum radial (side) play is 0.42 mm (0.0165 in.).
3. If measured value is greater than specified, replace the turbocharger.




70996

a. Measuring Radial (Side) Play

Assembly

IMPORTANT: When installing a new turbocharger, it may be necessary to turn intake, bearing, and/or exhaust housings to allow mounting bracket to be bolted to engine.

1. While aligning matching marks, assemble exhaust housing and bearing housing together. Install clamping plates and finger-tighten hex nuts or screws. Do NOT tighten securely at this time.




70993

- a** - Matching Marks
- b** - Exhaust Housing
- c** - Bearing Housing
- d** - Clamping Plates (3 Total - One Not Shown)
- e** - Hex Nuts or Hex Screws (6 Total - 2 Not Shown)

2. Follow instructions a. or b. :

a. On Engines With Gasket Seals:

- (1.) Being certain surfaces are clean of old gasket material or debris, install a new gasket on bearing housing oil drain/spacer flange.
- (2.) Assemble spacer with bracket attached as shown. Tighten hex nuts finger-tight at this time.




70997

- a** - Gasket
- b** - Spacer
- c** - Support Bracket
- d** - Hex Nut


b. On Engines With O-Ring Seals:

- (1.) Being certain surfaces are clean, install a new O-ring in groove of drain/spacer flange where it meets bearing housing of turbocharger.
- (2.) Assemble spacer with bracket attached as shown. Tighten hex nuts finger-tight at this time.



70998

- a** - O-ring (Now Shown In Assembled View)
- b** - Spacer (Oil Drain)
- c** - Support Bracket
- d** - Hex Nut

3. Position exhaust housing and bearing housing (with intake housing) as shown.


70999

- a** - Exhaust Housing
- b** - Bearing Housing (With Intake Housing)

Installation

IMPORTANT: When installing turbocharger, it may be necessary to turn intake and exhaust housings to line up with intake air duct and exhaust manifolds on engine.


1. Using a new gasket, install turbocharger on exhaust manifold as shown. Tighten nuts to 24 Nm (18 lb-ft).



70991

- a** - Gasket, Exhaust Manifold-to-Turbocharger
- b** - Nut (4 Total - 2 Not Shown)

2. Install support bracket screws with washers as shown. Tighten screws securely.




70992

- a** - Screws With Washers
- b** - Support Bracket

3. Tighten the six hex nuts or hex screws (on D4.2L) on clamping plates of exhaust housing-to-bearing housing to 30 Nm (22 lb-ft). (Refer to Step "1" in Assembly section, for location.)


4. **On Engines With Gasket Seal:** Remove hex nuts from spacer (previously installed finger-tight). Using a new gasket, install drain pipe. Tighten hex nuts securely.



71000

- a** - Spacer
- b** - Hex Nuts
- c** - Gasket
- d** - Oil Drain Pipe


5. **On Engines With O-ring Seal:** Remove hex nuts from spacer (previously installed finger-tight). Using a new O-ring positioned in spacer groove, install drain pipe. Tighten hex nuts with lockwashers securely.



70990

- a** - Spacer
- b** - Hex Nuts
- c** - O-ring
- d** - Oil Drain Pipe

6. Using new sealing washers on hollow bolt, install coolant vent line to turbocharger exhaust housing as shown. Tighten hollow bolt securely.
7. Clean sealing surfaces and using a new gasket, install oil feed pipe as shown. Tighten screws securely.
8. Install turbocharger-to-intake duct hose as shown. Tighten hose clamp at turbocharger securely.
9. Fit air filter to turbocharger and tighten clamp securely.



70989


Typical (All Similar)

- a** - Sealing Washers
- b** - Hollow Bolt
- c** - Coolant Vent Line
- d** - Turbocharger Exhaust Housing
- e** - Gasket
- f** - Oil Feed Pipe
- g** - Screw (2)
- h** - Air Filter
- i** - Hose Clamp

IMPORTANT: If it became necessary to remove the entire intercooler housing from the intake/exhaust manifold during disassembly (to gain better access to turbocharger mounting nuts) refer to **SECTION 7A - Intercooler**, at this time for proper installation.

10. Clean sealing flanges of intercooler housing and intake duct. Do NOT nick or gouge the surfaces.

- a. Apply Loctite 514 sealer to intake duct flange on intercooler as shown.




70931

D4.2L Shown (D2.8L Similar)

- a** - Intercooler Housing
b - Intake Duct
c - Flange (Apply Sealer Here)

11. Install intake duct on intercooler as shown. Torque four allen-head screws with wave washers to 10 Nm (7 lb-ft).


NOTE: Intercooler shown removed for visual clarity only.



70929

- a** - Intake Duct
b - Intercooler Housing
c - Screw With Wave Washer

12. Install lifting eye bracket as shown. Tighten screws securely.




70988

Typical

- a** - Bracket, Lifting Eye
- b** - Screws With Washers

13. As shown, tighten turbocharger-to-intake duct hose clamp securely.




70918

Typical

- a** - Hose
- b** - Hose Clamp
- c** - Turbocharger
- d** - Intake Duct

14. Install exhaust elbow, or riser, using new gaskets on exhaust elbow and wastegate exhaust pipe flange as shown. Align studs on elbow, or riser, with holes in wastegate exhaust pipe. Simultaneously, align with exhaust pipe. Tighten exhaust elbow clamp securely.


15. Install hex nuts and washers on wastegate exhaust pipe. Tighten fasteners securely and wrap with heat shield blanket. Fasten spring to retain blanket.



Typical Without Riser

- a** - Gasket, Exhaust Elbow
- b** - Gasket, Wastegate Exhaust Pipe To Elbow, Or Riser
- c** - Exhaust Elbow
- d** - Wastegate Exhaust Pipe
- e** - Clamp, Exhaust Elbow
- f** - Hex Nut
- g** - Heat Shield Blanket
- h** - Spring

16. Install seawater hose from fluid cooler-to-exhaust elbow, or riser if equipped. Tighten hose clamp securely.
17. Position exhaust hose as shown. Tighten hose clamps securely.



75297

Typical Riser Installation

- a** - Exhaust Riser
 - b** - Seawater Hose From Fluid Cooler
 - c** - Clamp, Seawater Hose
 - d** - Exhaust Hose
 - e** - Clamp, Exhaust Hose
 - f** - Exhaust Pipe
18. Fill closed cooling system at this time according to instructions in SECTION 6B - Closed Cooling System, Filling Closed Cooling System.
 19. Connect battery cables to battery by FIRST installing positive (+) battery cable end on positive (+) battery terminal. Tighten clamp securely. THEN install negative (-) battery cable end on negative (-) battery terminal. Tighten clamp securely.
 20. Start engine and check for leaks.
 21. Test turbocharger boost pressure as previously outlined.

Boost Pressure Control


⚠ WARNING

Always disconnect battery cables from battery before working around electrical system components to prevent injury to yourself or damage to electrical system.

Exhaust Pipe

INSPECTION

1. Loosen spring retaining heat shield blanket around wastegate exhaust pipe as shown.




71002

Typical Assembly Shown

- a** - Retaining Spring
 - b** - Blanket, Heat Shield
 - c** - Wastegate Exhaust Pipe
 - d** - Gasket
2. Visually examine pipe and convolutions for signs of cracking or leakage. Also, examine gaskets for signs of leakage. Repair as needed. (Refer to Removal if required.)

REMOVAL

1. Remove exhaust elbow.
2. Remove two remaining hex nuts, or screws and lockwashers on wastegate exhaust pipe as shown.



71004

Typical Pipe Shown

- a** - Hex Nut or Screws, With Lockwashers (2)
- b** - Wastegate Exhaust Pipe
- c** - Wastegate


3. Remove wastegate exhaust pipe.

CLEANING

1. Clean old gasket material from wastegate mating surfaces and pipe (if to be reused), being careful not to distort pipe or crack it. Do NOT allow debris to enter wastegate opening.

INSTALLATION

1. Install new gasket on wastegate flange.
2. Using hex nuts or screws, with lockwashers, install wastegate exhaust pipe. Tighten fasteners securely.



71004

Typical


- a** - Gasket
- b** - Wastegate Exhaust Pipe
- c** - Hex Nuts With Lockwashers

3. Install turbocharger exhaust elbow. Refer to Turbocharger - Installation as previously outlined, and accomplish appropriate instructions regarding installation of exhaust elbow or riser.

Valve

REMOVAL

1. Remove the two hollow bolt with sealing washers from pressure line on bottom of intercooler housing as shown.
2. Remove the two hollow bolt with sealing washers from pressure line on valve as shown.
3. Remove pressure line.




75297

Typical

- a** - Hollow Bolts
- b** - Sealing Washers (2 Each)
- c** - Pressure Line
- d** - Intercooler Housing
- e** - Wastegate
- f** - Valve

4. Remove screws and washers retaining valve to wastegate.
5. Remove the valve.



70983

Typical

- a** - Screws With Washers (3 Total - Two Not Shown)
- b** - Valve
- c** - Wastegate


INSTALLATION

1. Position pressure line fitting on valve toward front of engine and install on wastegate using allen-head screws and washers. In equal amounts, tighten screws securely.
2. Install pressure line on valve using hollow bolt with new sealing washers. Finger-tighten.
3. Install hollow bolt with new sealing washers on pressure line at exhaust manifold. Finger-tighten.
4. Tighten both hollow bolts securely. Do NOT overtighten.
5. Start engine and check for leaks.
6. Test turbocharger boost pressure as previously outlined.

Wastegate

REMOVAL

1. Drain closed cooling system.
2. Remove the exhaust elbow.
3. Remove the wastegate exhaust pipe.
4. Remove the wastegate valve.
5. Remove the four fasteners with lockwashers retaining wastegate to exhaust manifold.




71005

Typical

- a** - Hex Nuts Or Screws, With Lockwashers (4)
- b** - Wastegate
- c** - Exhaust Manifold

CLEANING

1. Clean all traces of old gasket material from exhaust manifold flange.




71006

2. Clean old gasket material from wastegate.

INSTALLATION

1. Using a new gasket install wastegate on exhaust manifold as shown. Securely tighten the four fasteners with lockwashers.
2. Install the wastegate valve.
3. Install the wastegate exhaust pipe.
4. Install the exhaust elbow or riser.



71005

Typical

- a** - Wastegate
- b** - Gasket
- c** - Hex Nuts Or Screws, With Lockwashers (4)

5. Start the engine and check for leaks.
6. Test turbocharger boost pressure.

THIS PAGE IS INTENTIONALLY BLANK

THIS PAGE IS INTENTIONALLY BLANK

DRIVES

Section 8A - ZF / Hurth Transmissions



Table of Contents

Identification	8A-3	Transmission Fluid Level	8A-8
Specifications	8A-4	Checking	8A-8
Operating Specifications	8A-4	Filling	8A-9
Ratios and Part Numbers	8A-4	Changing	8A-9
Fluid Specifications	8A-4	Transmission Removal	8A-12
Torque	8A-5	Transmission Inspection	8A-13
Tools	8A-5	Transmission Installation	8A-13
Lubricants / Sealants / Adhesives	8A-5	Shift Control And Cables	8A-15
Important Information	8A-6	Transmission Shift Lever And Shift	
Engine	8A-6	Cable Bracket	8A-15
Transmission	8A-6	Shift Cable Installation and	
Propeller	8A-6	Adjustment	8A-16
Transmission / Propeller Rotation	8A-7	Pressure And Temperature Tests	8A-21
		Transmission Repair	8A-21

THIS PAGE IS INTENTIONALLY BLANK

Identification

The transmission identification plate is located on the top rear of the transmission.



77626

Typical ZF / Hurth Transmission Identification Plate

a - Serial Number And Gear Ratio

Specifications

Operating Specifications

Description	Specification	
Shifting Pressure At 2000 rpm	21.5-23.5 bar (312-341 psi)	
Operating Temperature	54-79 degrees C (130-175 degrees F)	
Temperature Switch Settings + / – 10 degrees	Open	Close
	87.8 degrees C (190 degrees F)	110 degrees C (230 degrees F)

Ratios and Part Numbers

630A

Ratio (Normal)	ZF / Hurth Model Number	Mercury Marine Part Number
1.5:1	HSW630A	863744T2
2.0:1		863744T3
2.5:1		863744T4
2.7:1		863744T5

630V

Ratio (Normal)	ZF / Hurth Model Number	Mercury Marine Part Number
1.55:1	HSW630V	863745T2
2.0:1		863745T3
2.5:1		863745T4

¹Ratio may be rounded off in some cases.

Fluid Specifications

NOTICE
Unit Of Measurement: Liters (U.S. Quarts) All capacities are approximate fluid measures.

NOTE: Use dipstick to determine fluid exact level.

Model	Capacity	Fluid Type
630A	4.0 (4-1/2)	Dexron III Automatic Transmission Fluid
630V	4.0 (4-1/2)	

Torque

Description	Nm	lb-in.	lb-ft
Transmission Housing Halves Bolts and Nuts	49		36
Control Block-To-Housing	25		18
Output Flange	18		14
Mounts	61		45
Transmission To Flywheel Housing			

Tools

Description	Part Number
Thermometer [(3/8-NPT, Thread -18 to -132°C (0-270°F)]	Obtain Locally
Pressure Gauge (0-500 psi), (1/8-NPT)	

Lubricants / Sealants / Adhesives

Description	Part Number
Quicksilver Engine Coupler Spline Grease	92-816391A4
Quicksilver Liquid Neoprene	92-25711--3
Loctite Type A	Obtain Locally
Loctite 515	

Important Information

Engine

All current production engines are left hand rotation. Engine rotation is described when observed from the rear of the engine (transmission end) looking forward (water pump end).

Installed angle of Inboard (MIE) engine should not exceed a maximum of 18 degrees with respect to the water line.

Transmission

Transmission gear ratio is marked on transmission identification plate, which is located on the top of transmission. Transmission rotation is described when viewed from the rear of transmission.



- Do NOT start or crank engine without fluid in transmission.
- Use only recommended fluid in transmission.
- Except in an emergency, never shift transmission at engine speeds above 1000 rpm.
- Free wheeling of one propeller (in a twin engine boat) at trolling speeds will not cause damage to the transmission; however, boat operation above trolling speed should be avoided. Ensure that proper fluid level exists before free wheeling propeller.
- Always replace fluid cooler and hoses after a transmission failure or prior to installing a new or rebuilt transmission. Metallic particles from a failure tend to collect in the cooler and hoses and will gradually flow back into the fluid system and damage transmission.
- Always use specified fluid cooler, hoses and fittings.

Propeller

Propeller rotation is described when observed from the rear of the boat (stern) looking forward (bow end). The term left-hand (LH) refers to rotation in the counterclockwise (CCW) direction. The term right-hand (RH) refers to rotation in the clockwise (CW) direction. A LH propeller will move the boat forward when rotated counterclockwise. A RH propeller will move the boat forward when rotated clockwise.


Transmission / Propeller Rotation

The ZF / Hurth transmissions are full power reversing transmissions, allowing a standard LH rotation engine to be used for both propeller rotations. Propeller rotation is determined by shift cable attachment at the remote control. Use correct rotation propeller and shift cable hook up for direction desired.




25506

Hurth 630A or 800A - 8° Down-Angle Transmissions



72959



72959

Hurth 630V - V-Drive Transmissions

- a** - Direction Of Shift Lever Engagement (Toward Flywheel)
- b** - Engine/Transmission Input Shaft Rotation Direction (LH)
- c** - Transmission Output/Propeller Shaft Rotation Direction (LH)
- d** - Direction Of Shift Lever Engagement (Away From Flywheel)
- e** - Transmission Output/Propeller Shaft Rotation Direction (RH)
- f** - Transmission Output/Propeller Shaft Rotation Direction (LH As Viewed At Propeller)
- g** - Transmission Output/Propeller Shaft Rotation Direction (RH As Viewed At The Propeller)

Transmission Fluid

IMPORTANT: Use only specified transmission fluid.

IMPORTANT: The fluid level dipstick is located on the port side of transmission.

Checking Level

TRANSMISSION WARM

The transmission should be at operating temperature 54-79 degrees C (130-175 degrees F) to get an accurate fluid level reading. Fluid will expand when heated. Fluid will drain back from the cooler. Expansion and drain-back can significantly affect fluid level.

IMPORTANT: Fluid level must be checked immediately after engine shut-down to prevent an incorrect reading. Fluid drains back into the transmission from the cooler and cooler lines.

1. When the transmission is at operating temperature, place selector lever in NEUTRAL.
2. Shut off engine.
3. Remove dipstick and wipe clean.

IMPORTANT: Do not screw dipstick in; press it firmly in and remove.

4. Immediately insert clean dipstick, remove and read fluid level.
5. Add or remove fluid as necessary until the fluid is at the required mark.

TRANSMISSION COLD

NOTE: For ease of checking the fluid prior to engine start-up, a cold fluid level mark can be made. To find the cold fluid level mark, the fluid level must first be set according to the warm fluid level checking procedure.


1. Let the boat sit overnight. Insert clean dipstick and read level.
2. Put a mark on the dipstick at the cold fluid level.

NOTE: You can use the new mark to check the fluid level when cold. If fluid level adjustment is needed, add fluid to the new mark.

Filling

If transmission fluid level is low, fill with specified transmission fluid.

1. Remove dipstick.
2. Fill transmission through dipstick tube.
3. Replace dipstick and recheck level.




77564

a - Dipstick Tube


Changing

1. Clean the exterior of the transmission around the fluid filter assembly.
2. Use a 6 mm allen wrench and remove the fluid filter assembly from the transmission by turning counterclockwise and pulling at the same time.



27666

3. **630V Only:** Remove the drain plug from the transmission and allow the fluid to drain. Reinstall the drain plug and tighten securely.




73013

a - Drain Plug (630V Only)


4. **630A Only:** Push the hose of a suction pump through the suction pipe and down to the bottom of the housing and remove the fluid.

NOTE: The maximum outside diameter of the suction hose is 16 mm (5/8 in.).



71043


5. Remove and discard the filter element and the O-rings.
6. Coat new O-rings with transmission fluid.
7. Install new O-rings and filter element.



50975

a - Filter Element
b - O-ring
c - O-ring

8. Install the fluid filter assembly in the transmission cavity by turning clockwise and pushing at the same time.



27662

9. Fill the transmission with specified fluid.
10. Check the fluid level.

Transmission Removal

1. Disconnect negative battery cable.
2. If required, drain transmission fluid.

NOTE: Fluid cooler should be removed with transmission.

3. Disconnect seawater hoses from transmission fluid cooler.
4. Remove fluid cooler and lines from bracket.
5. Disconnect shift cable from transmission.
6. Disconnect wires from neutral start safety switch.
7. Disconnect wires from transmission fluid temperature switch.
8. Loosen trunnion clamping fasteners on engine mounts (port and starboard).
9. Remove coupling nuts and bolts and separate propeller shaft flange from transmission output flange.
10. Remove the four rear engine mount-to-engine bed fasteners and hardware.
11. Support rear part of engine using a suitable hoist or wooden blocks under flywheel housing.
12. Support transmission with a hoist or by other suitable means through the lifting eye on the transmission case.
13. Remove port and starboard rear mount brackets (with base and trunnion) from transmission.


CAUTION

Avoid damage to transmission input shaft or engine coupler. Make sure transmission is completely supported before removing hardware attaching transmission to flywheel housing.

14. Remove all hardware attaching transmission to flywheel housing.
15. Move transmission straight back and away from engine to completely disengage splines on input shaft.
16. Carefully lift out transmission.
17. Remove bolts and locknuts and remove transmission.

Transmission Installation


1. Apply Engine Coupler Spline Grease to transmission input shaft splines and engine drive plate splines.



71044

a - Input Shaft

2. Using a suitable hoist, position transmission in boat and align transmission splines with drive plate splines.
3. Slide transmission into place and secure with attaching hardware. Torque transmission to flywheel housing fasteners to 61 Nm (45 lb-ft). Remove hoist.
4. Install rear mount brackets to transmission. Torque fasteners and hardware to 61 Nm (45 lb-ft).
5. Using hoist, raise engine and transmission to remove blocks (if employed). Lower assembly to engine bed. Securely tighten the four rear engine mount to engine bed fasteners with hardware. Relieve hoist tension.




72720

a - Engine Mount To Engine Bed Fastener Location (4), 2 On Each Side

6. Install transmission fluid cooler and hoses. Torque hose fittings at cooler and transmission housing to 34 Nm (25 lb-ft).

7. Connect seawater hoses to transmission fluid cooler and tighten hose clamps securely.
8. Connect wires to neutral safety switch and to audio warning temperature switch. Coat connections on neutral safety switch with Liquid Neoprene.
9. Connect wires to neutral start safety switch.
10. Connect wires to transmission fluid temperature switch.



50686

- a** - Neutral Safety Switch
b - Audio Warning Temperature Switch

⚠ CAUTION

Improper shift cable connection and adjustment can cause premature clutch failure.

11. Connect and adjust shift cables. Refer to Shift Cable Installation And Adjustment.
12. Refer to SECTION 2B and check engine final alignment.
13. After final engine and coupler alignment has been properly set (with boat in the water), connect propeller shaft coupler-to-transmission output flange with bolts, lockwashers and nuts. Torque to 68 Nm (50 lb-ft).

IMPORTANT: Be certain to torque trunnion clamping fasteners on engine mounts (port and starboard) which were loosened during removal.


IMPORTANT: All coupler bolts must be Metric Grade 10.9 (SAE Grade 8) or better, with a shoulder (grip length) long enough to pass through the face mating plane of couplers.

14. Fill transmission. Refer to specifications and Filling.
15. Connect negative battery cable. Tighten clamp securely.
16. Check for leaks and check fluid level after first engine start-up.

Shift Control And Cables

Transmission Shift Lever And Shift Cable Bracket

1. The shift lever has two holes as illustrated. Ensure that the shift cable anchor stud is installed in the top hole when using Quicksilver Remote Control cables.




77520

- a** - Shift Lever
b - Shift Cable Anchor Stud Location (For Quicksilver Shift Cables)

2. **On bracket with two anchor location holes:** Ensure that anchor stud is installed in the hole marked "630."

⚠ WARNING

Avoid serious personal injury or property damage caused by improper shifting. Anchor stud for shift cable must be installed in the correct hole when using bracket with two anchor location holes.





71020

Shift Cable Bracket - Anchor Stud Position Shown for 630 Transmission

- a** - Shift Cable Bracket
b - Shift Cable Anchor Stud
c - Bracket To Transmission Fasteners

Shift Cable Installation And Adjustment

IMPORTANT: Ensure that shift lever is positioned approximately 10 degrees aft of vertical as shown when in the neutral detent position. Also, ensure that the distance between studs in the following is set at 181 mm (7-1/8 in.). If necessary, loosen clamping bolt and position lever so that dimension "c" is as shown when in the neutral detent position, and retighten clamping bolt.



Typical ZF / Hurth Transmission Shown


- a** - Shift Lever
- b** - Shift Lever In Neutral Detent
- c** - Dimension Between Studs - 181 mm (7-1/8 in.)
- d** - Clamping Bolt

CAUTION

Avoid severe transmission damage. All ZF / Hurth Transmissions require Standard Left-Hand rotation engines. NEVER connect a ZF / Hurth Transmission to a Right-Hand rotation engine.

IMPORTANT: Transmission propeller rotation is determined by the shift cable installation in the remote control.

- **Right-hand Propeller Rotation** - Control cable will have to be installed in remote control so that cable end will move in direction "A" when shift handle is placed in the forward position.
- **Left-hand Propeller Rotation** - Control cable will have to be installed in remote control so that cable end will move in direction "B" when shift handle is placed in the forward position.




23242

IMPORTANT: When installing shift cables, ensure that cables are routed to avoid sharp bends and/or contact with moving parts. Do NOT fasten any items to shift cables.

NOTE: On models with other than Quicksilver shift cables refer to the shift cable manufacturer's instructions.


1. Place remote control shift lever and transmission shift lever in neutral position.
2. Remove nuts and washers from shift cable attaching studs.
3. Locate center of remote control and control shift cable play (backlash), as follows:
 - a. Ensure that remote control is in neutral position.
 - b. Push in on control cable end with enough pressure to remove play and mark position "a" on tube.
 - c. Pull out on control cable end with enough effort to remove play and mark position "b" on tube.
 - d. Measure distance between marks "a" and "b," and mark position "c," halfway between marks "a" and "b."



4. Center cable-end play, then adjust cable barrel to align holes in barrel and in cable end guide with attaching points on transmission.
5. Temporarily install shift cable. Do NOT secure at this time.

IMPORTANT: Transmission is fully in gear when shift lever comes to a stop, in either direction.

6. Place remote control shift lever in forward gear position. Ensure transmission is fully in gear, as follows:
 - a. Hold shift lever in position.
 - b. Carefully slide shift cable off of anchor points.
 - c. Attempt to move shift lever further.
 - d. Temporarily install shift cable. Do NOT secure at this time.
7. Place remote control shift lever in reverse gear position. Again ensure transmission is fully in gear as follows:
 - a. Hold shift lever in position.
 - b. Carefully slide shift cable off of anchor points.
 - c. Attempt to move shift lever further.
 - d. Temporarily install shift cable. Do NOT secure at this time.
8. Follow instructions a. or b. :
 - a. If transmission shift lever will position properly in one gear, but not in the other, re-check shift cable adjustment.
 - b. If transmission shift lever will not position properly in both gears, move transmission shift lever stud from top hole in shift lever to bottom hole and recheck for proper positioning. If proper positioning is still not obtained, the remote control does not provide sufficient shift cable travel and must be adjusted, repaired or replaced. Refer to manufacturer's instructions.




50228

- a** - Shift Lever Stud (In Bottom Hole, If Required)
b - Lever, In Neutral Detent, Must Be Approximately 10 Degrees Of Vertical
c - Shift Lever Top Hole


9. Install nut and washer to cable end guide stud. Tighten until contact, then loosen 1/2 turn.
10. Install nut and washer to cable barrel stud. Tighten until contact, then loosen 1/2 turn.

NOTE: To change cable approach direction on single or dual station installations, only the spacer/bushings have to be switched to the opposite stud. The studs are identical.




Typical Single Cable Installation - Forward Approach

- a** - Cable End Guide
- b** - Locknut and Washer
- c** - Spacer (Fits Over Bushings)
- d** - Bushing
- e** - Cable Barrel
- f** - Spacers (Fits Over Stud)
- g** - Cable Barrel Stud
- h** - Cable End Guide Stud




Typical Single Cable Installation - Rear Approach

- a** - Cable End Guide
- b** - Locknut And Washer
- c** - Spacer (Fits Over Bushings)
- d** - Bushing
- e** - Cable Barrel
- f** - Cable Barrel Stud
- g** - Cable End Guide Stud



Typical Dual Cable Installation- Forward Approach

- a** - Cable End Guide
- a** - Cable End Guide
- b** - Locknut And Washer
- c** - Spacer (Fits Over Bushings)
- d** - Bushing
- e** - Cable Barrel
- f** - Spacers (Fits Over Stud)
- g** - Cable Barrel Stud
- h** - Cable End Guide Stud




Typical Dual Cable Installation- Rear Approach

- a** - Cable End Guide
- b** - Locknut And Washer
- c** - Spacer (Fits Over Bushings)
- d** - Bushing
- e** - Cable Barrel
- f** - Spacers (Fits Over Stud)
- g** - Cable Barrel Stud
- h** - Cable End Guide Stud

Pressure And Temperature Tests

1. Remove pressure service port plug from Port A.
2. Connect a pressure gauge to Port A.
3. Remove temperature sender and install thermocouple at Port B.



50686

a - Port A
b - Port B

4. Ensure that fluid temperature and shifting pressure meet specification.
5. Check for leaks.

Transmission Repair

Mercury Marine stocks a limited number of replacement parts for these transmissions. ZF Marine has a network of distributors throughout the world to service their product. These distributors, in turn, have a dealer network to service the transmissions. Also, service manuals for each transmission can be obtained from ZF Marine.

For the location of your closest distributor or service literature contact an Authorized Mercury MerCruiser dealer or:

ZF Marine
3131 Southwest 42nd Street
Fort Lauderdale, FL 33312
(954) 581-4040

THIS PAGE IS INTENTIONALLY BLANK

DRIVE SYSTEMS

Section 8B - Propeller Shaft Models

Table of Contents

Lubricants / Sealants / Adhesives	8B-2	Checks Made with Propeller Shaft	
Checks Made with Boat In Water	8B-3	Removed from Boat	8B-7
Checks Made with Boat Out of Water and Shaft Installed	8B-5	Strut	8B-7

Torque Specifications

Description	Nm	lb-in.	lb-ft
Propeller Shaft Coupling to Coupling Housing (MIE)	68		50
Coupling Set Screws (If Equipped)	Securely (See NOTE.)		

NOTE: Safety wire set screws, if equipped.

Lubricants / Sealants / Adhesives

Description	Part Number
2-4-C Marine Lubricant	92-86154A1
Engine Coupler Spline Grease	92-8166391A 4
Loctite 8831	92-823089--1
Loctite 290	Obtain Locally


NOTICE

The following information can be used as a guide for determining vibration problems on boats powered by inboard engines (MIE Engines). For installation, alignment and repairs to shafts, struts, shaft logs and rudders, refer to boat manufacturer's service manual. If boat is equipped with V-Drive or a remote mounted V-Drive refer to boat manufacturer's service manual. For MIE engine installation and alignment, refer to SECTION 2B.


Checks Made with Boat In Water

1. Disconnect propeller shaft coupling from transmission coupling.
2. Check fit of coupling to propeller shaft following instructions **a** or **b**:
 - a. **Straight Bore Type:**
 - (1.) Loosen set screws.
 - (2.) Try to move coupling by hand. The bore of the coupling should be a semi press fit to shaft.
 - (3.) Check shaft for wear. If worn replacement of shaft may be necessary. If shaft is not worn try another coupling.
 - b. **Tapered Bore Type:**
 - (1.) Check nut on shaft for tightness.
 - (2.) If nut was loose, remove coupling and check for damage to taper on shaft or in coupling.
 - (3.) Replace worn parts.
 - (4.) Always make sure key is not sticking out of coupling.
 - (5.) Install coupling on shaft without the key.
 - (6.) Mark the shaft (behind the coupling); then, remove the coupling.
 - (7.) Now install the key and coupling. Make sure coupling still lines up with the mark. This ensures that the key is not oversize and holding the tapers apart.

3. Check output coupling flange of transmission. Rotate at least one complete turn.



Checking Coupling Outside Diameter Of A Typical Drive System




Checking Coupling Face Of A Typical Drive System

4. If there is greater than 0.076 mm (0.003 in.) movement in Step 3, replace output coupling.
5. Replace damaged parts and realign engine as outlined.
6. Torque propeller shaft coupling and transmission coupling (output flange) to 68 Nm (50 lb-ft).
7. Tighten set screws securely. Safety wire set screws, if equipped.

Checks Made with Boat Out of Water and Shaft Installed

Possible causes for vibration may be propeller shaft, propeller to shaft fit or propeller. All three can be checked by using the rudder, a strong metal straight edge and a C-clamp.


1. Check installation of propeller to shaft.
 - a. Remove propeller.
 - b. Check for chipped or cracked keyway in propeller on shaft without key.
 - c. Install propeller on shaft without key.
 - d. Mark the shaft (behind the propeller), then remove propeller.
 - e. Install the key and propeller. Make sure propeller still lines up with mark. This ensures that key is not oversize and holding the tapers apart. Retighten propeller nut.
 - f. Ensure key is not sticking out of propeller.
2. Check for propeller shaft being bent behind the strut.



a - Metal Straight Edge (Held to Rudder with C-Clamp) - Position Corner of Straight Edge at Center of Shaft. Rotate Shaft One Complete Turn. If Shaft Wobbles, Replace Shaft.

b - Rudder

3. Check the diameter of all propeller blades. If not the same, repair propeller.




a - Metal Straight Edge (Held to Rudder with C-clamp)

b - Rudder

c - Rotate Propeller One Complete Turn

4. Ensure that all propeller blades are the same pitch and that propeller is properly seated on shaft. Rotate propeller at least one complete turn and check at three different points on blades. Repair or replace if necessary.


NOTE: Hold metal straight edge to rudder with a C-clamp or equivalent.



- a** - Metal Straight Edge
- b** - Rudder
- c** - Propeller Blades


Checks Made with Propeller Shaft Removed from Boat

1. Check propeller shaft for straightness. Rotate at least one complete turn and check at three or four places. If dial indicator deflects over 0.1 mm (0.004 in.), replace shaft.



- a** - V-Blocks
- b** - Dial Indicator
- c** - Shaft

2. Ensure that bore of coupling is 90 degrees from coupling flange. Rotate at least one complete turn. Replace coupling if needle moves.



- a** - V-Blocks
- b** - Dial Indicator
- c** - Coupling Flange
- d** - Shaft Against Block to Prevent Fore and Aft Movement

Strut

Refer to boat manufacturer's service manual for alignment and replacement. Normally, the shaft should be centered in the cutlass bearing. Shims (placed between the strut and hull) are used to align the strut to the shaft.

THIS PAGE IS INTENTIONALLY BLANK

POWER STEERING SYSTEM

Section 9A - Pump And Related Components

Table of Contents

Torque Specifications	9A-2	Power Steering Pump	9A-5
Lubricants / Sealants / Adhesives	9A-2	Removal	9A-5
Description	9A-2	Installation	9A-6
Exploded Views	9A-3	Checking Fluid Level	9A-8
Power Steering Pump	9A-3	Filling and Bleeding	9A-8
Related Components	9A-4		

Torque Specifications

NOTE: Securely tighten all fasteners not listed below.

Description	Nm	lb-in.	lb-ft
Front bracket	32		24
Rear Brace			
Mounting And Tensioning Bolt	21		15

Lubricants / Sealants / Adhesives


Description	Part Number
Quicksilver Power Trim and Steering Fluid	92-90100
Automatic Transmission Fluid - Dexron III	Obtain Locally

Description

IMPORTANT: Power Steering Pumps are considered non-repairable units and are intended to be removed and replaced with new units.

Exploded Views

Power Steering Pump




71035

- 1 - Pump
- 2 - Pulley
- 3 - Tensioning Bolt, Lockwasher And Flat Washer
- 4 - Mounting Bolt
- 5 - Bushing
- 6 - Fluid Pressure Hose
- 7 - Fluid Reservoir Hose
- 8 - Hose Clamp
- 9 - Bracket

Related Components

ALL ENGINES



78418

71034

- 1 - Fluid Reservoir Tank
- 2 - Hose Clamp (2)
- 3 - Fluid Reservoir Support
- 4 - Bracket
- 5 - Supply Hose
- 6 - Pressure Hose
- 7 - Return Hose (From Transom)
- 8 - Return Hose (From Cooler)
- 9 - Power Steering Fluid Cooler


Power Steering Pump

Removal

⚠ CAUTION

Disconnect Battery cables at battery to prevent engine rotation and injury while working on pump.

1. Remove vacuum pump belt, if equipped.
2. Remove and retain mounting and tensioning bolts and hardware.



70113


Typical

- a** - Mounting Bolts (One With A Bushing Not Shown In This View)
- b** - Tensioning Bolt, Lockwasher And Flat Washer

3. Lower pump down to gain access to hose connections. Remove hoses and adaptor as shown. Using clean, suitable plugs, quickly plug hoses to limit loss of fluid.

NOTE: If possible lift pump above power steering reservoir and then remove hoses to minimize fluid loss.

4. Drain power steering fluid from pump into a suitable container. Do NOT reuse fluid.
5. Using a suitable puller remove pulley from pump shaft. Retain pulley for installation on new pump.




71035

Typical

6. Drain fluid from power steering reservoir into a suitable container. Do NOT reuse fluid. Dispose of fluid properly.


Installation

1. Using a suitable screw, push (install) pulley onto shaft until pulley face is flush, as shown, with shaft end (screw head will bottom out).



74481


2. Install reservoir hose and pressure hose to pump as shown. Temporarily hand tighten only.



78418

- a** - Reservoir Hose
- b** - Hose Clamp
- c** - Pressure Hose
- d** - O-ring
- e** - Fitting

3. Place hoses appropriately between oil filter and pump mounting bracket, lift pump into place and attach with fasteners and hardware retained previously, as shown.



70113

- a** - Mounting Bolt With Washer (One Not Shown - Shown In Inset With Bushing)
- b** - Tensioning Bolt, Lockwasher and Flat Washer
- c** - Bushing

4. Tighten reservoir hose clamp securely. Tighten pressure hose fitting securely. Do NOT overtighten.
5. Position drive belt in pulley groove and tension belt. Belt must not deflect more than 5 mm (3/16 in.). Move or pry power steering pump to tension belt. Torque mounting bolts and tensioning bolt to 21 Nm (15 lb-ft).

NOTE: On all models, power steering drive pulley is behind crankshaft front pulley.

6. If not already accomplished, drain fluid from power steering reservoir into a suitable container. Do NOT reuse old fluid. Dispose of properly.
7. Fill power steering reservoir with new fluid.
8. Connect battery cables at battery by FIRST installing Positive (+) battery cable to Positive (+) battery terminal and tighten clamp. THEN, install Negative (-) battery cable to Negative (-) battery terminal and tighten clamp.
9. Bleed air from power steering system following instructions in SECTION 1B.

Checking Fluid Level

Refer to SECTION 1B.

Filling and Bleeding

Refer to SECTION 1B.

NOTICE
For more information on power steering system and components refer to appropriate Mercury MerCruiser Sterndrive Service Manual.

THIS PAGE IS INTENTIONALLY BLANK



VM MOTORI S.p.A.

A DETROIT DIESEL CO.

