



*Tournament  
234 SBX*

***SPORTSMAN***

*Owner's Manual and  
Quick-Reference Guide  
2020*

# Table of Contents

| <i>Topic</i>                     | <i>Page</i> |
|----------------------------------|-------------|
| Introduction                     | 3           |
| Important Information            | 4           |
| Specifications                   | 5           |
| Overall Dimensions & Terminology | 6           |
| Features & Performance           | 7           |
| Certifications & Registrations   | 12          |
| Boating Safety                   | 13          |
| Electrical & Plumbing Systems    | 19          |
| Fuel System                      | 33          |
| Boating Navigation Rules         | 38          |
| Warranty & Services              | 39          |
| Contact Information              | 42          |

## WELCOME TO THE SPORTSMAN TEAM!

Here at Sportsman Boats, we take great pride in producing the finest, most well designed saltwater fishing and pleasure boats on the market today. Our designs incorporate the most modern technology while applying good old “Common Sense” technology as well. From our advanced composite construction, ergonomic console designs, patented “Total Access” hatch, and superior ride and handling characteristics, we think you will agree that Sportsman is setting a new standard. Sportsman Boats builds the fastest growing line of family-friendly center console boats in-class, built with the latest designs, procedures and materials to give you and your family unparalleled performance with a dry, safe and comfortable ride

We do not take lightly the confidence you have placed in us with your decision to purchase your Sportsman boat. We will always strive to provide for you and your family the superior customer service you deserve. We hope that you enjoy your time out on the water as much as we enjoy building your Sportsman boat!

Safe Boating and Tight Lines,  
*Tommy Hancock*

# SPORTSMAN

---

# Important Information

## **BOAT INFORMATION / SPECIFICATIONS**

|                     |                 |
|---------------------|-----------------|
| MODEL:              | HULL SERIAL #:  |
| PURCHASE DATE:      | DELIVERED:      |
| IGNITION KEY #:     | REGISTRATION #: |
| DRAFT:              | WEIGHT:         |
| VERTICAL CLEARANCE: |                 |

## **ENGINE / PROPELLER INFORMATION**

|                   |              |
|-------------------|--------------|
| ENGINE MAKE:      | MODEL:       |
| ENGINE SERIAL #:  |              |
| PROPELLER MAKE:   | # OF BLADES: |
| DIAMETER / PITCH: | MODEL:       |
| PART #:           |              |

## **OPTIONAL EQUIPMENT / OPTION PACKAGES**

|  |
|--|
|  |
|  |
|  |

## **TRAILER INFORMATION**

|                         |        |
|-------------------------|--------|
| MAKE:                   | MODEL: |
| SERIAL #:               | GVRM:  |
| ADDITIONAL INFORMATION: |        |

## **DEALER**

## **SPORTSMAN**

|                 |                 |
|-----------------|-----------------|
| NAME:           | PHONE:          |
| PHONE:          | REPRESENTATIVE: |
| SALES PERSON:   | ADDRESS:        |
| SERVICE MANGER: |                 |
| ADDRESS:        |                 |

We recommend filling out the information in this table and keeping one copy of this page in your personal records and one copy with your owner's manual. This information will be important should you need to contact your dealer or Sportsman Boats Manufacturing for technical assistance and/or service.

# SPORTSMAN

# Specifications


Tournament  
234 SBX

|                                  |                   |
|----------------------------------|-------------------|
| Length Overall                   | 23'4"             |
| Beam                             | 8'5"              |
| Draft                            | 14"               |
| Deadrise at Transom              | 15°               |
| Approximate Usable Fuel Capacity | 71 gal.           |
| Approximate Dry Weight           | 2600 lbs.         |
| People Capacity                  | 8 persons         |
| Maximum Engine Horse Power       | 250 HP (4 Stroke) |

**SPORTSMAN**

# Overall Dimensions & Terminology

Tournament  
234 SBX



*Note: If your boat has a T-Top, we recommend measuring the trailered height of your boat for towing safety purposes. This height may depend on the specific trailer being used.*

## SPORTSMAN

# Features & Performance

## Standard Package

SportLink® Electronics Integration System  
Garmin ECHOMAP® Plus 64cv MFD 6"  
Garmin GT23 Transducer  
12V In-Dash Charging Plug  
12V Rocker Switches  
Analog Tachometer, Trim & Fuel Gauges  
Console Footrest w/ Glove Box & Storage Bin  
Console Grab Rail  
Console Windscreen  
Dual Battery Configuration w/ Switch & Trays  
Horn  
Hydraulic Steering  
Interior LED Lighting Package  
Rub Rail Navigation Lights  
Trolling Motor Plug & Harness  
Leaning Post w/ Bottom Cushion  
Premium SoftTouch Textured Marine Vinyl or White  
Rear Fold Up Bench Seat w/ Lockable Storage  
(1) 20 Gallon Port Insulated Cooler  
(1) 20 Gallon Starboard Rear Livewell  
Anchor Storage  
High Speed Livewell Pick Up  
Large Bow Casting Deck w/ Lockable Storage 10 Rods  
Large Bow Fish Box  
Step Storage Box

SportTech™ Advanced Fabrication Process  
10-Year Hull Warranty  
2 Flush Mount Gunwale Rod Holders  
6 Vertical Rod Holders on Console (Boats w/o T-Top)  
64 Gallon Fuel Tank w/ Fuel Level Sensor  
Advanced Fiberglass Stringer System (No Wood)  
All White Hull (Sides & Bottom)  
Enhanced Transom Angle  
Grip Tex Yacht Style Non-Skid  
Large Rear Casting Deck  
NMMA Certified  
Performance Planing Hull w/ Pocket  
Pull-Up Cleats  
Rear Total Access Hatch  
Self Bailing Cockpit  
Stainless Steel Cup Holders - 6  
Stainless Steel Drain Covers  
Stainless Steel Propeller  
Stainless Steel Rub Rail  
Stainless Steel Steering Wheel w/ Knob  
Swim Platform w/ 3-Step Ladder  
Underlid Gasket

## Powder Coat Selection

- Black - White

## Color Selection

|               |                  |
|---------------|------------------|
| - Driftwood   | - Sea Mist Green |
| - Ice Blue    | - Silver Cloud   |
| - Island Blue | - Steel Blue     |
| - Jet Black   | - White          |

# SPORTSMAN

# *Features & Performance*

## *Feature Packages (cont'd)*

*Note: If your boat has the SeaStar Jack Plate option, be aware of the hazards of the motor cowling hitting the poling platform and the hydraulic steering hitting the jack plate.*

### *Available Options*


JL Audio MM50 Stereo w/ M3-650X Speakers  
Bow Casting Chair  
Bimini Top  
Bow Cushion Set  
Console Drape (LP & Console, req. Top)  
Compass  
Deluxe T-Top w/ LED Lighting  
Freshwater Washdown w/ 13 gal. Tank  
Helm Pad  
YETI® Tundra 65 Cooler w/ Slide Out Track  
Slide Out Track only  
Light Hull Color  
Mooring Cover (w/o Top Only)

On-Board Battery Charging System (2-Bank)  
Raw Water Washdown  
SeaStar Jack Plate  
Spray Shield  
Transhield Shipping Cover  
Trim Tabs w/ LED Indicator  
Recirculating Livewell w/ Pro-Air (STBD)  
Gunwale Rod Holders / Each  
Under Leaning Post Tackle Storage

# Features & Performance

Tournament  
234 SBX

## Major Features



**SPORTSMAN**

# Features & Performance

## 200 LA HP

## 250 LA HP

### PERFORMANCE BULLETIN



YPB#: PB\_SPT\_Tournament234\_VF200LA\_2015-03-09\_BAY

Test Date 3/9/15




Boat Manufactured By:  
Sportsman Boats • 113 Isaac Way • Summerville, SC 29483  
843-378-2628 • www.sportsmanboatsmfg.com

#### PERFORMANCE DATA

| RPM  | MPH  | GPH  | MPG  |
|------|------|------|------|
| 1000 | 5.3  | 1.4  | 3.79 |
| 1500 | 7.2  | 2.3  | 3.13 |
| 2000 | 8.0  | 3.3  | 2.42 |
| 2500 | 10.3 | 4.5  | 2.29 |
| 3000 | 18.9 | 5.4  | 3.50 |
| 3500 | 30.5 | 8.1  | 3.77 |
| 4000 | 35.2 | 10.2 | 3.45 |
| 4500 | 40.5 | 14.1 | 2.87 |
| 5000 | 44.0 | 14.7 | 2.99 |
| 5500 | 49.8 | 19.1 | 2.61 |
| 6000 | 53.8 | 19.8 | 2.72 |

Time to Plane 2.76  
0-30 MPH 4.39



Test performed and verified by Yamaha Applications Engineers.

#### Sportsman® Tournament 234

|                       |           |
|-----------------------|-----------|
| Length                | 23' 4"    |
| Beam                  | 8' 5"     |
| Dry Weight (w/o fuel) | 2,450 lbs |
| Maximum HP            | 250       |
| Fuel Capacity         | 71 gal    |
| Weight as Tested      | 3,691 lbs |

#### VF200LA V MAX SHO®

|              |         |
|--------------|---------|
| Horsepower   | 200 HP  |
| Induction    | EFI     |
| Displacement | 4.2 L   |
| Weight       | 505 lbs |
| Gear Ratio   | 1.75:1  |

#### ENGINE MOUNTING HEIGHT

|                          |                                |
|--------------------------|--------------------------------|
| Mounting Hole Position   | #1 on 10" Hydraulic Jack Plate |
| Ventilation Plate Height | 4" Above Boat Bottom           |

#### PROPELLERS

|                    |                          |
|--------------------|--------------------------|
| Series             | Saltwater Series II™     |
| Diameter/Pitch     | 15-1/4 x 18              |
| Yamaha Part #      | 6CE-45934-00-00          |
| Propeller Material | Polished Stainless Steel |

#### TEST CONDITIONS

|                                      |            |
|--------------------------------------|------------|
| Number of People                     | 2          |
| Air / Water Temperature (Fahrenheit) | 75 / 65° F |
| Elevation (in feet above sea level)  | Sea Level  |
| Wind Velocity                        | 10-15 mph  |

Comments: Fuel weight includes 107 tank of fuel, 1 battery, 30 hydraulic jack plate, weight and fuel.

**Notice to Consumer:** The information and data contained in this performance bulletin are approximate and subject to many different factors and variables. It is provided as a guideline only and should not be relied upon as representation of actual performance. Your boat's performance may be affected by the information contained in this performance bulletin due to various factors, including your boat's actual weight, wind and wave conditions, hull design, loading, maintenance, battery used, load capacity, water conditions, etc. We warrant that weight and speed data. These control the specifications and performance data on your specific boat/engine combination only. These data are for reference only. Please do not use the data contained in this performance bulletin as a basis for comparison or performance data of other Yamaha boats or engines without notice. The document contains data of Yamaha's performance. It may also contain information belonging to other companies. Any reference to other companies or their products are for identification purposes only, and are not intended to be an endorsement.

For more information:  
Yamaha Motor Corporation, U.S.A.  
OEM Division, Marine Group  
1270 Chasler Road NW  
Kennesaw, GA 30144 • (800) 88-YAMAHA  
For other Performance Bulletins, visit [www.yamaha-motor.com](http://www.yamaha-motor.com).

© 2015 Yamaha Motor Corporation, U.S.A. All rights reserved.

### PERFORMANCE BULLETIN



YPB#: PB\_SPT\_Tournament234\_VF250LA\_2015-03-09\_BAY

Test Date 3/9/15




Boat Manufactured By:  
Sportsman Boats • 113 Isaac Way • Summerville, SC 29483  
843-378-2628 • www.sportsmanboatsmfg.com

#### PERFORMANCE DATA

| RPM  | MPH  | GPH  | MPG  |
|------|------|------|------|
| 1000 | 5.9  | 1.4  | 4.21 |
| 1500 | 7.7  | 2.4  | 3.21 |
| 2000 | 8.4  | 3.5  | 2.40 |
| 2500 | 11.4 | 4.8  | 2.38 |
| 3000 | 27.4 | 6.1  | 4.49 |
| 3500 | 32.6 | 8.5  | 3.86 |
| 4000 | 38.0 | 11.3 | 3.36 |
| 4500 | 42.3 | 14.6 | 2.90 |
| 5000 | 46.9 | 17.2 | 2.73 |
| 5500 | 51.5 | 22.3 | 2.31 |
| 6000 | 58.5 | 23.8 | 2.46 |

Time to Plane 2.67  
0-30 MPH 3.55



Test performed and verified by Yamaha Applications Engineers.

#### Sportsman® Tournament 234

|                       |           |
|-----------------------|-----------|
| Length                | 23' 4"    |
| Beam                  | 8' 5"     |
| Dry Weight (w/o fuel) | 2,450 lbs |
| Maximum HP            | 250       |
| Fuel Capacity         | 71 gal    |
| Weight as Tested      | 3,621 lbs |

#### VF250LA V MAX SHO®

|              |         |
|--------------|---------|
| Horsepower   | 250 HP  |
| Induction    | EFI     |
| Displacement | 4.2 L   |
| Weight       | 505 lbs |
| Gear Ratio   | 1.75:1  |

#### ENGINE MOUNTING HEIGHT

|                          |                                |
|--------------------------|--------------------------------|
| Mounting Hole Position   | #1 on 10" Hydraulic Jack Plate |
| Ventilation Plate Height | 4" Above Boat Bottom           |

#### PROPELLERS

|                    |                          |
|--------------------|--------------------------|
| Series             | Saltwater Series II™     |
| Diameter/Pitch     | 15-1/4 x 19              |
| Yamaha Part #      | 6CE-45970-00-00          |
| Propeller Material | Polished Stainless Steel |

#### TEST CONDITIONS

|                                      |            |
|--------------------------------------|------------|
| Number of People                     | 2          |
| Air / Water Temperature (Fahrenheit) | 75 / 65° F |
| Elevation (in feet above sea level)  | Sea Level  |
| Wind Velocity                        | 10-15 mph  |

Comments:

Notice to Consumer:

For more information:  
Yamaha Motor Corporation, U.S.A.  
OEM Division, Marine Group  
1270 Chasler Road NW  
Kennesaw, GA 30144 • (800) 88-YAMAHA  
For other Performance Bulletins, visit [www.yamaha-motor.com](http://www.yamaha-motor.com).

© 2015 Yamaha Motor Corporation, U.S.A. All rights reserved.

# SPORTSMAN

**Note:** This is posted on our website at  
<http://sportsmanboatsmfg.com/tournament-234-bay-boat/>

# *Certifications & Registrations*

## *NMMA Certification*

Sportsman Boats is certified by the National Marine Manufacturers Association (NMMA). NMMA certification not only meets the standards of the United States Coast Guard (USCG), but goes further to meet the standards set by the ABYC (American Boat and Yacht Counsel). All Sportsman models have been designed, constructed, and thoroughly tested to meet or exceed these standards. For more information about these standards, you may visit <http://www.nmma.org/certification/boats>.

## *Hull Identification Number & Registration*

Sportsman has a permanent record of your boat. This record is documented during the manufacturing process. It is identified by its "Hull Identification Number" (HIN). **The HIN is a 12-digit code located on the starboard side of the transom, just under the Rub Rail.** When contacting your dealer concerning maintenance or warranties, please have your HIN and model number available. This information can be found on your copy of the warranty card. Federal and State laws require a power boat to be registered in the state where it is primarily used. Registration numbers and validation stickers must be displayed according to regulations. The registration certificate must be on board when boating. The boat serial number, or Hull Identification Number (HIN), is required on the registration form. The HIN should be included on all documents or any correspondence.

## LIGHTING

Your Sportsman boat is equipped with navigation lights which comply with both Inland and International rules.

## REQUIRED SAFETY EQUIPMENT

The US Coast Guard (USCG) requires that every boat have specific equipment on board. Check with local regulations on mandatory equipment apart from the list of Coast Guard requirements.

## FIRE EXTINGUISHER

At least one Type-1 hand held portable fire extinguisher must be carried on board. For boats over 20' two are required. Check extinguisher regularly for charge status.

## SOUND SIGNALING DEVICES

Your Sportsman boat is equipped with an electric horn which meets the USCG requirements for a sound signal device.

## PERSONAL FLOTATION DEVICE (PFD)



You must have a USCG approved personal flotation device of Type I, II, or III aboard for each passenger, in addition to one Type IV throw able PFD. **Always wear a PFD when boating.** In some states, children are required to wear a PFD at all times. Check your local regulations.

## VISUAL DISTRESS SIGNALS

USCG approved visual distress signals are required for day and night use when operating on US waters. Approved signals include flares, orange smoke, an orange distress flag, or an electric distress light.


# Boating Safety

Being on the water is a great experience, but it can become a bad experience very quickly if safety and maintenance instructions of your boat are not followed. Therefore, warnings and notices have been included in order to help you operate and maintain your boat safely. They are defined as follows:



Please become familiar with the location and content of the Caution, Warning, and Danger Labels found on your boat.



Your Owner's Manual was written to include safety instructions to ensure safe operations. Safety alert symbols are used to show potential personal injury hazards.



Every precaution has been taken to reduce the risks associated with death, possible injury and damage from fire or explosion. You must also take your own necessary precautions and practice proper maintenance procedures in order to enjoy the optimal safe operation of your boat.

*If your label is damaged. Please call Sportsman's parts department for replacement stickers.*

Your boat produces carbon monoxide and uses flammable fuel. Carbon monoxide can cause brain damage or death. Carbon monoxide is colorless, odorless and extremely dangerous.



# Boating Safety Label Locations

## MAXIMUM CAPACITIES

**8 PERSONS OR 1500 LBS.**

4100 LBS. PERSONS, MOTOR, GEAR  
250 H.P. MOTOR

THIS BOAT COMPLIES WITH U.S. COAST GUARD SAFETY STANDARDS IN EFFECT ON THE DATE OF CERTIFICATION

MEETS U.S. EPA EVAP STANDARDS USING CERTIFIED COMPONENTS

MANUFACTURER: Sportsman Boats Manufacturing, Inc.

MODEL: Tournament 234 Summerville, SC







DESIGN COMPLIANCE WITH NMMA REQUIREMENTS IS VERIFIED. MANUFACTURER RESPONSIBLE FOR PRODUCTION CONTROL.



NATIONAL MARINE MANUFACTURERS ASSOCIATION

## MEETS U.S. EPA EVAP STANDARDS USING CERTIFIED COMPONENTS

Sportsman Boats Mfg. Summerville, SC




**SPORTSMAN**

# Boating Safety

## Tournament 234 SBX

The Sportsman Tournament 234 has an 8 Person Capacity. Seating locations are shown below.



For your safety, casting deck is not to be used while boat is in motion.

### MAXIMUM CAPACITIES

**8 PERSONS OR 1500 LBS.**

4100 LBS. PERSONS, MOTOR, GEAR  
250 H.P. MOTOR

THIS BOAT COMPLIES WITH U.S. COAST GUARD SAFETY STANDARDS IN EFFECT ON THE DATE OF CERTIFICATION  
MEETS U.S. EPA EVAP STANDARDS USING CERTIFIED COMPONENTS

MANUFACTURER: Sportsman Boats Manufacturing, Inc.

MODEL: Tournament 234 Summerville, SC

DESIGN COMPLIANCE WITH NMMA REQUIREMENTS IS VERIFIED.  
MANUFACTURER RESPONSIBLE FOR PRODUCTION CONTROL.



NATIONAL MARINE  
MANUFACTURERS ASSOCIATION

# SPORTSMAN


2

1

Tournament

234 SBX

|                                                                                   |                                 |
|-----------------------------------------------------------------------------------|---------------------------------|
|  | 1 1/2" HOSE-HELIX<br>PN: 100065 |
|  | 1 1/2" HOSE-BLACK<br>PN: 100071 |
|  | 1 1/2" HOSE-HELIX<br>PN: 101223 |
|  | COLLECTOR BOX<br>PN: 100052     |



Electrical &  
Plumbing Systems

A

A

## UNLESS OTHERWISE SPECIFIED

DIMENSIONS ARE IN INCHES  
TOLERANCES:  
FRACTIONAL  $\pm 1/16"$   
ANGULAR  $\pm 0.5$  deg

INTERPRET GEOMETRIC  
TOLERANCING PER

MATERIAL

N/A

FINISH

DO NOT SCALE DRAWING

NAME

ABT

DATE

2/19

DRAWN

CHECKED

ENG APPR.

MFG APPR.

Q.A.

COMMENTS

SPORTSMAN

TITLE:

234 DRAIN HOSE  
ROUTING

SIZE DWG. NO.

A

234CT-CW\*000

REV

SCALE: 1/8


WEIGHT:

SHEET 1 OF 1

2

1

The **fuse panel** is located under the console. It is clearly labeled for easy identification. The bilge pump's 6 amp fuse is also located here. There is also a 30 amp breaker branching off the main battery switch. **If an electrical component of your boat stops working properly, this should be the first place to look.**



# Electrical & Plumbing Systems

Tournament  
234 SBX

## **SportLink®** **Electronics Integration System**

### **Garmin ECHOMAP® Plus 64cv MFD 6"**

Bright, sunlight-readable 6" combo includes one transducer that features both Garmin CHIRP traditional sonar and CHIRP ClearVü scanning sonar and built-in WiFi. The unit comes preloaded with BlueChart g3 charts with integrated Navionics data, covering the coastal U.S. Plus, Quickdraw Contours mapping software to to instantly create personalized fishing maps on-screen with 1' contours as you fish.



### **Garmin GT23 Transom CHIRP Transducer**

The included GT23 transducer features both Garmin CHIRP traditional sonar and CHIRP ClearVü scanning sonar, and it's also compatible with Panoptix all-seeing sonar. It is the perfect setup for coastal and offshore fishermen who want CHIRP traditional sonar and CHIRP ClearVü scanning sonar. This transom mount transducer consistently displays clear and crisp fish arches with superior target separation as well as clear definition of structure below the boat.



# SPORTSMAN

# Electrical & Plumbing Systems

*Tournament  
234 SBX*

## **SportLink®** **Electronics Integration System**



### **12V Toggle Rocker Switches**

Easily toggle all of your 12V accessories with these labeled and rocker switches. The angle of the switches allows water to easily flow out when they get wet. A horn button is also located in-dash for easy operation.

# Electrical & Plumbing Systems

## Lights

The *NAV/ANC Switch* is a 3-position switch on the console that controls the running lights.

- **NAV** position will turn on the red and green navigation lights and the white all-round light for night driving.
- **ANC** turns on the all-round light only for night anchoring. Do not operate the boat in anchor position.
- Off is in the center position.

**Sidelights:** The Tournament 234 has integrated rub rail navigational lights installed at the bow (see figure to the right). A green light is located on the starboard (right) side and a red light on the port (left) side of the vessel. Each shows an unbroken light over an arc of the horizon of 112.5 degrees and is fixed to show from ahead to just behind the beams of the vessel on its respective side.

**All-round/Anchor Light:** This is a white light placed over the highest unobstructed point of the vessel, showing an unbroken light over an arc of the horizon of 225° and fixed to show from anywhere ahead, to just behind the beams of the vessel. See the figure to the right for location.


Recreational boats are required to display navigation lights between sunset and sunrise and other periods of reduced visibility (fog, rain, haze, etc.) Navigation lights are intended to keep other vessels informed of your presence and course. Your boat is equipped with the navigation lights required by the U.S. Coast Guard at the time of manufacture. It is up to you to make sure they are visible, operational and turned on.

### Bow Sidelights

If you have the underwater lights option installed, they can be turned on with the switch at the helm labeled "Accessory 1."

If your boat has a T-top, the anchor light is located on top of the T-top at the aft end. With no T-top, the location is at the stern of the boat as shown here.

### Anchor Light if no T-Top



# Electrical & Plumbing Systems


## Bilge Pump

A small bilge pump is located on the hull bottom at the stern of your boat. Water is pumped out of a thru-hull fitting located on the starboard side of the boat near the transom. The pump may be accessed by removing the aft seat and door, in the area shown to the right. You may turn your bilge pump on manually by flipping on your bilge switch located on the switch panel at the helm. Additionally, the bilge pump utilizes a float as an automated switch to turn it on automatically if necessary when the boat is unattended. The bilge pump is designed to remove excess water **only**, and it is **not** intended to stop or prevent rapid accumulation of on-board water due to rough weather, hull damage, or any other unsafe navigational conditions.

Bilge Pump



Drain Outlet



# *Electrical & Plumbing Systems*

## *Trim Tabs option*

Your Tournament 234 has trim tabs installed to improve performance. They are attached to the bottom edge of the transom, as shown in the image below. When the trim tabs control at the helm (pictured to the right) is pressed, the trim tabs automatically move into position. The force of passing water on these tabs results in upward pressure at the transom, which will lower the bow. This helps to improve the performance of the boat in a wide range of weight, weather, and water conditions.

The LEDs on the control panel indicate the position of the tabs. If all are lit up, that tab is all the way down. The port and starboard tabs may be operated independently if necessary. To lower the starboard bow, lower the port tab. To lower the port bow, lower the starboard tab. The lights on the left indicate the port tab position, and the lights on the right indicate the starboard tab position.



*Control Panel*

*Trim Tabs*



# Electrical & Plumbing Systems

## Trim Tabs

*If you keep your boat in a wet slip/marina environment.  
Here is a list of different anodes recommended for various water  
types to prolong the life and shine of your stainless steel tab.  
Never use a wire brush to clean your tab!*

**Zinc Alloy Anodes = Salt water only**

Not recommended for use in fresh water

Alloy is manufactured to meet or exceed US Military Specification (MIL-A-18001K)

**Aluminum Alloy Anodes = Salt or Brackish water**

Not recommended for use in fresh water

Proven to last longer than zinc due to increased capacity

Alloy is manufactured to meet or exceed US Military Specification (MIL-A-24779(SH))

**Magnesium Alloy Anodes = Fresh water only**

Not recommended for use in salt or brackish water




Trim Tabs

# Electrical & Plumbing Systems


## Bilge Pump

A small bilge pump is located on the hull bottom at the stern of your boat. Water is pumped out of a thru-hull fitting located on the starboard side of the boat near the transom. The pump may be accessed by removing the aft seat and door, in the area shown to the right. You may turn your bilge pump on manually by flipping on your bilge switch located on the switch panel at the helm. Additionally, the bilge pump utilizes a float as an automated switch to turn it on automatically if necessary when the boat is unattended. The bilge pump is designed to remove excess water **only**, and it is **not** intended to stop or prevent rapid accumulation of on-board water due to rough weather, hull damage, or any other unsafe navigational conditions.

Bilge Pump



Drain Outlet



# Electrical & Plumbing Systems

## Livewells

The Sportsman Tournament 234 SBX comes with a 20 gallon livewells at the stern of the boat and one 10 gallon livewell under the front seat of the console. For easy access to the pumps and plumbing systems, open the total access hatch forward of the transom. The livewell pumps are located on either side of the bilge pump in the hull of the boat, and the livewell fill hoses are connected to the top of the pumps. To operate the livewells, turn on the livewell switch at the helm and turn the fill valve in the livewell to "open." To operate the starboard aft livewell and the console livewell, use the switch labeled "Livewell 1." To operate the port aft livewell, use the switch labeled "Livewell 2." All livewells are equipped with overflow drains so water cannot exceed a certain level and overflow. These overflow drains are connected to the main drain lines at 'T' joints, which empty out an outlet drain at the stern of the boat. Additionally, each livewell has LED lighting installed. To illuminate the livewells, turn on the switch at the helm.

*Console Seat Livewell (with overflow, fill valve, and drain)*



*Rear Livewell*





*Fill Valve*

*Overflow Drain*



*Drain*


*Pumps To Fill Valves*



# *Electrical & Plumbing Systems*

## *Raw Water Wash-down*



Your Tournament 234 may have the raw water wash-down installed as an option. Rinsing your boat immediately after use with a powerful water jet helps to maintain the boat's condition and value. This system supplies water via a hose connected to bottom of the same pump that supplies water to your livewells with a shut off valve in the bilge area at the total access hatch. To operate the wash-down system, start by opening the valve mentioned above. Then turn on the switch labeled "WASHDOWN" on the switch panel at the helm. The wash-down outlet is found on the starboard side of the boat under the gunwale. See the figures here for important feature locations for the raw water wash-down system.



# Electrical & Plumbing Systems

## Fresh Water Wash-down

Your Tournament 234 may have the freshwater wash-down installed as an option. The freshwater fill fitting and outlet are marked and located on the starboard side of the console. **Do not leave the tank full if your boat will be left unattended for an extended period of time;** pump the tank dry to avoid stagnant water in the tank if necessary. It is also important to periodically inspect and clean the filter, which is located on the pump. The pump is mounted on the inside of the console on the starboard side. To operate this system, turn on the switch labeled "ACCESSORY 2" at the helm. This will pressurize the system for use. When the tank is empty or the boat is not in use, ensure that this switch is in the off position.





# Fuel System

## Fuel Tank

The Sportsman Tournament 234 comes with a fuel tank installed (71 approximate usable gallon capacity). The gasoline fuel system consists of a fuel tank (located underneath the helm seat as shown in the figure), anti-siphon valve, engine fuel supply line, and fill cap. Your boat contains a new EPA certified fuel system. The system prevents spit-back when filling the tanks and lowers the out gassing emissions through a vent in the new designed fuel fill cap.

*Note: This photo was taken during the assembly process. At this stage, some of the hoses had not yet been connected. In your boat all lines and hoses will be connected as necessary.*



**SPORTSMAN**

## Diurnal Fuel System



## EPA DIURNAL FUEL SYSTEMS

**NOTE: Pressure may be present when opening your deck fill, regardless of system type.**



### Only open the fuel cap for refueling

Note: The first time fuel is introduced to a fuel tank, be aware of the interaction of cold raw fuel vapors replacing air, on occasion a vapor pressure can occur producing spit-back anomalies!

### What is a diurnal fuel system?

Your new vessel is equipped with an Environmental Protection Agency (EPA) compliant diurnal fuel system, designed to reduce fuel emissions to atmosphere using criteria mandated by the EPA. Your vessels fuel tank is required and designed to have a positive pressure (>1PSI) as the sun heats the boat and the fuel in the tank expands or it may be equipped with a carbon canister to catch and contain fuel vapors

Your boats fuel tank also has valves installed inside that are designed to:

1. Produce a clean refueling shut off event
2. Create a 5% vapor space
3. Reduce the propensity of a refueling spit-back event.
4. Allow for appropriate venting when the vessel is stored or trailered. Your fuel cap also contains valves designed to retain fuel vapor (up to 1PSIG) and to allow make up air during engine operation

# Fuel System

## Diurnal Fuel System (cont'd)


### Vapor Space (Ullage) And Refueling Management

Another fuel system necessity to remain EPA compliant it is to keep elevated temperature gasoline from expanding into fuel system areas that are not low permeation rated or otherwise sensitive to raw fuel. A vapor (or ullage) space must be produced at the completion of the filling or refueling operation to ensure systems remain EPA compliant during the diurnal temperature cycle. To effectively manage this system function, BluSkies has created a series of valves that can mount to any marine fuel tank to achieve the appropriate fill level while maintaining ullage space of ~5%. Additionally these valves eliminate the propensity for refueling "spit-back" or tank "well-back", which is another requirement of the EPA regulation.

BluSkies primary ullage valves replace the existing fill and vent locations, while additional grade or tip level valves can be added to any tank to meet American Boat And Yacht Council standards (H-24) which allows vapor venting for boats slanting or sloping when stored, moored, parked or trailered.

The final decision on which system type and ullage valve type and placement that is best for your application should be based on application specific factors such as type and configuration of fuel tank, how much room there on board is for added components, how are the boats likely to be used and stored etc. and of course cost.

Choose individual components to create a compliant system from the following pages or you can turn to our specialists for sound guidance and direction as you go through the process to choosing the appropriate system for your particular vessel application.




## Tank Vapor Space & Fluid Management

### Ullage (Vapor Space) Level Attainment Spit-back/Well-back Control

This vent valve shuts off the refueling vapors and creates back pressure to lift the fill valve ball into place.

This fill valve ball is set lower than the vent valve ball but does not close until the refueling vapors are shut off by the vent valve.



# Fuel System

Tournament  
234 SBX

## Diurnal Fuel System: Refueling

Your fuel tank capacity will vary from the label or published capacity no less than 5% by law and up to 10% dependent upon the variation from static float due to equipment, occupants and gear etc. (Static Float = attitude in which your boat floats in calm water)

**Fill your vessel fuel tank as normal, stop refueling after two (shut off) clicks of the fuel nozzle.**

Topping off will over ride your fuel system design intent and could cause damage to your vessel due to overflow and will void any and all warranty claims related to fuel spillage.

BluSkies is expressly not responsible for any damage to your vessel subsequent to topping off.

### **WARNING**

CONTENTS CAN BE UNDER PRESSURE  
AVOID SERIOUS INJURY OR DEATH FROM  
FIRE OR EXPLOSION  
OPEN SLOWLY IN WELL VENTILATED AREA  
NO SMOKING OR OPEN FLAMES

It has been a common practice for many years to top off boats prior to storage or in preparation for a day on the water, however diurnal fuel systems are designed specifically to leave a space in your fuel tank to allow the fuel to expand during the heat of the day. GASOLINE EXPANDS 5%.

### **REFUELING**

**GASOLINE CONTENTS UNDER PRESSURE. FUEL SPRAY MAY OCCUR.**

1. OPEN CAP SLOWLY
2. INSERT FUEL NOZZLE
3. BEGIN & CONTINUE FUELING UNTIL FUEL NOZZLE KICKS OFF
4. WAIT 10 SECONDS & CONTINUE FUELING UNTIL NOZZLE KICKS OFF A SECOND TIME
5. RETURN NOZZLE TO PUMP
6. DO NOT TOP OFF

# SPORTSMAN


# Boating Navigation Rules

There are three main situations that you may encounter with other vessels which could lead to a collision unless the Steering Rules are followed:


- Meeting:** you are approaching another vessel head-on
- Crossing:** you are travelling across the path of another vessel
- Overtaking:** you are passing or being passed by another vessel




**When Meeting Port-to-port:** Continue on course. The same holds true for meeting starboard-to-starboard.



**When Meeting Head On:** As in a car, both stay to your right and as far apart as practical. Each boat should turn to starboard and pass port-to-port.



**When Crossing:** Every boat has a "Danger Zone" from straight in front (the bow) to past the middle of its right side. Like when meeting another car at a street intersection, the one on the right has the right of way. You must yield to boats in your Danger Zone. If you are the skipper of the Vessel A in the center of the diagram, you must keep out of the way of any boat that approaches you from any direction within the indicated Danger Zone, as you are the burdened craft. Likewise, boats approaching you from all other directions, except the meeting vessel, must keep clear of you.



**When Overtaking Another Boat:** The boat being overtaken is the privileged vessel. Only after signaling and receiving an acknowledgment can the overtaking boat pass. (Use one blast to pass on the right, and two blasts to pass on the left.

**When Being Overtaken:** Be ready for trouble when a power boat passes you in a narrow waterway. As the lead boat, which always has the right of way, stay on your side of the channel and maintain a steady speed so that the overtaking vessel can pass you safely. Use your radio to discuss this with the passing boat.

## *Product Changes*

Sportsman is committed the development of our product line. As a result, equipment described in this manual may have changed or no longer may be available. All information, illustrations and specifications contained in this manual reflect the latest product information available at the time of publication. Sportsman reserves the right to make changes to its boats at any time, without notice. These changes include, but are not limited to: color options, materials, standard and optional equipment, specifications and model availability. If you have any questions about the equipment on your boat, please feel free to contact Sportsman.

## *Insurance*

In most states, the boat owner is legally responsible for damages or injuries they or anyone else operating the boat causes. Some states have laws that require having at least minimum coverage. Before using your boat for the first time, you should contact your dealer, current insurance company, or state boating authority for information regarding insurance requirements in your area. Although it may not be required in your area, responsible boat owners carry liability and property damage for their boat. You should also protect the boat against physical damage and theft.

## *Service*

All warranty work must be performed by an authorized Sportsman Dealer. If a problem is discovered upon taking delivery of, or develops during routine use of the boat that is related to faulty workmanship and/or materials, as stated in the warranty, you need to contact your Sportsman dealer to arrange for your boat to be repaired. **The boat owner is responsible for delivering the boat to the dealer for warranty service.** If you are not near your dealer or any other authorized Sportsman dealer, please contact Sportsman. Likewise, if the dealer fails to repair the problem, please notify Sportsman within 14 days of the work being completed. **Sportsman will not reimburse owners for unauthorized warranty work.**

# Warranty and Services

## SPORTSMAN BOATS LIMITED WARRANTY

**Ten-Year Hull Limited Warranty:** This limited Warranty applies to any Structural Hull Defect (as that term is defined below) if such is due to a failure in material or workmanship and the was reported to Sportsman according to the terms of this Limited Warranty within ten (10) years from the date of the sale to the original purchaser of the Sportsman authorized dealer. Sportsman, in its sole discretion, will either repair or replace the Hull. For purposes of this Limited Warranty, the term “Hull” shall mean the single fiberglass molded shell and integral structural components of a Sportsman Boat, and the term “Structural Hull Defect” shall mean a substantial defect in the Sports Boat’s Hull that causes the boat to be unfit or unsafe for general use as a pleasure craft under normal operating conditions.

**One Year Nonstructural Limited Warranty:** This Limited Warranty applies to any Nonstructural Defect (as that term is defined below) if such is due to a failure in material or workmanship and the same was reported to Sportsman according to the terms of this Limited Warranty within one (1) year from the date of the sale to the original purchaser of the Sportsman Boat by a Sportsman authorized dealer. Sportsman, in its sole discretion, will either repair or replace the defective component. For purpose of this Limited Warranty, the term “Nonstructural Defect” shall mean a substantial defect in a Sportsman Boat’s components manufactured or installed by Sportsman (other than the Hull) that is not excluded in the exclusions below.

**Registration and Transfer of Limited Warranty:** Each original purchaser of a Sportsman Boat shall complete and return the boat registration card provided by Sportsman within thirty (30) days of such owner’s purchase of the boat in order to facilitate the processing of warranty claims and for manufacture notification. Except where a Sportsman Boats has been salvaged and resold after a declaration of a total loss or a total loss or a constructive total loss, this Limited Warranty is transferrable to a subsequent owner of the Sportsman Boat. PROVIDED SUCH SUBSEQUENT OWNER FILL OUT AND SEND TO SPORTSMAN A SPORTSMAN WARRANTY TRANSFER FORM (AVAILABLE FROM SPORTSMAN ON REQUEST). A COPY OF THE BILL OF SALE, WHITHIN THIRTY (30) DAYS OF SUCH TRANSFER OR PURCHASE.

# Warranty and Services

## SPORTSMAN BOATS LIMITED WARRANTY (cont'd)

### EXCLUSIONS:

This limited Warranty does not apply to any boat that has been salvaged or declared a total loss or constructive total loss for any reason not specifically covered in this Limited Warranty. In addition, this Limited Warranty does not apply to the following "Exclusions:"

- 1) A Hull, component, or other product that has been repaired without authorization of Sportsman or that has been altered in any way that affects its use and operation;
- 2) Expenses related to inspection or warranty service for hauling out, transportation to and from any dealer or Sportsman factory, towing or storage charges, inconvenience or loss of time or income;
- 3) Engines, outdrives, controls, propellers, engine brackets, stereos, depth finder, GPS units, trolling motors, batteries, outriggers bases' and other equipment or accessories that are not manufactured by Sportsman, whether the same is or is not warranted by such other manufacturer;
- 4) Blistering, discoloring, cracking, or crazing of the Gelcoat finish or other surface finishes
- 5) Any Sportsman Boat initially sold at retail by a party other than an authorized Sportsman dealer;
- 6) Damage to, breakage of, or leakage around any windshields, hatches, or apertures;
- 7) Any canvas, zippers, vinyl, upholstery, plastic, or fabric components;
- 8) Discoloration, oxidation, bleeding, or corrosion of any stainless steel or other metal products
- 9) Any Hull, component, or product that has been subject to unreasonable use, tampering, abuse, mishandling, improper maintenance, negligence, improper trailing, alterations, or accidents;
- 10) Any boat, or component or part thereof, that has been used for Commercial Purpose, racing purposes, or has otherwise been operated contrary to any printed instruction provided by Sportsman or contrary to any applicable law (for purposes of this Limited Warranty, the term "**Commercial Purposes**" shall mean the usage of any boat more than fifty percent (50%) for revenue-producing or other business purposes);
- 11) A boat, or component or part thereof, that has been overpowered according to the maximum recommended engine horsepower specified on the capacity plate attached to the boat;
- 12) Machinery, equipment and accessories not installed by Sportsman;
- 13) Condensation of gauges;
- 14) The failure of any part, area, or component of the boat to be dry, whether or not the same was represented as "dry";
- 15) Any representation relating to the speed or weight of any part or component of the boat;
- 16) Normal wear and tear maintenance items, including, but not limited to, filters bulbs, batteries, bungees, anchor rope, trailer finishes, tires, brakes, bearing, and lights;
- 17) Any defect or repair requiring redesign of the boat, except pursuant to the recall provisions of the United States Federal Boat Safety Act of 1971 or the recall laws of the recall laws of any other foreign jurisdiction;
- 18) Dealer preparation, cleaning, and final adjustments and alignments in preparing the boat for delivery or commissioning; or
- 19) Any act of God or force majeure.

Thank you for your purchase of your Sportsman Boat.

Sportsman Boats Manufacturing, Inc.  
113 Isaac Way · Summerville, South Carolina 29483  
Telephone (843) 376-2628 · Fax (843) 376-2636

Email  
*[sales@sportsmanboatsmfg.com](mailto:sales@sportsmanboatsmfg.com)*

Website  
*[www.sportsmanboatsmfg.com](http://www.sportsmanboatsmfg.com)*

P.O. Box 2100  
Summerville, SC 29484



***SPORTSMAN***